

# FUJITSU Server

## PRIMEQUEST 2000 Series

### Tool Reference

---



# Preface

This manual provides information on operation methods and settings, including details on the MMB, and EFI functions.

The manual is intended for system administrators.

For details on the regulatory compliance statements and safety precautions, see the *PRIMEQUEST 2000 Series Safety and Regulatory Information* (C122-E171XA).

## Errata and addenda for the manual

The *PRIMEQUEST 2000 Series Errata and Addenda* (C122-E182EN) provides errata and addenda for the manual.

Read the *PRIMEQUEST 2000 Series Errata and Addenda* (C122-E182EN) thoroughly in reference to the manual.

## For Safe Operation

### How to use this manual

This manual contains important information about the safe use of this product. Read the manual thoroughly to understand the information in it before using this product. Be sure to keep this manual in a safe and convenient location for quick reference.

Fujitsu makes every effort to prevent users and bystanders from being injured and to prevent property damage. Be sure to use the product according to the instructions in the manual.

### About this product

This product is designed and manufactured for standard applications. Such applications include, but are not limited to, general office work, personal and home use, and general industrial use. The product is not intended for applications that require extremely high levels of safety to be guaranteed (referred to below as "safety-critical" applications). Use of the product for a safety-critical application may present a significant risk of personal injury and/or death. Such applications include, but are not limited to, nuclear reactor control, aircraft flight control, air traffic control, mass transit control, medical life support, and missile launch control. Customers shall not use the product for a safety-critical application without guaranteeing the required level of safety. Customers who plan to use the product in a safety-critical system are requested to consult the Fujitsu sales representatives in charge.

### Storage of accessories

Keep the accessories in a safe place because they are required for server operations.

## Organization and Notation of This Manual

This section describes the following topics:

- [Organization of this manual](#)
- [Manuals for the PRIMEQUEST 2000 series](#)
- [Related manuals](#)
- [Abbreviations](#)
- [Trademarks](#)
- [Notation](#)
- [Notation for the CLI \(command line interface\)](#)

- Notes on notations
- Alert messages
- Product operating environment

## Organization of this manual

This manual is organized as follows.

### CHAPTER 1 MMB Web-UI (Web User Interface) Operations

Chapter 1 describes the menus used to manage and operate the PRIMEQUEST 2000 series server with the MMB Web-UI. It also describes how to use the MMB Web-UI.

### CHAPTER 2 MMB CLI (Command Line Interface) Operations

Chapter 2 describes the CLI (command line interface) provided by the MMB.

### CHAPTER 3 UEFI Menu Operations

Chapter 3 describes the menu operations of the UEFI.

### CHAPTER 4 UEFI Command Operations

Chapter 4 describes the command operations of the UEFI.

### CHAPTER 5 Dynamic Reconfiguration Operation

Chapter 5 describes the Dynamic Reconfiguration operation.

### CHAPTER 6 Setting of sadump environment

Chapter 6 describes the setting of sadump environment.

### Appendix A List of Setting Items

Appendix A lists the setting items for each window.

## Manuals for the PRIMEQUEST 2000 series

The following manuals have been prepared to provide you with the information necessary to use the PRIMEQUEST 2000 series.

You can access HTML versions of these manuals at the following sites:

Japanese-language site: <http://jp.fujitsu.com/platform/server/primequest/manual/2000/>

Global site: <http://www.fujitsu.com/global/services/computing/server/primequest/>

Title	Description	Manual code
<i>PRIMEQUEST 2000 Series Getting Started Guide</i>	Describes what manuals you should read and how to access important information after unpacking the PRIMEQUEST 2000 series server. (This manual comes with the product.)	C122-E170EN
<i>PRIMEQUEST 2000 Series Safety and Regulatory Information</i>	Contains important information required for using the PRIMEQUEST 2000 series safely.	C122-E171EN
<i>PRIMEQUEST 2000 Series Errata and Addenda</i>	Provides errata and addenda for the PRIMEQUEST 2000 series manuals. This manual will be updated as needed.	C122-E182EN
<i>PRIMEQUEST 2000 Series General Description</i>	Describes the functions and features of the PRIMEQUEST 2000 series.	C122-B025EN
<i>SPARC M10</i>	Provides the necessary information and	C120-H007EN

Title	Description	Manual code
<i>Systems/SPARC Enterprise/PRIMEQUEST Common Installation Planning Manual</i>	concepts you should understand for installation and facility planning for SPARC M10 Systems, SPARC Enterprise, and PRIMEQUEST installations.	
<i>PRIMEQUEST 2000 Series Hardware Installation Manual</i>	Includes the specifications of and the installation location requirements for the PRIMEQUEST 2000 series.	C122-H007EN
<i>PRIMEQUEST 2000 Series Installation Manual</i>	Describes how to set up the PRIMEQUEST 2000 series server, including the steps for installation preparation, initialization, and software installation.	C122-E174EN
<i>PRIMEQUEST 2000 Series User Interface Operating Instructions</i>	Describes how to use the Web-UI and UEFI to assure proper operation of the PRIMEQUEST 2000 series server.	C122-E176EN
<i>PRIMEQUEST 2000 Series Administration Manual</i>	Describes how to use tools and software for system administration and how to maintain the system (component replacement and error notification).	C122-E175EN
<i>PRIMEQUEST 2000 Series Tool Reference</i>	Provides information on operation methods and settings, including details on the MMB and UEFI functions.	C122-E177EN
<i>PRIMEQUEST 2000 Series Message Reference</i>	Lists the messages that may be displayed when a problem occurs during operation and describes how to respond to them	C122-E178EN
<i>PRIMEQUEST 2000 Series REMCS Installation Manual</i>	Describes REMCS service installation and operation.	C122-E180EN
<i>PRIMEQUEST 2000 Series Glossary</i>	Defines the PRIMEQUEST 2000 series related terms and abbreviations.	C122-E179EN

## Related manuals

The following manuals relate to the PRIMEQUEST 2000 series.

You can access these manuals at the following site:

<http://www.fujitsu.com/global/services/computing/server/primequest/>

Contact your sales representative for inquiries about the ServerView manuals.

Title	Description	Manual code
<i>ServerView Suite ServerView Operations Manager Quick Installation (Windows)</i>	Describes how to install and start ServerView Operations Manager in a Windows environment.	None
<i>ServerView Suite ServerView Operations Manager Quick</i>	Describes how to install and start ServerView Operations Manager in a Linux environment.	None



Title	Description	Manual code
<i>Installation (Linux)</i>		
<i>ServerView Suite ServerView Installation Manager</i>	Describes the installation procedure using ServerView Installation Manager.	None
<i>ServerView Suite ServerView Operations Manager Server Management</i>	Provides an overview of server monitoring using ServerView Operations Manager, and describes the user interface of ServerView Operations Manager.	None
<i>ServerView Suite ServerView RAID Management User Manual</i>	Describes RAID management using ServerView RAID Manager.	None
<i>ServerView Suite Basic Concepts</i>	Describes basic concepts about ServerView Suite.	None
<i>ServerView Operations Manager Installation ServerView Agents for Linux</i>	Describes installation and update installation of ServerView Linux Agent.	None
<i>ServerView Operations Manager Installation ServerView Agents for Windows</i>	Describes installation and update installation of ServerView Windows Agent.	None
<i>ServerView RAID Manager VMware vSphere ESXi 5 Installation Guide</i>	Describes the installation and settings required to use ServerView RAID Manager on the VMware vSphere ESXi 5 server.	None
<i>MegaRAID SAS User Guide</i>	Provides technical information on using array controller (RAID Ctrl SAS 6G 5/6 512MB(D2616), RAID Ctrl SAS 6G 0/1(D2607), MegaRAID SAS 9280-8e)	B7FY-2751

## Abbreviations

This manual uses the following product name abbreviations.

Formal product name	Abbreviation
Microsoft® Windows Server® 2012 R2 Datacenter	Windows, Windows Server 2012
Microsoft® Windows Server® 2012 R2 Standard	
Microsoft® Windows Server® 2012 Datacenter	
Microsoft® Windows Server® 2012 Standard	
Microsoft(R) Windows Server(R) 2008 R2 Standard	Windows, Windows Server 2008 R2
Microsoft(R) Windows Server(R) 2008 R2 Enterprise	
Microsoft(R) Windows Server(R) 2008 R2 Datacenter	
Red Hat(R) Enterprise Linux(R) 6(for Intel64)	Linux RHEL6

Formal product name	Abbreviation
Oracle Linux 6 (x86_64)	Oracle Linux, Oracle Linux 6
VMware vSphere(R) 5	VMware, vSphere 5.x, VMware 5, VMware 5.x
VMware(R) ESXi(R) 5	ESX, ESX 5, ESX 5.x
Novell (R) SUSE(R) LINUX Enterprise Server 11 Service Pack 3	SLES11 SP3

## Trademarks

- Microsoft, Windows, and Windows Server are trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries.
- Linux is a registered trademark of Linus Torvalds.
- Red Hat, the Shadowman logo and JBoss are registered trademarks of Red Hat, Inc. in the U.S. and other countries.
- Celeron, Celeron Inside, Centrino, Centrino Inside, Core Inside, Intel, the Intel logo, Intel Atom, Intel Atom Inside, Intel Core, Intel Inside, the Intel Inside logo, Intel vPro, Itanium, Itanium Inside, Pentium, Pentium Inside, the Rapid Start Technology logo, vPro Inside, Ultrabook, Xeon, and Xeon Inside are trademarks or registered trademarks of Intel Corporation in the U.S. and other countries.
- Ethernet is a registered trademark of Fuji Xerox Co., Ltd. in Japan and is a registered trademark of Xerox Corp. in the United States and other countries.
- VMware is a trademark or registered trademark of VMware, Inc. in the United States and other countries.
- Novell and SUSE Linux Enterprise Server are trademarks of Novell, Inc.
- Xen is a trademark or registered trademark of Citrix Systems, Inc. or its subsidiaries in the United States and other countries.
- Other company names and product names are the trademarks or registered trademarks of their respective owners.
- Trademark indications are omitted for some system and product names in this manual.

## Notation

This manual uses the following fonts and symbols to express specific types of information.

Font or symbol	Meaning	Example
<i>italics</i>	Title of a manual that you should refer to	See the PRIMEQUEST 2000 Series Installation Manual (C122-E174EN).
[ ]	Window names as well as the names of buttons, tabs, and drop-down menus in windows are enclosed in brackets.	Click the [OK] button.

## Notation for the CLI (command line interface)

The following notation is used for commands.

## Command syntax

Command syntax is represented as follows.

- Variables requiring the entry of a value are enclosed in angle brackets < >.
- Optional elements are enclosed in brackets [ ].
- Options for optional keywords are grouped in | (stroke) separated lists enclosed in brackets [ ].
- Options for required keywords are grouped in | (stroke) separated lists enclosed in braces { }.

Command syntax is written in a box.

**Remarks**



The command output shown in the PDF manuals may include line feeds at places where there is no line feed symbol (¥ at the end of the line).

**Notes on notations**

- In this manual, the Management Board and MMB firmware are abbreviated as "MMB."
- In this manual,, IOU\_10GbE and IOU\_1GbE are matched and it is written as "IOU".
- Screenshots contained in this manual may differ from the actual product screen displays.
- The IP addresses, configuration information, and other such information contained in this manual are display examples and differ from that for actual operation.

**Alert messages**

This manual uses the following alert messages to prevent users and bystanders from being injured and to prevent property damage.

 <b>WARNING</b>	This indicates a hazardous situation that is likely to result in death or serious personal injury if the user does not perform the procedure correctly.
 <b>CAUTION</b>	This indicates a hazardous situation that could result in minor or moderate personal injury if the user does not perform the procedure correctly. This also indicates that damage to the product or other property may occur if the user does not perform the procedure correctly.
<b>Important</b>	This indicates information that could help the user use the product more efficiently.

**Alert messages in the text**

An alert statement follows an alert symbol. An alert statement is indented on both ends to distinguish it from regular text. Similarly, one space line is inserted before and after the alert statement.



Only Fujitsu certified service engineers should perform the following tasks on this product and the options provided by Fujitsu. Customers must not perform these tasks under any circumstances. Otherwise, electric shock, injury, or fire may result.

- Newly installing or moving equipment
- Removing the front, rear, and side covers
- Installing and removing built-in options
- Connecting and disconnecting external interface cables
- Maintenance (repair and periodic diagnosis and maintenance)

The List of important alert items table lists important alert items.

**Product operating environment**

This product is a computer intended for use in a computer room environment. For details on the product operating environment, see the following manual:

*PRIMEQUEST 2000 Series Hardware Installation Manual (C122-H007EN)*

**Note**

- If you have a comment or request regarding this manual, or if you find any part of this manual unclear, please take a moment to share it with us by filling in the form at the following webpage, stating your points specifically, and sending the form to us:  
[https://www-s.fujitsu.com/global/contact/computing/PRMQST\\_feedback.html](https://www-s.fujitsu.com/global/contact/computing/PRMQST_feedback.html)
- The contents of this manual may be revised without prior notice.
- The PDF file of this manual is intended for display using Adobe® Reader® in single page viewing mode at 100% zoom.
- The PSU\_P supports only 200 V power supply.

## Safety Precautions

### List of important alert items

The important warning matter that has been described in this manual is as follows.



This indicates a hazardous situation that could result in minor or moderate personal injury if the user does not perform the procedure correctly. This also indicates that damage to the product or other property may occur if the user does not perform the procedure correctly

Operation division	Content of alert	Chapter of description
Normal operation	(data destruction) Reconfirm whether the selection of the disk is correct when you select the dump device. Data is destroyed when executing it with the selection makes a mistake.	6.6 Dump device selection menu

### Warning labels

The following warning labels are affixed to this product. These labels are intended for the users of this product.



Never remove the warning labels.

## Revision History

Edition	Date	Revised location (type) (*1)	Description
1	2014-2-18	-	-

\*1: Chapter, section, and item numbers in the "Revised location" column refer to those in the latest edition of the document. However, a number marked with an asterisk (\*) denotes a chapter, section, or item in a previous edition of the document.

# Contents

Preface.....	i
CHAPTER 1    MMB Web-UI (Web User Interface) Operations .....	30
1.1      Web-UI Menus.....	30
1.1.1    Web-UI menus (Administrator) .....	31
1.1.2    Web-UI menus (Operator).....	34
1.1.3    Web-UI menus (Partition Operator) .....	37
1.1.4    Web-UI menus (User) .....	41
1.1.5    Web-UI menus (CE).....	44
1.1.6    Web-UI menus in maintenance mode.....	48
1.1.7    Web-UI menus in maintenance mode (Administrator) .....	48
1.1.8    Web-UI menus in maintenance mode (Operator) .....	50
1.1.9    Web-UI menus in maintenance mode (Partition Operator) .....	52
1.1.10    Web-UI menus in maintenance mode (User) .....	54
1.1.11    Web-UI menus in maintenance mode (CE) .....	56
1.1.12    Web-UI menus in maintenance mode (maintenance personnel) .....	57
1.1.13    Web-UI menus (PRIMEQUEST 2800B model).....	60
1.2      [System] Menu for PRIMEQUEST 2400E/2800E .....	63
1.2.1    [System Status] window .....	63
1.2.2    [System Event Log] Window .....	64
1.2.3    [Operation Log] Window .....	70
1.2.4    [Partition Event Log] Window .....	73
1.2.5    [System Information] Window .....	76
1.2.6    [Firmware Information] Window .....	77
1.2.7    [System Setup] Window .....	79
1.2.8    [System Power Control] window .....	82
1.2.9    [LEDs] window .....	84
1.2.10    [Power Supply] window .....	86
1.2.11    [Fans] window .....	87
1.2.12    [Temperature] window .....	90
1.2.13    [SB] Menu.....	91
1.2.14    [IOU] Menu .....	101
1.2.15    [DU] Menu .....	107
1.2.16    [PCI_Box] Menu.....	110
1.2.17    [OPL] Window .....	115
1.2.18    [MMB] Menu.....	116
1.2.19    [Disk Enclosure] Menu.....	119
1.3      [Partition] Menu for PRIMEQUEST 2400E/2800E .....	123
1.3.1    [Power Control] Window .....	123
1.3.2    [Schedule] Menu.....	128
1.3.3    [Console Redirection Setup] window .....	135
1.3.4    [Partition Configuration] Menu .....	139
1.3.5    [Reserved SB Configuration] window .....	146

---

1.3.6	[Power Management Setup] Window.....	148
1.3.7	[Partition#x] Menu .....	150
1.4	[User Administration] Menu .....	159
1.4.1	[User List] window .....	159
1.4.2	[Change Password] window .....	163
1.4.3	[Who] window.....	165
1.5	[Network Configuration] Menu .....	167
1.5.1	[Date/Time] window .....	167
1.5.2	[Network Interface] window .....	170
1.5.3	[Management LAN Port Configuration] window.....	180
1.5.4	[Network Protocols] window .....	184
1.5.5	[Refresh Rate] window .....	186
1.5.6	[SNMP Configuration] window .....	187
1.5.7	[SSL] menu .....	193
1.5.8	[SSH] menu.....	199
1.5.9	[Remote Server Management] window.....	201
1.5.10	[Access Control] window .....	204
1.5.11	[Alarm E-Mail] window .....	208
1.6	[Maintenance] Menu .....	213
1.6.1	[Firmware Update] menu.....	213
1.6.2	[Backup/Restore Configuration] menu.....	214
1.6.3	[Maintenance Wizard] window .....	220
1.6.4	[REMCS] menu.....	220
1.7	[System] Menu for PRIMEQUEST 2800B.....	221
1.7.1	[System Status] window .....	221
1.7.2	[System Event Log] Window .....	222
1.7.3	[Operation Log] Window .....	227
1.7.4	[System Information] Window .....	227
1.7.5	[Firmware Information] Window .....	229
1.7.6	[System Setup] Window .....	231
1.7.7	[Power Control] Window .....	234
1.7.8	[Schedule] Menu .....	237
1.7.9	[Console Redirection Setup] Menu .....	243
1.7.10	[Power Management Setup] Window.....	246
1.7.11	[ASR Control] Window.....	247
1.7.12	[Console Redirection] Window .....	249
1.7.13	[Mode] Window .....	251
1.7.14	[SB] Menu.....	253
1.7.15	[IOU] Menu .....	262
1.7.16	[DU] Menu .....	265
1.7.17	[OPL] Window .....	266
1.7.18	[MMB] Window.....	266
CHAPTER 2	MMB CLI (Command Line Interface) Operations .....	269
2.1	Basic Operations with the CLI .....	269
2.1.1	Access to the CLI via the serial interface .....	269



---

2.1.2	Access via the management LAN interface .....	269
2.1.3	CLI command list .....	270
2.2	Setting Commands .....	282
2.2.1	add partition .....	282
2.2.2	clear access_control .....	283
2.2.3	clear ssh_key .....	284
2.2.4	console .....	284
2.2.5	download ssh_key .....	285
2.2.6	power off .....	286
2.2.7	power on .....	286
2.2.8	sadump .....	288
2.2.9	reset .....	288
2.2.10	nmi .....	289
2.2.11	remove partition .....	290
2.2.12	set active_mmb .....	291
2.2.13	set date .....	292
2.2.14	set partition dynamic_partitioning .....	293
2.2.15	set gateway .....	293
2.2.16	set gateway_ipv6 .....	294
2.2.17	set hostname .....	295
2.2.18	set http .....	295
2.2.19	set http_port .....	296
2.2.20	set https .....	296
2.2.21	set https_port .....	297
2.2.22	set ip .....	297
2.2.23	set ipv6 .....	298
2.2.24	set maintenance_ip .....	298
2.2.25	set partition home .....	299
2.2.26	set partition lan_device_mode .....	300
2.2.27	set partition memory_mirror_ras_mode .....	301
2.2.28	set partition memory_opration_mode .....	302
2.2.29	set partition name .....	304
2.2.30	set partition pci_address_mode .....	305
2.2.31	set ssh .....	305
2.2.32	set ssh_port .....	306
2.2.33	set telnet .....	306
2.2.34	set telnet_port .....	307
2.2.35	set timezone .....	307
2.2.36	hotadd partition .....	308
2.2.37	hotremove partition .....	310
2.3	Commands for Display .....	311
2.3.1	show access_control .....	311
2.3.2	show active_mmb .....	312
2.3.3	show date .....	312
2.3.4	show exit_code .....	313

---

2.3.5	show partition configuration .....	313
2.3.6	show partition dynamic_partitioning .....	314
2.3.7	show partition home .....	315
2.3.8	show partition lan_device_mode .....	316
2.3.9	show partition name .....	316
2.3.10	show partition memory_mirror_ras_mode .....	317
2.3.11	show partition memory_operation_mode .....	317
2.3.12	show partition pci_address_mode .....	318
2.3.13	show timezone .....	319
2.3.14	show gateway .....	319
2.3.15	show gateway_ipv6 .....	319
2.3.16	show http .....	320
2.3.17	show http_port .....	320
2.3.18	show https .....	321
2.3.19	show https_port .....	321
2.3.20	show ip .....	321
2.3.21	show ipv6 .....	322
2.3.22	show hostname .....	322
2.3.23	show maintenance_ip .....	323
2.3.24	show ssh .....	323
2.3.25	show ssh_port .....	323
2.3.26	show telnet .....	324
2.3.27	show telnet_port .....	324
2.3.28	show network .....	325
2.3.29	show ntpq .....	326
2.3.30	who .....	327
2.3.31	help .....	328
2.3.32	netck traceroute .....	334
2.3.33	netck arptbl .....	334
2.3.34	netck arping .....	335
2.3.35	netck ifconfig .....	335
2.3.36	netck stat .....	336
2.3.37	show dynamic_partitioning status .....	337
2.4	Update Command .....	338
2.4.1	Update ALL .....	338
2.4.2	show update_status .....	339
2.5	Other Commands .....	340
2.5.1	exit .....	340
2.5.2	passwd .....	341
2.5.3	ping .....	341
2.6	PRIMEQUEST2800B model Commands .....	343
2.6.1	PRIMEQUEST2800B model CLI command list .....	343
2.6.2	power off .....	347
2.6.3	power on .....	348
2.6.4	reset .....	348

---

2.6.5	nmi .....	349
2.6.6	set memory_opration_mode .....	349
2.6.7	set memory_mirror_ras_mode .....	351
2.6.8	set lan_device_mode .....	352
2.6.9	show memory_operation_mode .....	352
2.6.10	show memory_mirror_ras_mode .....	353
2.6.11	show lan_device_mode .....	354
2.6.12	set mmbcontrol reset .....	354
2.6.13	add user .....	355
2.6.14	show user_list .....	355
2.6.15	console .....	356
CHAPTER 3	UEFI Menu Operations .....	358
3.1	Front page of Boot Manager .....	358
3.1.1	Window area .....	358
3.2	[Continue] Menu .....	360
3.3	[Boot Manager] Menu .....	360
3.3.1	Boot Option .....	360
3.3.2	Boot specification of UEFI .....	361
3.3.3	About boot specification of legacy BIOS .....	362
3.3.4	Boot processing .....	363
3.4	[Device Manager] Menu .....	367
3.4.1	[System Information] Menu .....	368
3.4.2	[I/O Space Assignment Configuration] Menu .....	369
3.4.3	[LAN Remote Boot Configuration] Menu .....	371
3.4.4	[CPU Configuration] Menu .....	375
3.4.5	[PCI Bus Padding Configuration] Menu .....	379
3.4.6	[PCI Subsystem Configuration] Menu .....	380
3.4.7	[IOU OpROM Scan Configuration] Menu .....	382
3.4.8	[PCI_Box OpROM Scan Configuration] menu .....	385
3.4.9	[iSCSI Configuration] menu .....	390
3.4.10	[Memory Configuration] menu .....	403
3.4.11	[USB Configuration] menu .....	406
3.4.12	[Security Configuration] menu .....	408
3.5	[Boot maintenance Manager] Menu .....	410
3.5.1	[Boot Mode] Menu .....	411
3.5.2	[Boot Options] menu .....	412
3.5.3	[Boot From File] Menu .....	441
3.5.4	[Set Time out Value] Menu .....	444
3.6	Device Path .....	446
3.6.1	Parameter of Device Path .....	446
3.6.2	Identification of Device Path .....	447
CHAPTER 4	UEFI Command Operations .....	450
4.1	Automatic startup file .....	450
4.1.1	Automatic startup file .....	450
4.1.2	UEFI shell command syntax .....	451

---

4.1.3	Output redirection.....	451
4.1.4	UEFI shell command list.....	452
CHAPTER 5	Dynamic Reconfiguration Operation.....	453
5.1	DR Command.....	453
5.1.1	dr command (common part).....	453
5.1.2	Device hot-add/hot-remove operation (add/rm subcommand).....	453
5.1.3	Show slot status (slot subcommand).....	454
5.1.4	Show resources on device (show subcommand).....	455
5.1.5	Information gathering (dr report subcommand).....	455
5.2	Hot plug collaboration function.....	456
5.2.1	Description of collaboration function.....	456
5.2.2	Collaboration program execution timing.....	456
5.2.3	Timeout of collaboration program.....	457
5.2.4	Directory that stored collaboration program.....	457
5.2.5	Naming convention of collaboration program.....	457
5.2.6	Method of describing configuration file of collaboration program.....	458
5.2.7	Permission required for collaboration program.....	459
5.2.8	Argument passed to collaboration program.....	459
5.2.9	Exit status of collaboration program.....	461
5.2.10	Output of collaboration program.....	461
5.2.11	Flow of collaboration program execution.....	461
CHAPTER 6	Setting of sadump environment.....	466
6.1	Sadump Configuration Menu.....	466
6.1.1	Screen areas.....	470
6.2	Main menu.....	470
6.3	[Set up Manager] Menu.....	471
6.4	[Dump device Manager] Menu.....	473
6.5	[Create a dump device] Menu.....	474
6.6	[Select device] Menu.....	475
6.7	[Setting dump device] Menu.....	477
6.8	[Select device] Menu.....	478
6.9	[Select discard dump device] Menu.....	479
6.10	[Select multiple devices] Menu.....	480
Appendix A	List of Setting Items.....	483
A.1	Setting Items of MMB Web-UI.....	483
A.1.1	Setting items of [System Event Log Filtering Condition] Window.....	483
A.1.2	Setting Item of [Operation Log Filtering Condition] Window.....	484
A.1.3	Setting Items of [System Information] Window.....	485
A.1.4	Setting items of [System Setup] Window.....	485
A.1.5	Setting items of [System Power Control] Window.....	486
A.1.6	Setting items of [Power Control] Window.....	486
A.1.7	Setting Items of [Schedule Control] Window.....	487
A.1.8	Setting Items of [Add Schedule]/ [Edit User] Window.....	487
A.1.9	Setting Items of [Partition Configuration] Window.....	487
A.1.10	Setting Items of [IPv4 Console Redirection Setup] Window.....	488

---

A.1.11	Setting Items of [IPv6 Console Redirection Setup] Window.....	488
A.1.12	Setting Items of [Power Management Setup] Window.....	488
A.1.13	Setting Items of [ASR Control] Window.....	489
A.1.14	Setting Items of [Console Redirection] Window.....	489
A.1.15	Setting Items of [Mode] Window.....	490
A.1.16	Setting Items of [Add User]/ [Edit User] Window.....	490
A.1.17	Setting Items of [Date/Time] Window.....	491
A.1.18	Setting Items of [IPv4 Interface] Window.....	492
A.1.19	Setting Items of [IPv6 Interface] Window.....	493
A.1.20	Setting Items of [Management LAN Port Configuration] Window.....	494
A.1.21	Setting Items of [Network Protocols] Window.....	495
A.1.22	Setting Items of [Refresh Rate] Window.....	495
A.1.23	Setting Items of [SNMP Community] Window.....	496
A.1.24	Setting Items of [SNMP Trap] Window.....	496
A.1.25	Setting Items of [SNMP v3 Configuration] Window.....	497
A.1.26	Setting Items of [Create CSR] Window.....	498
A.1.27	Setting Items of [Create Selfsigned Certificate] Window.....	498
A.1.28	Setting Items of [Edit User] Window.....	499
A.1.29	Setting Items of [Add Filter] / [Edit Filter] Window.....	499
A.1.30	Setting Items of [Alarm E-Mail] Window.....	500
A.1.31	Setting Items of [Alarm E-Mail Filtering Condition] Window.....	500
A.2	Setting Items on UEFI.....	500
A.2.1	Setting Items on [I/O Space Assignment Configuration] Window.....	501
A.2.2	Setting Items on [LAN Remote Boot Configuration] Window.....	501
A.2.3	Setting Items on [CPU Configuration] Window.....	501
A.2.4	Setting Items on [PCI Bus Padding Configuration] Window.....	503
A.2.5	Setting Items on [PCI Subsystem Configuration] Window.....	503
A.2.6	Setting Items on [IOU OpROM Scan Configuration] Window.....	503
A.2.7	Setting Items on [PCI_Box OpROM Scan Configuration] Window.....	504
A.2.8	Setting Items on [iSCS Configuration] Window.....	506
A.2.9	Setting Items on [Attempt Configuration] Window.....	506
A.2.10	Setting Items on [Memory Configuration] Window.....	507
A.2.11	Setting Items on [USB Configuration] Window.....	508
A.2.12	Setting Items on [Security Configuration] Window.....	508
A.3	Setting Items on Video redirection.....	508
A.3.1	Setting Items on [Video] Window.....	509
A.3.2	Setting Items on [Keyboard] Window.....	509
A.3.3	Setting Items on [Mouse] Window.....	509
A.3.4	Setting Items on [Options] Window.....	510

# Figures

FIGURE 1.1 [System Status] window.....	63
FIGURE 1.2 [System Event Log] window.....	65
FIGURE 1.3 [System Event Log (Collect)] Window.....	67
FIGURE 1.4 [System Event Log Filtering Condition] Window.....	68
FIGURE 1.5 [Operation Log] Window.....	70
FIGURE 1.6 [Operating Log Filtering Condition] Window.....	72
FIGURE 1.7 [Partition Event Log] window.....	73
FIGURE 1.8 [Partition Event Log Filtering Condition] Window.....	75
FIGURE 1.9 [System Information] Window.....	76
FIGURE 1.10 [Firmware Information] Window.....	78
FIGURE 1.11 [System Setup] Window.....	80
FIGURE 1.12 [System Power Control] Window.....	83
FIGURE 1.13 [LEDs] Window.....	85
FIGURE 1.14 [Power Supply] Window.....	86
FIGURE 1.15 [Fans] Window(1) .....	88
FIGURE 1.16 [Fans] Window(2) .....	88
FIGURE 1.17 [Temperature] Window.....	90
FIGURE 1.18 [SB#x] Window (1).....	91
FIGURE 1.19 [SB#x] Window (2).....	92
FIGURE 1.20 [SB#x] Window (3).....	92
FIGURE 1.21 [SB#x] Window (4).....	93
FIGURE 1.22 [SB#x] Window (5).....	93
FIGURE 1.23 [SB#x] Window (6).....	94
FIGURE 1.24 [SB#x Status Clear] Window (Message Display) .....	100
FIGURE 1.25 [SB#x] Window (When there is no CPU/DIMM) .....	101
FIGURE 1.26 [IOU#x] Window (1) .....	102
FIGURE 1.27 [IOU#x] Window (2) .....	103
FIGURE 1.28 [IOU#x] Window (3) .....	104
FIGURE 1.29 [DU#x] Window.....	107
FIGURE 1.30 [PCI_Box] Window (1).....	110
FIGURE 1.31 [PCI_Box] Window (2).....	111
FIGURE 1.32 [PCI_Box] Window (3).....	111
FIGURE 1.33 [PCI_Box] Window (4).....	112
FIGURE 1.34 [OPL] window .....	115
FIGURE 1.35 [MMB#x] Window .....	117
FIGURE 1.36 [Disk Enclosure#x] Window (1).....	119
FIGURE 1.37 [Disk Enclosure#x] Window (2).....	120
FIGURE 1.38 [Power Control] Window .....	124
FIGURE 1.39 [Power Control] Window (Grayout Display) .....	125
FIGURE 1.40 Display of Errors of [Power Control] Window .....	127
FIGURE 1.41 [Schedule Control] Window .....	129
FIGURE 1.42 [Schedule List] Window.....	131

---

FIGURE 1.43 [Schedule List] Window.....	134
FIGURE 1.44 [IPv4 Console Redirection Setup].....	136
FIGURE 1.45 [IPv6 Console Redirection Setup] Window.....	138
FIGURE 1.46 [Partition Configuration] Window.....	140
FIGURE 1.47 [Add SB/IOU to Partition] Window.....	142
FIGURE 1.48 [Remove SB/IOU from Partition] Window.....	144
FIGURE 1.49 [Partition Home] window.....	145
FIGURE 1.50 [Reserved SB Configuration] Window.....	146
FIGURE 1.51 [Power Management Setup] window.....	148
FIGURE 1.52 [Information] Window.....	150
FIGURE 1.53 [ASR (Automatic Server Restart) Control] Window.....	152
FIGURE 1.54 [Console Redirection] Window.....	154
FIGURE 1.55 [Mode] Window.....	155
FIGURE 1.56 [User List] Window.....	159
FIGURE 1.57 [Add List] Window.....	161
FIGURE 1.58 [Edit List] Window.....	162
FIGURE 1.59 [Change Password] window.....	164
FIGURE 1.60 [Change Password] window.....	165
FIGURE 1.61 [Date/Time] window.....	167
FIGURE 1.62 [IPv4 Interface] window (PRIMEQUEST 2400E/2800E) (1).....	170
FIGURE 1.63 [IPv4 Interface] window (PRIMEQUEST 2400E/2800E) (2).....	171
FIGURE 1.64 [IPv4 Interface] window (PRIMEQUEST 2800B) (1).....	173
FIGURE 1.65 [IPv4 Interface] window (PRIMEQUEST 2800B) (2).....	173
FIGURE 1.66 [IPv6 Interface] window (PRIMEQUEST 2400E/2800E) (1).....	175
FIGURE 1.67 [IPv6 Interface] window (PRIMEQUEST 2400E/2800E) (2).....	176
FIGURE 1.68 [IPv6 Interface] window (PRIMEQUEST 2800B) (1).....	178
FIGURE 1.69 [IPv6 Interface] window (PRIMEQUEST 2800B) (2).....	179
FIGURE 1.70 [Management LAN Port Configuration] window (PRIMEQUEST 2400E/2800E).....	181
FIGURE 1.71 [Management LAN Port Configuration] window (PRIMEQUEST 2800B).....	181
FIGURE 1.72 [Network Protocols] window.....	184
FIGURE 1.73 [Refresh Rate] window.....	186
FIGURE 1.74 [SNMP Community] window.....	188
FIGURE 1.75 [SNMP Trap] window.....	190
FIGURE 1.76 [SNMP v3 Configuration] window.....	192
FIGURE 1.77 [Create CSR] window.....	194
FIGURE 1.78 Confirmation dialog box.....	195
FIGURE 1.79 [Export Key/CSR] window.....	196
FIGURE 1.80 [Import Certificate] window.....	197
FIGURE 1.81 [Create Selfsigned Certificate] window.....	198
FIGURE 1.82 [Create SSH Server Key] window.....	200
FIGURE 1.83 [Remote Server Management] window.....	201
FIGURE 1.84 [Edit User] window.....	203
FIGURE 1.85 [Access Control] window.....	205
FIGURE 1.86 [Add Filter] window.....	207
FIGURE 1.87 [Alarm E-Mail] window.....	209

---

FIGURE 1.88 [Alarm E-Mail Filtering Condition] window(PRIMEQUEST 2400E/2800E).....	211
FIGURE 1.89 [Alarm E-Mail Filtering Condition] window(PRIMQUEST 2800B) .....	211
FIGURE 1.90 [Unified Firmware Update] window.....	213
FIGURE 1.91 Backup/Restore MMB Configuration window.....	215
FIGURE 1.92 Backup BIOS Configuration window.....	216
FIGURE 1.93 [Restore BIOS Configuration] window (1).....	217
FIGURE 1.94 [Restore BIOS Configuration] window (2).....	218
FIGURE 1.95 Backup/Restore BIOS Configuration window.....	219
FIGURE 1.96 [System Status] window.....	221
FIGURE 1.97 [System Event Log] window.....	223
FIGURE 1.98 [System Event Log (Collect)] Window.....	225
FIGURE 1.99 [System Event Log Filtering Condition] Window.....	226
FIGURE 1.100 [System Information] Window.....	228
FIGURE 1.101 [Firmware Information] Window.....	230
FIGURE 1.102 [System Setup] Window.....	232
FIGURE 1.103 [Power Control] Window .....	234
FIGURE 1.104 [Schedule Control] Window .....	238
FIGURE 1.105 [Schedule List] Window.....	239
FIGURE 1.106 [Schedule List] Window.....	241
FIGURE 1.107 [IPv4 Console Redirection Setup] Window.....	243
FIGURE 1.108 [IPv6 Console Redirection Setup] Window.....	245
FIGURE 1.109 [Power management Setup] window.....	246
FIGURE 1.110 [ASR (Automatic Server Restart) Control] Window.....	248
FIGURE 1.111 [Console Redirection] Window .....	250
FIGURE 1.112 [Mode] Window .....	251
FIGURE 1.113 [SB#x] Window (1).....	253
FIGURE 1.114 [SB#x] Window (2).....	254
FIGURE 1.115 [SB#x] Window (3).....	254
FIGURE 1.116 [SB#x] Window (4).....	255
FIGURE 1.117 [SB#x] Window (5).....	255
FIGURE 1.118 [SB#x] Window (6).....	256
FIGURE 1.119 [IOU#x] Window (1).....	262
FIGURE 1.120 [IOU#x] Window (2).....	263
FIGURE 1.121 [IOU#x] Window (3).....	263
FIGURE 1.122 [MMB#x] Window(1) .....	266
FIGURE 1.123 [MMB#x] Window(2) .....	267
FIGURE 3.1 Display Example of Front page of Boot Manager.....	358
FIGURE 3.2 Window area of Boot Manager Front Page .....	359
FIGURE 3.3 Display example of [Boot Manager] Menu.....	360
FIGURE 3.4 Boot Option of Boot Manager .....	361
FIGURE 3.5 Execution of Legacy Boot Option .....	362
FIGURE 3.6 Example of displayed [Boot Manager] menu.....	366
FIGURE 3.7 Example of displayed [Device Manager] menu .....	367
FIGURE 3.8 Example of displaying [System Information] menu.....	368
FIGURE 3.9 Display example of [I/O Space Assignment Configuration] Menu.....	370



---

FIGURE 3.10 Display of [LAN Remote Boot Configuration] Menu .....	372
FIGURE 3.11 Operation Window of PXE/iSCSI boot Enable Setting” .....	373
FIGURE 3.12 Display of [Boot Manager] Menu .....	374
FIGURE 3.13 Display of [MAC Selection].....	374
FIGURE 3.14 Display of [Set Legacy Net Drive Order] Menu.....	375
FIGURE 3.15 Display Example of [CPU Configuration] Menu.....	375
FIGURE 3.16 Example of Display on [PCI Bus Padding Configuration] Menu.....	379
FIGURE 3.17 Display Example on [PCI Subsystem Configuration] Menu.....	380
FIGURE 3.18 Display Example of [IOU OpROM Scan Configuration] Menu .....	382
FIGURE 3.19 Example of display of [PCI_Box OpROM Scan Configuration] menu.....	385
FIGURE 3.20 Example of [iSCSI Configuration] menu window display .....	391
FIGURE 3.21 iSCSI Environment Setting Operation Windows (1).....	393
FIGURE 3.22 iSCSI Environment Setting Operation Windows (2) [MAC Selection] menu. ....	394
FIGURE 3.23 iSCSI Environment Setting Operation Windows (3) [Attempt Configuration]menu .....	395
FIGURE 3.24 Display example of [MAC Selection] menu.....	396
FIGURE 3.25 Display example of [Attempt Configuration] Menu .....	397
FIGURE 3.26 Display example of [Delete Attempts] menu.....	401
FIGURE 3.27 Display example of [Change Attempt Order] Menu.....	402
FIGURE 3.28 Display Example of [Memory Configuration] Menu .....	404
FIGURE 3.29 Display example of [USB Configuration] menu .....	406
FIGURE 3.30 Display Example of [Security Configuration] Menu .....	408
FIGURE 3.31 [Boot Maintenance manager] Menu.....	410
FIGURE 3.32 Example Display of [Boot Mode] Menu.....	411
FIGURE 3.33 [Boot options] menu .....	412
FIGURE 3.34 Display Example of [Boot Manager] Menu .....	413
FIGURE 3.35 Display Example of [Add Boot Option] Menu .....	414
FIGURE 3.36 A list of Devices .....	415
FIGURE 3.37 Display example of File Selection Window .....	415
FIGURE 3.38 Windows Server 2012 Installed Disk Window .....	416
FIGURE 3.39 Display Example of Boot Option Name Change Window .....	417
FIGURE 3.40 Display Example of [Boot Manager] Menu .....	418
FIGURE 3.41 Display example of [Delete Boot option] menu.....	419
FIGURE 3.42 Delete window (1) of boot option .....	420
FIGURE 3.43 Boot Option Deletion Window (2) .....	420
FIGURE 3.44 [Change Boot Order] Menu .....	421
FIGURE 3.45 Change Window of Priority Order (Change Boot Order) (1) .....	422
FIGURE 3.46 Change Window of Priority Order (Change Boot Order) (2) .....	423
FIGURE 3.47 Windows after setting of priority level is changed (Change Boot Order) (3).....	423
FIGURE 3.48 Display example of [Set Legacy Floppy Drive Order] menu .....	424
FIGURE 3.49 Change in priority level (Set Legacy Floppy Drive Order) (1).....	425
FIGURE 3.50 Change in priority level (Set Legacy Floppy Drive Order) (2).....	426
FIGURE 3.51 Change of priority level (Set Legacy Floppy Drive Order) (3) .....	426
FIGURE 3.52 Change of the priority level (Set Legacy Floppy Drive Order) (4) .....	427
FIGURE 3.53 Display Example of [Set Legacy HardDisk Drive Order] Menu .....	428
FIGURE 3.54 Change of the Priority Level (Set Legacy HardDisk Drive Order) (1) .....	429

---

FIGURE 3.55 Change in Priority Level (Set Legacy HardDisk Drive Order) (2).....	430
FIGURE 3.56 Change in Priority Level (Set Legacy HardDisk Drive Order) (3).....	430
FIGURE 3.57 Change in Priority Level (Set Legacy HardDisk Drive Order) (4).....	431
FIGURE 3.58 Example of Displayed [Set Legacy CD-ROM Drive Order] Menu.....	432
FIGURE 3.59 Change in priority level (Set Legacy CD-ROM Drive Order) (1) .....	433
FIGURE 3.60 Change in priority level (Set Legacy CD-ROM Drive Order) (2) .....	434
FIGURE 3.61 Change in priority level (Set Legacy CD-ROM Drive Order) (3) .....	435
FIGURE 3.62 Change in priority level (Set Legacy CD-ROM Drive Order) (4) .....	435
FIGURE 3.63 Display example of the [Set Legacy NET Drive Order] menu .....	436
FIGURE 3.64 Change (Set Legacy NET Drive Order) (1) of priority level.....	438
FIGURE 3.65 Change of Priority Level (Set Legacy NET Drive Order) (2) .....	438
FIGURE 3.66 Change of Priority Level (Set Legacy NET Drive Order) (3) .....	439
FIGURE 3.67 Change of Priority Level (Set Legacy NET Drive Order) (4) .....	440
FIGURE 3.68 Display Example of [Boot From File] Menu.....	441
FIGURE 3.69 Specifications of Boot File (1).....	442
FIGURE 3.70 Specifications of Boot File (2).....	443
FIGURE 3.71 Specifications of Boot File (3).....	443
FIGURE 3.72 Logo Window.....	444
FIGURE 3.73 Display Example of [Set Time out Value] Menu .....	445
FIGURE 3.74 Specification of SAS disk built in SB.....	447
FIGURE 3.75 Specification of SAS Disk built in DU#0 .....	448
FIGURE 3.76 Specification of Disk from Fibre Card .....	448
FIGURE 3.77 Specification of GigaLAN .....	449
FIGURE 4.1 Sample screenshot of the UEFI shell immediately after it starts .....	450
FIGURE 6.1 Structure of menu for sadump configuration (1) .....	467
FIGURE 6.2 Structure of menu for sadump configuration (2) .....	468
FIGURE 6.3 Structure of menu for sadump configuration (3) .....	469
FIGURE 6.4 Screen areas of sadump configuration.....	470
FIGURE 6.5 Main menu .....	471
FIGURE 6.6 sadump setup menu .....	472
FIGURE 6.7 Dump device maintenance menu .....	473
FIGURE 6.8 Dump device create menu.....	474
FIGURE 6.9 Dump device select menu .....	475
FIGURE 6.10 [Setting dump device] Menu .....	477
FIGURE 6.11 [Select device] Menu .....	478
FIGURE 6.12 [Select discard dump device] Menu .....	479
FIGURE 6.13 [Select discard dump device] Menu [Select multiple devices] Menu .....	480
FIGURE 6.14 [Confirmation] Menu .....	481

# Tables

TABLE 1.1 User privileges.....	30
TABLE 1.2 Web-UI menus (Administrator) .....	31
TABLE 1.3 Web-UI menus (Operator).....	34
TABLE 1.4 Web-UI menus (Partition Operator).....	37
TABLE 1.5 Web-UI menus (User) .....	41
TABLE 1.6 Web-UI menus (CE) .....	44
TABLE 1.7 Types of maintenance mode.....	48
TABLE 1.8 Web-UI menus in maintenance mode (Administrator) .....	49
TABLE 1.9 Web-UI menus in maintenance mode (Operator) .....	51
TABLE 1.10 Web-UI menus in maintenance mode (Partition Operator).....	53
TABLE 1.11 Web-UI menus in maintenance mode (User) .....	54
TABLE 1.12 Web-UI menus in maintenance mode (CE).....	56
TABLE 1.13 Web-UI menus in maintenance mode (maintenance personnel) .....	58
TABLE 1.14 Web-UI menus (PRIMEQUEST 2800B model) .....	60
TABLE 1.15 Status of Unit and its Icons .....	64
TABLE 1.16 Items displayed in [System Status] Window .....	64
TABLE 1.17 Items displayed in [System Event Log] Window .....	65
TABLE 1.18 Buttons on [System Event Log] Window .....	66
TABLE 1.19 Display and Setting Items on [System Event Log Filtering Condition] Window .....	68
TABLE 1.20 [System Events Log Filtering Condition] Window Buttons .....	69
TABLE 1.21 Display items of [Operation Log] window .....	70
TABLE 1.22 [Operation Log] Window Buttons .....	71
TABLE 1.23 Display and Set Items of [Operating Log Filtering Condition] Window .....	72
TABLE 1.24 Buttons on [Operation Log Filtering Condition] window.....	73
TABLE 1.25 Display items of [Partition Event Log] window.....	74
TABLE 1.26 [Partition Event Log] Window Buttons .....	74
TABLE 1.27 Display and Set Items of [Partition Event Log Filtering Condition] Window.....	75
TABLE 1.28 Buttons on the [Partition Event Log Filtering Condition] Window .....	75
TABLE 1.29 Display and Set Items of [System Information] window.....	76
TABLE 1.30 Buttons on the [System Information] Window .....	77
TABLE 1.31 Display Item of [Firmware Information] Window.....	78
TABLE 1.32 Display Items and Setting Items in [System Setup] Window.....	80
TABLE 1.33 [System Setup] window button.....	81
TABLE 1.34 Display Items and Setting Items in [System Power Control] Window.....	83
TABLE 1.35 [System Power Control] Window Button .....	83
TABLE 1.36 Display Items and Setting Items in [LEDs] Window.....	85
TABLE 1.37 [LEDs] Window Button .....	85
TABLE 1.38 Display Item on [Power Supply] Window .....	86
TABLE 1.39 Button of [Power Supply] Window .....	87
TABLE 1.40 Display items of [Fans] window.....	89
TABLE 1.41 [Fans] Window Button .....	89
TABLE 1.42 Display Items on [Temperature] Window .....	90

---

TABLE 1.43 Display and Setting items on [SB#x] Window .....	94
TABLE 1.44 [SB#x] Window Button.....	99
TABLE 1.45 Display Items and Setting Items in [IOU#x] Window .....	104
TABLE 1.46 Button of [IOB#x] Screen.....	106
TABLE 1.47 Display and Setting items of [DU#x] Window.....	107
TABLE 1.48 Buttons on [DU#x] Window.....	109
TABLE 1.49 Display Items of [PCI_Box#x] Window .....	112
TABLE 1.50 [MMB#x] Window button .....	115
TABLE 1.51 Display items of [OPL] Window.....	116
TABLE 1.52 Button on [OPL] window.....	116
TABLE 1.53 Display of [MMB#x] Window / setting items .....	117
TABLE 1.54 [MMB#x] Window button .....	118
TABLE 1.55 Display and Setting items of [Disk Enclosure#x] Window .....	120
TABLE 1.56 Display Items and Set Items of [Power Control] Window .....	125
TABLE 1.57 [Power Control] Window Buttons .....	127
TABLE 1.58 Display Items and Setting Items of [Schedule Control] Window .....	129
TABLE 1.59 [Schedule Control] Window Buttons.....	131
TABLE 1.60 Display Items and Set Items of [Schedule List] Window .....	132
TABLE 1.61 [Schedule List] Window Buttons .....	132
TABLE 1.62 Display Items and Set Items of [Add Schedule] Window .....	134
TABLE 1.63 [Add Schedule] Window Buttons .....	135
TABLE 1.64 Display Items and Set Items of [IPv4 Console redirection Setup] Window .....	136
TABLE 1.65 [IPv4 Console redirection Setup] Window Buttons .....	137
TABLE 1.66 Display Items and Set Items of [IPv6 Console redirection Setup] Window .....	138
TABLE 1.67 [IPv6 Console redirection Setup] Window Buttons .....	139
TABLE 1.68 Display Items and Set Items of [Add Schedule] Window .....	140
TABLE 1.69 [Partition Configuration] Window Buttons .....	141
TABLE 1.70 Display Items and Set Items of [Add SB/IOU to Partition] Window.....	142
TABLE 1.71 Display Items and Set Items of [Remove SB/IOU to partition] Window.....	144
TABLE 1.72 Display Items and Set Items of [Reserved SB Configuration] Window .....	147
TABLE 1.73 [Reserved SB Configuration] Window Buttons .....	147
TABLE 1.74 Display Items and Set Items of [Power Management Setup] Window.....	149
TABLE 1.75 [Power Management Setup] Window Buttons.....	149
TABLE 1.76 Display Items of [Information] Window .....	150
TABLE 1.77 Display Items and Set Items of [ASR (Automatic Server Restart) Control] Window.....	152
TABLE 1.78 [ASR (Automatic Server Restart) Control] Window Buttons.....	153
TABLE 1.79 Display Items of [Console Redirection] Window .....	154
TABLE 1.80 Display Items and Setting Items in [Mode] Window.....	155
TABLE 1.81 Display items in the [User List] window.....	159
TABLE 1.82 Buttons in the [User List] window .....	160
TABLE 1.83 Setting and display items in the [Add User] and [Edit User] windows.....	162
TABLE 1.84 Buttons in the [Add User] and [Edit User] windows.....	163
TABLE 1.85 Buttons in the [Change Password] window.....	164
TABLE 1.86 Display items in the [Who] window .....	165
TABLE 1.87 Setting and display items in the [Date/Time] window.....	167

---

TABLE 1.88 Buttons in the [Date/Time] window .....	168
TABLE 1.89 Setting and display items in the [IPv4 Interface] window (PRIMEQUEST 2400E/2800E) .....	171
TABLE 1.90 Setting and display items in the [IPv4 Interface] window (PRIMEQUEST 2800B) .....	174
TABLE 1.91 Buttons in the [IPv4 Interface] window .....	174
TABLE 1.92 Setting and display items in the [IPv6 Interface] window (PRIMEQUEST 2400E/2800E) .....	177
TABLE 1.93 Setting and display items in the [IPv6 Interface] window (PRIMEQUEST 2800B) .....	179
TABLE 1.94 Buttons in the [IPv6 Interface] window .....	180
TABLE 1.95 Setting and display items in the [Management LAN Port Configuration] window in case of PRIMEQUEST 2400E/2800E .....	182
TABLE 1.96 Setting and display items in the [Management LAN Port Configuration] window in case of PRIMEQUEST 2800B .....	183
TABLE 1.97 Buttons in the [Management LAN Port Configuration] window .....	183
TABLE 1.98 Setting and display items in the [Network Protocols] window .....	184
TABLE 1.99 Buttons in the [Network Protocols] window .....	185
TABLE 1.100 Setting and display items in the [Refresh Rate] window .....	187
TABLE 1.101 Buttons in the [Refresh Rate] window .....	187
TABLE 1.102 Setting and display items in the [SNMP Community] window .....	188
TABLE 1.103 Buttons in the [SNMP Community] window .....	189
TABLE 1.104 Setting and display items in the [SNMP Trap] window .....	190
TABLE 1.105 Buttons in the [SNMP Trap] window .....	191
TABLE 1.106 Setting and display items in the [SNMP v3 Configuration] window .....	192
TABLE 1.107 Buttons in the [SNMP v3 Configuration] window .....	192
TABLE 1.108 Setting and display items in the [Create CSR] window .....	194
TABLE 1.109 Buttons in the [Create CSR] window .....	195
TABLE 1.110 Buttons in the [Export Key/CSR] window .....	196
TABLE 1.111 Buttons in the [Import Certificate] window .....	197
TABLE 1.112 Display items in the [Create Selfsigned Certificate] window .....	198
TABLE 1.113 Buttons in the [Create Selfsigned Certificate] window .....	198
TABLE 1.114 Buttons in the [Create SSH Server Key] window .....	200
TABLE 1.115 Display and setting items in the [Remote Server Management] window .....	201
TABLE 1.116 Buttons in the [Remote Server Management] window .....	202
TABLE 1.117 Display and setting items in the [Edit User] window .....	203
TABLE 1.118 Buttons in the [Edit User] .....	203
TABLE 1.119 Setting and display items in the [Access Control] window .....	205
TABLE 1.120 Buttons in the [Access Control] window .....	205
TABLE 1.121 Setting and display items in the [Add Filter] window .....	207
TABLE 1.122 Buttons in the [Add Filter] window .....	208
TABLE 1.123 Setting and display items in the [Alarm E-Mail] window .....	209
TABLE 1.124 Buttons in the [Alarm E-Mail] window .....	210
TABLE 1.125 Setting and display items in the [Alarm E-Mail Filtering Condition] window .....	212
TABLE 1.126 Buttons in the [Alarm E-Mail Filtering Condition] window .....	212
TABLE 1.127 Buttons in the [Backup BIOS Configuration] window .....	216
TABLE 1.128 Setting and display items in the [Restore BIOS Configuration] window (2) .....	218
TABLE 1.129 Buttons in the [Restore BIOS Configuration] window (2) .....	218
TABLE 1.130 Status of Unit and its Icons .....	222
TABLE 1.131 Items displayed in [System Status] Window .....	222

---

TABLE 1.132 Items displayed in [System Event Log] Window .....	223
TABLE 1.133 Buttons on [System Event Log] Window .....	224
TABLE 1.134 Display and Setting Items on [System Event Log Filtering Condition] Window .....	226
TABLE 1.135 [System Events Log Filtering Condition] Window Buttons .....	227
TABLE 1.136 Display and Set Items of [System Information] window .....	228
TABLE 1.137 Buttons on the [System Information] Window .....	229
TABLE 1.138 Display Item of [Firmware Information] Window .....	230
TABLE 1.139 Display Items and Setting Items in [System Setup] Window .....	232
TABLE 1.140 [System Setup] window button .....	233
TABLE 1.141 Display Items and Set Items of [Power Control] Window .....	235
TABLE 1.142 [Power Control] Window Buttons .....	236
TABLE 1.143 Display Items and Setting Items of [Schedule Control] Window .....	238
TABLE 1.144 [Schedule Control] Window Buttons .....	239
TABLE 1.145 Display Items and Set Items of [Schedule List] Window .....	240
TABLE 1.146 [Schedule List] Window Buttons .....	240
TABLE 1.147 Display Items and Set Items of [Add Schedule] Window .....	242
TABLE 1.148 [Add Schedule] Window Buttons .....	242
TABLE 1.149 Display Items and Set Items of [IPv4 Console redirection Setup] Window .....	243
TABLE 1.150 [IPv4 Console redirection Setup] Window Buttons .....	244
TABLE 1.151 Display Items and Set Items of [IPv6 Console redirection Setup] Window .....	245
TABLE 1.152 [IPv6 Console redirection Setup] Window Buttons .....	245
TABLE 1.153 Display Items and Set Items of [Power Management Setup] Window .....	246
TABLE 1.154 [Power Management Setup] Window Buttons .....	247
TABLE 1.155 Display Items and Set Items of [ASR (Automatic Server Restart) Control] Window .....	248
TABLE 1.156 [ASR (Automatic Server Restart) Control] Window Buttons .....	249
TABLE 1.157 Display Items of [Console Redirection] Window .....	250
TABLE 1.158 Display Items and Setting Items in [Mode] Window .....	251
TABLE 1.159 Display and Setting items on [SB#x] Window .....	256
TABLE 1.160 [SB#x] Window Button .....	261
TABLE 1.161 Display Items and Setting Items in [IOU#x] Window .....	264
TABLE 1.162 Button of [IOB#x] Screen .....	265
TABLE 1.163 Display of [MMB] Window / setting items .....	267
TABLE 1.164 [MMB#x] Window button .....	268
TABLE 2.1 Terminal software setting values .....	269
TABLE 2.2 MMB CLI commands (Administrator) .....	270
TABLE 2.3 MMB CLI commands (Operator) .....	272
TABLE 2.4 MMB CLI commands (Partition Operator) .....	274
TABLE 2.5 MMB CLI commands (User) .....	277
TABLE 2.6 MMB CLI commands (CE) .....	279
TABLE 2.7 Parameter specification range .....	281
TABLE 2.8 Output Items of show ntpq .....	326
TABLE 2.9 MMB CLI commands (Administrator) .....	343
TABLE 2.10 MMB CLI commands (Operator) .....	344
TABLE 2.11 MMB CLI commands (User) .....	345
TABLE 2.12 MMB CLI commands (CE) .....	346

---

TABLE 3.1 Display item of menu selection.....	359
TABLE 3.2 Display Items on Operation Help Display .....	359
TABLE 3.3 Initial state of Default .....	361
TABLE 3.4 Flow of startup by boot specification of UEFI and boot specification of legacy BIOS .....	363
TABLE 3.5 Boot success of Windows Server 2008.....	363
TABLE 3.6 Boot failure of Windows Server 2008 (UEFI Boot success of EFI USB Device).....	364
TABLE 3.7 If boot of Windows Boot Manager, EFI Network Device and EFI USB Device fails or if booted from Legacy Floppy	364
TABLE 3.8 If UEFI aware operating system Boot and Legacy operating system Boot fails and if UEFI Start up is successful ....	365
TABLE 3.9 Displayed contents of operation help display .....	366
TABLE 3.10 Displayed contents of menu selection .....	367
TABLE 3.11 Displayed contents of operation help display .....	368
TABLE 3.12 Display Contents of the System Information Display .....	369
TABLE 3.13 Display Contents of Help Operation Display .....	369
TABLE 3.14 Display Contents of Menu Selection.....	370
TABLE 3.15 Display contents of Display of Operation help.....	371
TABLE 3.16 Reflection of [LAN Remote Boot Configuration] Menu .....	371
TABLE 3.17 Display contents of Menu Selection.....	372
TABLE 3.18 Display contents of Display of Operation help.....	372
TABLE 3.19 Display Contents of Menu Selection.....	376
TABLE 3.20 Display Contents of Operation Help Display .....	378
TABLE 3.21 Display Contents of Menu Selection.....	379
TABLE 3.22 Display Contents of Operation Help Display .....	380
TABLE 3.23 Display Contents of Menu Selection.....	381
TABLE 3.24 Display Contents of Operation Help Display .....	381
TABLE 3.25 Display Contents of Menu Selection.....	382
TABLE 3.26 Display contents of operation help display .....	384
TABLE 3.27 Display contents of menu selection .....	385
TABLE 3.28 Display contents of operation help display .....	390
TABLE 3.29 Display contents of Menu Selection.....	392
TABLE 3.30 Display contents of Operation Help Display .....	392
TABLE 3.31 Display contents of menu selection .....	396
TABLE 3.32 Display contents of operation help display .....	396
TABLE 3.33 Display contents of menu selection .....	397
TABLE 3.34 Display contents of operation help display .....	401
TABLE 3.35 Display contents of Menu selection .....	401
TABLE 3.36 Display Contents of Operation Help Display .....	402
TABLE 3.37 Display contents of Menu selection .....	403
TABLE 3.38 Display Contents of Operation Help Display .....	403
TABLE 3.39 Display Contents of Menu Selection.....	404
TABLE 3.40 Display Contents of Operation Help Display .....	406
TABLE 3.41 Display contents of Menu selection .....	407
TABLE 3.42 Display Contents of Operation Help Display .....	407
TABLE 3.43 Display Contents of Menu Selection.....	408
TABLE 3.44 Display contents of operation help display .....	409
TABLE 3.45 Display Contents of Menu Selection.....	410

---

TABLE 3.46 Display Contents of Operation Help Display .....	411
TABLE 3.47 Display Contents of Menu Selection Section .....	411
TABLE 3.48 Display contents of operation help display .....	412
TABLE 3.49 Display contents of Menu selection .....	413
TABLE 3.50 Display contents of Display of operation help.....	413
TABLE 3.51 Display contents of Display of Operation help.....	414
TABLE 3.52 Number of Characters and Types of Characters that can be entered.....	418
TABLE 3.53 Display contents of operation help display .....	419
TABLE 3.54 Display Contents of Menu Selection.....	421
TABLE 3.55 Display Contents of Operation Help Display .....	422
TABLE 3.56 Display Contents of Operation Help Display when Pop-up Window appears.....	422
TABLE 3.57 Display contents of menu selection .....	424
TABLE 3.58 Display contents of operation help display .....	425
TABLE 3.59 Display Contents of operation help display when pop-up window appears .....	425
TABLE 3.60 Display Contents of Menu Selection.....	428
TABLE 3.61 Display Contents of the Operation Help Display .....	429
TABLE 3.62 Display Contents of the Operation Help Display when Pop-up Window appears .....	429
TABLE 3.63 Displayed Contents of Menu Selection .....	432
TABLE 3.64 Display Contents of Operation Help Display .....	432
TABLE 3.65 Display Contents of Operation Help Display when Pop-up Window appears.....	433
TABLE 3.66 Display contents of menu selection .....	437
TABLE 3.67 Display content of Operation Help Display .....	437
TABLE 3.68 Display Content of Operation Help Display When Pop up Window Appears .....	437
TABLE 3.69 Display Contents of Operation Help Display .....	441
TABLE 3.70 Display Content of Menu Selection Help Display.....	445
TABLE 3.71 Display Contents of Operation Help Display .....	445
TABLE 3.72 Content of Operation Helps Display when Pop -up Window appears.....	446
TABLE 3.73 Parameter of Device Path .....	446
TABLE 4.1 Wildcard characters in the UEFI shell.....	451
TABLE 4.2 Output redirection.....	451
TABLE 4.3 UEFI shell commands .....	452
TABLE 6.1 Displayed contents of the menu selection area.....	471
TABLE 6.2 Displayed contents of the help display area for operation .....	471
TABLE 6.3 Displayed contents of the menu selection area.....	472
TABLE 6.4 Displayed contents of the help display area for operation .....	473
TABLE 6.5 Displayed contents of menu selection area.....	473
TABLE 6.6 Displayed contents of the help display area for operation .....	474
TABLE 6.7 Displayed contents of menu selection area.....	474
TABLE 6.8 Displayed contents of the help display area for operation .....	475
TABLE 6.9 Displayed contents of menu selection area.....	476
TABLE 6.10 Displayed contents of the help display area for operation .....	476
TABLE 6.11 Displayed contents of the menu selection area .....	477
TABLE 6.12 Displayed contents of the help display area for operation .....	478
TABLE 6.13 Displayed contents of menu selection area.....	479
TABLE 6.14 Displayed contents of the help display area for operation .....	479



TABLE 6.15 Displayed contents of menu selection area.....	480
TABLE 6.16 Displayed contents of the help display area for operation .....	480
TABLE 6.17 Displayed contents of menu selection area.....	481
TABLE 6.18 Displayed contents of the help display area for operation .....	481
TABLE 6.19 Displayed contents of menu selection area.....	482
TABLE 6.20 Displayed contents of the help display area for operation .....	482
TABLE A.1 Setting item of [System Event Log Filtering Condition] Window .....	483
TABLE A.2 Setting Items of [Operation Log Filtering Condition] Window.....	484
TABLE A.3 Setting Items of [System Information] Window .....	485
TABLE A.4 Setting items of [System Setup] Window .....	485
TABLE A.5 Setting Items of [System Power Control] Window .....	486
TABLE A.6 Setting Items of [Power Control] Window.....	486
TABLE A.7 Setting Items of [Schedule Control] Window.....	487
TABLE A.8 Setting Items of [Add Schedule]/ [Edit User] Window.....	487
TABLE A.9 Setting Items of [Partition Configuration] Window.....	487
TABLE A.10 Setting Items of [IPv4 Console Redirection Setup] Window .....	488
TABLE A.11 Setting Items of [IPv6 Console Redirection Setup] Window .....	488
TABLE A.12 Setting Items of [Power Management Setup] Window .....	488
TABLE A.13 Setting Items of [ASR Control] Window .....	489
TABLE A.14 Setting Items of [Console Redirection] Window.....	489
TABLE A.15 Setting Items of [Mode] Window.....	490
TABLE A.16 Setting Items of [Add User]/ [Edit User] Window .....	490
TABLE A.17 Setting Items of [Date/Time] Window .....	491
TABLE A.18 Setting Items of [IPv4 Interface] Window .....	492
TABLE A.19 Setting Items of [IPv6 Interface] Window .....	493
TABLE A.20 Setting Items of [Management LAN Port Configuration] Window .....	494
TABLE A.21 Setting Items of [Network Protocols] Window.....	495
TABLE A.22 Setting Items of [Refresh Rate] Window .....	495
TABLE A.23 Setting Items of [SNMP Community] Window.....	496
TABLE A.24 Setting Items of [SNMP Trap] Window .....	496
TABLE A.25 Setting Items of [SNMP v3 Configuration] Window.....	497
TABLE A.26 Setting Items of [Create CSR] Window.....	498
TABLE A.27 Setting Items of [Create Selfsigned Certificate] Window .....	498
TABLE A.28 Setting Items of [Edit User] Window.....	499
TABLE A.29 Setting Items of [Add Filter] / [Edit Filter] Window .....	499
TABLE A.30 Setting Items of [Alarm E-Mail] Window.....	500
TABLE A.31 Setting Items of [Alarm E-Mail Filtering Condition] Window .....	500
TABLE A.32 Setting Items of [I/O Space Assignment Configuration] Window.....	501
TABLE A.33 Setting Items of [LAN Remote Boot Configuration] Window .....	501
TABLE A.34 Setting Items of [CPU Configuration] Window.....	501
TABLE A.35 Setting Items of [PCI Bus Padding Configuration] Window .....	503
TABLE A.36 Setting Items of [PCI Subsystem Configuration] Window .....	503
TABLE A.37 Setting Items of [IOU OpROM Scan Configuration] Window .....	503
TABLE A.38 Setting Items of [PCI_Box OpROM Scan Configuration] Window .....	504
TABLE A.39 Setting Items of [iSCS Configuration] Window .....	506

TABLE A.40 Setting Items of [Attempt Configuration] Window ..... 506

TABLE A.41 Setting Items of [Memory Configuration] Window ..... 507

TABLE A.42 Setting Items of [USB Configuration] Window ..... 508

TABLE A.43 Setting Items of [Security Configuration] Window..... 508

TABLE A.44 Setting Items of [Video] Window..... 509

TABLE A.45 Setting Items of [Keyboard] Window ..... 509

TABLE A.46 Setting Items of [Mouse] Window..... 509

TABLE A.47 Setting Items of [Options] Window ..... 510

# CHAPTER 1 MMB Web-UI (Web User Interface) Operations

This chapter describes the menus used to manage and operate the PRIMEQUEST 2000 series server with the MMB Web-UI. It also describes how to use the MMB Web-UI.

## 1.1 Web-UI Menus

The available MMB Web-UI menus differ depending on the user privileges. TABLE 1.1 User privileges lists the user privileges needed to check and operate the MMB Web-UI menus.

TABLE 1.1 User privileges

Privilege level	Description
Administrator	Administrator accounts are permitted to perform all operations and checks.
Operator	Operator accounts are permitted to check the PRIMEQUEST 2000 series server status and configure the system. They are not permitted to manage users or change the network configuration. With Operator privileges, you cannot: <ul style="list-style-type: none"><li>- Manipulate the power supply from the [System Power Control] window</li><li>- Change the status of the FANs and PSUs</li><li>- Change the partition configuration</li><li>- Configure a Reserved SB</li></ul>
Partition Operator	Partition Operator accounts have the same privileges as Operator accounts, except that their privileges are restricted to specific partitions. Like Operator accounts, they are permitted to check the system status. Unlike Operator accounts, they are not permitted to perform some operations such as clearing the status of an SB/IOU.
User	User accounts are only permitted to check the PRIMEQUEST 2000 series server status. They are not permitted to set system configuration information or power on or off the partitions.
CE	CE accounts are permitted to check the PRIMEQUEST 2000 series server status. They are also permitted to manipulate the power supply.

The following sections outline the Web-UI menus that are available for each type of user privilege.

- [1.1.1 Web-UI menus \(Administrator\)](#)
- [1.1.2 Web-UI menus \(Operator\)](#)
- [1.1.3 Web-UI menus \(Partition Operator\)](#)
- [1.1.4 Web-UI menus \(User\)](#)
- [1.1.5 Web-UI menus \(CE\)](#)
- [1.1.6 Web-UI menus in maintenance mode](#)
- [1.1.7 Web-UI menus in maintenance mode \(Administrator\)](#)
- [1.1.8 Web-UI menus in maintenance mode \(Operator\)](#)
- [1.1.9 Web-UI menus in maintenance mode \(Partition Operator\)](#)
- [1.1.10 Web-UI menus in maintenance mode \(User\)](#)
- [1.1.11 Web-UI menus in maintenance mode \(CE\)](#)
- [1.1.12 Web-UI menus in maintenance mode \(maintenance personnel\)](#)
- [1.1.13 Web-UI menus \(PRIMEQUEST 2800B model\)](#)

### 1.1.1 Web-UI menus (Administrator)

This section lists the Web-UI menus that are available with the Administrator privileges.

The meanings of abbreviations in the table are as follows:

- RW: The account user can refer to and set information and control operation from the menu.
- RO: The account user can only refer to information from the menu.
- N/A: The account user cannot view the menu and submenus.

TABLE 1.2 Web-UI menus (Administrator)

Navigation bar	1st level	2nd level	3rd level	Privileges	Remarks
System					
	System Status			RO	Displays the overall system status.
	System Event Log			RW	Displays system event logs.
	Operation Log			RW	Displays the operations on the Web-UI and CLI.
	Partition Event Log			RW	Displays the REMCS notification messages of a PRIMEQUEST partition.
	System Information			RW	Displays system information, such as the system name or product name.
	Firmware Information			RO	Displays firmware version information.
	System Setup			RW	Sets the system configuration.
	System Power Control			RW	Controls the power.
	LEDs			RW	Displays the LED status.
	Power Supply			RW	Displays the power supply status.
	Fans			RW	Displays the fan status.
	Temperature			RO	Displays the temperatures detected by the temperature sensors of the PRIMEQUEST 2000 series system.
	SB				
		SB#0		RW	Displays the SB status. The menu is not displayed for an unmounted SB.
		SB#1		RW	
		SB#2		RW	
		SB#3		RW	
	IOU				
		IOU#0		RW	Displays the IOU status. The menu is not displayed for an unmounted IOU.
		IOU#1		RW	
		IOU#2		RW	
		IOU#3		RW	
	DU				
		DU#0		RW	Displays the DU status. The menu is not displayed for an unmounted DU.
		DU#1		RW	
	PCI_Box				If no PCI_Box is

Navigation bar	1st level	2nd level	3rd level	Privileges	Remarks
					connected, this menu is not displayed.
		PCI_Box#0		RW	Displays the PCI_Box status. The menu is not displayed for an unmounted PCI_Box.
		PCI_Box#1		RW	
		PCI_Box#2		RW	
		PCI_Box#3		RW	
	OPL			RW	
	MMB				
		MMB#0		RW	Displays the MMB status and information.
		MMB#1		RW	
	Disk Enclosure				
		Disk Enclosure#x		RW	
Partition					
	Power Control			RW	Controls the partition power.
	Schedule				
		Schedule Control		RW	Sets scheduled operations.
		Schedule List		RW	Sets the power-on/off schedule.
	Console Redirection Setup			RW	Sets Video Redirection, Remote Storage, and Text Console Redirection.
		IPv4 Console Redirection Setup		RW	Setting for IPv4 Console Redirection.
		IPv6 Console Redirection Setup		RW	Setting for IPv6 Console Redirection.
	Partition Configuration			RW	Changes the partition configuration.
	Partition xPAR Configuration				Changes the xPAR partition configuration.
		SB		RW	
		IOU#n		RW	
		PCI_Box#n		RW	
	Reserved SB Configuration			RW	Defines a Reserved SB.
	Power Management Setup			RW	
	Partition#0				If no board belongs to the partition, this submenu is not displayed.
		Information		RO	Displays the partition status and partition-related information.
		ASR Control		RW	Sets the conditions for automatically restarting the partition.
		Console Redirection		RW	Displays the console output of the partition.
		Mode		RW	Sets the mode for the partition.
	Partition#1				Same as for Partition#0
	Partition#2				
	Partition#3				

Navigation bar	1st level	2nd level	3rd level	Privileges	Remarks
User Administration					
	User List			RW	Lists, edits, and deletes registered user accounts.
	Change Password			RW	Changes the password of the user's own account.
	Who			RO	Displays all users who are logged in to the MMB.
Network Configuration					
	Date/Time			RW	
	Network Interface				
		IPv4 Interface		RW	Sets the IPv4 IP address, etc.
		IPv6 Interface		RW	Sets the IPv6 IP address, etc.
	Management LAN Port Configuration			RW	Configures the Port LAN of the MMB HUB.
	Network Protocols			RW	
	Refresh Rate			RW	Sets the refresh rate of the Web-UI window.
	SNMP Configuration			RW	
		Community		RW	
		Trap		RW	
		SNMPv3 Configuration		RW	
	SSL				
		Create CSR		RW	Creates a secret key and CSR.
		Export Key/CSR		RW	Exports a secret key and CSR.
		Import Security Certificate		RW	Installs a certificate.
		Create Selfsigned Certificate		RW	Creates a selfsigned certificate.
	SSH				
		SSH Server Key		RW	Creates a private key for the SSH server.
	Remote Server Management			RW	
	Access Control			RW	Sets the IP filtering that permits connections.
	Alarm E-mail			RW	
Maintenance					
	Firmware Update				
		Unified Firmware Update		RW	Performs a batch update.
	Backup/Restore Configuration				Backs up and restores setting information.
		Backup/Restore MMB Configuration		RW	
		Backup EFI Configuration		RW	
		Restore EFI Configuration		RW	

Navigation bar	1st level	2nd level	3rd level	Privileges	Remarks
	Maintenance Wizard			RW	Performs maintenance through a wizard.
	REMCS				
		REMCS		RW	
		Detailed Setup		RW	

### 1.1.2 Web-UI menus (Operator)

This section lists the Web-UI menus that are available with the Operator privileges.

The meanings of abbreviations in the table are as follows:

- RW: The account user can refer to and set information and control operation from the menu.
- RO: The account user can only refer to information from the menu.
- N/A: The account user cannot view the menu and submenus.

TABLE 1.3 Web-UI menus (Operator)

Navigation bar	1st level	2nd level	3rd level	Privileges	Remarks
System					
	System Status			RO	Displays the overall system status.
	System Event Log			RO	Displays system event logs.
	Operation Log			RO	Displays the operations on the Web-UI and CLI.
	Partition Event Log			RO	Displays the REMCS notification messages of a PRIMEQUEST partition.
	System Information			RO	Displays system information, such as the system name or product name.
	Firmware Information			RO	Displays firmware version information.
	System Setup			RO	Sets the system configuration.
	System Power Control			RO	Controls the power.
	LEDs			RW	Displays the LED status.
	Power Supply			RO	Displays the power supply status.
	Fans			RO	Displays the fan status.
	Temperature			RO	Displays the temperatures detected by the temperature sensors of the PRIMEQUEST 2000 series system.
	SB				
		SB#0		RW	Displays the SB status. The menu is not displayed for an unmounted SB.
		SB#1		RW	
		SB#2		RW	
		SB#3		RW	
	IOU				
		IOU#0		RW	Displays the IOU status. The menu is not displayed for an unmounted IOU.
		IOU#1		RW	
		IOU#2		RW	
		IOU#3		RW	

Navigation bar	1st level	2nd level	3rd level	Privileges	Remarks
	DU				
		DU#0		RW	Displays the DU status. The menu is not displayed for an unmounted DU.
		DU#1		RW	
	PCI_Box				If no PCI_Box is connected, this menu is not displayed.
		PCI_Box#0		RW	Displays the PCI_Box status. The menu is not displayed for an unmounted PCI_Box.
		PCI_Box#1		RW	
		PCI_Box#2		RW	
		PCI_Box#3		RW	
	OPL			RW	
	MMB				
		MMB#0		RW	Displays the MMB status and information.
		MMB#1		RW	
	Disk Enclosure				
		Disk Enclosure#x		RW	
Partition					
	Power Control			RW	Controls the partition power.
	Schedule				
		Schedule Control		RW	Sets scheduled operations.
		Schedule List		RW	Sets the power-on/off schedule.
	Console Redirection Setup			RO	Sets Video Redirection, Remote Storage, and Text Console Redirection.
		IPv4 Console Redirection Setup		RO	Setting for IPv4 Console Redirection.
		IPv6 Console Redirection Setup		RO	Setting for IPv6 Console Redirection.
	Partition Configuration			RO	Changes the partition configuration.
		SB		RO	
		IOU#n		RO	
		PCI_Box#n		RO	
	Reserved SB Configuration			RO	Defines a Reserved SB.
	Power Management Setup			RO	
	Partition#0				If no board belongs to the partition, this submenu is not displayed.
		Information		RO	Displays the partition status and partition-related information.
		ASR Control		RO	Sets the conditions for automatically restarting the partition.
		Console Redirection		RW	Displays the console output of the partition.
		Mode		RW	Sets the mode for the partition.



Navigation bar	1st level	2nd level	3rd level	Privileges	Remarks
	Partition#1				Same as for Partition#0
	Partition#2				
	Partition#3				
User Administration					
	User List			N/A	Lists, edits, and deletes registered user accounts.
	Change Password			RW	Changes the password of the user's own account.
	Who			RO	Displays all users who are logged in to the MMB.
Network Configuration					
	Date/Time			RO	
	Network Interface				
		IPv4 Interface		RO	Sets the IPv4 IP address, etc.
		IPv6 Interface		RO	Sets the IPv6 IP address, etc.
	Management LAN Port Configuration			N/A	Configures the Port LAN of the MMB HUB.
	Network Protocols			RO	
	Refresh Rate			RW	Sets the refresh rate of the Web-UI window.
	SNMP Configuration			N/A	
		Community		N/A	
		Trap		N/A	
		SNMPv3 Configuration		N/A	
	SSL				
		Create CSR		N/A	Creates a secret key and CSR.
		Export Key/CSR		N/A	Exports a secret key and CSR.
		Import Security Certificate		N/A	Installs a certificate.
		Create Selfsigned Certificate		N/A	Creates a selfsigned certificate.
	SSH				
		SSH Server Key		N/A	Creates a private key for the SSH server.
	Remote Server Management			N/A	
	Access Control			N/A	Sets the IP filtering that permits connections.
	Alarm E-mail			N/A	
Maintenance					
	Firmware Update				
		Unified Firmware Update		N/A	Performs a batch update.
	Backup/Restore Configuration				Backs up and restores setting information.
		Backup/Restore MMB Configuration		N/A	
		Backup EFI		N/A	

Navigation bar	1st level	2nd level	3rd level	Privileges	Remarks
		Configuration			
		Restore EFI Configuration		N/A	
	Maintenance Wizard			N/A	Performs maintenance through a wizard.
	REMCS				
		REMCS		N/A	
		Detailed Setup		N/A	

### 1.1.3 Web-UI menus (Partition Operator)

This section lists the Web-UI menus that are available with the Partition Operator privileges.

The meanings of abbreviations in the table are as follows:

- RW: The account user can refer to and set information and control operation from the menu.
- RO: The account user can only refer to information from the menu.
- N/A: The account user cannot view the menu and submenus.

TABLE 1.4 Web-UI menus (Partition Operator)

Navigation bar	1st level	2nd level	3rd level	Privileges (Same partition)	Privileges (Other partition)	Remarks
System						
	System Status			RO	RO	Displays the overall system status.
	System Event Log			RO	RO	Displays system event logs.
	Operation Log			RO	RO	Displays the operations on the Web-UI and CLI.
	Partition Event Log			RO	RO	Displays the REMCS notification messages of a PRIMEQUEST partition.
	System Information			RO	RO	Displays system information, such as the system name or product name.
	Firmware Information			RO	RO	Displays firmware version information.
	System Setup			RO	RO	Sets the system configuration.
	System Power Control			RO	RO	Controls the power.
	LEDs			RW	RW	Displays the LED status.
	Power Supply			RO	RO	Displays the power supply status.
	Fans			RO	RO	Displays the fan status.
	Temperature			RO	RO	Displays the temperatures detected by the temperature sensors of the

Navigation bar	1st level	2nd level	3rd level	Privileges (Same partition)	Privileges (Other partition)	Remarks
						PRIMEQUEST 2000 series system.
	SB					
		SB#0		RO	RO	Displays the SB status. The menu is not displayed for an unmounted SB.
		SB#1		RO	RO	
		SB#2		RO	RO	
		SB#3		RO	RO	
	IOU					
		IOU#0		RO	RO	Displays the IOU status. The menu is not displayed for an unmounted IOU.
		IOU#1		RO	RO	
		IOU#2		RO	RO	
		IOU#3		RO	RO	
	DU					
		DU#0		RO	RO	Displays the DU status. The menu is not displayed for an unmounted DU.
		DU#1		RO	RO	
	PCI_Box					If no PCI_Box is connected, this menu is not displayed.
		PCI_Box#0		RO	RO	Displays the PCI_Box status. The menu is not displayed for an unmounted PCI_Box.
		PCI_Box#1		RO	RO	
		PCI_Box#2		RO	RO	
		PCI_Box#3		RO	RO	
	OPL			RO	RO	
	MMB					
		MMB#0		RO	RO	Displays the MMB status and information.
		MMB#1		RO	RO	
	Disk Enclosure					
		Disk Enclosure#x		RO	RO	
Partition						
	Power Control			RW	RO	Controls the partition power.
	Schedule					
		Schedule Control		RW	RO	Sets scheduled operations.
		Schedule List		RW	RO	Sets the power-on/off schedule.
	Console Redirection Setup			RO	RO	Sets Video Redirection, Remote Storage, and Text Console Redirection.
		IPv4 Console Redirection Setup		RO	RO	Setting for IPv4 Console Redirection.
		IPv6 Console Redirection Setup		RO	RO	Setting for IPv6 Console Redirection.
	Partition Configuration			RO	RO	Changes the partition configuration.

Navigation bar	1st level	2nd level	3rd level	Privileges (Same partition)	Privileges (Other partition)	Remarks
		SB		RO	RO	
		IOU#n		RO	RO	
		PCI_Box#n		RO	RO	
	Reserved SB Configuration			RO	RO	Defines a Reserved SB.
	Power Management Setup			RO	RO	
	Partition#0					If no board belongs to the partition, this submenu is not displayed.
		Information		RO	N/A	Displays the partition status and partition-related information.
		ASR Control		RW	N/A	Sets the conditions for automatically restarting the partition.
		Console Redirection		RW	N/A	Displays the console output of the partition.
		Mode		RW	N/A	Sets the mode for the partition.
	Partition#1					Same as for Partition#0
	Partition#2					
	Partition#3					
User Administration						
	User List			N/A	N/A	Lists, edits, and deletes registered user accounts.
	Change Password			RW	N/A	Changes the password of the user's own account.
	Who			RO	RO	Displays all users who are logged in to the MMB.
Network Configuration						
	Date/Time			RO	RO	
	Network Interface					
		IPv4 Interface		RO	RO	Sets the IPv4 IP address, etc.
		IPv6 Interface		RO	RO	Sets the IPv6 IP address, etc.
	Management LAN Port Configuration			N/A	N/A	Configures the Port LAN of the MMB HUB.
	Network Protocols			RO	RO	
	Refresh Rate			RW	RW	Sets the refresh rate of the Web-UI window.
	SNMP Configuration			N/A	N/A	
		Community		N/A	N/A	
		Trap		N/A	N/A	

Navigation bar	1st level	2nd level	3rd level	Privileges (Same partition)	Privileges (Other partition)	Remarks
		SNMPv3 Configuration		N/A	N/A	
	SSL					
		Create CSR		N/A	N/A	Creates a secret key and CSR.
		Export Key/CSR		N/A	N/A	Exports a secret key and CSR.
		Import Security Certificate		N/A	N/A	Installs a certificate.
		Create Selfsigned Certificate		N/A	N/A	Creates a selfsigned certificate.
	SSH					
		SSH Server Key		N/A	N/A	Creates a private key for the SSH server.
	Remote Server Management			N/A	N/A	
	Access Control			N/A	N/A	Sets the IP filtering that permits connections.
	Alarm E-mail			N/A	N/A	
Maintenance						
	Firmware Update					
		Unified Firmware Update		N/A	N/A	Performs a batch update.
	Backup/Restore Configuration					Backs up and restores setting information.
		Backup/Restore MMB Configuration		N/A	N/A	
		Backup EFI Configuration		N/A	N/A	
		Restore EFI Configuration		N/A	N/A	
	Maintenance Wizard			N/A	N/A	Performs maintenance through a wizard.
	REMCS					
		REMCS		N/A	N/A	
		Detailed Setup		N/A	N/A	

### 1.1.4 Web-UI menus (User)

This section lists the Web-UI menus that are available with the User privileges.

The meanings of abbreviations in the table are as follows:

- RW: The account user can refer to and set information and control operation from the menu.
- RO: The account user can only refer to information from the menu.
- N/A: The account user cannot view the menu and submenus.

TABLE 1.5 Web-UI menus (User)

Navigation bar	1st level	2nd level	3rd level	Privileges	Remarks
System					
	System Status			RO	Displays the overall system status.
	System Event Log			RO	Displays system event logs.
	Operation Log			RO	Displays the operations on the Web-UI and CLI.
	Partition Event Log			RO	Displays the REMCS notification messages of a PRIMEQUEST partition.
	System Information			RO	Displays system information, such as the system name or product name.
	Firmware Information			RO	Displays firmware version information.
	System Setup			RO	Sets the system configuration.
	System Power Control			RO	Controls the power.
	LEDs			RW	Displays the LED status.
	Power Supply			RO	Displays the power supply status.
	Fans			RO	Displays the fan status.
	Temperature			RO	Displays the temperatures detected by the temperature sensors of the PRIMEQUEST 2000 series system.
	SB				
		SB#0		RO	Displays the SB status. The menu is not displayed for an unmounted SB.
		SB#1		RO	
		SB#2		RO	
		SB#3		RO	
	IOU				
		IOU#0		RO	Displays the IOU status. The menu is not displayed for an unmounted IOU.
		IOU#1		RO	
		IOU#2		RO	
		IOU#3		RO	
	DU				
		DU#0		RO	Displays the DU status. The menu is not displayed for an unmounted DU.
		DU#1		RO	
	PCI_Box				If no PCI_Box is

Navigation bar	1st level	2nd level	3rd level	Privileges	Remarks
					connected, this menu is not displayed.
		PCI_Box#0		RO	Displays the PCI_Box status. The menu is not displayed for an unmounted PCI_Box.
		PCI_Box#1		RO	
		PCI_Box#2		RO	
		PCI_Box#3		RO	
	OPL			RO	
	MMB				
		MMB#0		RO	Displays the MMB status and information.
		MMB#1		RO	
	Disk Enclosure				
		Disk Enclosure#x		RO	
Partition					
	Power Control			RO	Controls the partition power.
	Schedule				
		Schedule Control		RO	Sets scheduled operations.
		Schedule List		RO	Sets the power-on/off schedule.
	Console Redirection Setup			RO	Sets Video Redirection, Remote Storage, and Text Console Redirection.
		IPv4 Console Redirection Setup		RO	Setting for IPv4 Console Redirection.
		IPv6 Console Redirection Setup		RO	Setting for IPv6 Console Redirection.
	Partition Configuration			RO	Changes the partition configuration.
		SB		RO	
		IOU#n		RO	
		PCI_Box#n		RO	
	Reserved SB Configuration			RO	Defines a Reserved SB.
	Power Management Setup			RO	
	Partition#0				If no board belongs to the partition, this submenu is not displayed.
		Information		RO	Displays the partition status and partition-related information.
		ASR Control		RO	Sets the conditions for automatically restarting the partition.
		Console Redirection		N/A	Displays the console output of the partition.
		Mode		RO	Sets the mode for the partition.
	Partition#1				Same as for Partition#0
	Partition#2				
	Partition#3				
User Administration					
	User List			N/A	Lists, edits, and deletes registered user

Navigation bar	1st level	2nd level	3rd level	Privileges	Remarks
					accounts.
	Change Password			RW	Changes the password of the user's own account.
	Who			RO	Displays all users who are logged in to the MMB.
Network Configuration					
	Date/Time			RO	
	Network Interface				
		IPv4 Interface		RO	Sets the IPv4 IP address, etc.
		IPv6 Interface		RO	Sets the IPv6 IP address, etc.
	Management LAN Port Configuration			N/A	Configures the Port LAN of the MMB HUB.
	Network Protocols			RO	
	Refresh Rate			RW	Sets the refresh rate of the Web-UI window.
	SNMP Configuration			N/A	
		Community		N/A	
		Trap		N/A	
		SNMPv3 Configuration		N/A	
	SSL				
		Create CSR		N/A	Creates a secret key and CSR.
		Export Key/CSR		N/A	Exports a secret key and CSR.
		Import Security Certificate		N/A	Installs a certificate.
		Create Selfsigned Certificate		N/A	Creates a selfsigned certificate.
	SSH				
		SSH Server Key		N/A	Creates a private key for the SSH server.
	Remote Server Management			N/A	
	Access Control			N/A	Sets the IP filtering that permits connections.
	Alarm E-mail			N/A	
Maintenance					
	Firmware Update				
		Unified Firmware Update		N/A	Performs a batch update.
	Backup/Restore Configuration				Backs up and restores setting information.
		Backup/Restore MMB Configuration		N/A	
		Backup EFI Configuration		N/A	
		Restore EFI Configuration		N/A	
	Maintenance Wizard			N/A	Performs maintenance through a wizard.
	REMCS				



Navigation bar	1st level	2nd level	3rd level	Privileges	Remarks
		REMCS		N/A	
		Detailed Setup		N/A	

### 1.1.5 Web-UI menus (CE)

This section lists the Web-UI menus that are available with the CE privileges.

The meanings of abbreviations in the table are as follows:

- RW: The account user can refer to and set information and control operation from the menu.
- RO: The account user can only refer to information from the menu.
- N/A: The account user cannot view the menu and submenus.

TABLE 1.6 Web-UI menus (CE)

Navigation bar	1st level	2nd level	3rd level	Privileges	Remarks
System					
	System Status			RO	Displays the overall system status.
	System Event Log			RO	Displays system event logs.
	Operation Log			RO	Displays the operations on the Web-UI and CLI.
	Partition Event Log			RO	Displays the REMCS notification messages of a PRIMEQUEST partition.
	System Information			RO	Displays system information, such as the system name or product name.
	Firmware Information			RO	Displays firmware version information.
	System Setup			RW	Sets the system configuration.
	System Power Control			RO	Controls the power.
	LEDs			RW	Displays the LED status.
	Power Supply			RW	Displays the power supply status.
	Fans			RW	Displays the fan status.
	Temperature			RO	Displays the temperatures detected by the temperature sensors of the PRIMEQUEST 2000 series system.
	SB				
		SB#0		RW	Displays the SB status. The menu is not displayed for an unmounted SB.
		SB#1		RW	
		SB#2		RW	
		SB#3		RW	
	IOU				
		IOU#0		RW	Displays the IOU status. The menu is not displayed for an unmounted IOU.
		IOU#1		RW	
		IOU#2		RW	
		IOU#3		RW	
	DU				
		DU#0		RW	Displays the DU status. The menu is not displayed for an
		DU#1		RW	

Navigation bar	1st level	2nd level	3rd level	Privileges	Remarks
					unmounted DU.
	PCI_Box				If no PCI_Box is connected, this menu is not displayed.
		PCI_Box#0		RW	Displays the PCI_Box status. The menu is not displayed for an unmounted PCI_Box.
		PCI_Box#1		RW	
		PCI_Box#2		RW	
		PCI_Box#3		RW	
	OPL			RW	
	MMB				
		MMB#0		RW	Displays the MMB status and information.
		MMB#1		RW	
	Disk Enclosure				
		Disk Enclosure#x		RW	
Partition					
	Power Control			RO	Controls the partition power.
	Schedule				
		Schedule Control		RO	Sets scheduled operations.
		Schedule List		RO	Sets the power-on/off schedule.
	Console Redirection Setup			RO	Sets Video Redirection, Remote Storage, and Text Console Redirection.
		IPv4 Console Redirection Setup		RO	Setting for IPv4 Console Redirection.
		IPv6 Console Redirection Setup		RO	Setting for IPv6 Console Redirection.
	Partition Configuration			RO	Changes the partition configuration.
		SB		RO	
		IOU#n		RO	
		PCI_Box#n		RO	
	Reserved SB Configuration			RO	Defines a Reserved SB.
	Power Management Setup			RO	
	Partition#0				If no board belongs to the partition, this submenu is not displayed.
		Information		RO	Displays the partition status and partition-related information.
		ASR Control		RO	Sets the conditions for automatically restarting the partition.
		Console Redirection		N/A	Displays the console output of the partition.
		Mode		RO	Sets the mode for the partition.
	Partition#1				Same as for Partition#0
	Partition#2				
	Partition#3				
User Administration					

Navigation bar	1st level	2nd level	3rd level	Privileges	Remarks
	User List			N/A	Lists, edits, and deletes registered user accounts.
	Change Password			RW	Changes the password of the user's own account.
	Who			RO	Displays all users who are logged in to the MMB.
Network Configuration					
	Date/Time			RO	
	Network Interface				
		IPv4 Interface		RO	Sets the IPv4 IP address, etc.
		IPv6 Interface		RO	Sets the IPv6 IP address, etc.
	Management LAN Port Configuration			N/A	Configures the Port LAN of the MMB HUB.
	Network Protocols			RO	
	Refresh Rate			RW	Sets the refresh rate of the Web-UI window.
	SNMP Configuration			N/A	
		Community		N/A	
		Trap		N/A	
		SNMPv3 Configuration		N/A	
	SSL				
		Create CSR		N/A	Creates a secret key and CSR.
		Export Key/CSR		N/A	Exports a secret key and CSR.
		Import Security Certificate		N/A	Installs a certificate.
		Create Selfsigned Certificate		N/A	Creates a selfsigned certificate.
	SSH				
		SSH Server Key		N/A	Creates a private key for the SSH server.
	Remote Server Management			N/A	
	Access Control			N/A	Sets the IP filtering that permits connections.
	Alarm E-mail			N/A	
Maintenance					
	Firmware Update				
		Unified Firmware Update		RW	Performs a batch update.
	Backup/Restore Configuration				Backs up and restores setting information.
		Backup/Restore MMB Configuration		RW	
		Backup EFI Configuration		RW	
		Restore EFI Configuration		RW	
	Maintenance			RW	Performs maintenance

## MMB Web-UI (Web User Interface) Operations

---

Navigation bar	1st level	2nd level	3rd level	Privileges	Remarks
	Wizard				through a wizard.
	REMCS				
		REMCS		RW	
		Detailed Setup		RW	

### 1.1.6 Web-UI menus in maintenance mode

Some parameters have operational restrictions when maintenance mode is set. These restrictions apply to the user who is set to maintenance mode and other users.

The following table lists the Web-UI window restrictions that apply to maintenance personnel and non-maintenance personnel in maintenance mode.

The five types of maintenance mode are as follows.

TABLE 1.7 Types of maintenance mode

Maintenance mode	Description
Hot System Maintenance (Target unit not included in a partition) Active (system) for work	For maintenance work on the target unit not included in a partition. The work can be performed without stopping application software.
Hot Partition Maintenance (Target unit in a activated partition) Active (partition) for work	For maintenance work on a partition that is still operating while under maintenance. This work can be performed without stopping application software.
Warm System Maintenance (Target unit in a powered off partition) Partition stopped for work	For maintenance work on the partition under maintenance or the partition containing the target maintenance unit. The partition must be stopped during maintenance. The partitions not under maintenance need not be stopped.
Cold System Maintenance (All partitions powered off, breaker on) Stopped (standby) for work	For maintenance work that requires the system to be stopped. All applications are forcibly stopped during maintenance operation.
Cold System Maintenance (All partitions powered off, breaker off) Stopped (AC off) for work	For maintenance work that requires the system to be stopped and the AC power to be turned off (MMB power off). All applications are forcibly stopped during maintenance operation.

The following sections outline the Web-UI menus that are available in maintenance mode for each type of user privilege.

- [1.1.7 Web-UI menus in maintenance mode \(Administrator\)](#)
- [1.1.8 Web-UI menus in maintenance mode \(Operator\)](#)
- [1.1.9 Web-UI menus in maintenance mode \(Partition Operator\)](#)
- [1.1.10 Web-UI menus in maintenance mode \(User\)](#)
- [1.1.11 Web-UI menus in maintenance mode \(CE\)](#)
- [1.1.12 Web-UI menus in maintenance mode \(maintenance personnel\)](#)

### 1.1.7 Web-UI menus in maintenance mode (Administrator)

This section outlines the Web-UI menus that are available with the Administrator privileges in maintenance mode.

The maintenance mode column has the following items. For details on the maintenance mode, see [1.1.6 Web-UI menus in maintenance mode](#).

- Hot System: Hot System Maintenance (Target unit not included in a partition)
- Hot Partition: Hot Partition Maintenance (Target unit in a activated partition)
- Warm System: Warm System Maintenance (Target unit in a powered-off partition)
- Cold System: Cold System Maintenance (All partitions are powered off and turned on their breakers), and Cold System Maintenance (All partitions are powered off and turned off their breakers)

The meanings of abbreviations in the table are as follows:

RW: The account user can refer to and set information in the window.

RO: The account user can only refer to information in the window.

N/A: The account user cannot view the menu and submenu.

\*1 The account user can operate partitions not in maintenance mode in this window.

\*2 The account user can operate only partitions in maintenance mode in this window.

\*3 The SB is neither a Home SB nor Reserved SB. Alternatively, the SB is the Home SB in the Power Off status in a partition in the Standby status.

\*4 The partition is in the Standby status.

TABLE 1.8 Web-UI menus in maintenance mode (Administrator)

Navigation bar	1st level	2nd level	3rd level	Maintenance mode	Privileges	Remarks
System						
	System Power Control			Hot System	RW	
				Hot Partition	RO	
				Warm System	RO	
				Cold System	RO	
	MMB					
		MMB#0		Hot System	RO	
				Hot Partition	RO	
				Warm System	RO	
				Cold System	RO	
		MMB#1			Same as for MMB#0	
Partition						
	Power Control			Hot System	RW	
				Hot Partition	RW(*1)	
				Warm System	RW(*1)	
				Cold System	RO	
	Partition Configuration			Hot System	RW	[Add...] is suppressed since the Free unit may be a replacement unit.
				Hot Partition	RW(*1)	
				Warm System	RW(*1)	
				Cold System	RO	
		Add SB / IOU to Partition			Same as for Partition Configuration	
		Remove SB / IOU from Partition			Same as for Partition Configuration	
		Partition Home			Same as for Partition Configuration	
				Hot Partition	RW(*1)	
				Warm System	RW(*1)	
				Cold System	RO	
	Reserved SB Configuration			Hot System	RW	
				Hot Partition	RW(*1)	
				Warm System	RW(*1)	
				Cold System	RO	
	Console Redirection			Hot System	RW	
				Hot Partition	RW(*1)	
				Warm System	RW(*1)	
				Cold System	RO	
Network Configuration						
	Network Interface	IPv4 Interface		Hot System	RO	
				Hot Partition	RO	
		IPv6 Interface		Warm System	RO	
				Cold System	RO	
Maintenance						
	Firmware Update					
		Unified Firmware Update		Hot System	RO	
				Hot Partition	RO	
				Warm System	RO	

Navigation bar	1st level	2nd level	3rd level	Maintenance mode	Privileges	Remarks
				Cold System	RO	
	Backup/ Restore Configuration					
		Backup/ Restore MMB Configuration			RW	[Backup MMB...] is not affected by maintenance mode. [Restore MMB...] can be operated only by maintenance personnel.
	Maintenance Wizard			Hot System	RO	
				Hot Partition	RO	
				Warm System	RO	
				Cold System	RO	

### 1.1.8 Web-UI menus in maintenance mode (Operator)

This section outlines the Web-UI menus that are available with the Operator privileges in maintenance mode.

The maintenance mode column has the following items. For details on the maintenance mode, see Web-UI menus in maintenance mode.

- Hot System: Hot System Maintenance (Target unit not included in a partition)
- Hot Partition: Hot Partition Maintenance (Target unit in a activated partition)
- Warm System: Warm System Maintenance (Target unit in a powered off partition)
- Cold System: Cold System Maintenance (All partitions powered off, breaker on), and Cold System Maintenance (All partitions powered off, breaker off)

The meanings of abbreviations in the table are as follows:

RW: The account user can refer to and set information in the window.

RO: The account user can only refer to information in the window.

N/A: The account user cannot view the menu and submenu.

\*1 The account user can operate partitions not in maintenance mode in this window.

\*2 The account user can operate only partitions in maintenance mode in this window.

\*3 The SB is neither a Home SB nor Reserved SB. Alternatively, the SB is the Home SB in the Power Off status in a partition in the Standby status.

\*4 The partition is in the Standby status.

TABLE 1.9 Web-UI menus in maintenance mode (Operator)

Navigation bar	1st level	2nd level	3rd level	Maintenance mode	Privileges	Remarks	
System							
	System Power Control			Hot System	RO		
				Hot Partition	RO		
				Warm System	RO		
				Cold System	RO		
	MMB						
		MMB#0		Hot System	RO		
				Hot Partition	RO		
				Warm System	RO		
				Cold System	RO		
		MMB#1			Same as for MMB#0		
Partition							
	Power Control			Hot System	RW		
				Hot Partition	RW(*1)		
				Warm System	RW(*1)		
				Cold System	RO		
	Partition Configuration			Hot System	RO	[Add...] is suppressed since the Free unit may be a replacement unit.	
				Hot Partition	RO		
				Warm System	RO		
				Cold System	RO		
		Add SB / IOU to Partition			Same as for Partition Configuration		
		Remove SB / IOU from Partition			Same as for Partition Configuration		
		Partition Home			Same as for Partition Configuration		
	Reserved SB Configuration			Hot System	RO		
				Hot Partition	RO		
				Warm System	RO		
				Cold System	RO		
	Console Redirection			Hot System	RW		
				Hot Partition	RW(*1)		
				Warm System	RW(*1)		
				Cold System	RO		
Network Configuration							
	Network Interface	IPv4 Interface		Hot System	RO		
		IPv6 Interface		Hot Partition	RO		
				Warm System	RO		
				Cold System	RO		
Maintenance							
	Firmware Update						
		Unified Firmware Update		Hot System	N/A		
				Hot Partition	N/A		
				Warm System	N/A		
				Cold System	N/A		
	Backup/Restore						



Navigation bar	1st level	2nd level	3rd level	Maintenance mode	Privileges	Remarks
	Configuration					
		Backup/ Restore MMB Configuration			N/A	[Backup MMB...] is not affected by maintenance mode. [Restore MMB...] can be operated only by maintenance personnel.
	Maintenance Wizard			Hot System	N/A	
				Hot Partition	N/A	
				Warm System	N/A	
				Cold System	N/A	

### 1.1.9 Web-UI menus in maintenance mode (Partition Operator)

This section outlines the Web-UI menus that are available with the Partition Operator privileges in maintenance mode.

The maintenance mode column has the following items. For details on the maintenance mode, see [1.1.6 Web-UI menus in maintenance mode](#) Hot System: Hot System Maintenance (Target unit not included in a partition)

- Hot Partition: Hot Partition Maintenance (Target unit in a activated partition)
- Warm System: Warm System Maintenance (Target unit in a powered off partition)
- Cold System: Cold System Maintenance (All partitions powered off, breaker on), and Cold System Maintenance (All partitions powered off, breaker off)

The meanings of abbreviations in the table are as follows:

RW: The account user can refer to and set information in the window.

RO: The account user can only refer to information in the window.

N/A: The account user cannot view the menu and submenu.

\*1 The account user can operate partitions not in maintenance mode in this window.

\*2 The account user can operate only partitions in maintenance mode in this window.

\*3 The SB is neither a Home SB nor Reserved SB. Alternatively, the SB is the Home SB in the Power Off status in a partition in the Standby status.

\*4 The partition is in the Standby status.

TABLE 1.10 Web-UI menus in maintenance mode (Partition Operator)

Navigation bar	1st level	2nd level	3rd level	Maintenance mode	Privileges (Same partition)	Privileges (Other partition)	Remarks
System							
	System Power Control			Hot System	RO	RO	
				Hot Partition	RO	RO	
				Warm System	RO	RO	
				Cold System	RO	RO	
	MMB						
		MMB#0		Hot System	RO	RO	
				Hot Partition	RO	RO	
				Warm System	RO	RO	
				Cold System	RO	RO	
		MMB#1			Same as for MMB#0		
Partition							
	Power Control			Hot System	RW	RO	
				Hot Partition	RW(*1)	RO	
				Warm System	RW(*1)	RO	
				Cold System	RO	RO	
	Partition Configuration			Hot System	RO	RO	[Add...] is suppressed since the Free unit may be a replacement unit.
				Hot Partition	RO	RO	
				Warm System	RO	RO	
				Cold System	RO	RO	
		Add SB / IOU to Partition			Same as for Partition Configuration		
		Remove SB / IOU from Partition			Same as for Partition Configuration		
		Partition Home			Same as for Partition Configuration		
	Reserved SB Configuration			Hot System	RO	RO	
				Hot Partition	RO	RO	
				Warm System	RO	RO	
				Cold System	RO	RO	
	Console Redirection			Hot System	RW	N/A	
				Hot Partition	RW(*1)	N/A	
				Warm System	RW(*1)	N/A	
				Cold System	RO	N/A	
Network Configuration							
	Network Interface	IPv4 Interface		Hot System	RO	RO	
				Hot Partition	RO	RO	
		IPv6 Interface		Warm System	RO	RO	
				Cold System	RO	RO	
Maintenance							
	Firmware Update						
		Unified Firmware Update		Hot System	N/A	N/A	
				Hot Partition	N/A	N/A	
				Warm System	N/A	N/A	
				Cold System	N/A	N/A	
	Backup/Restore Configuration						
		Backup/			N/A	N/A	[Backup

Navigation bar	1st level	2nd level	3rd level	Maintenance mode	Privileges (Same partition)	Privileges (Other partition)	Remarks
		Restore MMB Configuration					MMB...] is not affected by maintenance mode. [Restore MMB...] can be operated only by maintenance personnel.
	Maintenance Wizard			Hot System	N/A	N/A	
				Hot Partition	N/A	N/A	
				Warm System	N/A	N/A	
				Cold System	N/A	N/A	

### 1.1.10 Web-UI menus in maintenance mode (User)

This section outlines the Web-UI menus that are available with the User privileges in maintenance mode.

The maintenance mode column has the following items. For details on the maintenance mode, see [1.1.6 Web-UI menus in maintenance mode. Web-UI menus in](#)

- Hot System: Hot System Maintenance (Target unit not included in a partition)
- Hot Partition: Hot Partition Maintenance (Target unit in a activated partition)
- Warm System: Warm System Maintenance (Target unit in a powered off partition)
- Cold System: Cold System Maintenance (All partitions powered off, breaker on), and Cold System Maintenance (All partitions powered off, breaker off)

The meanings of abbreviations in the table are as follows:

RW: The account user can refer to and set information in the window.

RO: The account user can only refer to information in the window.

N/A: The account user cannot view the menu and submenu.

\*1 The account user can operate partitions not in maintenance mode in this window.

\*2 The account user can operate only partitions in maintenance mode in this window.

\*3 The SB is neither a Home SB nor Reserved SB. Alternatively, the SB is the Home SB in the Power Off status in a partition in the Standby status.

\*4 The partition is in the Standby status.

TABLE 1.11 Web-UI menus in maintenance mode (User)

Navigation bar	1st level	2nd level	3rd level	Maintenance mode	Privileges	Remarks
System						
	System Power Control			Hot System	RO	
				Hot Partition	RO	
				Warm System	RO	
				Cold System	RO	
	MMB					
		MMB#0		Hot System	RO	
				Hot Partition	RO	
				Warm System	RO	
				Cold System	RO	
		MMB#1			Same as for MMB#0	
Partition						
	Power Control			Hot System	RO	
				Hot Partition	RO	
				Warm System	RO	

Navigation bar	1st level	2nd level	3rd level	Maintenance mode	Privileges	Remarks
				Cold System	RO	
	Partition Configuration			Hot System	RO	[Add...] is suppressed since the Free unit may be a replacement unit.
				Hot Partition	RO	
				Warm System	RO	
				Cold System	RO	
		Add SB / IOU to Partition			Same as for Partition Configuration	
		Remove SB / IOU from Partition			Same as for Partition Configuration	
		Partition Home			Same as for Partition Configuration	
	Reserved SB Configuration			Hot System	RO	
				Hot Partition	RO	
				Warm System	RO	
				Cold System	RO	
	Console Redirection			Hot System	N/A	
				Hot Partition	N/A	
				Warm System	N/A	
				Cold System	N/A	
Network Configuration						
	Network Interface	IPv4 Interface		Hot System	RO	
		IPv6 Interface		Hot Partition	RO	
				Warm System	RO	
				Cold System	RO	
Maintenance						
	Firmware Update					
		Unified Firmware Update		Hot System	N/A	
				Hot Partition	N/A	
				Warm System	N/A	
				Cold System	N/A	
	Backup/Restore Configuration					
		Backup/Restore MMB Configuration			N/A	[Backup MMB...] is not affected by maintenance mode. [Restore MMB...] can be operated only by maintenance personnel.
	Maintenance Wizard			Hot System	N/A	
				Hot Partition	N/A	
				Warm System	N/A	
				Cold System	N/A	

### 1.1.11 Web-UI menus in maintenance mode (CE)

This section outlines the Web-UI menus that are available with the CE privileges in maintenance mode.

The maintenance mode column has the following items. For details on the maintenance mode, see [1.1.6 Web-UI menus in maintenance mode](#).

- Hot System: Hot System Maintenance (Target unit not included in a partition)
- Hot Partition: Hot Partition Maintenance (Target unit in a activated partition)
- Warm System: Warm System Maintenance (Target unit in a powered off partition)
- Cold System: Cold System Maintenance (All partitions powered off, breaker on), and Cold System Maintenance (All partitions powered off, breaker off)

The meanings of abbreviations in the table are as follows:

RW: The account user can refer to and set information in the window.

RO: The account user can only refer to information in the window.

N/A: The account user cannot view the menu and submenu.

\*1 The account user can operate partitions not in maintenance mode in this window.

\*2 The account user can operate only partitions in maintenance mode in this window.

\*3 The SB is neither a Home SB nor Reserved SB. Alternatively, the SB is the Home SB in the Power Off status in a partition in the Standby status.

\*4 The partition is in the Standby status.

TABLE 1.12 Web-UI menus in maintenance mode (CE)

Navigation bar	1st level	2nd level	3rd level	Maintenance mode	Privileges	Remarks
System						
	System Power Control			Hot System	RO	
				Hot Partition	RO	
				Warm System	RO	
				Cold System	RO	
	MMB					
		MMB#0		Hot System	RO	
				Hot Partition	RO	
				Warm System	RO	
				Cold System	RO	
		MMB#1			Same as for MMB#0	
Partition						
	Power Control			Hot System	RO	
				Hot Partition	RO	
				Warm System	RO	
				Cold System	RO	
	Partition Configuration			Hot System	RO	[Add...] is suppressed since the Free unit may be a replacement unit.
				Hot Partition	RO	
				Warm System	RO	
				Cold System	RO	
		Add SB / IOU to Partition			Same as for Partition Configuration	
		Remove SB / IOU from Partition			Same as for Partition Configuration	
		Partition Home			Same as for Partition Configuration	
	Reserved SB Configuration			Hot System	RO	
				Hot Partition	RO	

Navigation bar	1st level	2nd level	3rd level	Maintenance mode	Privileges	Remarks
				Warm System	RO	
				Cold System	RO	
	Console Redirection			Hot System	RO	
				Hot Partition	RO	
				Warm System	RO	
				Cold System	RO	
Network Configuration						
	Network Interface	IPv4 Interface		Hot System	RO	
				Hot Partition	RO	
		IPv6 Interface		Warm System	RO	
				Cold System	RO	
Maintenance						
	Firmware Update					
		Unified Firmware Update		Hot System	RO	
				Hot Partition	RO	
				Warm System	RO	
				Cold System	RO	
	Backup/Restore Configuration					
		Backup/Restore MMB Configuration			RW	[Backup MMB...] is not affected by maintenance mode.
						[Restore MMB...] can be operated only by maintenance personnel.
	Maintenance Wizard			Hot System	RO	
				Hot Partition	RO	
				Warm System	RO	
				Cold System	RO	

### 1.1.12 Web-UI menus in maintenance mode (maintenance personnel)

This section outlines the Web-UI menus that are available to maintenance personnel (Administrator or CE privileges) in maintenance mode.

The maintenance mode column has the following items. For details on the maintenance mode, see [1.1.6 Web-UI menus in maintenance mode](#).

- Hot System: Hot System Maintenance (Target unit not included in a partition)
- Hot Partition: Hot Partition Maintenance (Target unit in a activated partition)
- Warm System: Warm System Maintenance (Target unit in a powered off partition)
- Cold System: Cold System Maintenance (All partitions powered off, breaker on), and Cold System Maintenance (All partitions powered off, breaker off)

The meanings of abbreviations in the table are as follows:

RW: The account user can refer to and set information in the window.

RO: The account user can only refer to information in the window.

N/A: The account user cannot view the menu and submenu.

\*1 The account user can operate partitions not in maintenance mode in this window.

\*2 The account user can operate only partitions in maintenance mode in this window.

\*3 The SB is neither a Home SB nor Reserved SB. Alternatively, the SB is the Home SB in the Power Off status in a partition in the Standby status.

\*4 The partition is in the Standby status.

TABLE 1.13 Web-UI menus in maintenance mode (maintenance personnel)

Navigation bar	1st level	2nd level	3rd level	Maintenance mode	Privileges (Administrator)	Privileges (CE)	Remarks	
System								
	System Power Control			Hot System	RW	RO		
				Hot Partition	RO	RO		
				Warm System	RO	RO		
				Cold System	RW	RW		
	MMB							
		MMB#0		Hot System	RW	RW		
				Hot Partition	RO	RO		
				Warm System	RO	RO		
				Cold System	RW	RW		
		MMB#1			Same as for MMB#0			
Partition								
	Power Control			Hot System	RW	RO		
				Hot Partition	RW(*1)	RO		
				Warm System	RW	RW(*2)		
				Cold System	RW	RW		
	Partition Configuration			Hot System	RW	RO	[Add...] is suppressed since the Free unit may be a replacement unit.	
				Hot Partition	RW	RO		
				Warm System	RW	RO		
				Cold System	RW	RO		
		Add SB / IOU to Partition			Same as for Partition Configuration			
		Remove SB / IOU from Partition			Same as for Partition Configuration			
		Partition Home			Same as for Partition Configuration			
	Reserved SB Configuration			Hot System	RW	RO		
				Hot Partition	RW	RO		
				Warm System	RW	RO		
				Cold System	RW	RO		
	Console Redirection			Hot System	RW	RO		
				Hot Partition	RW(*1)	RO		
				Warm System	RW	RW(*2)		
				Cold System	RW	RW		
Network Configuration								
	Network Interface	IPv4 Interface		Hot System	RO	RO		
				Hot Partition	RO	RO		
		IPv6 Interface		Warm System	RO	RO		
				Cold System	RO	RO		
Maintenance								
	Firmware Update							
		Unified Firmware Update		Hot System	RW	RW		
				Hot Partition	RO	RO		
				Warm System	RO	RO		
				Cold System	RW	RW		
	Backup/Restore Configuration							
		Backup/Restore MMB Configuration			RW	RW	[Backup MMB...] is not affected by	

Navigation bar	1st level	2nd level	3rd level	Maintenance mode	Privileges (Administrator)	Privileges (CE)	Remarks
							maintenance mode. [Restore MMB...] can be operated only by maintenance personnel.
	Maintenance Wizard			Hot System	RW	RW	
				Hot Partition	RW	RW	
				Warm System	RW	RW	
				Cold System	RW	RW	



### 1.1.13 Web-UI menus (PRIMEQUEST 2800B model)

This section lists the Web-UI menus that are available for the PRIMEQUEST 2800B model.

The meanings of abbreviations in the table are as follows:

- RW: The account user can refer to and set information and control operation from the menu.
- RO: The account user can only refer to information from the menu.
- N/A: The account user cannot view the menu and submenus.

TABLE 1.14 Web-UI menus (PRIMEQUEST 2800B model)

Navigation bar	1st level	2nd level	Privileges				Remarks
			Admin	Operator	User	CE	
System							
	System Status		RO	RO	RO	RO	Displays the overall system status.
	System Event Log		RW	RO	RO	RO	Displays system event logs.
	Operation Log		RW	RO	RO	RO	Displays the operations on the Web-UI and CLI.
	System Information		RW	RO	RO	RO	Displays system information, such as the system name or product name.
	Firmware Information		RO	RO	RO	RO	Displays firmware version information.
	System Setup		RW	RO	RO	RW	Sets the system configuration.
	Power Control		RW	RW	RO	RO	Controls the power.
	Schedule						
		Schedule Control	RW	RW	RO	RO	Sets scheduled operations.
		Schedule List	RW	RW	RO	RO	Sets the power-on/off schedule.
	Console Redirection Setup		RW	RO	RO	RO	Sets Video Redirection, Remote Storage, and Text Console Redirection.
		IPv4 Console Redirection Setup	RW	RO	RO	RO	Setting for IPv4 Console Redirection.
		IPv6 Console Redirection Setup	RW	RO	RO	RO	Setting for IPv6 Console Redirection.
	Power Management Setup		RW	RO	RO	RO	
	ASR Control		RW	RO	RO	RO	Sets the conditions for automatically restarting the partition.
	Console Redirection		RW	RW	N/A	RO	Displays the console output of the partition.
	Mode		RW	RW	RO	RO	Sets the mode for the partition.
	LEDs		RW	RW	RW	RW	Displays the LED status.
	Power Supply		RW	RO	RO	RW	Displays the power supply status.
	Fans		RW	RO	RO	RW	Displays the fan status.
	Temperature		RO	RO	RO	RO	Displays the

Navigation bar	1st level	2nd level	Privileges				Remarks
			Admin	Operator	User	CE	
							temperatures detected by the temperature sensors of the PRIMEQUEST 2000 series system.
	SB						
		SB#0	RW	RW	RO	RW	Displays the SB status. The menu is not displayed for an unmounted SB.
		SB#1	RW	RW	RO	RW	
		SB#2	RW	RW	RO	RW	
		SB#3	RW	RW	RO	RW	
	IOU						
		IOU#0	RW	RW	RO	RW	Displays the IOU status. The menu is not displayed for an unmounted IOU.
		IOU#1	RW	RW	RO	RW	
		IOU#2	RW	RW	RO	RW	
		IOU#3	RW	RW	RO	RW	
	DU						
		DU#0	RW	RW	RO	RW	Displays the DU status. The menu is not displayed for an unmounted DU.
		DU#1	RW	RW	RO	RW	
	OPL		RW	RW	RO	RW	
	MMB		RW	RW	RO	RW	
User Administration							
	User List		RW	N/A	N/A	N/A	Lists, edits, and deletes registered user accounts.
	Change Password		RW	RW	RW	RW	Changes the password of the user's own account.
	Who		RO	RO	RO	RO	Displays all users who are logged in to the MMB.
Network Configuration							
	Date/Time		RW	RO	RO	RO	
	Network Interface		RW	RO	RO	RO	
		IPv4 Interface	RW	RO	RO	RO	Sets the IPv4 IP address, etc.
		IPv6 Interface	RW	RO	RO	RO	Sets the IPv6 IP address, etc.
	Management LAN Port Configuration		RW	N/A	N/A	N/A	Configures the Port LAN of the MMB HUB.
	Network Protocols		RW	RO	RO	RO	
	Refresh Rate		RW	RW	RW	RW	Sets the refresh rate of the Web-UI window.
	SNMP Configuration		RW	N/A	N/A	N/A	
		Community	RW	N/A	N/A	N/A	
		Trap	RW	N/A	N/A	N/A	
		SNMPv3 Configuration	RW	N/A	N/A	N/A	
	SSL						
		Create CSR	RW	N/A	N/A	N/A	Creates a secret key and CSR.
		Export Key/CSR	RW	N/A	N/A	N/A	Exports a secret key and CSR.
		Import	RW	N/A	N/A	N/A	Installs a certificate.

Navigation bar	1st level	2nd level	Privileges				Remarks
			Admin	Operator	User	CE	
		Security Certificate					
		Create Selfsigned Certificate	RW	N/A	N/A	N/A	Creates a selfsigned certificate.
	SSH						
		SSH Server Key	RW	N/A	N/A	N/A	Creates a private key for the SSH server.
	Remote Server Management		RW	N/A	N/A	N/A	
	Access Control		RW	N/A	N/A	N/A	Sets the IP filtering that permits connections.
	Alarm E-mail		RW	N/A	N/A	N/A	
Maintenance							
	Firmware Update						
		Unified Firmware Update	RW	N/A	N/A	RW	Performs a batch update.
	Backup/Restore Configuration						Backs up and restores setting information.
		Backup/Restore MMB Configuration	RW	N/A	N/A	RW	
		Backup/Restore BIOS Configuration	RW	N/A	N/A	RW	
	Maintenance Wizard		RW	N/A	N/A	RW	Performs maintenance through a wizard.
	REMCS						
		REMCS	RW	N/A	N/A	RW	
		Detailed Setup	RW	N/A	N/A	RW	

## 1.2 [System] Menu for PRIMEQUEST 2400E/2800E

In [System] menu, it is possible to display and set the status of all the hardware components in the PRIMEQUEST 2400E and PRIMEQUEST 2800E system.

A display and a set item of [System] menu are different in PRIMEQUEST 2800B.

Refer to Chapter 1.7 for details.

### Remarks

If "Read Error" is displayed for [Part Number] and [Serial Number] on MMB Web-UI (contents area and information area), confirm the problem by referring to "11.2 Troubleshooting" of *PRIMEQUEST 2000 Series Administration Manual* (C122-E175EN). If the error could not be resolved, contact your sales representative or repairs assistance service.


Confirm the model name and serial number shown on the label affixed on the main unit and report it.

### 1.2.1 [System Status] window

[System Status] window shows the status of entire PRIMEQUEST 2000 series system. The contents displayed may differ depending on the configuration of the unit.

You can also display details of each unit by clicking the link displayed in the frame.


FIGURE 1.1 [System Status] window




The contents which are displayed as the status of unit are as follows.

[OK] : It is shown for the unit which operates normally without any trouble.

[Not-present] : It is shown for the unit which is not mounted. It is shown in gray colored background.

[Warning] : Though it is not serious, it shows the unit where a problem may occur. It is shown by .

[Failed] : It shows the unit, where failure has occurred, and it must be disconnected. It is shown by .




[Degraded] : It shows that a failure has occurred in the component of a certain unit, and the unit is operated without disconnecting the failed component. It is shown by  icon.

TABLE 1.15 Status of Unit and its Icons

Status	Display Color	Icon
Normal (Normal state)	Green	None
Warning, Degraded	Yellow	Black '!' mark in yellow triangle. 
Failed	Red	White 'X' in red circle. 

Each unit is linked with the window showing the detailed status. However, for units which are not mounted, there is no window showing the details. Therefore, these units are not linked.

TABLE 1.16 Items displayed in [System Status] Window

Items	Description
Power Supply	Shows the status of PSU
Fans	Shows the status of FAN
Temperature	Shows the status of temperature sensor
SB#0 ~ SB#3	Shows the status of system board In case of PRIMEQUEST 2400E model, it is SB#0 ~ SB#1
IOU#0 ~ IOU#3	Shows the status of IOU
DU#0 ~ DU#1	Shows the status of DU
OPL	Shows the status of OPL
MMB#0 ~ MMB#1	Shows the status of MMB
PCI_Box#0 ~ PCI_Box#3	Shows the status of PCI_Box which are connected

(1) Menu Operation

[System] – [System Status]

(2) Window Operations

1. Click the link corresponding to each unit when the detailed status of unit is to be confirmed. The window showing detailed status of each unit appears.

### Remarks

The detailed status can also be displayed by selecting the menu of target unit from [System] sub menu directly. For details on the operations, see “[1.2.9 \[LEDs\] window](#)” ~ “[1.2.16 \[PCI\\_Box\] Menu](#)”.

## 1.2.2 [System Event Log] Window

Among the events generated in the PRIMEQUEST 2000 series system, events of MMB and BMC stored in the current MMB system event log are displayed on the [System Event Log] window in chronological order.

Maximum 32000 events can be stored in system event log. When the entries in the system event log are full, oldest event log is deleted, and latest event log is stored in system event log.

FIGURE 1.2 [System Event Log] window

Model: PRIMEQUEST2800E  
Part Number: MCXXXXXX  
Serial Number: 00000000  
Status: Normal

Active:MMB#0

System Partition User Administration Network Configuration Maintenance Logon

>System >System Event Log

System Event Log

Severity	Date/Time	Unit Part Number	Source P=2 Sys Status	Event ID	Description	Detail
Info	2013-04-12 14:50:31	Partition#2	P=2 Sys Status	C06F00FF	Power Off	Detail
Info	2013-04-12 14:49:48	Partition#2	P=2 Sys Status	C06F08FF	Power Off In Progress	Detail
Info	2013-04-12 14:47:07	Partition#2	P=2 Sys Status	C06F03FF	POST	Detail
Info	2013-04-12 14:47:05	Partition#2	P=2 Sys Status	C06F03FF	POST	Detail
Info	2013-04-12 14:47:03	Partition#2	P=2 Sys Status	C06F02FF	Reset	Detail
Info	2013-04-12 14:46:42	Partition#2	P=2 Sys Status	C06F01FF	Power On In Progress	Detail
Info	2013-04-12 14:28:00	Partition#2	P=2 Sys Status	C06F00FF	Power Off	Detail
Info	2013-04-12 14:27:17	Partition#2	P=2 Sys Status	C06F08FF	Power Off In Progress	Detail
Info	2013-04-12 14:26:38	Partition#2	P=2 Sys Status	C06F03FF	POST	Detail
Info	2013-04-12 14:26:36	Partition#2	P=2 Sys Status	C06F03FF	POST	Detail

Clear All Events Download Filter

In the [System Event Log] Window, only the contents and not the title in the table can be scrolled. When there are no events to be displayed, a message showing "There is no Event Logs." is displayed instead of the table.

TABLE 1.17 Items displayed in [System Event Log] Window

Items	Description
Severity	Displays the severity of the event and error <ul style="list-style-type: none"> <li>Error : Severe errors like hardware error</li> <li>Warning : Not a severe error, but an error is likely in future</li> <li>Info : Shows the information like 'Partition power ON'</li> </ul>
Date/Time	Displays the local time when an event or error occurred. Format: YYYY-MM-DD HH:MM:SS
Source	Displays the name of the sensor where an event or error occurred.
Unit	Displays the unit with the sensor where an event or error occurred. For example, displays [SB#0] if an error occurs in CPU#0 of SB#0. This unit retrieves FRU with this sensor from Entity ID of the sensor, and also retrieves Parent Entity from Entity Association Record. It displays Board/Unit name described in FRU Record of parent entry. It is linked to the window (Window on which part number and serial number of each unit can be referenced) showing detailed status of each unit.
Part Number	Displays the part number stored in system event log. If part number is not stored, "[ ]" is displayed.
Event ID	Displays the ID (8 digits in hexadecimal system) for identifying contents of Event. For details on the allocation of the Event ID, see "Chapter 2 MMB Message" of <a href="#">PRIMEQUEST 2000 Series Message Reference</a> (C122-E178EN).
Description	Displays the contents of Events and Errors. <b>Remarks</b> For the event of insertion/removal of the board, part number and serial number of board are displayed.

TABLE 1.18 Buttons on [System Event Log] Window

Buttons	Description
Clear All Events	When you click [Clear All Events] button, all the events saved in system event log, are cleared. This is used only if Field engineer instructs to do so.
Download	After the confirmation message is displayed, [System Event Log (Collect)] window appears.
Filter	When you click [Filter] button, [System Event Log Filtering Condition] window for entering filter conditions appears.
Detail	When you click [Detail] button, the details of corresponding event are displayed on [System Event Log (Detail)] window.

## (1) Menu Operation

[System] – [System Event Log]

## (2) Window Operations

- When the event data saved in system event log is downloaded (if the system event log collected in advance does not exist)
  1. When you click [Download] button, a message showing [I\_00417 Are you sure?] is displayed. Click [OK] button.
  2. The collection of system event log information is starts automatically; [Progress] window appears.
  3. [System Event Log (Collect)] window appears, and the link to event data which is collected, is displayed with date information. When you click the link, dialog box appears. By specifying the file name and path name, event data can be downloaded to the PC which displays Web-UI.
- When the event data saved in system event log is downloaded (if the system event log which is collected in advance, exists)
  1. When you click [Download] button, a message showing [I\_00417 Are you sure?] is displayed. Click [OK] button.
  2. [System Event Log (Collect)] window appears, and the link to system event log information collected in advance, is displayed.
  3. Click [Collect] button to collect the latest system event log. A message showing [I\_00417 Are you sure?] is displayed. Click [OK] button. [Progress] window appears while the system event log information is collected.
  4. [System Event Log (Collect)] window appears, and the link to event data which is collected, is displayed with date information. When you click the link, a dialog box appears. By specifying the file name and path name, event data can be downloaded to the PC which displays Web-UI.

FIGURE 1.3 [System Event Log (Collect)] Window



- Narrowing down the events displayed in the window
  1. Click the [Filter] button.  
The [System Event Log Filtering Condition] window for entering filtering conditions appears.
  2. Enter the conditions in the [System Event Log Filtering Condition] window. Then, click the [Apply] button. The browser returns to the [System Event Log] window. The window displays the events that satisfy the specified conditions.

## ☐ [System Event Log Filtering Condition] Window

Click [Filter] button on the [System Event Log] window. The [System Event Log Filtering Condition] window for entering filtering conditions appears.

The filtering conditions of events which are displayed in [System Event Log] window can be set in the [System Event Log Filtering Condition] window.



FIGURE 1.4 [System Event Log Filtering Condition] Window

Model: PRIMEQUEST2800E  
Part Number: MCXXXXXXX  
Serial Number: XXXXXXXXXX  
Status: Normal  
Active: MMB#0

System Partition User Administration Network Configuration Maintenance Logon

>System >System Event Log

System Status  
System Event Log  
Operation Log  
Partition Event Log  
System Information  
Firmware Information  
System Setup  
System Power Control  
LEDs  
Power Supply  
Fans  
Temperature  
SB  
IOU  
OPL  
MMB

### System Event Log Filtering Condition

Select the filtering conditions and click the Apply button to take effect.  
Note : The followings are AND conditions.

1)Severity: ☒ Error ☒ Warning ☒ Info

2)Partition: ☒ All  
☐ Specified ☐ 0 ☐ 1 ☐ 2 ☐ 3

3)Unit: ☒ All  
☐ Specified ☐ PSUs ☐ Fans  
☐ SB#0 ☐ SB#1 ☐ SB#2 ☐ SB#3  
☐ IOU#0 ☐ IOU#1 ☐ IOU#2 ☐ IOU#3  
☐ DU#0 ☐ DU#1  
☐ OPL  
☐ MMB#0 ☐ MMB#1  
☐ PCI\_Box#0 ☐ PCI\_Box#1 ☐ PCI\_Box#2 ☐ PCI\_Box#3

4)Source: ☒ All  
☐ Specified ☐ CPU ☐ DIMM ☐ Chipset  
☐ Voltage ☐ Temperature ☐ Other

5)Sort by Date/Time: ☒ New event first ☐ Old event first

6)Start Date/Time: ☒ First event ☐ Specified Time 2013 - 1 - 1 0 - 0 - 0

7)End Date/Time: ☒ Last event ☐ Specified Time 2013 - 1 - 1 0 - 0 - 0

8)Number of events to display (Max 3000): 100 /6040

Apply Cancel Default Setting

TABLE 1.19 Display and Setting Items on [System Event Log Filtering Condition] Window

Items	Description
Severity	<p>Check the Severity check box. Multiple selections are possible.</p> <ul style="list-style-type: none"> <li>Error</li> <li>Warning</li> <li>Info</li> <li>Monitor</li> </ul> <p>All are ON by default.</p> <p><b>Note</b> [Monitor] check box is displayed only when login is done with CE privilege.</p>
Partition	<p>Selects the partition to be displayed. Select [All] or [Specified] by radio button.</p> <ul style="list-style-type: none"> <li>All: Filtering is not done by the Partition</li> <li>Specified: Filtering of partition unit can be set. Select the partition to be displayed.</li> </ul> <p>In case of Partition Operator, [All] is grayed out and selection is not possible. Further, for filtering of partition; only the partition to be managed can be selected.</p> <p>Default</p> <ul style="list-style-type: none"> <li>Partition Operator privilege : [Specified] and Partition to be managed is turned on.</li> <li>Other than the above : [All]</li> </ul> <p>Remarks Specify both CPU and Chipset when filtering as Source with the unit of</p>

Items	Description
	CPU.
Source	Select target source to be displayed. Select [All] or [Specified] by Radio button. <ul style="list-style-type: none"> <li>All: Filtering is not done by Source.</li> <li>Specified: Filtering of Source unit can be set. Select the Source to be displayed.</li> </ul> Default setting is All.
Unit	Select the target unit to be displayed. Select [All] or [Specified] by Radio button. <ul style="list-style-type: none"> <li>All: Filtering is not done by Unit.</li> <li>Specified: Filtering of Unit can be set. Select the Source to be displayed.</li> </ul> Default setting is All.
Sort by Date/ Time	Specifies either display by new order or display by old order by using the radio button. <ul style="list-style-type: none"> <li>New event first</li> <li>Old event first</li> </ul> The default setting is New event first.
Start Date/ Time	Specifies either display from recent event or specify the time, by using the radio button. <ul style="list-style-type: none"> <li>First event: Display by recent event</li> <li>Specified Time: Specify the time. In case of Specified Time, enter the Start Date and Time.</li> </ul> The default setting is First event.
End Date/ Time	Specifies either display till last event or specify the time, by using the radio button. <ul style="list-style-type: none"> <li>Last event: Display till Last event</li> <li>Specified Time: Specify the time. In case of Specified Time, enter the End Date and Time.</li> </ul> The default setting is Last event.
Number of events to display	Specifies the number of log to be displayed. As for the denominator, display the total number of events that are logged. A maximum of 3000 events can be specified. The default setting is 100 events.

TABLE 1.20 [System Events Log Filtering Condition] Window Buttons

Buttons	Description
Apply	Log which matches with the specified conditions will be listed on [System Event Log] window by clicking the [Apply] button.
Cancel	Returns to [System Event Log] window by clicking the [Cancel] button.
Default Setting	Selected value returns to the default value.

**[Message]**

This section describes the messages to be displayed on this window.

Message Number	Message
W_00413	Nothing is selected.
W_00414	Invalid Date Format.
W_00426	Invalid Values Specified.
W_00434	Invalid Time Format.
W_00441	Range over error.
I_00417	Are you sure?
I_00468	Are you sure you want to clear the SEL?

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference \(C122-E178EN\)](#).

### 1.2.3 [Operation Log] Window

[Operation Log] Window displays the log related to the settings or the operations of Web-UI and CLI. Each Operation Log consists of the login information (Web-UI/CLI, IP address, Account) of operating source.

FIGURE 1.5 [Operation Log] Window

Date/Time	Operation	IP Address	User Name(SessionID)
2013-04-12 14:49:34	Web-UI I_10110 Partition#2 : Force Power Off.	10.18.107.164	Administrator(95)
2013-04-12 14:47:59	Web-UI I_10101 GUI Login.	10.18.107.71	Administrator(11)
2013-04-12 14:46:40	Web-UI I_10110 Partition#2 : Power On.	10.18.107.164	Administrator(95)
2013-04-12 14:27:05	Web-UI I_10110 Partition#2 : Force Power Off.	10.18.107.164	Administrator(95)
2013-04-12 14:26:11	Web-UI I_10110 Partition#2 : Power On.	10.18.107.164	Administrator(95)
2013-04-12 14:22:32	Web-UI I_10110 Partition#0 : Force Power Off.	10.18.107.90	Administrator(83)
2013-04-12 14:10:33	Web-UI I_10101 GUI Login.	10.18.107.164	Administrator(95)
2013-04-12 13:58:15	Web-UI I_10107 GUI Session Timeout.	10.18.107.164	Administrator(52)
2013-04-12 13:52:08	Web-UI I_10101 GUI Login.	10.18.107.184	Administrator(71)
2013-04-12 13:51:22	CLI I_10138 CLI Logout.	10.18.107.164	Administrator(-)
2013-04-12 13:51:15	CLI I_10137 CLI Login.	10.18.107.164	Administrator(-)
2013-04-12	...	...	...

In the [Operation Log] window, only the table contents can be scrolled without scrolling the title of the table. When there is no event to be displayed, a message "There is no Event Logs"; would be displayed instead of table.

TABLE 1.21 Display items of [Operation Log] window

Items	Description
Date/ Time	Displays the local time of occurrence of the event or error. Format: YYYY-MM-DD HH:MM:SS
Operation	Displays the source (Web-UI or CLI) and contents of the operation.
IP Address	Displays the source IP address (IPv4 or IPv6 address) of the operation. This column displays [Console] for a CLI operation performed on a console with serial connection. If the host name can be identified from the DNS set on the MMB at the login time, this field displays the host name. Otherwise, it displays the IP address. If the user is logged in from the Web-UI, the field displays only the IP address using the DNS. If the logged-in user is using the IPv6 address connection, the field displays only the IP address using the DNS.
User Name (Session ID)	Displays the operator's name and session ID for Web-UI operations. The session ID for CLI operations is displayed as [ - ].

TABLE 1.22 [Operation Log] Window Buttons

Buttons	Description
Filter	When [Filter] button is clicked, [Operation Log Filtering Condition] window for entering the filtering conditions appears.
Clear	When [Click] button is clicked, all the operating logs are cleared.

## (1) Menu Operation

[System] – [Operation Log]

## (2) Window Operations

- When the entire operation log is to be cleared
  1. Click [Clear] button. A dialog box is displayed for confirmation.
  2. Click [OK] button, to clear operation log. Click [Cancel] button, when you do not want to clear operation log.
- Narrowing down the operation log displayed in the window
  1. Click the [Filter] button.  
The [Operation Log Filtering Condition] window for entering filtering conditions appears.
  2. Enter the conditions in the [Operation Log Filtering Condition] window. Then, click the [Apply] button.  
The browser returns to the [Operation Log] window. The window displays the log that satisfies the specified conditions.

**☐ [Operation Log Filtering Condition] Window**

When [Filter] button on the [Operation Log] window is clicked, the [Operation Log Filtering Condition] window for entering filtering conditions appeared.

Filtering conditions of event which appears on [Operation Log] window can be set on [Operating Log Filtering Condition] Window.

FIGURE 1.6 [Operating Log Filtering Condition] Window

Model: PRIMEQUEST2800E  
Part Number: MCXXXXXX  
Serial Number: 00000000  
Status: Normal

Active:MMB#0

System Partition User Administration Network Configuration Maintenance Logout

>System >Operation Log

System Status  
System Event Log  
**Operation Log**  
Partition Event Log  
System Information  
Firmware Information  
System Setup  
System Power Control  
LEDs  
Power Supply  
Fans  
Temperature  
SB  
IOU  
OPL  
MMB

### Operation Log Filtering Condition

Select the filtering conditions and click the Apply button to take effect.  
Note : The followings are AND conditions.

1)Operation: ☒ All  
☐ Specified ☒ Web-UI ☒ CLI

2)Sort by Date/Time: ☒ New event first ☐ Old event first

3)Start Date/Time: ☒ First event ☐ SpecifiedTime 2009 - 1 - 1 0 : 0 : 0

4)End Date/Time: ☒ Last event ☐ SpecifiedTime 2009 - 1 - 1 0 : 0 : 0

5)Number of events to display (Max 1000): 100 / 1000

Apply Cancel

TABLE 1.23 Display and Set Items of [Operating Log Filtering Condition] Window

Items	Description
Operation	<p>Selects the operation to be displayed. Select [All] or [Specified] by the radio button.</p> <ul style="list-style-type: none"> <li>All: Do not do filtering by Operation.</li> <li>Specified: Filtering of Operation can be set. Select the operation to be displayed.</li> </ul> <p>The default setting is All.</p>
Sort by Date/ Time	<p>Specified by using radio buttons whether to display by new order or to display by old order.</p> <ul style="list-style-type: none"> <li>New event first</li> <li>Old event first</li> </ul> <p>The default setting is New event first.</p>
Start Date/ Time	<p>Specified by using radio button either display from recent event or time specified event.</p> <ul style="list-style-type: none"> <li>First event: Set to first event</li> <li>Specified Time: Set to specified time</li> </ul> <p>If Specified Time is selected, enter the date and time of start time. By default, it is First event.</p>
End Date/ Time	<p>Specified by using radio button either display from the last event or time specified event.</p> <ul style="list-style-type: none"> <li>Last event : Set to last event</li> <li>Specified Time : Set to specified time</li> </ul> <p>If Specified Time is selected, enter the date and time of end time. By default, it is Last event.</p>
Number of events to display	<p>Specifies the number of log to be displayed. For the denominator part, the total number of logged in events is displayed.</p>

Items	Description
	It is specified that maximum value is 1000. By default, it is 100.

TABLE 1.24 Buttons on [Operation Log Filtering Condition] window

Buttons	Description
Apply	When [Apply] button is clicked, the log corresponding to the conditions specified is displayed in the list format on [Operation Log] window.
Cancel	Returns to the [Operation Log] window by clicking the [Cancel] button.

**[Message]**

This section describes the messages to be displayed on this window.

Message Number	Message
W_00413	Nothing is selected.
W_00414	Invalid Date Format.
W_00426	Invalid Values Specified.
W_00434	Invalid Time Format.
W_00441	Range over error.
I_00417	Are you sure?

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

## 1.2.4 [Partition Event Log] Window

[Partition Event Log] Window displays the hardware error information (REMCS message target message). Maximum 1000 events can be stored. When the log is full with the entries, the oldest event log is deleted and newly generated event log is stored.

FIGURE 1.7 [Partition Event Log] window

Model: PRIMEQUEST2800E  
Part Number: MCXXXXXX  
Serial Number: 000000001  
Status: Normal

Active:MMB#0

Logout

>System >Partition Event Log

System Status  
System Event Log  
Operation Log  
**Partition Event Log**  
System Information  
Firmware Information  
System Setup  
System Power Control  
LEDs  
Power Supply  
Fans  
Temperature  
SB  
IOU  
DU  
PCI\_Box  
OPL  
MMB

### Partition Event Log

Severity	Date/Time	Partition No	Unit	Event ID	Description
Error	2013/11/15 05:57:25	Partition#0	Firmware	30500	PXMD9 0000 0X 00000PX0, time:20131122085700.956
Error	2013/11/15 05:56:18	Partition#0	Firmware	30500	PXMD9 IGR TX 00000PX0, time:20131122085554.000
Error	2013/11/15 05:55:39	Partition#0	Firmware	30500	PXMD9 3333 3X 00000PX0, time:20131122085514.961
Error	2013/11/15 05:55:15	Partition#0	Firmware	30500	PXM:00 0000 00 00000000, time:20131122085450.954
Error	2013/11/14 17:30:53	Partition#0	Firmware	30500	PXMD9 0000 0X 00000PX0, time:20131121203029.536
Error	2013/11/21 18:57:56	Partition#3	Firmware	30500	PXM:10 1001 A9 007B0P00, time:20131121185755.873
Error	2013/11/21 18:16:05	Partition#2	Firmware	30500	PXM:5X NH33 01 05XX0P00, time:20131121181605.444
Error	2013/11/21 18:16:05	Partition#2	Firmware	30500	PXM:5X NH33 01 04XX0P00, time:20131121181605.381

Filter Clear

[Partition Event Log] allows scroll up/down window while keeping table titles on the top.  
When there is no event to be displayed, a message "There is no Event Logs"; is displayed instead of table.

TABLE 1.25 Display items of [Partition Event Log] window

Items	Description
Severity	Displays the severity of event. <ul style="list-style-type: none"> <li>Error: Severe problems like hardware damage</li> <li>Warning: Though it is not severe, problems may occur in the future for events.</li> <li>Information: Event assumed as information when partition power is on.</li> </ul>
Date/ Time	Displays the time when event and errors occurs. Format: YYYY-MM-DD HH:MM:SS
Partition No.	Displays the partition number.
Unit	Displays the unit which has the event or error detected sensor.
Event ID	Displays the ID (8 digit hexadecimal) which identifies the contents of the event. For the details of allocation of Event ID, see Chapter 2 MMB Messages in <a href="#">PRIMEQUEST 2000 series Message Reference</a> (C122-E178).
Description	Displays the events or details of the error.

TABLE 1.26 [Partition Event Log] Window Buttons

Buttons	Description
Filter	When [Filter] button is clicked, [Partition Event Log Filtering Condition] window for entering the filtering conditions is appeared.
Clear	When [Clear] button is clicked, a verification message "Do you want to clear all the partition log events?" displayed.

## (1) Menu Operation

[System] – [Partition Event Log]

## (2) Window Operations

- When the events displayed on window repeat
  1. Click the [Filter] button.  
[Partition Event Log Filtering Condition] window for entering the filter conditions appears.
  2. Enter the conditions on [Partition Event Log Filtering Condition] window. Then, click the [Apply] button.  
Return to [Partition Event Log] window. Events satisfying the specified conditions appear.
- When the partition event log is to be cleared
  1. Click the [Clear] button.  
A dialog box for confirmation appears.
  2. Click the [OK] button if the partition log event is to be cleared. Else, click the [Cancel] button.

☐ [Partition Event Log Filtering Condition] Window

When [Filter] button on the [Partition Event Log] is clicked, [Partition Event Log Condition] window for entering the filter condition appears.

Filtering conditions of events to be displayed on [Partition Event Log] window can be set on [Partition Event Log Filtering Condition] window.



FIGURE 1.8 [Partition Event Log Filtering Condition] Window

Model: PRIMEQUEST2800E  
Part Number: MCXXXXXXX  
Serial Number: 000000001  
Status: Normal

Active:MMB#0

System Partition User Administration Network Configuration Maintenance Logout

>System >Partition Event Log

System Status  
System Event Log  
Operation Log  
Partition Event Log  
System Information  
Firmware Information  
System Setup  
System Power Control  
LEDs  
Power Supply  
Fans  
Temperature  
SB  
IOU  
DU  
PCI\_Box  
OPL  
MMB

### Partition Event Log Filtering Condition

Select the filtering conditions and click the Apply button to take effect.  
Note : The followings are AND conditions.

1)Partition: ☒ All  
☐ Specified ☐ 0 ☐ 1 ☐ 2 ☐ 3

2)Number of events to display (Max 1000):  /1000

Apply Cancel

TABLE 1.27 Display and Set Items of [Partition Event Log Filtering Condition] Window

Items	Description
Partition	<p>Selects the partition to be displayed. Select [All] or [Specified] by using radio button.</p> <ul style="list-style-type: none"> <li>All: Filtering is not done for Partition</li> <li>Specified: Filtering of partition unit can be set. Select the partition to be displayed. In case of Partition Operator, [All] option is grayed out, selection is not possible. Further, for filtering of the partition; only the partition to be managed can be selected.</li> </ul> <p>Default</p> <ul style="list-style-type: none"> <li>Partition Operator privilege. : [Specified] and Partition to be managed is turned on.</li> <li>Other than the above. : [All]</li> </ul>
Number of events to display	<p>Specifies the number of logs to be displayed. The denominator represents the total number of logged events. Maximum 1000 events can be displayed. The default setting is 100</p>

TABLE 1.28 Buttons on the [Partition Event Log Filtering Condition] Window

Buttons	Description
Apply	When [Apply] button is clicked, the log corresponding to the conditions specified is displayed on the [Partition Event Log] screen.
Cancel	Returns to [Partition Event Log] window when [Cancel] button is clicked.

**[Message]**

This section describes the messages to be displayed on this window.

Message Number	Message
W_00413	Nothing is selected.
W_00414	Invalid Date Format.
W_00426	Invalid Values Specified.



Message Number	Message
W_00434	Invalid Time Format.
W_00441	Range over error.
I_00417	Are you sure?
I_00531	Are you sure you want to clear the Partition Event Log?
E_00100	Failed to set the Partition Event Log Clear

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

## 1.2.5 [System Information] Window

[System Information] window displays the information, such as name of the systems and name of the products etc., related to the PRIMEQUEST 2000 Series System. Moreover, names and Asset Tag (Property management number) corresponding to the PRIMEQUEST 2000 Series System (Chassis) can be set.

FIGURE 1.9 [System Information] Window

The screenshot shows the MMB Web-UI interface. At the top, the Fujitsu logo is on the left, and system details (Model: PRIMEQUEST2800E, Part Number: MCXXXXXX, Serial Number: 00000000, Status: Normal) are in the center. The top right shows 'Active:MMB#0'. Below this is a navigation bar with tabs: System, Partition, User Administration, Network Configuration, and Maintenance. The 'System' tab is active, and the breadcrumb path is '>System >System Information'. On the left, a sidebar menu lists various system management options, with 'System Information' highlighted. The main content area is titled 'System Information' and includes a 'Help' button. Below the title, it says 'Click the Apply Button to apply all changes.' There is a table of fields: System Name (PRIMEQUEST), Product Name (PRIMEQUEST2800E), Part Number (MCXXXXXX), Serial Number (00000000), and Asset Tag (empty). At the bottom right of this section are 'Apply' and 'Cancel' buttons.

TABLE 1.29 Display and Set Items of [System Information] window

Items	Description
System Name	<p>System name of PRIMEQUEST 2000 series is displayed. User with Administrator privilege can change system name. Maximum 64 characters can be entered.</p> <p><b>Remarks</b></p> <ul style="list-style-type: none"> <li>Characters which can be entered: Alphanumeric characters, half-width space. The following characters can also be entered. ! " # \$ % &amp; ' ( ) = - ^ ~ ¥ @ ` [ ] { } ; , * + ? &lt; &gt; . / _  </li> </ul> <p>However, there is a limitation.</p>

Items	Description
	<ul style="list-style-type: none"> <li># and half-width space cannot be used as first character.</li> <li>Half-width space cannot be used as last character.</li> </ul> <p>Default is &lt; PRIMEQUEST +Product serial number&gt;. When [system Name] is blank, it becomes system name of default.</p>
Product Name	Product name of PRIMEQUEST 2000 series is displayed.
Part Number	Model name of PRIMEQUEST 2000 series is displayed.
Serial Number	Serial number of PRIMEQUEST 2000 series is displayed.
Asset Tag	<p>Property administration information (Asset Tag) is displayed.</p> <p>User with the administrator privilege can change Asset Tag information. Maximum 32 characters can be entered.</p> <p>No default value.</p>

TABLE 1.30 Buttons on the [System Information] Window

Buttons	Description
Apply	When the characters are entered in the [System Name] or [Asset Tag] fields and click the [Apply] button is clicked, the entered information is set.
Cancel	When the [Cancel] button is clicked, the system is restored to the original condition without setting the information entered in the [System Name] or [Asset Tag]

## (1) Menu Operation

[System] – [System Information]

## (2) Window Operations

1. Change the items of [System Name] or [Asset Tag] and click the [Apply] button.  
Information in each field is set.

**[Message]**

This section describes the messages to be displayed on this window.

Message Number	Message
I_00013	Setting completed.
W_00431	Invalid character included.
W_00407	Input characters are too long.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

## 1.2.6 [Firmware Information] Window

Latest version number of applied Firmware, information of the Firmware version which is operating inside the system and the information of the Firmware version with backup is displayed on the [Firmware Information] window.

FIGURE 1.10 [Firmware Information] Window

**Firmware Information**

Model: PRIMEQUEST2800E  
 Part Number: MCXXXXXX  
 Serial Number: 000000001  
 Status: Normal

Active:MMB#0

System Partition User Administration Network Configuration Maintenance Logout

>System >Firmware Information

System Status  
 System Event Log  
 Operation Log  
 Partition Event Log  
 System Information  
**Firmware Information**  
 System Setup  
 System Power Control  
 LEDs  
 Power Supply  
 Fans  
 Temperature  
 SB  
 IOU  
 DU  
 PCI\_Box  
 OPL  
 MMB

Unified Firmware Version BA13112

**Current Firmware**

Unit	Firmware	active bank	Unified Firmware Version
		Version(bank1)	
		Version(bank2)	
SB#0	BMC	bank2	BA13112
		0.60F	
	BIOS	bank2	BA13112
		90.07	
SB#1	BMC	bank2	BA13112
		0.60F	
	BIOS	bank1	BA13112
		1.12	

TABLE 1.31 Display Item of [Firmware Information] Window

Items	Description
Unified Firmware Version	Latest version number of applied Firmware.
Current Firmware	
Unit	Target unit mounted with Firmware is displayed. <ul style="list-style-type: none"> <li>SB#n</li> <li>MMB#0</li> <li>MMB#1</li> </ul>
Firmware	Type and Current version (Active) of Firmware are displayed. <ul style="list-style-type: none"> <li>BMC</li> <li>BIOS</li> <li>MMB</li> <li>Not-present: It shows that Unit is not mounted. Gray color background is displayed.</li> </ul>
active bank	Bank (bank1 or bank2) of the memory that is operating now is displayed.. After start/restart of the partition, latest Firmware information is reflected in this display.
Version (bank1)	Firmware Version of bank1 is displayed. [Version display format] Firmware maintains Version information in the following format. <ul style="list-style-type: none"> <li>Major Version=1Byte data (Binary format)</li> <li>Minor Version=1Byte data (BCD format)</li> </ul> This data is displayed as follows. X.YY X displays Major version in decimal (0~255) Y displays Minor version as it is by double digit in BCD format (Binary coded decimal) (00~99).

Items	Description
Version (bank2)	Firmware Version of bank2 is displayed. [Version display format] Same as bank1
Unified Firmware version	Displays firmware version of target unit. Firmware maintains version information in the following format. <ul style="list-style-type: none"><li>• Model identification XX=1 byte data (01h=SA)</li><li>• Last two digits of the year YY=1 byte data (BCD format) 09-99</li><li>• Month MM=1 byte data (BCD format) 01-12</li><li>• Serial number N=1 byte data (Binary format) 1-9</li></ul> This data is displayed as below. XXYYMMN Example: BA13012 In case of uncertain version number “-” is displayed.

After start/restart of the partition is executed by the system administrator or the partition administrator, the latest written Firmware is reflected.

#### Remarks

After executing Firmware update, it is recommended to reflect in the Firmware by prompt start/restart of the partition.

(1) Menu Operation  
[System] – [System Information]

(2) Window Operations  
None

### 1.2.7 [System Setup] Window

In [System Setup] window, Power supply of PRIMEQUEST 2000 system and restoration action etc. can be set.

FIGURE 1.11 [System Setup] Window

**FUJITSU** Model: PRIMEQUEST2800E Active:MMB#0  
 Part Number: MCXXXXXXX  
 Serial Number: 0000000001  
 Status: Normal

System Partition User Administration Network Configuration Maintenance Logout

>System >System Setup

**System Setup** Help

Click the Apply Button to apply all changes.

Input Voltage	100V
Power Feed Mode	<input checked="" type="radio"/> Single <input type="radio"/> Dual
Power Restoration Policy	Always ON - chassis always powers up after AC is restored. Always OFF - chassis remains powered off after AC is restored. Restore - power is returned to the state that was in effect before AC was removed or lost. Schedule Sync - Synchronize with the schedule. Restore
Partition Power on Delay	0 sec
Altitude	Altitude < 1000m
PSU Redundant Mode	<input type="radio"/> Redundant <input checked="" type="radio"/> Non-Redundant
Reserved SB Force Power Off Wait	51 min
System Power Save Control	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
System Power Saving Threshold	0 W (0W - 0W)

Apply Cancel

TABLE 1.32 Display Items and Setting Items in [System Setup] Window

Items	Description
Input Voltage	Displays input voltage. <ul style="list-style-type: none"> <li>100V</li> <li>200V</li> </ul> When information cannot be acquired, it is displayed as 200V.
Power Feed Mode	Whether power supply of PRIMEQUEST 2000 system is configured in primary power feed mode or dual power feed mode is set. <ul style="list-style-type: none"> <li>Single: primary power feed mode</li> <li>Dual: dual power feed mode</li> </ul> Default setting is Single.
Power Restoration Policy	Sets the display of the restoration action after power failure. <ul style="list-style-type: none"> <li>Always off: Maintains the power-off status after the power restoration.</li> <li>Always on: Regardless of the condition at the time of power failure, the partition is powered on after the power restoration.</li> <li>Restore: Restores the status immediately before the power failure. If the power was on when the power failure occurred, it restores the power-on status of the partition. If the power was off, the partition power stays off.</li> <li>Schedule Sync: If the partition is in the operating time zone, power of partition turns on automatically depending on the schedule operations at the time of restoration of power. (attention) The schedule set with Special is applied only on the specified day.</li> </ul> Default setting is Restore.
Partition Power On Delay	Sets the standby time until power on of partition is specified as per the restoration power policy that is set after the AC power is On (also includes restoration power).

Items	Description
	<p>This item becomes effective at the time of the Power ON by the schedule. Specifies within the range of 0~9999 seconds.</p> <p>Default value is 0 seconds. (attention) Other start processing is not executed until the processing of Partition Power On Delay ends. However, when Power On by the schedule driving is done for the period of Power on delay by the AC power supply turning on (includes restoration power), Power On delay by the AC power supply turning on (includes restoration power) is given to priority, and Power on delay by Power On by the schedule driving is disregarded.</p>
Altitude	<p>Sets the altitude where PRIMEQUEST 2000 series system is installed or placed.</p> <ul style="list-style-type: none"> <li>Altitude &lt; 1000 m</li> <li>1000 m &lt;= Altitude &lt; 1500 m</li> <li>1500 m &lt;= Altitude &lt; 2000 m</li> <li>2000 m &lt;= Altitude</li> </ul> <p>Default value is Altitude &lt; 1000 m. Setting error of altitude condition is possible up to ±100m.</p>
PSU Redundant Mode	<p>Sets whether PSU is redundantly operated.</p> <ul style="list-style-type: none"> <li>Redundant</li> <li>Non-redundant</li> </ul> <p>When Power Feed Mode is Single, it is by default Non-Redundant. When Power Feed Mode is Dual, it is always Redundant.</p>
Reserved SB Force Power Off Wait	<p>While switching to Reserved SB, sets the maximum standby time till the start of force power off of partition which includes the concerned SB. Specifies within the range of 0~99 minutes.</p> <p>Default is 10 minutes.</p>
System Power Save Control	<p>Sets enable/disable for Power Saving function for entire system.</p> <ul style="list-style-type: none"> <li>Enable</li> <li>Disable</li> </ul> <p>Power Saving function supports only PSU_P 200V.</p> <p>Default is Disable.</p>
System Power Saving Threshold	<p>Sets the power consumption threshold (Limit value) of entire system. Minimum value is 300W. Maximum value is as shown below.</p> <ul style="list-style-type: none"> <li>PRIMEQUEST 2400E : 8640W</li> <li>PRIMEQUEST 2800E/B : 8640W</li> </ul> <p>Setting is possible only when System Power Save Control is Enable, gray-out at the time of disable.</p> <p>Default value is the maximum value of each model.</p>

TABLE 1.33 [System Setup] window button

Buttons	Description
Apply	When items such as [Power Feed Mode] and [Power Restore Policy] are specified and [Apply] button is clicked, the information is set.
Cancel	When [Cancel] button is clicked, returns to the original status without setting the changed or input items.

[System] – [System Setup]

(2) Window Operations

Specify the items such as [Power Feed Mode] and [Power Restoration Policy] and click on the [Apply] button.

Respective information is set.

**[Message]**

This section describes the messages to be displayed on this window.

Message Number	Message
I_00013	Setting completed.
E_00100	Failed to set the System Setup
W_00426	Invalid values specified.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

## 1.2.8 [System Power Control] window

In [System Power Control] window, power of the entire PRIMEQUEST 2000 series system can be controlled.

**Remarks**

- Please shutdown the OS for the partition in which Windows is installed. In case of emergency such as, no response from the system, cut the power supply using Power Off (Force Power Off) of MMB.
- In case of following condition, confirm the contents by referring to "11.2 Troubleshooting" of [PRIMEQUEST 2000 Series Administration Manual](#) (C122-E175EN). If the error could not be solved, contact your sales representative or sales representative.
  - Confirm the model name and serial number shown on the label affixed on the main unit and report it. Moreover, do not [Reset] or [Force Power Off] the partition till the error is solved.
  - When [Power off], [Reset], [Force Power Off] and shut down of partition is done by operating system, and if the state of each component on the MMB Web-UI screen is displayed in the state in which processing does not end even for a long time, Part Number and Serial Number are displayed as "Read Error".

FIGURE 1.12 [System Power Control] Window




TABLE 1.34 Display Items and Setting Items in [System Power Control] Window

Items	Description
Power on all partition(s)	Turns on the power of all the partition(s). If the status, in which only the power of the chassis is ON, is selected, the power of all partitions is turned on.
Power off all partition(s)(all partition(s) will be automatically shutdown)	Shuts-down all the partitions and turns off the power of the chassis.
Force Power Off	Turns off the power supply without shutting down the running operating system on the partition.

TABLE 1.35 [System Power Control] Window Button

Buttons	Description
Apply	When the [Apply] button is clicked after selecting the control item by the radio button, the power supply is controlled according to the selected information.
Cancel	When the [Cancel] button is clicked, the power supply returns to the original state without being controlled.

(1) Menu Operation  
[System] – [System Power Control]

- (2) Window Operations
1. Select the power control item by radio button and then click the [Apply] button.  
Dialogue box is displayed for confirmation
  2. Click the [OK] button.  
The power supply is controlled according to the selected information

**[Message]**



This section describes the messages to be displayed on this window.

Message Number	Message
I_00013	Setting completed.
E_00069	Can't control system power under maintenance. Release maintenance mode.
E_00077	Partition#xx cannot execute Power On.
E_00078	Partition#xx cannot execute Power Off.
E_00100	Failed to set the System Power Control
E_00101	Unable to power on the partition#%aa due to CPU mismatch between SBs.
E_00107	Unable to power on the chassis.
E_00108	Unable to power off the chassis.
E_00109	Unable to force power off.
I_00212	System Power Control cannot be executed because the system is under maintenance.
E_00422	Unable to power on the partition#%aa due to CPU composition abnormal.
E_00482	Unable to power on the partition#%aa due to DIMM composition abnormal.
E_00491	Unable to power on the partition#%aa due to DIMM does not satisfy requirements of Mirror Mode.
E_00517	Unable to power on the partition#%d due to abnormal SB composition.
E_00522	Unable to power on the partition#%d due to abnormal VRM composition.


For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

In case of multiple errors, 'multiple errors' message appears in the warning dialogue box.

## 1.2.9 [LEDs] window

[LEDs] window displays the status of the LED in the system.

FIGURE 1.13 [LEDs] Window



Displays 'Not-present' for the units which are not installed, background color of those rows is displayed in gray color.

Following is displayed only in case of PRIMEQUEST 2400E model.

SB: SB#0~SB#1

TABLE 1.36 Display Items and Setting Items in [LEDs] Window

Items	Description
Unit	Displays unit name.
Power LED	The power status is displayed.
Alarm LED	Displays whether the unit is normal or abnormal.
Location LED	Displays/sets the Location LED status of unit.

TABLE 1.37 [LEDs] Window Button

Buttons	Description
On	When [On] button is clicked, Location LED is turned on.
Off	When [Off] button is clicked, Location LED is turned off
Turn off all Location LEDs	When [Turn off all Location LEDs] button is clicked, all [Location LED] in system are turned off.

(1) Menu Operation

[System] – [LEDs]

(2) Window Operations

- Click the [Turn off all Location LEDs] button.  
All [Location LED] in system are turned off.

## 1.2.10 [Power Supply] window

[Power Supply] window displays the PSU status in the PRIMEQUEST 2000 series. Once the error in the status of each PSU is detected, the abnormality status is maintained till the PSU is replaced or the abnormality status is cleared by clicking the [Status Clear] button.

FIGURE 1.14 [Power Supply] Window

Model: PRIMEQUEST2800E  
Part Number: MCXXXXXXX  
Serial Number: 0000000001  
Status: **Normal**

Active:MMB#0

System Partition User Administration Network Configuration Maintenance Logout

>System >Power Supply

System Status  
System Event Log  
Operation Log  
Partition Event Log  
System Information  
Firmware Information  
System Setup  
System Power Control  
LEDs  
**Power Supply**  
Fans  
Temperature  
SB  
IOU  
DU  
PCI\_Box  
OPL  
MMB

### Power Supply

Click the Status Clear button to clear the status.

System Power Status	On
Power Supply Redundancy	Redundant

PSU

PSU/FANU Slot	Status	Power Status	Type	Part Number	Serial Number
0	OK	On	PSU_S	CA07603-E402	G817L7001505F
1	OK	On	PSU_S	CA07603-E402	G817L7000505F
2	-	-	FANU	CA07603-E501	G818L6005H05F
3	Not-present	-	-	Read Error	Read Error
4	Not-present	-	-	Read Error	Read Error
5	Not-present	-	-	-	-

Power Consumption

System Power Consumption(W)	840
-----------------------------	-----

Status Clear

TABLE 1.38 Display Item on [Power Supply] Window

Items	Description
System Power Status	Displays the power supply status of PRIMEQUEST 2000 series system (chassis) <ul style="list-style-type: none"> <li>On</li> <li>Standby</li> </ul>
Power Supply Redundancy	Displays redundancy status of PSU/FANU. <ul style="list-style-type: none"> <li>Redundant: In case of the PSU is redundant.</li> <li>Non-redundant: Sufficient Resources: When there is a PSU which is required to operate the system even if redundancy of the PSU is lost.</li> <li>Non-redundant: Insufficient Resources: When redundancy of the PSU is lost, and when there is no PSU which is required for operating the system.</li> </ul>
PSU Status	Displays the status of PSU/FANU <ul style="list-style-type: none"> <li>OK</li> <li>Not-present</li> <li>Failed</li> <li>A/C Lost</li> <li>Configuration error</li> <li>- (When Type is FANU)</li> </ul>
PSU Power Status	Displays power supply ON/OFF status of PSU/FANU

Items	Description
	<ul style="list-style-type: none"><li>• On</li><li>• Off</li><li>• - (When Type is FANU)</li></ul>
Type	Displays the types of PSU/FANU <ul style="list-style-type: none"><li>• PSU_P : PSU supporting 80PLUS PLATINUM</li><li>• PSU_S : PSU supporting 80PLUS SILVER</li><li>• FANU : Module of FAN only</li><li>• -: (For Not-present)</li></ul> Mixing of PSU_P/PSU_S in the same component is not possible.
Part Number	Displays the part number of the PSU/FANU.
Serial Number	Displays the serial number of the PSU/FANU
Power Consumption	Displays the power consumption.

TABLE 1.39 Button of [Power Supply] Window

Button	Description
Status Clear	Clears the error status of the PSU

(1) Menu Operation  
[System] – [Power Supply]

- (2) Window Operations
1. Click the [Status Clear] button.  
Dialog box for confirmation appears.
  2. Click the [OK] button to clear the Status of the PSU and click the [Cancel] button when you do not want to clear the Status of the PSU.

#### [Message]

This section describes the messages to be displayed on this window.


Message Number	Message
I_00029	Status Clear completed.
E_00123	Failed to clear the status.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

## 1.2.11 [Fans] window

[Fans] window displays the Fan status in PRIMEQUEST 2000 Series System and clears the Fan status setting.

FIGURE 1.15 [Fans] Window(1)



Model: PRIMEQUEST2800E  
Part Number: MCXXXXXXX  
Serial Number: 000000001  
Status: Normal

Active:MMB#0

System Partition User Administration Network Configuration Maintenance Logout

>System >Fans

System Status

System Event Log

Operation Log

Partition Event Log

System Information

Firmware Information

System Setup

System Power Control

LEDs

Power Supply

Fans

Temperature

SB

IOU

DU

PCI\_Box

OPL

MMB

## Fans


Click the Status Clear button to clear the status.

Fan Redundancy Redundant

PSU/FANU Slot	FANM#	Part Number	Status	Fan speed (rpm)	Threshold(rpm)	
					Warning(Low/High)	Critical(Low/High)
0	FANM#0	CA07603-H402	OK		- / 17446	9138 / -
			OK		- / 14420	7344 / -
			OK		- / 17446	9138 / -
			OK		- / 14420	7344 / -
	FANM#1	CA07603-H402	OK		- / 17446	9138 / -
			OK		- / 14420	7344 / -
			OK		- / 17446	9138 / -
			OK		- / 14420	7344 / -
	FANM#0	CA07603-H402	OK		- / 17446	9138 / -
			OK		- / 14420	7344 / -
			OK		- / 17446	9138 / -
			OK		- / 14420	7344 / -

Status Clear

FIGURE 1.16 [Fans] Window(2)



Model: PRIMEQUEST2800E  
Part Number: MCXXXXXXX  
Serial Number: 000000001  
Status: Normal

Active:MMB#0

System Partition User Administration Network Configuration Maintenance Logout

>System >Fans

System Status

System Event Log

Operation Log

Partition Event Log

System Information

Firmware Information

System Setup

System Power Control

LEDs

Power Supply

Fans

Temperature

SB

IOU

DU

PCI\_Box

OPL

MMB

## Fans

Refresh Help

4	FANM#1	CA07603-H402	OK		- / 14420	7344 / -
			OK		- / 17446	9138 / -
			OK		- / 14420	7344 / -
			OK		- / 17446	9138 / -
5	FANM#0		Not-present			
			Not-present			
			Not-present			
	FANM#1		Not-present			
			Not-present			
			Not-present			

Airflow Volume

Airflow Volume(m3/h) 944

Status Clear

Once an abnormality is detected in the Status of each fan, the abnormal status is maintained until the fan is replaced or until the abnormal status is cleared by clicking the [Status Clear] button.

**Remarks**

If the abnormality in rotational frequency of a fan is detected again after executing [Status Clear], then, the status changes to [Failed Status]. Accordingly, even if the status of a fan, having abnormal rotational frequency from the beginning is cleared, the status remains as [Failed].

TABLE 1.40 Display items of [Fans] window

Items	Description	
Fan Redundancy	Fan Redundancy Displays the redundancy status of fan. <ul style="list-style-type: none"> <li>Redundant: The Fans are Redundant</li> <li>Non-Redundant: Sufficient Resource: Redundancy of fan is lost, however, there are sufficient fans, to continue the operations of the system.</li> <li>Non-Redundant: Insufficient Resource: The number of fans is less due to redundancy, and fans to continue operations of the system are sufficient.</li> </ul>	
PSU/FANU Slot	Displays the slot location of the PSU or FANU to which the FANM belongs.	
Status	Displays the status of each fan <ul style="list-style-type: none"> <li>OK</li> <li>Not-present</li> <li>Failed</li> </ul>	
Part Number	Displays the part number of the fan.	
Fan Speed(rpm)	Displays the rotational frequency (rpm) of each fan.	
Threshold(rpm)	Warning(Low/High)	Displays the lower limit and upper limit of the warning-level rotational frequency of each fan. (If the rotational frequency is lower or upper than this limit, it is considered to be abnormal)
	Critical(Low/High)	Displays the lower limit and upper limit of the critical-level rotational frequency of each fan. (If the rotational frequency is lower or upper than this limit, it is considered to be abnormal)
Airflow Volume	Displays the airflow.	

TABLE 1.41 [Fans] Window Button

Button	Description
Status Clear	Clears the status of fan.

## (1) Menu Operation

[System] – [Fans]

## (2) Window Operations

- Click the [Status Clear] button.  
Dialog box for confirmation appears.
- Click the [OK] button to clear the Status of the fan and, click the [Cancel] button when you do not want to clear the fan status.

**[Message]**

This section describes the messages to be displayed on this window.

Message Number	Message
I_00029	Status Clear completed.
E_00123	Failed to clear the status.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference \(C122-E178EN\)](#).



## 1.2.12 [Temperature] window

[Temperature] Window displays the temperature of the temperature sensor of PRIMEQUEST 2000 series system.

In case of PRIMEQUEST 2400E model, only the following items are displayed.

SB: SB#0~SB#1

FIGURE 1.17 [Temperature] Window

**Fujitsu** Model: PRIMEQUEST2800E Active:MMB#0  
 Part Number: MCXXXXXXX  
 Serial Number: 000000001  
 Status: Normal

System Partition User Administration Network Configuration Maintenance Logout

>System >Temperature

**Temperature** [Refresh] [Help]

Sensor	Status	Temperature	Threshold	
			Warning (Low/High)	Critical (Low/High)
Inlet Temp.	OK	- °C	2 / 38°C	- / -°C

Sensor	Status	Temperature	Threshold	
			Warning (Low/High)	Critical (Low/High)
CPU#0	OK	- °C	- / 87°C	- / 89°C
CPU#1	Not-present			
DIMM#0A0 - 0A5	OK	- °C	- / 87°C	- / 90°C
DIMM#0B0 - 0B5	Not-present			
DIMM#0C0 - 0C5	Not-present			
DIMM#0D0 - 0D5	Not-present			
DIMM#1A0 - 1A5	Not-present			
DIMM#1B0 - 1B5	Not-present			
DIMM#1C0 - 1C5	Not-present			
DIMM#1D0 - 1D5	Not-present			
RAID Ctrl Temp.	-	-	-	-
RAID BBU Temp.	-	-	-	-

TABLE 1.42 Display Items on [Temperature] Window

Items	Description
Status	Displays the status of each temperature sensor. <ul style="list-style-type: none"> <li>• OK</li> <li>• Not-present</li> <li>• Warning</li> <li>• Critical</li> </ul>
Temperature	Displays the temperature of each temperature sensor.
Threshold	Displays the threshold which maintained the by each temperature sensor. <ul style="list-style-type: none"> <li>• Warning: Low/High</li> <li>• Critical :Low/High</li> </ul>

(1) Menu Operation  
 [System] – [Temperature]

(2) Window Operations  
 None

## 1.2.13 [SB] Menu

[SB] Menu consists of the menus in each SB unit.

The menu of uninstalled SB is not displayed.

The format of window and operating method are same for each menu, therefore only one menu is explained here.

### □ [SB#x] Window

[SB#x] window displays the status of SB#x board and the settings of SB#x board can be carried out.

FIGURE 1.18 [SB#x] Window (1)

Model: PRIMEQUEST2800E  
Part Number: MCXXXXXXX  
Serial Number: 0000000001  
Status: Normal

Active:MMB#0

System Partition User Administration Network Configuration Maintenance Logout

>System >SB >SB#0

**SB#0** Refresh Help

Click the Status Clear button to clear the status.

**Board Information**

Status	OK
Power Status	Standby
Home	Yes
Part Number	CA07603-D003 A0
Serial Number	PP132500PT
Location LED	Off <input type="button" value="On"/> <input type="button" value="Off"/>

**CPUs**

CPU#	Status	Core / Max Core	Model	Stepping	Part Number	Serial Number
0	OK	15/15	Intel® Xeon® E7-8890V2	C0	CA46100-7441	7C5B277D43A3AB00
1	Not-present					

**DIMMs**

Status Clear



FIGURE 1.19 [SB#x] Window (2)

**FUJITSU** Model: PRIMEQUEST2800E Active:MMB#0  
Part Number: MCXXXXXXX  
Serial Number: 0000000001  
Status: **Normal**

System Partition User Administration Network Configuration Maintenance Logout

>System >SB >SB#0

**SB#0** Refresh Help

**DIMMs**

DIMM#	Status	Size	Rank	Data Rate	Part Number	Serial Number
0A0	OK	8GB	1	DDR3-1600	M393B1G70BH0-YK0	85E0526E
0A1	Not-present					
0A2	Not-present					
0A3	OK	8GB	1	DDR3-1600	M393B1G70BH0-YK0	85E05269
0A4	Not-present					
0A5	Not-present					
0B0	Not-present					
0B1	Not-present					
0B2	Not-present					
0B3	Not-present					
0B4	Not-present					
0B5	Not-present					
0C0	Not-present					
0C1	Not-present					

Status Clear

FIGURE 1.20 [SB#x] Window (3)

**FUJITSU** Model: PRIMEQUEST2800E Active:MMB#0  
Part Number: MCXXXXXXX  
Serial Number: 0000000001  
Status: **Normal**

System Partition User Administration Network Configuration Maintenance Logout

>System >SB >SB#0

**SB#0** Refresh Help

**Mezzanine**

Mezzanine#	Status
0	OK
1	OK

**RAID Slot**

Power Status	Slot Status	Link Width	Seg/Bus/Dev
Standby	OK	Unknown	Unknown

**RAID Card**

Status	BBU Status	Vendor ID	Device ID	Physical Drives Count	Logical Drives Count	Serial Number	Firmware Version
-	-	-	-	-	-	-	-

**Physical Drives**

Slot#	Status	Vendor	Model	Capacity
0	-	-	-	-
1	-	-	-	-
2	-	-	-	-
3	-	-	-	-

Status Clear

FIGURE 1.21 [SB#x] Window (4)

**FUJITSU** Model: PRIMEQUEST2800E Active:MMB#0  
Part Number: MCXXXXXXX  
Serial Number: 0000000001  
Status: **Normal**

System Partition User Administration Network Configuration Maintenance Logout

>System >SB >SB#0

**SB#0** Refresh Help

**Logical Drives**

Sensor#	Status	RAID Level	Physical Drives assignment	Missing drives Count
-	-	-	-	-

**RAID Action Progress**

Drive Type	Slot#/Sensor#	Action	Progress	Estimated time remaining (hh:mm:ss)
-	-	-	-	-

**Chipsets**

Chipset	Status
Chipset	OK

**TPM**

TPM	Status
TPM	OK

**BMC**

BMC	Status
BMC	OK

**FBU**

FBU	Status
FBU	OK

Status Clear

FIGURE 1.22 [SB#x] Window (5)

**FUJITSU** Model: PRIMEQUEST2800E Active:MMB#0  
Part Number: MCXXXXXXX  
Serial Number: 0000000001  
Status: **Normal**

System Partition User Administration Network Configuration Maintenance Logout

>System >SB >SB#0

**SB#0** Refresh Help

**Clock**

Clock	Status
Clock	OK

**Voltage**

Sensor	Voltage	Threshold	
		Warning(Low/High)	Critical(Low/High)
P5VL	4.97 V	4.63/ 5.37 V	3.23/ 6.00 V
P1.1VL	- V	1.02/ 1.19 V	0.71/ 1.32 V
P1.8VL	1.80 V	1.67/ 1.93 V	1.16/ 2.17 V
P1.5VL	1.50 V	1.39/ 1.61 V	0.97/ 1.81 V
P1.0VL	0.99 V	0.92/ 1.08 V	0.64/ 1.21 V
P1.8V_CPU	- V	1.67/ 1.93 V	1.16/ 2.17 V
P1.0V_JC#0A	- V	0.92/ 1.08 V	0.65/ 1.21 V
P1.5V_PCH	- V	1.39/ 1.61 V	0.97/ 1.80 V
P1.1V	- V	1.02/ 1.19 V	0.71/ 1.32 V
P0.9V_PCIEX#0	- V	0.83/ 0.97 V	0.58/ 1.09 V
P1.8V_PCIEX#0	- V	1.67/ 1.93 V	1.17/ 2.17 V
P0.9V_PCIEX#1	- V	0.83/ 0.97 V	0.58/ 1.09 V
P1.8V_PCIEX#1	- V	1.67/ 1.93 V	1.17/ 2.17 V
P1.0V#0	- V	1.15/ 1.27 V	0.70/ 1.45 V

Status Clear

FIGURE 1.23 [SB#x] Window (6)

Model: PRIMEQUEST2800E  
Part Number: MCXXXXXXX  
Serial Number: 0000000001  
Status: **Normal**

Active:MMB#0

System Partition User Administration Network Configuration Maintenance Logout

>System >SB >SB#0

System Status  
System Event Log  
Operation Log  
Partition Event Log  
System Information  
Firmware Information  
System Setup  
System Power Control  
LEDs  
Power Supply  
Fans  
Temperature  
SB  
SB#0  
SB#1  
SB#2  
SB#3  
IOU  
DU  
PCI\_Box  
OPL  
MMB

**SB#0**

P1.8V_PCIEX#1	- V	1.67/ 1.93 V	1.17/ 2.17 V
P12V#0	- V	11.15/12.87 V	7.79/14.45 V
P5V	- V	4.65/ 5.38 V	3.25/ 6.02 V
P3.3V	- V	3.06/ 3.54 V	2.14/ 3.98 V
P1.35V_CPU#0	- V	1.25/ 1.45 V	0.87/ 1.63 V
VCC_CPU#0	- V	0.55/ 1.45 V	0.38/ 1.63 V
VSA_CPU#0	- V	0.65/ 1.29 V	0.45/ 1.45 V
VTT_CPU#0	- V	0.92/ 1.08 V	0.64/ 1.21 V
VDDQ_DIMM#0A	- V	1.25/ 1.61 V	0.87/ 1.81 V
VDDQ_DIMM#0B	- V	1.25/ 1.61 V	0.87/ 1.81 V
P1.0V_JC#0B	- V	0.92/ 1.08 V	0.64/ 1.21 V
P1.5V_JC#0AB	- V	1.39/ 1.61 V	0.97/ 1.81 V
P1.35V_JC#0AB	- V	1.25/ 1.45 V	0.87/ 1.63 V
VDDQ_DIMM#0C	- V	1.25/ 1.61 V	0.87/ 1.81 V
VDDQ_DIMM#0D	- V	1.25/ 1.61 V	0.87/ 1.81 V
P1.0V_JC#0C	- V	0.92/ 1.08 V	0.64/ 1.21 V
P1.0V_JC#0D	- V	0.92/ 1.08 V	0.64/ 1.21 V
P1.5V_JC#0CD	- V	1.39/ 1.61 V	0.97/ 1.81 V
P1.35V_JC#0CD	- V	1.25/ 1.45 V	0.87/ 1.63 V

Refresh Help

Status Clear

The CPU and DIMM row that is not mounted is displayed in gray background.

The [Status clear] button and a message [Click the Status Clear Button to clear the status.] are not displayed for a user who does not have setting privileges.

TABLE 1.43 Display and Setting items on [SB#x] Window

Items	Description
<b>Board Information</b>	
Status	Displays the status of SB. <ul style="list-style-type: none"> <li>• OK: No fault on the SB.</li> <li>• Not-present: The SB is not mounted.</li> <li>• Warning: Warning is detected by the voltage sensor on the SB.</li> <li>• Degraded: Error has occurred in a component on the SB. However, the SB can be operated by disconnecting the faulty components.</li> <li>• Failed: A fault has occurred in the SB, and the SB must be disconnected, or the SB has been disconnected.</li> <li>• Unsupported: In case there is an SB which is not supported by the MMB.</li> </ul>
Power Status	Displays the power status of the SB. <ul style="list-style-type: none"> <li>• On: On status</li> <li>• Standby: Standby status</li> </ul>
Home	Displays whether SB is at Home status or not. <ul style="list-style-type: none"> <li>• Yes: Home status</li> <li>• No: Not a Home status</li> </ul>
Part Number	Displays the part number of the SB
Serial Number	Displays the serial number of the SB

Location LED	Indicates the display status of the Location LED. The display status consists of the following conditions. <ul style="list-style-type: none"><li>On: The light is on</li><li>Off: The light is off</li></ul> On, Off and blinking of the Location LED can be controlled by clicking the respective [On], [Off], [Blink] buttons.	
CPUs		
CPU#0 CPU#1	Status	Displays the status of the CPU. <ul style="list-style-type: none"><li>OK</li><li>Not-present</li><li>Disabled</li><li>Warning</li><li>Failed</li><li>Configuration error</li><li>Unknown</li></ul>
	Core/Max Core	Displays Normal number of cores number/ maximum number of cores number. <ul style="list-style-type: none"><li>Indicates the degeneracy status of the core.</li></ul> Maximum number of cores also includes the number of Disable cores.
	Model	Displays the product name of the CPU.
	Stepping	Displays the version number of the CPU.
	Part Number	Displays the part number of the CPU.
	Serial Number	Displays the serial number of the CPU.
DIMMs		
DIMM#0A0 ~ DIMM#1D5	Status	Displays the status of the DIMM. <ul style="list-style-type: none"><li>OK</li><li>Not-present</li><li>Warning</li><li>Uncorrectable error</li><li>Disabled</li><li>Configuration error</li><li>Degraded Configuration</li><li>Unknown</li></ul>
	Size	Displays the size of the DIMM. <ul style="list-style-type: none"><li>8GB</li><li>16GB</li><li>32GB</li><li>64GB</li></ul> There is no display when the DIMM status is Not-present, Not-supported, or Unknown.
	Rank	Displays number of DIMM Ranks(1 or 2 or 4). There is no display when the DIMM status is Not-present, Not-supported, or Unknown.
	Data Rate	Displays Data Rate of DIMM. <ul style="list-style-type: none"><li>DDR3-1066, 1333, 1600</li></ul> There is no display when the DIMM status is Not-present, Not-supported, or Unknown.

	Part Number	Displays the part number of DIMM. There is no display when the DIMM status is Not-present, Not-supported, or Unknown.
	Serial Number	Displays the serial number of DIMM. There is no display when the DIMM status is Not-present, Not-supported, or Unknown.
Mezzanine		
Mezzanine#0 Mezzanine#1	Status <ul style="list-style-type: none"><li></li></ul>	Displays the status of the Mezzanine board. <ul style="list-style-type: none"><li>OK</li><li>Not-present</li><li>Failed</li></ul>
RAID Slot		
Power Status	Displays the power status of the RAID slot. <ul style="list-style-type: none"><li>On</li><li>Standby</li></ul>	
Slot Status	Displays the status of the RAID slot. <ul style="list-style-type: none"><li>OK</li><li>Warning</li><li>Not-present</li><li>Failed</li><li>Disabled</li></ul>	
Link Width	Displays Link Width of the RAID slot format. <ul style="list-style-type: none"><li>x1</li><li>x2</li><li>x4</li><li>x8</li></ul>	
Seg/Bus/Dev	Displays Segment#, Bus#, Device# of the RAID device.	
RAID Card		
BBU Status	The state of RAID BBU(Battery Backup Unit) is displayed. <ul style="list-style-type: none"><li>Online</li><li>On Battery</li><li>Charging</li><li>Discharging</li><li>Battery Low</li><li>Relearn Required</li><li>Failed</li><li>Not-present</li></ul>	
Vendor ID	Vendor ID of RAID Card is displayed. Remarks: ID uniquely allocated in manufacturer of card. For details of the ID, see the PRIMEQUEST 2000 Series Administration Manual(C122-E175EN)	
Device ID	Device ID of RAID Card is displayed. Remarks: ID uniquely allocated in device of manufacturer. For details of the ID, see the PRIMEQUEST 2000 Series Administration Manual(C122-E175EN)	
Physical Drives Count	The number of physical drives connected with RAID Card is displayed.	

Logical Drives Count	The number of logical drives composed under the control of RAID Card is displayed.
Serial Number	The serial number of RAID Card is displayed.
Firmware Version	The firmware version of RAID Card is displayed.
Physical Drives	
Slot#	The slot number equipped with a physical drive is displayed.
Status	<p>The state of a physical drive is displayed.</p> <ul style="list-style-type: none"> <li>Operational</li> <li>Available</li> <li>Failed</li> <li>Hot Spare</li> <li>Rebuilding</li> <li>SMART err</li> <li>Not-present</li> </ul>
Vendor	The vendor of a physical drive is displayed.
Model	The model name of a physical drive is displayed.
Capacity	The capacity of a physical drive is displayed.
Logical Drives	
Sensor#	The sensor number of a logical drive is displayed.
Status	The state of a logical drive is displayed.
RAID Level	The RAID level of a logical drive is displayed.
Physical Drives assignment	The slot number of a physical drive that composes a logical drive is displayed.
Missing drives Count	The number of physical drives missed to compose a logical drive at the RAID level is displayed.
RAID Action Progress	
Drive Type	<p>The drive type that the RAID action is executed is displayed.</p> <ul style="list-style-type: none"> <li>Physical : Hardware RAID</li> <li>Logical : Software RAID</li> </ul>
Slot#/Sensor#	Slot# from which the RAID action is executed is shown when Drive Type is Physical, and Sensor# from which the RAID action is executed is shown when Drive Type is Logical.
Action	<p>The RAID action under execution is displayed.</p> <ul style="list-style-type: none"> <li>Rebuilding : It is shown for a physical drive to execute the rebuild of the RAID drive.</li> <li>MDC Running : It is shown for a logical drive to execute MDC(Make Data Consistent).</li> </ul>
Progress	The progress rate of the RAID action under execution is displayed by the percentage.
Estimated time remaining (hh:mm:ss)	The remaining time that will be expected by the time the RAID action under execution is completed is displayed.
Chipset	
Chipset	<ul style="list-style-type: none"> <li>OK</li> <li>Warning</li> <li>Failed</li> </ul>
TPM	

TPM	Displays the status of the TPM. <ul style="list-style-type: none"><li>• OK</li><li>• Warning</li><li>• Failed</li></ul> Notes When the SB is 'without TPM mode', this field is not displayed. Remark The TPM is not displayed in the SB for China.
BMC	
BMC	Displays the status of the BMC. <ul style="list-style-type: none"><li>• OK</li><li>• Warning</li><li>• Failed</li></ul>
FBU	
FBU	Displays the status of the FBU(Flash Backup Unit). <ul style="list-style-type: none"><li>• OK</li><li>• Failed</li></ul>
Clock	
Clock	Displays the status of the System Clock. <ul style="list-style-type: none"><li>• OK</li><li>• Failed</li></ul>
Voltage	

Sensor		Displays the Voltage sensor type. P5VL P1.1VL P1.8VL P1.5VL P1.0VL P1.8V_CPU VDDQ_DIMM#1A P1.0V_JC#0A P1.5V_PCH P1.1V P0.9V_PCIEX#0 P1.8V_PCIEX#0 P0.9V_PCIEX#1 P1.8V_PCIEX#1 P12V#0 P5V P3.3V P1.35V_CPU#0 P1.35V_CPU#1 VCC_CPU#0 VSA_CPU#0 VTT_CPU#0 VDDQ_DIMM#0A VDDQ_DIMM#0B P1.0V_JC#0B P1.5V_JC#0AB P1.35V_JC#0AB VCC_CPU#1 VSA_CPU#1 VTT_CPU#1 VDDQ_DIMM#1B P1.0V_JC#1A P1.0V_JC#1B P1.5V_JC#1AB P1.35V_JC#1AB VDDQ_DIMM#0C VDDQ_DIMM#0D P1.0V_JC#0C P1.0V_JC#0D P1.5V_JC#0CD P1.35V_JC#0CD VDDQ_DIMM#1C VDDQ_DIMM#1D P1.0V_JC#1C P1.0V_JC#1D P1.5V_JC#1CD P1.35V_JC#1CD
Voltage		Displays the current power voltage.
Threshold	Warning(Low/High)	Lower and upper limits of the warning-level voltage.  Displays “ – ”, when the threshold is not set. Displays the power voltage in the last two decimal places.
	Critical(Low/High)	Lower and upper limits of the critical-level voltage.  Displays “ – ”, when the threshold is not set. Displays the power voltage in the last two decimal places.

TABLE 1.44 [SB#x] Window Button

Buttons	Description
On	When the [On] button is clicked, the Location LED is ON.
Off	When the [Off] button is clicked, the Location LED is OFF.
Status Clear	Clears the status of the SB.



**[Message]**

This section describes the messages to be displayed on this window.

Message Number	Message
I_00029	Status Clear completed.
E_00048	The specified unit is not installed.
E_00123	Failed to clear the status.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

**□ [SB#x Status Clear] Window**

When the [Status Clear] button on the [SB#x] window is clicked, whether to clear the error status of the component can be specified.

The error status of the component in which an abnormality is detected on the SB is canceled, the relevant component can be specified so that it can be used again at the time of next reboot. If error is detected again at the time of re-boot, then the error status of that such component is registered again.

FIGURE 1.24 [SB#x Status Clear] Window (Message Display)

Model: PRIMEQUEST2800E  
Part Number: MCXXXXXX  
Serial Number: 000000001  
Status: Normal

Active:MMB#0

System Partition User Administration Network Configuration Maintenance Logout

>System >SB >SB#0

System Status  
System Event Log  
Operation Log  
Partition Event Log  
System Information  
Firmware Information  
System Setup  
System Power Control  
LEDs  
Power Supply  
Fans  
Temperature  
SB

SB#0  
SB#1  
SB#2  
SB#3

IOU  
DU  
PCI\_Box  
OPL  
MMB

### SB#0 Status Clear

Click the Apply Button to apply all changes.

☒ Clear All Status  
☐ Clear Specified Status Select the appropriate "Status Clear" box.  
☐ Clear Status of common parts

**CPUs**

CPU#	Status	Status Clear
0	OK	<input type="checkbox"/>
1	Not-present	<input type="checkbox"/>

**DIMMs**

DIMM#	Status	Status Clear
0A0	OK	<input type="checkbox"/>
0A1	Not-present	<input type="checkbox"/>
0A2	Not-present	<input type="checkbox"/>
0A3	OK	<input type="checkbox"/>
0A4	Not-present	<input type="checkbox"/>
0A5	Not-present	<input type="checkbox"/>
0B0	Not-present	<input type="checkbox"/>

Apply Cancel

## (1) Menu Operation

[System] – [SB] – [SB#x] – [Status Clear] button

## (2) Window Operations

1. Specify as given below to clear the component.

- Select [Clear All Status] to clear all the components.
- Select [Clear Specified Status] to individually clear the error status of the components, and check the [Status Clear] checkbox of the status of the components to be cleared.
- Check the [Clear Status of common parts] check box to clear the common parts.

- Click the [Apply] button.  
The specified components are set to clear.

### ☐ Display when there is no CPU/DIMM installed

When there is no CPU or DIMM mounted, the SB is not degraded from the partition and stops the Partition start.

At that time, the following messages are displayed on the table of the composition display of CPU or DIMM respectively to make CPU or any DIMM easy to recognize not installed as follows by the deficit and the boldface character.

"\*It is necessary to install at least one CPU in SB#x." (In case of CPU)

"\*It is necessary to install at least one DIMM set per one DIMM in SB#x." (In case of DIMM)

FIGURE 1.25 [SB#x] Window (When there is no CPU/DIMM)

Model: PRIMEQUEST 2800E  
Part Number: MCXXXXXXX  
Serial Number:   
Status: **Error**

Active:MMB#0

System Partition User Administration Network Configuration Maintenance Logout

>System >SB >SB#2

**SB#2** Refresh Help

Click the Status Clear button to clear the status.

**Board Information**

Status	OK
Power Status	Standby
Home	Yes
Part Number	CA07603-D001 A8
Serial Number	PP131302A4
Location LED	Off <input type="button" value="On"/> <input type="button" value="Off"/>

**CPUs** \*It is necessary to install at least one CPU in SB#2.

CPU#	Status	Core / Max Core	Model	Stepping	Part Number	Serial Number
0	Not-present					
1	Not-present					

**DIMMs** \*It is necessary to install at least one DIMM set per one DIMM in SB#2.

DIMM#	Status	Size	Rank	Data Rate	Part Number	Serial Number
	Not-present					

Status Clear

## 1.2.14 [IOU] Menu

The IOU menu includes the following menus for each IOU.

- [IOU#0] ~ [IOU#3]

The menu is not displayed for the IOU which is not installed.

Since the window and the operating method are same for each menu, only one menu is described here.

### ☐ [IOU#x] Window

[IOU#x] window displays the status of the IOU installed in IOU#x slot. In addition, IOU can be set.

FIGURE 1.26 [IOU#x] Window (1)

**FUJITSU** Model: PRIMEQUEST Active:MMB#1  
 Part Number: MCXXXXXXX  
 Serial Number:   
 Status: Normal

System Partition User Administration Network Configuration Maintenance Logout

>System >IOU >IOU#1

**IOU#1** Refresh Help

Click the Status Clear button to clear the status.

**Board Information**

Type	IOU_1GbE
Status	OK
Power Status	Standby
Part Number	<input type="text"/>
Serial Number	<input type="text"/>
Location LED	Off <input type="button" value="On"/> <input type="button" value="Off"/>

**On board LAN**

LAN#	MAC Address
0	Unknown
1	Unknown

**PCI\_Box connection**

PCI Slot#	Status	Connected to	
		PCI_Box#	Connector
2	OK	0	0
3	OK	0	1

**PCI-Express Slots**

PCI Slot#	Power Status	Slot Status	Link Width	Seg/Bus/Dev

PCI\_Box connection is available for PRIMEQUEST 2800E and 2400E.

FIGURE 1.27 [IOU#x] Window (2)

**Fujitsu** Model: PRIMEQUEST Active:MMB#1  
 Part Number: MCXXXXXXX  
 Serial Number:   
 Status: Normal

System Partition User Administration Network Configuration Maintenance Logout  
 >System >IOU >IOU#1

**IOU#1** Refresh Help

Click the Status Clear button to clear the status.

**Board Information**

Type	IOU_1GbE
Status	OK
Power Status	Standby
Part Number	
Serial Number	
Location LED	Off <input type="button" value="On"/> <input type="button" value="Off"/>

**On board LAN**

LAN#	MAC Address
0	Unknown
1	Unknown

**PCI\_Box connection**

PCI Slot#	Status	Connected to	
		PCI_Box#	Connector
2	OK	0	0
3	OK	0	1

**PCI-Express Slots**

PCI Slot#	Power Status	Slot Status	Link Width	Seg/Bus/Dev

The displays other than PCI\_Box connection do not depend on the model and are the same.

FIGURE 1.28 [IOU#x] Window (3)

**Fujitsu** Model: PRIMEQUEST Active:MMB#1  
 Part Number: MCXXXXXX  
 Serial Number:   
 Status: Normal

System Partition User Administration Network Configuration Maintenance Logout  
 >System >IOU >IOU#1

**IOU#1** Refresh Help

**PCI-Express Slots**

PCI Slot#	Power Status	Slot Status	Link Width	Seg/Bus/Dev
0	Standby	Not-present		
1	Standby	Not-present		
2	Standby	OK	Unknown	Unknown
3	Standby	OK	Unknown	Unknown

**PCIeSW**

PCIeSW	Status
PCIeSW#0	OK
PCIeSW#1	OK

**Voltage**

Sensor	Voltage	Threshold	
		Warning(Low/High)	Critical(Low/High)
P1.8VL	1.79 V	1.66/ 1.94 V	1.17/ 2.16 V
P1.0VL	0.99 V	0.92/ 1.08 V	0.65/ 1.20 V
P3.3V	3.30 V	3.04/ 3.56 V	1.96/ 3.96 V
P1.8V_PCIEX#0	1.80 V	1.66/ 1.94 V	1.17/ 2.16 V
P1.8V_PCIEX#1	1.79 V	1.66/ 1.94 V	1.17/ 2.16 V
P0.9V_PCIEX#0	0.90 V	0.82/ 0.98 V	0.58/ 1.08 V
P0.9V_PCIEX#1	0.89 V	0.82/ 0.98 V	0.58/ 1.08 V

Status Clear

TABLE 1.45 Display Items and Setting Items in [IOU#x] Window

Items	Description
<b>Board Information</b>	
Type	Displays types of IOUs. <ul style="list-style-type: none"> <li>IOU_10GbE</li> <li>IOU_1GbE</li> </ul>
Status	Displays status of the IOU <ul style="list-style-type: none"> <li>OK</li> <li>Not-present</li> <li>Warning</li> <li>Degraded</li> <li>Failed</li> </ul>
Power Status	Displays the power status of the IOU. <ul style="list-style-type: none"> <li>On</li> <li>Standby</li> </ul>
Part Number	Displays the part number of the IOU.
Serial Number	Displays the serial number of the IOU.
Location LED	Shows the display status of the Location LED. Following are the display status. <ul style="list-style-type: none"> <li>On: During ON</li> </ul>

Items	Description	
	<ul style="list-style-type: none"><li>Off: During OFF</li></ul> On/Off of the Location LED can be controlled by clicking [On], [Off] button.	
On board LAN		
LAN	Displays the LAN number.	
MAC Address	Displays the MAC Address for GbE that is being installed on the IOU. Displays “Unknown” when MAC Address is not clear.	
PCI_Box connection (PCI_Box connection is not displayed in the case of PRIMEQUEST 2800B)		
PCIC#	Displays PCIC# for PCI_Box connection on the IOU.	
Status	Displays the status of connection with the PCI_Box. <ul style="list-style-type: none"><li>OK</li><li>Not-connected</li><li>Incorrect connection</li></ul>	
Connected to	PCI_Box#	Displays the destination PCI_Box#. When not connected, background color is displayed in gray color.
	Connector	Displays the destination Connector number of PEXU. When not connected, background color is displayed in gray.
Connector	Displays the destination Connector number of the PEXU. When not connected, background color is displayed in gray.	
DU connection		
PCIC#	Displays PCIC# for DU connection on the IOU.	
Status	Displays the status of connection with the DU. <ul style="list-style-type: none"><li>OK</li><li>Not-connected</li><li>Incorrect connection</li></ul>	
Connector	Displays the destination Cconnector number of the DU. When not connected, background color is displayed in gray.	
PCI-Express Slots		
PCIC#	Displays the number of the PCI_Express slot.	
Power Status	Displays the power status of the IOU. <ul style="list-style-type: none"><li>On</li><li>Standby</li></ul>	
Slot Status	Displays the status of the PCI_Express slot. <ul style="list-style-type: none"><li>OK</li><li>Not-present</li><li>Failed</li><li>Disabled</li></ul>	
Link Width	Displays Link Width of PCI_Express slot format. <ul style="list-style-type: none"><li>x1</li><li>x2</li><li>x4</li><li>x8</li></ul>	
Seg/Bus/Dev	Displays Segment#, Bus#, Device# of PCI Device.	
Vendor ID	Displays the Vender ID of the PCI Card. Remarks: ID uniquely allocated in manufacturer of card. For details of the ID, see the PRIMEQUEST 2000 Series Administration Manual(C122-E175EN)	
Device ID	Displays the Device ID of the PCI Card. Remarks: ID uniquely allocated in device of manufacturer. For details of the ID, see the PRIMEQUEST 2000 Series Administration Manual(C122-E175EN)	
PCIeSW		
PCIeSW	Displays the number of PCIeSW.	
Status	Displays the status of PCIeSW.	



Items	Description
	<ul style="list-style-type: none"> <li>• OK</li> <li>• Warning</li> <li>• Failed</li> </ul>
Voltage	
Sensor	Displays the Voltage sensor type. P1.8VL(*1) P1.0VL(*1) P2.5VL(*2) P1.2VL(*2) P0.8VL(*2) P0.67VL(*2) P3.3V(*3) P1.8V_PCIEX#0(*1) P1.8V_PCIEX#1(*1) P1.8V(*2) P0.9V_PCIEX#0(*3) P0.9V_PCIEX#1(*3)  *1: IOUL,*2: IOUF,*3: IOUL/IOUF commonness
Voltage	Displays the current power voltage.
Threshold	Warning (Low/High) <div>             Lower and upper limits of the warning-level voltage.               Displays “ – ”, when the threshold is not set.              Displays the power voltage in the last two decimal places.           </div>
	Critical (Low/High) <div>             Lower and upper limits of the critical-level voltage.               Displays “ – ”, when the threshold is not set.              Displays the power voltage in the last two decimal places.           </div>

TABLE 1.46 Button of [IOB#x] Screen

Buttons	Description
On	Turns on the Location LED by clicking [On] button.
Off	Turns off the Location LED by clicking [Off] button
Status Clear	Clears the error status of IOU#x

When you click [Status Clear], the error message of the IOU gets cleared and it is possible to specify the IOU at the time of next reboot. If error is detected again at the time of reboot, the error status of the IOU gets registered once again.

(1) Menu Operation  
[System] – [IOU] – [IOU#x]

- (2) Window Operations
1. Click the [Status Clear] button.  
Confirmation dialogue box is displayed.
  2. Click the [Apply] button. Click the [OK] button to clear the error status and click the [Cancel] when you do not want to clear the error status of the IOU.

### [Message]

This section describes the messages to be displayed on this window.

Message Number	Message
I_00029	Status Clear completed.
E_00123	Failed to clear the status.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

## 1.2.15 [DU] Menu

In [DU#x] Window, the status of disk unit #x mounted in PRIMEQUEST 2000 series can be displayed and status of board can be controlled.

FIGURE 1.29 [DU#x] Window

Model: PRIMEQUEST 2800E  
Part Number: MCF3AC111  
Serial Number:   
Status: Normal

Active:MMB#0

System Partition User Administration Network Configuration Maintenance Logout

>System >DU >DU#0

System Status  
System Event Log  
Operation Log  
Partition Event Log  
System Information  
Firmware Information  
System Setup  
System Power Control  
LEDs  
Power Supply  
Fan  
Temperature  
SB  
IOU  
DU  
PCI\_Box  
OPL  
XNB

DU#0

Click the Status Clear button to clear the status.

Board Information

Status	OK
Power Status	On
Part Number	CA07683-1012
Serial Number	SQ1210MK00005

RAID Slot

RAID Slot#	Power Status	Slot Status	Link Width	Seg/Bus Dev
0	On	OK	x4	0:67:0
1	On	OK	x4	0:37:0

RAID Card

Slot#	Status	BBU Status	Vendor ID	Device ID	Physical Drives Count	Logical Drives Count	Serial Number	Firmware Version
0	OK	Not present	1000	005b	2	1	0000000041232910	23.9.0-0022
1	OK	Not present	1000	005b	2	1	0000000041232885	23.9.0-0022

Physical Drives

Status Clear

For a user without setting privileges, [Status Clear] button and 'Click the Status Clear button to clear the status.' Message will not be displayed.

TABLE 1.47 Display and Setting items of [DU#x] Window

Items	Description
Board Information	
Status	Displays the status of the disk unit. <ul style="list-style-type: none"> <li>OK</li> <li>Not-present</li> <li>Warning</li> <li>Degraded</li> <li>Failed</li> </ul>
Power Status	Displays the power status of the disk unit. <ul style="list-style-type: none"> <li>On</li> <li>Standby</li> </ul>
DU Part Number	Displays the part number of the disk unit. "-" is displayed whenever it Power OFFs it.
DU Serial Number	Displays the serial number of the disk unit. "-" is displayed whenever it Power OFFs it.
RAID Slot	



Items	Description	
RAID Slot	Power Status	Displays power status of the RAID slot. <ul style="list-style-type: none"><li>• On</li><li>• Standby</li></ul>
	Slot Status	Displays the status of the RAID Slot. <ul style="list-style-type: none"><li>• OK</li><li>• Not-present</li><li>• Failed</li><li>• Degraded</li></ul>
	Link Width	Displays the Link Width of the DU/RAID slot format. <ul style="list-style-type: none"><li>• x1</li><li>• x2</li><li>• x4</li><li>• x8</li></ul>
	Seg/Bus/Dev	Displays Segment#, Bus#, Device# of the DU/RAID Device.
RAID Slot#1	Same as RAID Slot#0.	
RAID Card		
Slot#	The slot number equipped with the RA identification card is displayed.	
BBU Status	The state of RAID BBU is displayed. <ul style="list-style-type: none"><li>• Online</li><li>• On Battery</li><li>• Charging</li><li>• Discharging</li><li>• Battery Low</li><li>• Relearn Required</li><li>• Failed</li><li>• Not-present</li></ul>	
Vendor ID	Vender ID of RAID Card is displayed. Remarks: ID uniquely allocated in manufacturer of card. For details of the ID, see the PRIMEQUEST 2000 Series Administration Manual(C122-E175EN)	
Device ID	Device ID of RAID Card is displayed. Remarks: ID uniquely allocated in device of manufacturer. For details of the ID, see the PRIMEQUEST 2000 Series Administration Manual(C122-E175EN)	
Physical Drives count	The number of physical drives connected with RAID Card is displayed.	
Logical Drives count	The number of logical drives composed under the control of RAID Card is displayed.	
Serial Number	The serial number of RAID Card is displayed.	
Firmware Version	The firmware version of RAID Card is displayed.	
Physical Drives		
Slot#	The slot number equipped with a physical drive is displayed.	
Status	The state of a physical drive is displayed. <ul style="list-style-type: none"><li>• Operational</li><li>• Available</li><li>• Failed</li><li>• Hot Spare</li><li>• Rebuilding</li><li>• SMART err</li></ul>	

Items	Description	
	<ul style="list-style-type: none"><li>Not-present</li></ul>	
Vendor	The vender of a physical drive is displayed.	
Model	The model name of a physical drive is displayed.	
Capacity	The capacity of a physical drive is displayed.	
RAID Card#	The slot number of RAID Card that connects a physical drive is displayed.	
Logical Drives		
Sensor#	The sensor number of a logical drive is displayed.	
Status	The state of a logical drive is displayed.	
Raid Level	The RAID level of a logical drive is displayed.	
Physical Drives assignment	The slot number of a physical drive that composes a logical drive is displayed.	
Missing drives count	The number of physical drives missed to compose a logical drive at the RAID level is displayed.	
RAID Action Progress		
Drive Type	The drive type that the RAID action is executed is displayed. <ul style="list-style-type: none"><li>Physical : Hardware RAID</li><li>Logical : Software RAID</li></ul>	
Slot#/Sensor#	Slot# from which the RAID action is executed is shown when Drive Type is Physical, and Sensor# from which the RAID action is executed is shown when Drive Type is Logical.	
Action	The RAID action under execution is displayed. <ul style="list-style-type: none"><li>Rebuilding : It is shown for a physical drive to execute the rebuild of the RAID drive.</li><li>MDC Running : It is shown for a logical drive to execute MDC(Make Data Consistent).</li></ul>	
Progress	The progress rate of the RAID action under execution is displayed by the percentage.	
Estimated time remaining (hh:mm:ss)	The remainder time that will be expected by the time the RAID action under execution is completed is displayed.	
Voltage		
Sensor	Displays the Voltage sensor type. 12V_DU_SLOT0 12V_DU_SLOT1	
Voltage	Displays the current power voltage.	
Threshold	Warning (Low/High)	Lower and upper limits of the warning-level voltage.  Displays “ – ”, when the threshold is not set. Displays the power voltage in the last two decimal places.
	Critical (Low/High)	Lower and upper limits of the critical-level voltage.  Displays “ – ”, when the threshold is not set. Displays the power voltage in the last two decimal places.

TABLE 1.48 Buttons on [DU#x] Window

Button	Description
Status Clear	Clears the error message of the disk unit

When the [Status Clear] button is clicked, the error status of the disk unit will be cleared and it can be specified so that the disk unit can be used again at the time of the next reboot. When an error is detected again at the time of re-boot, the error status of the disk unit would be recorded again.

(1) Menu Operation  
[System] – [DU] – [DU#x]

(2) Window Operations

1. Click the [Status Clear] button.  
A confirmation dialogue box is displayed.
2. Click the [OK] button to clear the error message and click the [Cancel] when you do not want to clear the error status of the disk unit.

**[Message]**

This section describes the messages to be displayed on this window.

Message Number	Message
I_00029	Status Clear completed.
E_00123	Failed to clear the status.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

## 1.2.16 [PCI\_Box] Menu

The PCI\_Box#x window displays the status of the PCI\_Box connected with the PRIMEQUEST 2000 series.

FIGURE 1.30 [PCI\_Box] Window (1)

The screenshot shows the MMB Web-UI interface. At the top, the Fujitsu logo is on the left, and system information is on the right: Model: PRIMEQUEST2800E, Part Number: MCXXXXXX, Serial Number: 000000001, Status: Normal. Below this is a navigation bar with tabs: System, Partition, User Administration, Network Configuration, Maintenance, and Logout. The main content area is titled '>System >PCI\_Box >PCI\_Box#0'. On the left is a sidebar menu with various system status options, including 'PCI\_Box' which is expanded to show 'PCI\_Box#0' and 'PCI\_Box#1'. The main area displays 'PCI\_Box#0' with a 'Refresh' and 'Help' button. Below this is a table of 'PCI\_Box Information' and a 'Power Supply' table. At the bottom right is a 'Status Clear' button.

Model: PRIMEQUEST2800E  
Part Number: MCXXXXXX  
Serial Number: 000000001  
Status: Normal

Active:MMB#0

System Partition User Administration Network Configuration Maintenance Logout

>System >PCI\_Box >PCI\_Box#0

System Status  
System Event Log  
Operation Log  
Partition Event Log  
System Information  
Firmware Information  
System Setup  
System Power Control  
LEDs  
Power Supply  
Fans  
Temperature  
SB  
IOU  
DU  
PCI\_Box  
PCI\_Box#0  
PCI\_Box#1  
OPL  
MMB

**PCI\_Box#0** Refresh Help

Click the Status Clear button to clear the status.

**PCI\_Box Information**

Status	OK
Power Status	On
Power Supply Redundancy	Redundant
Fan Speed Mode	Low
IO_PSU Fan Speed Mode	Low
Fan Redundancy	Redundant
Part Number	CA07608EAXXX
PEXU	Part Number CA07608-D001 08
	Serial Number PT13050445
Location LED	Off On Off

**Power Supply**

IO_PSU#	Status	Power Status	Part Number	Serial Number
0	OK	On	CA01022-0720/300-2193-11	EA12397292
1	OK	On	CA01022-0720/300-2193-11	EA12397293

Status Clear

FIGURE 1.31 [PCI\_Box] Window (2)

**FUJITSU** Model: PRIMEQUEST2800E Active:MMB#0  
 Part Number: MCXXXXXXX  
 Serial Number: 0000000001  
 Status: **Normal**

System Partition User Administration Network Configuration Maintenance Logout

>System >PCI\_Box >PCI\_Box#0

**PCI\_Box#0** Refresh Help

**Fan**

FAN#	Status	Fan speed	Threshold	
			Warning(Low/High)	Critical(Low/High)
IO_FAN#0	OK	- rpm	- / 8065	1516 / -
IO_FAN#1	OK	- rpm	- / 8065	1516 / -
IO_PSU#0_FAN	OK	1568 rpm	- / 7605	3077 / -
IO_PSU#1_FAN	OK	1568 rpm	- / 7605	3077 / -

**Temperature**

Sensor	Status	Temperature	Threshold	
			Warning(Low/High)	Critical(Low/High)
Inlet Temp.	OK	26°C	2/38°C	-/-°C

**Power Consumption**

Power Consumption(W)	140
----------------------	-----

**Airflow Volume**

Airflow Volume(m3/h)	160
----------------------	-----

**Cable Connection**

Status Clear

FIGURE 1.32 [PCI\_Box] Window (3)

**FUJITSU** Model: PRIMEQUEST2800E Active:MMB#0  
 Part Number: MCXXXXXXX  
 Serial Number: 0000000001  
 Status: **Normal**

System Partition User Administration Network Configuration Maintenance Logout

>System >PCI\_Box >PCI\_Box#0

**PCI\_Box#0** Refresh Help

**Cable Connection**

LNKC#	Status	Connected to	
		IOU#	PCIC#
0	OK	0	2
1	OK	1	2

**PCI-Express Slots**

PCIC#	Power Status	Slot Status	Link Width	Seg/Bus/Dev	Vendor ID	Device ID
0	On	OK	x1	0/113/0	12D8	E130
1	On	OK	x4	0/110/0	12D8	E130
2	On	OK	x1	0/101/0	12D8	E130
3	On	OK	x1	0/107/0	12D8	E130
4	On	OK	x1	0/104/0	12D8	E130
5	On	OK	x1	0/116/0	12D8	E130
6	Standby	OK	x4	0/28/0	12D8	E130
7	Standby	OK	x4	0/25/0	12D8	E130
8	Standby	OK	x1	0/16/0	12D8	E130
9	Standby	OK	x4	0/22/0	8086	1521
10	Standby	OK	x1	0/19/0	12D8	E130

Status Clear

FIGURE 1.33 [PCI\_Box] Window (4)

Model: PRIMEQUEST2800E  
 Part Number: MCXXXXXXX  
 Serial Number: 0000000001  
 Status: **Normal**

Active:MMB#0

System Partition User Administration Network Configuration Maintenance Logout

>System >PCI\_Box >PCI\_Box#0

System Status  
 System Event Log  
 Operation Log  
 Partition Event Log  
 System Information  
 Firmware Information  
 System Setup  
 System Power Control  
 LEDs  
 Power Supply  
 Fans  
 Temperature  
 SB  
 IOU  
 DU  
 PCI\_Box  
 PCI\_Box#0  
 PCI\_Box#1  
 OPL  
 MMB

### PCI\_Box#0

Refresh Help

#	Chip	Status
0	PCIeSW	OK
1	PCIeSW	OK

### Voltage

Sensor	Voltage	Threshold	
		Warning(Low/High)	Critical(Low/High)
P3.3V#0	3.30 V	3.06/ 3.54 V	2.14/ 3.98 V
P1.8V_PCIEX#0	1.80 V	1.67/ 1.93 V	1.16/ 2.17 V
P0.9V_PCIEX#0	0.90 V	0.83/ 0.97 V	0.58/ 1.09 V
P0.9VA_PCIEX#0	0.90 V	0.83/ 0.97 V	0.58/ 1.09 V
P3.3V#1	3.30 V	3.06/ 3.54 V	2.14/ 3.98 V
P1.8V_PCIEX#1	1.80 V	1.67/ 1.93 V	1.16/ 2.17 V
P0.9V_PCIEX#1	0.90 V	0.83/ 0.97 V	0.58/ 1.09 V
P0.9VA_PCIEX#1	0.90 V	0.83/ 0.97 V	0.58/ 1.09 V
P12V	12.41 V	11.15/12.87 V	7.79/14.45 V

Status Clear

TABLE 1.49 Display Items of [PCI\_Box#x] Window

Items	Description
PCI_Box Information	
Status	Displays the status of the PCI_Box. <ul style="list-style-type: none"> <li>OK</li> <li>Not-present</li> <li>Warning</li> <li>Degraded</li> <li>Failed</li> </ul>
Power Status	Displays the power status of the PCI_Box. <ul style="list-style-type: none"> <li>On</li> <li>Standby</li> </ul>
Power Supply Redundancy	Displays the redundancy status of the IO_PSU <ul style="list-style-type: none"> <li>Redundant</li> <li>Non-redundant: Sufficient Resources</li> </ul>
Fan Speed Mode	Displays the rpm status of the fan. <ul style="list-style-type: none"> <li>Low</li> <li>Normal</li> <li>High</li> <li>Full</li> </ul>
IO_PSU Fan Speed Mode	Displays the IO_PSU Fan Speed Mode <ul style="list-style-type: none"> <li>Low</li> <li>Normal</li> <li>High</li> <li>Full</li> </ul>
Fan Redundancy	Displays the redundancy status of the fan. <ul style="list-style-type: none"> <li>Redundant</li> </ul>

Items		Description
		<ul style="list-style-type: none"> <li>Non-redundant: Sufficient Resources</li> </ul>
Part Number		Displays the part number of the PCI_Box.
PEXU	Part Number	Displays the part number of the PEXU.
	Serial Number	Displays the serial number of the PEXU.
Location LED		Displays the status of the Location LED. The following are the various display statuses. <ul style="list-style-type: none"> <li>On: Turn On</li> <li>Off: Turn Off</li> </ul> On/ Off/ of the Location LED can be controlled by clicking the [On], [Off] buttons.
Power Supply		
IO_PSU#		IO_PSU# Displays the IO_PSU number.
Status		Displays the display status of the IO_PSU. <ul style="list-style-type: none"> <li>OK</li> <li>Not-present</li> <li>Failed</li> <li>A/C Lost</li> <li>Configuration error</li> </ul>
Power Status		Displays the power status of the IO_PSU. <ul style="list-style-type: none"> <li>On</li> <li>Standby</li> </ul>
Part Number		Displays the part number of the IO_PSU.
Serial Number		Displays the serial number of the IO_PSU.
Fan		
Fan#		Displays the fan number.
Status		Displays the status of the fan. <ul style="list-style-type: none"> <li>OK</li> <li>Not-present</li> <li>Failed</li> </ul>
Fan speed		Displays the rpm of the fan.
Threshold		Displays the threshold of the fan.
Temperature		
Sensor		Displays the ID of the temperature sensor.
Status		Displays the status of temperature sensor.
Temperature		Displays the current temperature.
Threshold		Displays the threshold at which each temperature sensor is maintained <ul style="list-style-type: none"> <li>Warning: Low/High</li> <li>Critical: Low/High</li> </ul>
Power Consumption		
Power Consumption		Displays the power consumption.
Airflow Volume		
Airflow Volume		Displays the airflow volume.
Cable Connection		
LNKC#		Displays the Link Card number.
Status		Displays the connection status of the cable. <ul style="list-style-type: none"> <li>OK</li> <li>Not-connected</li> <li>ncorrect connection</li> </ul>
Connect to	IOU#	Displays the connection destination IOU#. When not connected, the display is grayed out.
	PCIC#	Displays the PCI Slot# of the connection destination IOU. When not connected, the display is grayed out.
PCI-Express Slots		
PCIC#		Displays the PCI-Express slot number.

Items		Description
Power Status		Displays the power status of the GPCI-Express slot. <ul style="list-style-type: none"> <li>On</li> <li>Standby</li> </ul>
Slot Status		Displays the status of PCI-Express slot. <ul style="list-style-type: none"> <li>OK</li> <li>Not-present</li> <li>Failed</li> <li>Disabled</li> </ul>
Link Width		Displays the Link Width of the PCI-Express slot format. <ul style="list-style-type: none"> <li>x1</li> <li>x2</li> <li>x4</li> <li>x8</li> </ul>
Seg/Bus/Dev		Displays the Segment#, Bus# and Device# of the PCI-Express slot.
Vendor ID		Displays the Vendor ID of the PCI Card. Remarks: ID uniquely allocated in manufacturer of card. For details of the ID, see the PRIMEQUEST 2000 Series Administration Manual(C122-E175EN)
Device ID		Displays the Device ID of the PCI Card. Remarks: ID uniquely allocated in device of manufacturer. For details of the ID, see the PRIMEQUEST 2000 Series Administration Manual(C122-E175EN)
Chipset		
#		Displays the Chipset number.
Chip		Displays the Chip name <ul style="list-style-type: none"> <li>PCIeSW</li> </ul>
Status		Displays the status. <ul style="list-style-type: none"> <li>OK</li> <li>Warning</li> <li>Failed</li> </ul>
Voltage		
Sensor		Displays the Voltage sensor type. P3.3V#0 P1.8V_PCIEX#0 P0.9V_PCIEX#0 P0.9VA_PCIEX#0 P3.3V#1 P1.8V_PCIEX#1 P0.9V_PCIEX#1 P0.9VA_PCIEX#1
Voltage		Displays the current power voltage.
Threshold	Warning(Low/High)	Lower and upper limits of the warning-level voltage.  Displays “ – ”, when the threshold is not set. Displays the power voltage in the last two decimal places.
	Critical(Low/High)	Lower and upper limits of the critical-level voltage.  Displays “ – ”, when the threshold is not set. Displays the power voltage in the last two decimal places.

TABLE 1.50 [MMB#x] Window button

Buttons	Description
On	The Location LED lights up when the [On] button is clicked.
Off	The Location LED light out when the [Off] button is clicked.
Status Clear	The error status of PCI_Box is cleared.

- (1) Menu Operation  
[System] – [PCI\_Box] – [PCI\_Box#x]
- (2) Window Operations
- Click the [Status Clear] button.  
Clear the error status of the PCI\_Box.

**[Message]**

This section describes the messages to be displayed on this window.

Message Number	Message
I_00029	Status Clear completed.
E_00123	Failed to clear the status.

For details on the messages displayed on the window, see [PRIMEQUEST 2800 Series Message Reference](#) (C122-E178EN).

## 1.2.17 [OPL] Window

[OPL] Window has the following windows.

### ☐ [OPL] Window

The OPL Board status is displayed in the [OPL] Window.

FIGURE 1.34 [OPL] window

Model: PRIMEQUEST 2800E  
Part Number: MCXXXXXX  
Serial Number: [redacted]  
Status: Normal

Active:MMB#0

System Partition User Administration Network Configuration Maintenance Logout

>System >OPL

☐ System Status  
☐ System Event Log  
☐ Operation Log  
☐ Partition Event Log  
☐ System Information  
☐ Firmware Information  
☐ System Setup  
☐ System Power Control  
☐ LEDs  
☐ Power Supply  
☐ Fans  
☐ Temperature  
☐ SB  
☐ IOU  
☐ DU  
☒ OPL  
☐ MMB

**OPL**

Click the Status Clear button to clear the status.

Board Information

Status	OK
Power Status	On
Part Number	CA07130-TEST
Location LED	Off <input type="button" value="On"/> <input type="button" value="Off"/>



[Status Clear] button and 'Click the Status Clear button to clear the status.' Message is not be displayed for a user without the setting privilege.

TABLE 1.51 Display items of [OPL] Window

Items	Description
Status	Displays the status of the OPL. <ul style="list-style-type: none"> <li>• OK</li> <li>• Not-present</li> <li>• Warning</li> <li>• Degraded</li> <li>• Failed</li> </ul>
Power Status	Displays the Ppower status of the OPL. <ul style="list-style-type: none"> <li>• On</li> <li>• Standby</li> </ul>
Location LED	Displays the status of the Location LED. Following are the various display status. <ul style="list-style-type: none"> <li>• On: Lighting</li> <li>• Off: Light out</li> </ul> On/ Off of the Location LED can be controlled by clicking the [On], [Off] buttons.
Part Number	Displays the part number of the OPL.

TABLE 1.52 Button on [OPL] window

Button	Description
Part Number	Clears the error status of the OPL.

**[Message]**

This section describes the messages to be displayed on this window.

Message Number	Message
I_00029	Status Clear completed.
E_00123	Failed to clear the status.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference \(C122-E178EN\)](#).

(1) Menu Operation  
 [System] – [OPL]

(2) Window Operations

1. Click the [Status Clear] button.  
 Confirmation dialogue box is displayed.
2. Click the [OK] button to clear the error message and click the [Cancel] when you do not want to clear the error status of OPL.

## 1.2.18 [MMB] Menu

In [MMB] menu, each MMB Unit has menu.

- [MMB#0] ~ [MMB#1]

Since the window and the operation method are the same in all menus units, of only one unit is described here.

### ☐ [MMB#x] Window

In [MMB#x] Window, information related to MMB can be displayed and the Location LEDs can be set.

FIGURE 1.35 [MMB#x] Window

**Fujitsu** Model: PRIMEQUEST2800E Active:MMB#0  
 Part Number: MCXXXXXX  
 Serial Number: 0000000002  
 Status: Normal

System Partition User Administration Network Configuration Maintenance Logout

>System >MMB >MMB#0

**MMB#0**

Click the Apply Button to apply all changes.

Status	OK
Role	Active
Part Number	CA07603-D051 A1
Serial Number	PP124403JL
MAC Address	User port: 2C:D4:44:F0:8DF8
	Maintenance port: 2C:D4:44:F0:13:4A
Firmware Version	0.08
Location LED	Off <input type="checkbox"/> On <input type="checkbox"/> Off <input type="checkbox"/>
Reset MMB	<input type="checkbox"/> Reset the MMB All existing network connections will be lost. You will need to login again.
Enable/Disable	<input checked="" type="radio"/> Enable <input type="radio"/> Disable

**Voltage**

Sensor	Voltage	Threshold	
		Warning(Low/High)	Critical(Low/High)
+3.3VL	3.31 V	3.00/ 3.57 V	2.12/ 3.96 V
+1.5VL	1.48 V	1.37/ 1.62 V	0.97/ 1.80 V
+1.5VL_C	1.48 V	1.37/ 1.62 V	0.97/ 1.80 V
+1.2VL	1.21 V	1.10/ 1.30 V	0.78/ 1.40 V
+1.0VL	1.00 V	0.92/ 1.08 V	0.65/ 1.20 V
+0.75VL	0.76 V	0.69/ 0.81 V	0.48/ 0.90 V
+12V_IN	0.00 V	-/- 2.98 V	-/- V

Apply Cancel

TABLE 1.53 Display of [MMB#x] Window / setting items

Items		Description
Board Information		
Status	Displays the status of the MMB. <ul style="list-style-type: none"> <li>• OK</li> <li>• Not-present</li> <li>• Warning</li> <li>• Degraded</li> <li>• Failed</li> </ul>	
Role	Displays the operation status of the MMB. <ul style="list-style-type: none"> <li>• Active</li> <li>• Standby</li> <li>• Disabled</li> </ul>	
Part Number	Displays part number of the MMB.	
Serial Number	Displays the serial number of the MMB.	
MAC address	User port	Displays MAC address of the MMB management port. 00:00:00:00:00:00
	Maintenance Port	Displays MAC address of the MMB port. 00:00:00:00:00:00
Location LED	Displays the status of the Location LED. The following are the various display status. <ul style="list-style-type: none"> <li>• On: During power on.</li> <li>• Off: During power off</li> </ul>	

Items		Description
		On/ Off of the Location LED can be controlled by clicking [On], [Off] buttons.
Reset MMB		Resets the MMB if this check box is checked. When this check box is checked, [Switch Over to MMB] mentioned below cannot be set.
Switch Over to MMB		Switches the Active/Standby of the MMB if this check box is checked. When this check box is checked, [Reset MMB] mentioned above cannot be set. <b>Remarks</b> This check box is displayed only, when two MMBs are mounted.
Enable/Disable MMB		Controls Enable/ Disable of the MMB. Because this item is a facility used for testing, it is not possible to usually set it.
Voltage		
Sensor		Displays the Voltage sensor type. P3.3VL P1.5VL P1.5VL_CPLD P1.2VL P1.0VL P0.75VL
Voltage		Displays the current power voltage.
Threshold	Warning (Low/High)	Lower and upper limits of the warning-level voltage.  Displays “ – ”, when the threshold is not set. Displays the power voltage in the last two decimal places.
	Critical (Low/High)	Lower and upper limits of the critical-level voltage.  Displays “ – ”, when the threshold is not set. Displays the power voltage in the last two decimal places.

TABLE 1.54 [MMB#x] Window button

Buttons	Description
On	Turns on the Location LED when the [On] button is clicked.
Off	Turns off the Location LED when the [Off] button is clicked
Apply	Click the [Apply] button to set the specified control information.
Cancel	Click the [Cancel] button to restore the original information and not set the specified information.

(1) Menu Operation  
[System] – [MMB] – [MMB#x]

(2) Window Operations  
Confirmation dialogue box is displayed. Specify the information which shows the change in MMB status, click the [Apply] button. Sets the information which shows the change in MMB status.

#### [Message]

This section describes the messages to be displayed on this window.

Message Number	Message
I_00013	Setting completed.
I_00052	MMB switch processing has started.
I_00095	The standby MMB is rebooting now. Please wait several minutes.
E_00100	Failed to set the LED
E_00125	Failed to switch over to another MMB.
E_00125	Failed to change Enable/Disable status of the MMB.
E_00125	Failed to reset the MMB.
I_00213	%aa cannot be executed because the system is under maintenance.
I_00467	The reboot is done. Login after a while.
W_00413	Nothing is selected.

Message Number	Message
I_00013	Setting completed.
I_00052	MMB switch processing has started.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

## 1.2.19 [Disk Enclosure] Menu

The [Disk Enclosure#x] Window displays the state of Disk Enclosure and the disk connected with PRIMEQUEST 2000 series. When Disk Enclosure is connected with IOU or PCI-BOX, it is displayed in the menu.

FIGURE 1.36 [Disk Enclosure#x] Window (1)

The screenshot displays the MMB Web-UI interface for the [Disk Enclosure#0] window. At the top, the Fujitsu logo is on the left, and system information (Model: PRIMEQUEST2800E, Part Number: MCXXXXXX, Serial Number: [REDACTED], Status: Warning) is on the right. A red navigation bar contains links for System, Partition, User Administration, Network Configuration, Maintenance, and Logout. Below this, a breadcrumb trail shows the path: >System >Disk Enclosure >Disk Enclosure#0.

A left-hand navigation menu lists various system components, with 'Disk Enclosure#0' highlighted in green. The main content area is titled 'Disk Enclosure#0' and includes a 'Refresh' and 'Help' button. It contains several data sections:

- Disk Enclosure Information:** A table showing Status (Warning), Location (PCI\_Box#3-PCIC#11-Port#1-Cascade#0), and Location LED (On/Off).
- Temperature:** A table with columns for Sensor, Status, Temperature, and Threshold (Warning/Critical). It shows RAID Ctrl Temp. at 52 C (OK) and RAID BBU Temp. as Not-present.
- RAID Card:** A table with columns for BBU Status, Vendor ID, Device ID, Physical Drives Count, Logical Drives Count, Serial Number, and Firmware Version. It shows a Not-present BBU, Vendor ID 1000, Device ID 005b, 0 physical drives, 0 logical drives, Serial Number SV225P2246, and Firmware Version 23.9.0-0028.
- Physical Drives:** A table with columns for Slot#, Status, Vendor, Model, and Capacity. It shows slots 0, 1, 2, and 3, all with a status of 'Not-present'.

FIGURE 1.37 [Disk Enclosure#x] Window (2)

Model: PRIMEQUEST2800E  
Part Number: MCXXXXXXX  
Serial Number: [REDACTED]  
Status: **Warning**

Active:MMB#0

System Partition User Administration Network Configuration Maintenance Logout

>System >Disk Enclosure >Disk Enclosure#0

**Disk Enclosure#0** Refresh Help

**Logical Drives**

Sensor#	Status	RAID Level	Physical Drives assignment	Missing drives Count
-	-	-	-	-

**RAID Action Progress**

Drive Type	Slot#/Sensor#	Action	Progress	Estimated time remaining (hh:mm:ss)
-	-	-	-	-

**Expander**

Expander#	Status
0	OK

**PSU**

PSU#	Status
0	OK
1	OK

**Fans**

FAN#	Status
0	OK
1	OK
2	Failed
3	Failed

TABLE 1.55 Display and Setting items of [Disk Enclosure#x] Window

Items	Description
<b>Disk Enclosure Information</b>	
Status	Displays the status of the Disk Enclosure. <ul style="list-style-type: none"> <li>• OK</li> <li>• Warning</li> <li>• Failed</li> </ul>
Location	Displays the location where Disk Enclosure is connected.
Location LED	Displays the status of the Location LED. Following are the various display status. <ul style="list-style-type: none"> <li>• <input type="checkbox"/> On: Lighting</li> <li>• <input type="checkbox"/> Off: Light out</li> </ul> On/ Off of the Location LED can be controlled by clicking the [On], [Off] buttons.
Status	Displays the status of each temperature sensor. <ul style="list-style-type: none"> <li>• OK</li> <li>• Not-present</li> <li>• Warning</li> <li>• Critical</li> </ul>
Temperature	Displays the temperature of each temperature sensor.
Threshold	Displays the threshold which maintained the by each temperature sensor. <ul style="list-style-type: none"> <li>• Warning: Low/High</li> <li>• Critical :Low/High</li> </ul>
<b>RAID Card</b>	
BBU Status	The state of RAID BBU is displayed. <ul style="list-style-type: none"> <li>• Online</li> </ul>

Items	Description
	<ul style="list-style-type: none"> <li>On Battery</li> <li>Charging</li> <li>Discharging</li> <li>Battery Low</li> <li>Relearn Required</li> <li>Failed</li> <li>Not-present</li> </ul>
Vendor ID	Vender ID of RAID Card is displayed. Remarks: ID uniquely allocated in manufacturer of card. For details of the ID, see the PRIMEQUEST 2000 Series Administration Manual(C122-E175EN)
Device ID	Device ID of RAID Card is displayed. Remarks: ID uniquely allocated in device of manufacturer. For details of the ID, see the PRIMEQUEST 2000 Series Administration Manual(C122-E175EN)
Physical Drives count	The number of physical drives connected with RAID Card is displayed.
Logical Drives count	The number of logical drives composed under the control of RAID Card is displayed.
Serial Number	The serial number of RAID Card is displayed.
Firmware Version	The firmware version of RAID Card is displayed.
Physical Drives	
Slot#	The slot number equipped with a physical drive is displayed.
Status	The state of a physical drive is displayed. <ul style="list-style-type: none"> <li>Operational</li> <li>Available</li> <li>Failed</li> <li>Hot Spare</li> <li>Rebuilding</li> <li>SMART err</li> <li>Shielded</li> <li>Bad Block</li> <li>Not-present</li> </ul>
Vendor	The vender of a physical drive is displayed.
Model	The model name of a physical drive is displayed.
Capacity	The capacity of a physical drive is displayed.
Temperature	The temperature of a physical drive is displayed.
Logical Drives	
Sensor#	The sensor number of a logical drive is displayed.
Status	The state of a logical drive is displayed.
Raid Level	The RAID level of a logical drive is displayed.
Physical Drives assignment	The slot number of a physical drive that composes a logical drive is displayed.
Missing drives count	The number of physical drives missed to compose a logical drive at the RAID level is displayed.
RAID Action Progress	
Drive Type	The drive type that the RAID action is executed is displayed. <ul style="list-style-type: none"> <li>Physical : Hardware RAID</li> <li>Logical : Software RAID</li> </ul>

Items	Description
Slot#/Sensor#	Slot# from which the RAID action is executed is shown when Drive Type is Physical, and Sensor# from which the RAID action is executed is shown when Drive Type is Logical.
Action	The RAID action under execution is displayed. <ul style="list-style-type: none"><li>Rebuilding : It is shown for a physical drive to execute the rebuild of the RAID drive.</li><li>MDC Running : It is shown for a logical drive to execute MDC(Make Data Consistent).</li></ul>
Progress(%)	The progress rate of the RAID action under execution is displayed by the percentage.
Estimated time remaining (hh:mm:ss)	The remainder time that will be expected by the time the RAID action under execution is completed is displayed.
Expander	
Expander#	The number of the expander is displayed.
Status	Displays the status of the Expander. <ul style="list-style-type: none"><li>OK</li><li>Warning</li><li>Failed</li><li>Not-Present</li></ul>
PSU	
PSU#	The number of the exp PSU ander is displayed.
Status	Displays the status of the PSU. <ul style="list-style-type: none"><li>OK</li><li>Warning</li><li>Failed</li><li>Not-Present</li></ul>
Fans	
FAN#	The number of the Fan is displayed.
Status	Displays the status of the Fan. <ul style="list-style-type: none"><li>OK</li><li>Warning</li><li>Failed</li><li>Not-Present</li></ul>

## 1.3 [Partition] Menu for PRIMEQUEST 2400E/2800E

Status display and partition settings of PRIMEQUEST 2400E and PRIMEQUEST 2800E can be done on [Partition] Menu.

This menu is not displayed in PRIMEQUEST 2800B.

### 1.3.1 [Power Control] Window

[Power Control] window displays the power control of the partition.

Only the partition having the SB and IOU is displayed in this window.

The display window and display conditions are different depending on the model of PRIMEQUEST 2400E or PRIMEQUEST 2800E.

The partition that satisfies the following conditions is displayed in the correction.

- (1) Partition with at least one SB, and
- (2) Partition with at least one IOU, and

#### Remarks

When the operating system supports ACPI (Advanced Configuration and Power Interface), the power can be turned Off after the operating system is Shutdown by Power Off operation. If ACPI is not supported, power can be Off without the Shutdown of the operating system. Moreover, even if the operating system supports ACPI, and applications running on the operating system are not supported, sometimes power Off is not possible. Since these depend on the specifications of the operating system and applications, for details, refer to the operating system and application specifications.



FIGURE 1.38 [Power Control] Window

Model: PRIMEQUEST2800E  
Part Number: MCXXXXXX  
Serial Number: 00000000  
Status: Normal

Active:MMB#0

System Partition User Administration Network Configuration Maintenance Logout

>Partition >Power Control

Power Control

Refresh Help

Select a Power Control option for one or more partitions, then click the Apply button to take effect.

#	Partition Name	Power Status	System Progress	Power Control	Force Power Off Delay
0	hayashi	Standby	Power Off	(Not specified)	<div>Boot Selector</div> <div><input type="checkbox"/> min</div> <div>No Override</div>
1	take	Standby	Power Off	(Not specified)	<div>Boot Selector</div> <div><input type="checkbox"/> min</div> <div>No Override</div>

Apply Cancel

- In case of Partition Operator privilege (In case of management target Partition#0)  
Operations can be performed only for a partition which is targeted for management.  
When it is not targeted for management, Pull-down Menu and the setting items are displayed as gray out.

FIGURE 1.39 [Power Control] Window (Grayout Display)

Model: PRIMEQUEST2800E  
Part Number: MCXXXXXX  
Serial Number: J000400010  
Status: Normal

Active:MMB#0

System Partition User Administration Network Configuration Logout

>Partition >Power Control

Power Control

Select a Power Control option for one or more partitions, then click the Apply button to take effect.

#	Partition Name	Power Status	System Progress	Power Control	Force Power Off Delay
0	hayashi	Standby	Power Off	[Not specified]	Boot Selector <input type="checkbox"/> min No Override
1	take	Standby	Power Off	[Not specified]	Boot Selector <input type="checkbox"/> min No Override

Apply Cancel

1. Select the process executed for the partition from Pull-down menu of [Power Control]. Then, click the [Apply] button. Dialog box for confirmation appears.
2. Click the [OK] button to execute the process. Click the [Cancel] button to cancel the process.

When Partition Power is On, or when Power is Off, and when the specified control is failed, Warning dialog box appears.

When the CPU mounted on the SB of partition is not matched at the time of specifying the Power On of partition, Warning dialog box appears. Error occurs in the Power On operation.

TABLE 1.56 Display Items and Set Items of [Power Control] Window

Items	Description
#	Displays the number by which the partition is identified. [In case of the PRIMEQUEST 2800E model] There are 0-3 Partitions. However, only the partitions with SB and IOU registration are displayed.
P#	Displays only In case of the PRIMEQUEST 2800E model.
Partition Name	Displays the name of the Partition.
Power Status	Displays the Power Status of the Partition. <ul style="list-style-type: none"> <li>• On</li> <li>• Standby</li> </ul>
System Progress	The status of the partition progress is displayed. <ul style="list-style-type: none"> <li>• Power Off: The partition power is off.</li> <li>• Power On In Progress: Partition power on is in process.</li> <li>• Reset: The status of the partition from the beginning of reset till the completion of the operating system boot.</li> </ul>

Items	Description
	<ul style="list-style-type: none"> <li>• EFI: The UEFI menu screen is displayed.</li> <li>• Boot: Operating system is being booted.</li> <li>• Operating system Running: Operating system running state</li> <li>• Operating system Shutdown: Operating system shutting down.</li> <li>• Panic: Panic (Only in RHEL)</li> <li>• Power Off In Progress: Partition power off is in process.</li> <li>• Fatal: Stopped.</li> <li>• Dumping: The dumping is being output.</li> <li>• Halt: Halting.</li> <li>• Stop Error: Stop error. (Only in Windows)</li> </ul> <p><b>Remarks</b></p> <ul style="list-style-type: none"> <li>• When SVAS (Server View Agentless Service) is not installed to partition, the display is not switched over in 'Operating system Running' even if Operating system is working. Moreover, for 'Operating system shutdown', 'Panic' commanded by SVAS if SVAS is not installed, there is no display. SVAS : Specifies the piece of software running on the OS in managed nodes to help BMC with management. Unless SVAgent, it does not provide management interface to the outside.</li> </ul>
Power Control	<p>Selects power control specified for the partition. However, for the partition which is already in power-on state, [Power On] is not displayed. On the contrary, for the partition which is already in powered off, [Power Off], [Reset], [NMI], [Power Cycle], [Force Power Off] and [sadump] are not displayed.</p> <ul style="list-style-type: none"> <li>• Power On: Partition is the powered on.</li> <li>• Power Off: Partition is powered off. From the view point of Operating system, it is same as that the power button of the device is on. Therefore, when the operating system supports the ACPI, power can be turned off after the operating system is shutdown. For details, see Power Specifications (ACPI) of the operating system. When the operating system does not support the ACPI, the power can be turned off without shutting down the operating system.</li> <li>• Power Cycle: Powered on again after the partition is forcibly powered on.</li> <li>• Reset: Resets the partition.</li> <li>• NMI: Produces the NMI interruption for the partition.</li> <li>• Force Power Off: Turns off the power forcefully.</li> <li>• sadump: Specifies the SADUMP for the partition.</li> <li>• (Not specified): There is no instruction for this partition.</li> </ul>
Force Power Off Delay	<p>Specifies whether to enforce power off, when power off is done without proper operation of the shutdown instruction for the operating system by [Power Off] on the partition. In case enforced power off has been specified, the specified time (1~9 minutes) can be set. The partition is forcibly powered off when the specified time has lapsed. The default setting of check box is Off.</p>
Boot Selector	<p>Specifies the boot device for which the Boot Manager setting of BIOS is Override temporarily. Select the device to be boot from pull-down menu.</p> <ul style="list-style-type: none"> <li>• No Override: Boots by the EFI Boot Manager settings.</li> <li>• Force boot into EFI Boot Manager: Waiting for input by the EFI Boot Manager. Boot by selecting the boot device from the EFI Boot Manager</li> <li>• Force PXE/iSCSI: Overrides the EFI Boot Manager settings, forcibly tries the PXE.</li> <li>• Force boot from DVD: Overrides the EFI Boot Manager settings, and forcibly tries the booting from the System DVD.</li> </ul>

Items	Description
	Default setting is 'No Override'. This setting is applied only for the first partition boot setting the value. After the partition boots, this setting automatically returns to 'No Override'. Therefore, it is necessary to set the boot for each partition. In case of constant setting, it is set in the Boot Manager of the UEFI.

TABLE 1.57 [Power Control] Window Buttons

Buttons	Description
Apply	When you click the [Apply] button, the information of power control items is set. Confirm the setting contents if dialog box prompts for Confirmation.
Cancel	When you click the [Cancel] button, returns to source without setting the information of power control items corresponding to partition,.

**Remarks**

When the operating system supports the ACPI, the operating system can be shutdown by the above mentioned Power Off operation and the power can be turned off. When the operating system is not supported by the ACPI, the power is turned off without shutting down the operating system. Moreover, when the application which is operating in the operating system is not supported even if the operating system is supported by the ACPI, the power cannot be turned off. Since this is according to the operating system and application specifications, for details, see the Operating System and Application Manual.

**❑ “Error Display”**

Even if there is no bootable partition configured, the window mentioned below appears.

FIGURE 1.40 Display of Errors of [Power Control] Window

**FUJITSU** Model: PRIMEQUEST 2800E Active:MMB#0  
Part Number: MCF3AC111  
Serial Number:   
Status: Normal

System Partition User Administration Network Configuration Maintenance Logout

>Partition >Power Control

☒ Power Control  
☐ Schedule  
☐ Console Redirection Setup  
☐ Partition Configuration  
☐ Reserved SB Configuration  
☐ Partition#3

**Power Control** Refresh Help

Select a Power Control option for one or more partitions, then click the Apply button to take effect.

#	Partition Name	Power Status	System Progress	Power Control	Force Power Off Delay	Boot Selector
There are no partitions configured.						

Apply Cancel

(1) Menu Operation  
[Partition] – [Power Control]

## (2) Window Operations

1. Click the [Status Clear] button. Selects the power control items related to each partition from the pull-down list of [Power Control]. Then click the [Apply] button.  
Dialog box for setting confirmation appears.
2. Click [OK] button to execute the settings.

**[Message]**

This section describes the messages to be displayed on this window.

Message Number	Message
E_00075	Partition#aa cannot execute sadump
E_00077	Partition#aa cannot execute Power On.
E_00078	Partition#aa cannot execute Power Off.
E_00079	Partition#aa command failed
E_00080	Partition#%aa cannot execute Power Cycle.
E_00081	Partition#%aa cannot execute Reset.
E_00082	Partition#%aa cannot execute NMI.
E_00084	Partition#%aa cannot execute Force Power Off.
E_00091	Force Power Off Delay setting failed.
E_00101	Unable to power on the partition#%aa due to CPU mismatch between SBs.
I_00214	Unable to Power On the Partition#%aa because this Partition is under maintenance.
I_00222	Unable to %aa the Partition#%aa because this Partition is under maintenance.
E_00422	Unable to power on the partition#%aa due to CPU composition abnormal.
E_00154	Unable to power on due to mismatch between supply voltage and input voltage.
E_00482	Unable to power on the partition#%aa due to DIMM composition abnormal.
E_00491	Unable to power on the partition#%aa due to DIMM does not satisfy requirements of Mirror Mode.
W_00504	The Power On failed, because of switching the Home SB. Please execute it after a while again.
E_00517	Unable to power on the partition#%d due to abnormal SB composition.
E_00522	Unable to power on the partition#%d due to abnormal VRM composition.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

## 1.3.2 [Schedule] Menu

The [Schedule] menu has the [Schedule Control] and [Schedule List] windows. This section describes the windows and the operation.

**Note**

As mentioned below, there may be a delay in the time recorded in SEL compared to the time reserved for scheduled operations.

- After checking the configuration and after performing the start up preparation process, it takes some time until the power is ON. In this case, the SEL display is delayed about from six seconds up to 8 seconds than the time reserved for the scheduled operations.
- The shutdown instructions from MMB to OPERATING SYSTEM take certain time from the set time. However, the following interval times may be changed under the various conditions like setting and the configuration.
- Interval time until shutdown instructions reaches OS from MMB.
- Interval time until MMB notifies SEL begin shutdown after OS begins shutdown.
- Even if the [Power on Delay] is 0 seconds, it takes about 30 seconds ~ 70 seconds from starting the power on up to the reset.

### ☐ [Schedule Control] window

In the [Schedule Control] window, the setting related to the schedule can be set for each partition.

FIGURE 1.41 [Schedule Control] Window

Model: PRIMEQUEST2800E  
Part Number: MCXXXXXX  
Serial Number: 7000-10000-0  
Status: Normal

Active:MMB#0

System Partition User Administration Network Configuration Maintenance Logout

>Partition >Schedule >Schedule Control

**Schedule Control**

Select Schedule Control for each partition then click the Apply button to take effect.

#	Partition Name	Schedule Control	Number of schedules
0	hayashi	<input type="radio"/> On <input checked="" type="radio"/> Off	0
1	take	<input type="radio"/> On <input checked="" type="radio"/> Off	0

Apply Cancel

If the maintenance work (Either Hot Partition Maintenance, Warm System Maintenance or Cold System Maintenance) of the targeted partition is executed in the schedule execution time, the scheduled operation does not execute the power operation of the partition.

If the schedule overlaps on the same day, it is processed according to the following priority levels.

Special > Monthly > Weekly > Daily

- Daily: Schedule executed every day
- Weekly: Schedule executed every week
- Monthly: Schedule executed every month
- Special: Schedule executed on specific day every year

Moreover, if the Power On and Power Off is specified at the same time, the priority is given to Power Off.

In case of Partition Operator, only the management target partition can be operated.

Because Partition does not do Power On in Power On Delay, Schedule Power Off is disregarded. Moreover, when OS does not accept the Shutdown demand, Power Off is not done.

TABLE 1.58 Display Items and Setting Items of [Schedule Control] Window

Items	Description
#	Displays the number that identifies the partition (0~3). However, only the partition to which SB/IOU is registered is displayed.
Partition Name	Displays the partition name.
Schedule Control	Sets whether schedule operation is done for every partition. • On

Items	Description
	<ul style="list-style-type: none"><li>Off</li></ul> Default setting is Off.
Number of schedules	Displays the number of schedules that are set.

TABLE 1.59 [Schedule Control] Window Buttons

Buttons	Description
Apply	When the [Apply] button is clicked, the schedule operation information for the specified partition is set.
Cancel	When the [Cancel] button is clicked, the browser returns to the original status without setting the schedule operation information for the partition.

(1) Menu Operation

[Partition] - [Schedule] - [Schedule Control]

(2) Window Operations

1. Specifies whether schedule operation has to be carried out by Radio button for every partition.
2. Click the [Apply] button.

## ☐ [Schedule list] Window

Up to 1000 instances of partition power On / Off schedule can be recorded in the [Schedule list] Window.

FIGURE 1.42 [Schedule List] Window

Model: PRIMEQUEST2800E  
Part Number: MCXXXXXX  
Serial Number: J000-100000-  
Status: Normal

Active:MMB#0

System Partition User Administration Network Configuration Maintenance Logout

>Partition >Schedule >Schedule List

☐ Power Control  
☐ Schedule  
☐ Schedule Control  
☒ Schedule List  
☐ Console Redirection Setup  
☐ Partition Configuration  
☐ Reserved SB Configuration  
☐ Partition#0  
☐ Partition#1

### Schedule List

Select a schedule then click the Edit/Remove button to edit or remove the schedule.  
Click Add button to add a new schedule.

#	Partition Name	Type	Pattern	Term	On Time	Off Time
<input type="radio"/> 0	hayashi	-	-	-	-	-
<input type="radio"/> 1	take	-	-	-	-	-

Add Edit Remove Cancel

Schedule will appear in the order of the partition number.

Partition, will appear in chronological order of the start date of the period.

If the partition and the start date are the same, the schedule appears in the sequence in which it is listed.

### Remarks

If the Type is Weekly, the start date is considered to be "Oneday".

Only the partition to be managed can be operated for Partition Operator.



TABLE 1.60 Display Items and Set Items of [Schedule List] Window

Items	Description
#	Displays the number to identify the partition (0~3). However, only the partition to which SB/IOU is registered is displayed.
Partition Name	Displays the partition name.
Type	Displays the type of schedule set in the partition. <ul style="list-style-type: none"> <li>• Daily: Select when you want to execute every day</li> <li>• Weekly: Select when you want to execute every week</li> <li>• Monthly: Select when you want to execute every month</li> <li>• Special: Select when you want to execute on a particular day every year.</li> </ul> If the schedule overlaps on the same day, it is processed according to the following priority order. Special > Monthly > Weekly > Daily
Pattern	Displays the schedule pattern corresponding to the type of the schedule. Days of week in Weekly (Sun ~ Sat) The period in Monthly The specific month and day in Special
Term	Displays the period of the schedule according to the type and the pattern of the schedule. <ul style="list-style-type: none"> <li>• Daily: Starting month and date and ending month and date.</li> <li>• Weekly: Starting month and ending month.</li> <li>• Monthly: Starting month and ending month.</li> </ul> Default setting is as follows <ul style="list-style-type: none"> <li>• Daily: From: Jan / 1 To: Jan / 1 Note --- It is executed only on January 1.</li> <li>• Weekly: From: Jan To: Jan Note --- It is executed only in January.</li> <li>• Monthly: From: Jan To: Jan Note --- It is executed only in January.</li> </ul>
On Time	Displays the time when the process of Power On is executed on the specified execution day. Time specifies 24 hours. Minute indicates the interval of 10 minutes, as 00, 10, 20, 30, 40, and 50.
Off Time	Displays the time when the process of Power Off is executed on the specified execution day. Time indicates 24 hours. Minute indicates the interval of 10 minutes, as 00, 10, 20, 30, 40, and 50.

TABLE 1.61 [Schedule List] Window Buttons

Buttons	Description
Add	If [Add] button is clicked, [Add Schedule] window appears and the schedule can be added.
Edit	If [EDIT] button is clicked, [Edit Schedule] window appears and the schedule can be changed.
Remove	If [Remove] button is clicked, the selected schedule can be deleted.
Cancel	If [Cancel] button is clicked, the browser returns to the previous window.

## (1) Menu Operation

[Partition] - [Schedule] - [Schedule List]

## (2) Window Operations

- If the schedule is to be added newly
  1. Click [Add] button.  
[Add/Edit Schedule] window appears.
  2. Add the schedule to the [Add/Edit Schedule] window.

- If the schedule is to be changed
  1. Select an existing schedule with [Radio] button.
  2. Click [Edit] button.  
[Add/Edit Schedule] window appears.
  3. Changes an existing schedule in [Add/Edit Schedule] window.
- If the schedule is to be deleted
  1. Select the schedule with [Radio] button.
  2. Click [Remove] button.  
The confirmation dialog box appears.
  3. Click [OK] button.  
Deletes the schedule.

#### **[Message]**

This section describes the messages to be displayed on this window.

Message Number	Message
I_00013	Setting completed.
E_00412	You need an empty entry.
W_00413	Nothing is selected.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

#### **☐ [Add Schedule] window/ [Edit Schedule] window**

In [Add Schedule] window, the schedule of Power On / Off for each partition, can be added newly.  
In [Edit Schedule] window, an existing schedule can be changed.

The window items of [Add Schedule] window and [Edit Schedule] window are common.

In this section, an explanation is given by using the [Add Schedule] window.

FIGURE 1.43 [Schedule List] Window

Model: PRIMEQUEST2800E  
Part Number: MCXXXXXXX  
Serial Number: [redacted]  
Status: Normal

Active:MMB#0

System Partition User Administration Network Configuration Maintenance Logout

>Partition >Schedule >Schedule List

**Add Schedule**

Select a partition and input a schedule, then click the Apply button to take effect.

Partition: #0 hayashi

Type	Pattern	Term
<input type="radio"/> Daily	-	From: Jan 1 To: Jan 1
<input type="radio"/> Weekly	<input type="checkbox"/> Sun <input type="checkbox"/> Mon <input type="checkbox"/> Tue <input type="checkbox"/> Wed <input type="checkbox"/> Thu <input type="checkbox"/> Fri <input type="checkbox"/> Sat	From: Jan To: Jan
<input type="radio"/> Monthly	From: 1 To: 1	From: Jan To: Jan
<input type="radio"/> Special	Jan 1	-

☐ On Time Hour: 0 Min: 0  
☐ Off Time Hour: 0 Min: 0

Apply Cancel

TABLE 1.62 Display Items and Set Items of [Add Schedule] Window

Items	Description
#	Displays the number to identify the partition (0~3). However, only the partition to which SB/IOU is registered is displayed.
Pattern	Select the partition to be added or edited. Default setting is the defined partition with the smallest number.
Type	Select the types of schedule to be set in the partition. <ul style="list-style-type: none"> <li>Daily: Select when you want to execute every day</li> <li>Weekly: Select when you want to execute every week</li> <li>Monthly: Select when you want to execute every month</li> <li>Special: Select when you want to execute on a particular day every year. (The useful range of Special becomes only a specified day.)</li> </ul> If the schedule overlaps on the same day, it is processed according to the following priority order. Special > Monthly > Weekly > Daily By default, it is not selected.
Pattern	Specify the schedule pattern corresponding to the types of the schedule. <ul style="list-style-type: none"> <li>Weekly : Day in a week (Sun ~ Sat)</li> <li>Monthly: Period in a month</li> <li>Special: Specified month</li> </ul> Default settings are as follows. <ul style="list-style-type: none"> <li>Day in a week: Not selected</li> <li>Period: From : 1 To: 1</li> <li>Specified date: Jan/1</li> </ul>
Term	Specify the period of the schedule according to the type and pattern of the schedule.

Items	Description
	<ul style="list-style-type: none"> <li>• Daily: Starting month and date, and ending month and date</li> <li>• Weekly: Starting month and ending month</li> <li>• Monthly: Starting month and ending month</li> </ul> Default settings are as follows. <ul style="list-style-type: none"> <li>• Daily: From: Jan / 1 To: Jan / 1</li> <li>• Weekly: From: Jan To: Jan</li> <li>• Monthly: From: Jan To: Jan</li> </ul>
On Time	On the specified execution date, set whether the power-supply is to be turned ON. If the power-supply is to be ON, set the time. Time is specified in 24 hours. Minute specifies the interval of 10 minutes as 00, 10, 20, 30, 40, and 50.
Off Time	Set whether the power-supply is OFF on the specified execution date. If the power-supply is OFF, set the time. Time is specified in 24 hours. Minute is specified in the interval of 10 minutes, as 00, 10, 20, 30, 40, and 50.

TABLE 1.63 [Add Schedule] Window Buttons

Buttons	Description
Apply	If the [Apply] button is clicked, the schedule information specified in each item is applied to the partition.
Cancel	If the [Cancel] button is clicked, returns to the original state without applying the schedule information specified in each item.

**[Message]**

This section describes the messages to be displayed on this window.

Message Number	Message
I_00013	Setting completed.
W_00414	Invalid Date Format
W_00415	The duplicate On/Off Time is found.
W_00416	Both On/ Off Time are disabled.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

### 1.3.3 [Console Redirection Setup] window

There are following windows in the [Console Redirection Setup] menu.

- ☐ [IPv4 Console Redirection Setup] window
- ☐ [IPv6 Console Redirection Setup] window

#### ☐ [IPv4 Console Redirection Setup] window

The IP address settings for accessing Console Redirection Setup of IPv4, subnet mask, video redirection and enable/disable settings of virtual media can be done in the [IPv4 Console Redirection Setup] window.

FIGURE 1.44 [IPv4 Console Redirection Setup]

Model: PRIMEQUEST 2800E  
Part Number: MCXXXXXXX  
Serial Number:   
Status: Warning

Active:MMB#0

System Partition User Administration Network Configuration Maintenance Logout

>Partition >Console Redirection Setup >IPv4 Console Redirection Setup

IPv4 Console Redirection Setup

Click the Apply Button to apply all changes.  
Note: For using Video Redirection and Virtual Media in xPAR Partition, VGA/USB2+KVMs must be connected to the partition.

#	Partition Name	IP Address	Subnet Mask	Video Redirection	Virtual Media
0	free	10 . 24 . 76 . 50	255 . 255 . 255 . 0	<input checked="" type="radio"/> Enable <input type="radio"/> Disable	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
1	free	10 . 24 . 76 . 51	255 . 255 . 255 . 0	<input checked="" type="radio"/> Enable <input type="radio"/> Disable	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
2	FAE	10 . 24 . 76 . 52	255 . 255 . 255 . 0	<input checked="" type="radio"/> Enable <input type="radio"/> Disable	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
3	free	10 . 24 . 76 . 53	255 . 255 . 255 . 0	<input checked="" type="radio"/> Enable <input type="radio"/> Disable	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
4	xPAR#4	10 . 24 . 76 . 68	255 . 255 . 255 . 0	<input checked="" type="radio"/> Enable <input type="radio"/> Disable	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
8	xPAR#8	0 . 0 . 0 . 0	255 . 255 . 255 . 255	<input type="radio"/> Enable <input checked="" type="radio"/> Disable	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
11	xPAR#11	10 . 24 . 76 . 75	255 . 255 . 255 . 0	<input checked="" type="radio"/> Enable <input type="radio"/> Disable	<input checked="" type="radio"/> Enable <input type="radio"/> Disable

Apply Cancel

TABLE 1.64 Display Items and Set Items of [IPv4 Console redirection Setup] Window

Items	Description
#	Displays the number for identifying the Partition. 0~11 Partitions exist.
Partition Name	Displays name given to the Partition.
IP Address	Enters the IP address of the partition permitted to connect. Specify an IP address of the same segment as the virtual IP address used to access the MMB Web-UI (see "1.5.2 [Network Interface] Menu"). Note that this IP address must be different from that virtual IP address. Default is 0.0.0.0.
Subnet Mask	Enters the subnet mask of IP address which is allowed for connection. Default is 255.255.255.255.
Video Redirection	Sets whether video redirection can be used. <ul style="list-style-type: none"> <li>Enable: Video redirection can be used.</li> <li>Disable: Video redirection cannot be used.</li> </ul> Default is Disable.
Virtual Media	Sets whether virtual media can be used. <ul style="list-style-type: none"> <li>Enable: Virtual media can be used.</li> <li>Disable: Virtual media cannot be used.</li> </ul> Default is Disable.

TABLE 1.65 [IPv4 Console redirection Setup] Window Buttons

Buttons	Description
Apply	When [Apply] button is clicked, video redirection, virtual media settings of the specified Partition are applied.
Cancel	When [Cancel] button is clicked, video redirection, virtual media settings are not applied and it returns to the original state.

## (1) Menu Operation

[Partition] - [Console Redirection Setup] - [IPv4 Console Redirection Setup]

## (2) Window Operations

1. IP address and the subnet mask are entered and it is set whether video redirection, virtual media can be used.
2. [Apply] button is clicked.

**[Message]**

This section describes the messages to be displayed on this window.

Message Number	Message
W_00432	Invalid IP Address specified
W_00433	The duplicate IP address was found.
I_00539	The settings for the Console Redirection IP are changed. All existing network connections about this settings will be lost. You will need to login again. If you want to continue, please click OK button. If not, click Cancel button. Are you sure?

**□ [IPv6 Console Redirection Setup] window**

The IP address settings for accessing Console Redirection LAN of IPv6, prefix length settings, video redirection and enable/disable settings of virtual media can be done in the [IPv6 Console Redirection Setup] window.

In case of automatic settings, when [Auto] button is clicked, IP address, prefix length are automatically acquired.

FIGURE 1.45 [IPv6 Console Redirection Setup] Window

Model: PRIMEQUEST 2800E  
Part Number: MCXXXXXXX  
Serial Number:   
Status: **Warning**

System Partition User Administration Network Configuration Maintenance Logout

>Partition >Console Redirection Setup >IPv6 Console Redirection Setup

**IPv6 Console Redirection Setup**

Click the Apply Button to apply all changes.  
Note: For using Video Redirection and Virtual Media in xPAR Partition, VGA/USB2/rKVMs must be connected to the partition.

#	Partition Name	IP Address	Prefix Length	Video Redirection	Virtual Media
0	free	..	0	<input type="radio"/> Enable <input checked="" type="radio"/> Disable	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
1	free	..	0	<input type="radio"/> Enable <input checked="" type="radio"/> Disable	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
2	FAE	..	0	<input type="radio"/> Enable <input checked="" type="radio"/> Disable	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
3	free	..	0	<input type="radio"/> Enable <input checked="" type="radio"/> Disable	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
4	xPAR#4	..	0	<input type="radio"/> Enable <input checked="" type="radio"/> Disable	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
8	xPAR#8	..	0	<input type="radio"/> Enable <input checked="" type="radio"/> Disable	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
11	xPAR#11	..	0	<input type="radio"/> Enable <input checked="" type="radio"/> Disable	<input type="radio"/> Enable <input checked="" type="radio"/> Disable

Apply Cancel

TABLE 1.66 Display Items and Set Items of [IPv6 Console redirection Setup] Window

Items	Description
#	Displays the number for identifying the Partition. 0~11 Partitions exist.
Partition Name	Displays the name given to the Partition.
IP Address	Enters the global address for IPv6 which can be connected. In case of automatic acquisition, the acquired IP Address is displayed.
Prefix Length	Enters the prefix length for IPv6. In case of automatic acquisition, the acquired prefix length is displayed.
Video Redirection	Sets whether video redirection can be used. <ul style="list-style-type: none"> <li>Enable: Video redirection can be used.</li> <li>Disable: Video redirection cannot be used.</li> </ul> Default is Disable.
Virtual Media	Sets whether the virtual media can be used or not. <ul style="list-style-type: none"> <li>Enable: Virtual media can be used.</li> <li>Disable: Virtual media cannot be used.</li> </ul> Default is Disable.
Automatic acquisition	When IPv6 address is automatically acquired, the "Auto" button is clicked. IP address and prefix length are automatically acquired and overwritten.

TABLE 1.67 [IPv6 Console redirection Setup] Window Buttons

Buttons	Description
Auto	When you Click [Auto] button IP address and prefix length is automatically displayed.
Apply	When you click the [Apply] button, video direction of the specified partition, virtual media setting is applied.
Cancel	When you click the [Cancel] button, virtual media setting, video redirection is not applied and it returns to the original state.

## (1) Menu Operation

[Partition] - [Console Redirection Setup] - [IPv6 Console Redirection Setup]

## (2) Window Operations

1. Input the IP address, prefix length and sets whether video redirection and virtual media should be used.
2. Click the [Apply] button.

**[Message]**

This section describes the messages to be displayed on this window.

Message Number	Message
W_00432	Invalid IP Address specified
W_00433	The duplicate IP address was found.
I_00539	The settings for the Console Redirection IP are changed. All existing network connections about this settings will be lost. You will need to login again. If you want to continue, please click OK button. If not, click Cancel button. Are you sure?

### 1.3.4 [Partition Configuration] Menu

The SB and IOU which configure the partition can be set on [Partition Configuration] window.

In case of PRIMEQUEST 2400E model, only 0 and 1 are displayed for partition.



FIGURE 1.46 [Partition Configuration] Window

Model: PRIMEQUEST 2800E  
Part Number: MCXXXXXX  
Serial Number: [redacted]  
Status: Normal

Active:MMB#0

System Partition **User Administration** Network Configuration Maintenance Logout

>Partition >Partition Configuration

**Partition Configuration** Help

Select a partition, then click the Add/Remove Unit, Set Partition Name, or Home buttons to configure the partition.

#	Partition Name	Power Status	SB				IOU			
			0	1	2	3	0	1	2	3
<input type="radio"/> 0	PQ2800#09-P0	Standby	H				●			
<input type="radio"/> 1	PQ2800#09-P1	Standby		H				●		
<input type="radio"/> 2	PQ2800#09-P2	On			H				●	
<input type="radio"/> 3	PQ2800#09-P3	On				H				●
Reserved										
Free										

Note) R represents Reserved SB  
H represents Home SB  
● represents Installed SB/IOU other than the above

Set Partition Name Add Unit Remove Unit Home Cancel

For the series of SB and IOU which are not installed, the background color is displayed in the gray.

Select the set partition by using the left radio button, and select the button corresponding to set process from [Add Unit], [Remove Unit] and [Home].

If SB/IOU link is clicked, [SB#x] window, [IOU#x] window are displayed respectively.

If the maintenance mode (Hot Partition Maintenance, Warm System Maintenance or Cold system Maintenance) is set, only the user (Maintenance person, Administrator privilege) who sets the maintenance mode can operate this mode. If the partition is selected other than the maintenance target, a message is displayed and operation is disabled.

TABLE 1.68 Display Items and Set Items of [Add Schedule] Window

Items	Description
#	<p>It displays the number for identifying the partition. Exists up to 0~3 Partition.</p> <p>SB/IOU which does not belong to the partition is displayed as follows.</p> <ul style="list-style-type: none"> <li>Reserved: Reserved SB</li> <li>Free: Free SB/IOB</li> </ul>
Partition Name	<p>Displays/sets the name attached to the partition. The name can be entered up to 16 characters. It is possible to use alphanumeric characters, single bytes spaces, # (Sharp), _ (Underline), - (Hyphen) in the Partition Name.</p> <p>By default, there are no settings.</p>
Power Status	<p>Displays the Power status of the partition</p> <ul style="list-style-type: none"> <li>On</li> <li>Standby</li> </ul>
SB	Displays the partition to which the SB belongs.

Items	Description
IOU	Displays the partition to which the IOU belongs.

TABLE 1.69 [Partition Configuration] Window Buttons

Buttons	Description
Set Partition Name	Sets the name in the partition.
Add Unit	Displays the [Add Unit] window for incorporating the unit.
Remove unit	Displays the [Remove Unit] window for deleting the unit.
Home	Displays the [Partition Home] window for setting the Home of Partition.
Cancel	Returns to original status without setting the information.
View Configuration	Displays the [View Partition Configuration] where the configuration information of partition is displayed.

**[Message]**

This section describes the messages to be displayed on this window.

Message Number	Message
I_00217	Unable to set Partition Name of Partition#%aa because this partition is under maintenance.
I_00220	Unable to set Home on Partition#%aa because this partition is under maintenance.
I_00427	Select a partition.
W_00428	Only the alphanumeric character can be input to Partition Name area.
I_00429	The partition is not defined.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference \(C122-E178EN\)](#).

The operation method in the [Partition Configuration] window is described as follows.

**☐ [Set Partition Name] Button**

The partition name is entered in each cell of [Partition Name], and when [Set Partition Name] button is clicked, the name for each partition is set.

**☐ [Add SB/IOU to Partition] Window**

When the partition is selected by using radio button of [Partition Configuration] window and when [Add Unit] button is clicked, [Add SB/ IOU to Partition] window appears.

FIGURE 1.47 [Add SB/IOU to Partition] Window

Model: PRIMEQUEST 2800E  
Part Number: MCXXXXXXX  
Serial Number:   
Status: Warning

Active:MMB#0

System Partition User Administration Network Configuration Maintenance Logout

>Partition >Partition Configuration

Power Control  
Schedule  
Console Redirection Setup  
Partition Configuration  
Partition#2 xPAR Configuration  
Reserved SB Configuration  
Partition#0  
Partition#1  
Partition#2  
Partition#3  
Partition#4  
Partition#8  
Partition#11

### Add SB/IOU/xPAR to Partition

Select an SB or IOU or xPAR to add to the partition #3, then click the Apply Button.

Free SB/IOU/xPAR	Status	Note
<input type="radio"/> xPAR#9	OK	
<input type="radio"/> xPAR#10	OK	

Apply Cancel

#### Remarks

Radio button is attached for the display of each Free SB and IOU, and it is not possible to select more than one at the same time.

In case of eight Socket Model, check whether SB in which one CPU can be mounted, is not mounted in the partitions of two or more SBs.

- Only when one partition is configured by one SB, one CPU can be mounted for one SB.
- When one partition is configured by multiple SBs, it is mandatory to mount two CPUs for each SB in the partition.

If the maintenance mode (Hot Partition Maintenance, Warm System Maintenance or Cold system Maintenance) is set, only the user (Maintenance person, Administrator privilege) who sets the maintenance mode can operate this mode.

In case of the partition other than the maintenance target, a message is displayed and operation is not possible.

TABLE 1.70 Display Items and Set Items of [Add SB/IOU to Partition] Window

Items	Description
Free SB	Displays the SB in the free status (Status which does not belong to any partition)
Status	Displays the status of the SB.
Number of CPUs	Displays the number of CPU mounted on the SB.
Memory	Displays the amount of memory mounted on the SB.
Free IOU	Displays the IOU in the free status (Status which does not belong to any partition)
Status	Displays the status of the IOU.
Number of PCI-Express slots	Displays the number of PCI-Express slot of the IOU.

“DR”

When Add is instructed for a Partition in which operating system has already operated, and when the operating system supports Hot-add, SB/IOU added during operating system operation executed by Hot-add can be used.

(1) Menu Operation

[Partition] - [Partition Configuration] - [Add Unit] button

(2) Window Operations

1. Select the SB or IOU to be incorporated in the partition, and then click the [Apply] button.  
A confirmation dialog box appears.
2. Click [OK] button.  
The SB or IOU will be incorporated.
3. Click the [Apply] or [Cancel] button.  
Return to [Partition Configuration] window.

**[Message]**

This section describes the messages to be displayed on this window.

Message Number	Message
E_00045	Free node doesn't exist.
E_00112	Unable to add the specified SB#%aa to the partition due to CPU mismatch between SBs.
E_00424	Unable to add the specified SB to the partition due to CPU composition abnormal.
E_00425	Unable to add the specified SB to the partition due to DIMM composition abnormal.
E_00490	Unable to add the specified SB to the partition due to DIMM does not satisfy requirements of Mirror Mode.
W_00505	Unable to set configuration because the power on/off is processing. Please execute it after a while again.
E_00519	Unable to add the specified SB to the partition due to SB composition abnormal.
E_00524	Unable to add the specified SB to the partition due to VRM composition abnormal.


For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference \(C122-E178EN\)](#).

When multiple errors are detected, multiple errors are displayed in the dialog box.

☐ **[Remove SB/IOU from Partition] Window**

Select the partition by using radio button of [Partition Configuration] window, and when [Remove] button is clicked, [Remove SB/ IOU from Partition] window appears.

FIGURE 1.48 [Remove SB/IOU from Partition] Window



When maintenance mode (Hot Partition Maintenance, Warm System Maintenance, or Cold System Maintenance) is set, only the user (Maintenance person, Administrator privilege) who sets the maintenance mode can operate this mode.

If the partition is selected other than the maintenance target, message is displayed and operation is not possible.

TABLE 1.71 Display Items and Set Items of [Remove SB/IOU to partition] Window

Items	Description
SB	Displays SB which belongs to partition
Status	Displays the status of SB.
Number of CPUs	Displays the number of CPUs mounted on the SB.
Memory	Displays the amount of memory mounted on the SB.
IOU	Displays the IOU which belongs to the partition.
Status	Displays the status of the IOU
Number of PCI-Express slots	Displays the number of PCI-Express of the IOU.

“DR”

When Remove is instructed for a Partition where the operating system is already running, and if operating system supports Hot-remove, the SB/IOU is removed from the concerned partition though the operation system is running state. Then SB/IOU is in Free status.

(1) Menu Operation

[Partition] - [Partition Configuration] - [Remove Unit] button

(2) Window Operations

1. Select the SB or IOU which is to be removed from the partition and click the [Apply] button.  
Confirmation dialog box is displayed.
2. Click [OK] button.  
SB or IOU is removed.
3. Click the [Apply] or [Cancel] button.

Back to [Partition Configuration] window.

### [Message]

This section describes the messages to be displayed on this window.

Message Number	Message
E_00022	The partition doesn't have a node.
W_00505	Unable to set configuration because the power on/off is processing.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

### □ [Partition Home] window

If you select the partition using the radio button on the [Partition Configuration] window and click the [Home] button, [Partition Home] window is displayed.

FIGURE 1.49 [Partition Home] window

Model: PRIMEQUEST 2800E  
Part Number: MCXXXXXX  
Serial Number: SWBG09  
Status: Normal

Active:MMB#0

System Partition User Administration Network Configuration Maintenance Logout

>Partition >Partition Configuration

Power Control  
Schedule  
Console Redirection Setup  
Partition Configuration  
Reserved SB Configuration  
Partition#0  
Partition#1  
Partition#2  
Partition#3

### Partition Home

Select a Home SB for the partition #3, then click the Apply Button.

SB	Status
<input checked="" type="radio"/> SB#3	OK

Apply Cancel

1. Select the SB which is considered as the Home SB, by using the radio button.  
When SB which is set as Home SB is not mounted, the background color is displayed in gray.  
You can switch from the selected radio button on a grayed row to a radio button on a row that is not grayed. However, if the selection on the row displayed in gray is removed once, it is not possible to select the original radio button again.  
When the Home SB is not set, the SB which is initially installed in the partition by default is considered as the Home SB. However, when the Home SB is removed and degenerated, SB with smallest number is the Home SB.
2. Click the [Apply] button.  
Confirmation dialogue box is displayed.
3. Click the [OK] button when you want to continue the processing.  
Click the [Cancel] button when you want to cancel the processing.
4. Click the [Apply] or the [Cancel] button.  
Return to [Partition Configuration] window.  
When the [Apply] button is clicked and the power supply of the target partition is ON, change of [Home] is not possible. A warning dialogue box is displayed.

**[Message]**

This section describes the messages to be displayed on this window.

Message Number	Message
E_00022	The partition doesn't have a node.
W_00423	The partition home cannot be changed while the partition is running. Please try to change the partition home after the partition is shutdown.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

### 1.3.5 [Reserved SB Configuration] window

In the [Reserved SB Configuration] window, the Partition which is to be considered as a Reserved SB for an Free SB defined as Free or Reserved SB of the Partition, can be defined.

Reserved SB is an SB which is incorporated newly in the Partition, in place of a disconnected SB when the SB which was incorporated in the Partition was disconnected due to hardware problems.

The background color of the un-mounted SB is displayed in gray.

FIGURE 1.50 [Reserved SB Configuration] Window

Model: PRIMEQUEST2800E  
Part Number: MCXXXXXX  
Serial Number: 0000000000  
Status: Normal

System Partition User Administration Network Configuration Maintenance Logout

>Partition >Reserved SB Configuration

Reserved SB Configuration

Check the check boxes of the partitions to register the Reserved SB, then click the Apply button.

#	Partition Name	Power Status	Mirror Mode (setting)	SB	0	1	2	3
0	hayashi	Standby	-	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
1	take	Standby	-	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
2			Disable	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
3			Disable	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Reserved								
Free								

Apply Cancel

In case of an eight Socket Model, check the number of CPUs of the SB which is incorporated in the specified Partition while setting it in the Reserved SB, and check with the following mounting conditions.

- Mounting of one CPU for a SB is possible only when the Partition is configured with one SB.
- Mounting of two 2CPUs for a SB is mandatory when the Partition is configured with several SB.

The Reserved SB cannot be set when TPM function is used for the Home SB.  
The Reserved SB cannot be set though Fixed I/O Mode is specified in the Partition.

When mounting conditions are not fulfilled, a message is displayed and Reserved SB cannot be set.

For a partition that is set to Mirror mode, if you attempt to set an SB with a DIMM configuration that does not satisfy the Mirror mode requirements as a Reserved SB for a partition that is set to Mirror mode, a confirmation dialog box appears. A warning message stating that Mirror Mode is cancelled while shifting to Reserved SB is displayed in the dialog box for confirmation and whether to continue with the Reserved SB settings is confirmed.

When several Reserved SBs are registered in one Partition, they operate as Reserved SBs in ascending order of SB number.

TABLE 1.72 Display Items and Set Items of [Reserved SB Configuration] Window

Items	Description
#	Displays number that identifies the Partition. <ul style="list-style-type: none"> <li>Reserved: Reserved SB</li> <li>Free: Free SB</li> </ul>
Partition Name	Displays name given to Partition.
Power Status	Displays the power status of the partition <ul style="list-style-type: none"> <li>On</li> <li>Standby</li> </ul>
Mirror Mode (setting)	Displays the setting value of Mirror Mode corresponding to the Partition. <ul style="list-style-type: none"> <li>Enable: Mirror Mode is set</li> <li>Disable: Mirror Mode is not set</li> </ul>
SB	Displays the Partition to which the SB belongs. The check box to register the SB as a Reserved SB in the Partition of the corresponding line is displayed in the cell which corresponds to Reserved SB or Free SB.

TABLE 1.73 [Reserved SB Configuration] Window Buttons

Buttons	Description
Apply	If "[Apply]" button is clicked, it is defined as Reserved SB.
Cancel	If "[Cancel]" button is clicked, it returns to the original state without being defined as a Reserved SB.

(1) Menu Operation  
[Partition] - [Reserved SB Configuration]

(2) Window Operations  
 1. The check box of Partition intended for Reserved SB is set to ON.  
 2. Click the [Apply] button.

#### [Message]

This section describes the messages to be displayed on this window.

Message Number	Message
E_00098	Failed to get the Replacement Condition
E_00100	Failed to set the Replacement Condition
E_00113	Unable to register the specified SB#%aa as a Reserved SB due to CPU mismatch between SBs.
E_00114	The specified SB#%aa cannot be registered as a Reserved SB.
I_00223	Unable to change the specified SB(s) because the partition including the specified SB(s) is under maintenance.
E_00419	Unable to register the specified SB#%s as a Reserved SB due to unsupported CPU configuration.
E_00420	Unable to register the specified SB#%s as a Reserved SB because the DIMM does



Message Number	Message
	not satisfy requirements of Mirror Mode.
E_00421	No change.
E_00460	Unable to set the specified SB to the partition due to CPU composition abnormal.
W_00481	Unable to register the specified SB#%s as a Reserved SB due to the home SB is TPM enabled.
W_00492	Unable to register the specified SB#%d as a Reserved SB due to Partition is Fixed I/O Mode.
W_00493	Unable to register the specified SB#%d as a Reserved SB due to abnormal DIMM composition.
I_00494	The DIMM does not satisfy requirements of Mirror Mode. If you register the specified SB% as a Reserved SB, Mirror Mode will be disabled when switching to specified SB. Are you sure to continue?
W_00520	Unable to register the specified SB#%d as a Reserved SB due to abnormal SB composition.
W_00525	Unable to register the specified SB#%d as a Reserved SB due to abnormal VRM composition.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference \(C122-E178EN\)](#).

When multiple errors are detected, multiple errors are displayed in the dialogue box.

### 1.3.6 [Power Management Setup] Window

In the [Power Management Setup] window, Power Saving can be set in the partition unit.

Power Saving can be set only when the Power save Control as system is Enable.

When the System Power Save setting is Disable, then the display of this screen is shown as gray and cannot be set.

FIGURE 1.51 [Power Management Setup] window

Model: PRIMEQUEST 2800E  
Part Number: MCF3AC111  
Serial Number:   
Status: Normal

Active:MMB#0

System Partition User Administration Network Configuration Maintenance Logout

>Partition >Power Management Setup

Power Control  
Schedule  
Console Redirection Setup  
Partition Configuration  
Reserved SB Configuration  
Power Management Setup  
Partition#0

### Power Management Setup

Click the Apply Button to apply all changes.

#	Partition Name	Power Control Status	Power Save Control	Power Save Grace Period	Action reaching Power Save
0		Normal	<input type="radio"/> Enable <input checked="" type="radio"/> Disable	0 min	Partition Power Off

Apply Cancel

TABLE 1.74 Display Items and Set Items of [Power Management Setup] Window

Items	Description
#	Displays number (0~3) to identify the partition. However displays only the partitions registered by SB/IOU.
Partition Name	Displays the name given to the Partition.
Power Control Status	Displays the operating state of power control status of each partition. <ul style="list-style-type: none"> <li>Normal: Normal operating state. Shows that the operating rate suppression function for limitation of the electric power consumption is not working.</li> <li>Power Saving: Shows that the operating rate is being suppressed</li> </ul>
Power Save Control	Valid/ invalid Power Saving function setting is executed in the partition unit. <ul style="list-style-type: none"> <li>Enable</li> <li>Disable</li> </ul> <p>The setting can be done only when System Power Save Control is Enable and gray color is shown when System Power Saving Control is Disable.</p> <p>Default is Enable</p>
Power save Grace Period	Sets shutdown waiting time in Power Save Grace Period Partition unit when the Limit threshold is exceeded. Specified in the range of 0 ~ 99 minutes.
	Shows a valid item when Power Save Control of partition is Enable and shows gray color when Disable.
	Default is 5 minutes.
Action reaching Power Save	Executes the operation setting in the partition unit after the Limit threshold excess stand-by time. <ul style="list-style-type: none"> <li>Continue: Continues operation for the partition under operation.</li> <li>Partition Power Off: Power Off is done for the partition under operation.</li> <li>Partition Force Power Off: Force Power Off is done for the partition under operation.</li> </ul> <p>Displays a valid item when Power Save Control of partition is Enable and displays gray color in case of Disable.</p> <p>Default is Partition Power Off</p>

TABLE 1.75 [Power Management Setup] Window Buttons

Buttons	Description
Apply	The setting of the Power Management Setup is changed.
Cancel	Returns to the original state without changing the setting of the Power Management Setup.

(1) Menu Operation  
[Partition] - [Power Management Setup]

(2) Window Operations  
1. Set the items for changing the settings of the Power Management Setup and click the [Apply] button.  
Set the connection.

**[Message]**

This section describes the messages to be displayed on this window.

Message Number	Message
I_00013	Setting completed.
W_00426	Invalid values specified.

Message Number	Message
E_00098	Failed to get Partition Power Management.
E_00098	Failed to get the system configuration.
W_00559	Unable to set Power Save Control because PSU type is not PSU_P.
W_00560	Unable to set Partition Power Save Control because System Power Save Control is disabled.
E_00100	Failed to set Partition Power Management.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

### 1.3.7 [Partition#x] Menu

The following settings and the displays for the partition can be done in the Partition#x menu.

- Status display
- ASR condition setting
- Video redirection display
- Various modes

#### ☐ [Information] Window

Displays the status of the partition and various information on the partition, on the information screen.

FIGURE 1.52 [Information] Window




TABLE 1.76 Display Items of [Information] Window

Items	Description
Partition Name	Displays the name given to the partition
Power Status	Displays the power status of the partition. <ul style="list-style-type: none"> <li>• On</li> <li>• Standby</li> </ul>

Items	Description
System Progress	<p>Displays the progress status of partition.</p> <ul style="list-style-type: none"> <li>Power Off: The power supply for partition has been cut.</li> <li>Power On In Progress: The partition power on is in progress.</li> <li>Reset: The partition is being reset.</li> <li>EFI: The UEFI menu screen is displayed.</li> <li>Boot: Operating system is being booted</li> <li>OS Running: operating system is operating.</li> <li>OS Shutdown: operating system is shutting down.</li> <li>Panic: Panic (Only RHEL).</li> <li>Power Off In Progress: The partition power off is in progress.</li> <li>Fatal: Is stopping.</li> <li>Dumping: It is a dumping output.</li> <li>Halt: It is halting</li> <li>Stop Error: It is a stop error.</li> </ul> <p><b>Remarks</b> If the SVAS is not installed, the display does not change to “Operating System Running” even if the operating system is actually operating. Also, “operating system Shutdown”, “Panic”, “Stop Error” which are specified by SVAS are not displayed if SVAS is not installed.</p>
Core / Max Core (Assigned Core / Requested Core)	<p>The CPU core number included in the partition, Max Core number is displayed in the PPAR Partition.</p> <p><b>Remarks</b> Degenerated CPU is not included in the number.</p>
Physical Memory Size (Assigned Memory Size / Requested Memory Size)	<p>PPAR Partition displays the physical memory volume that is included in the partition.</p> <p><b>Remarks</b> The physical memory volume that has been displayed differs from the memory volume that can be actually used by the operating system. Degraded DIMM is not included in the memory.</p>

(1) Menu Operation  
[Partition] - [Partition#x] – [Information]

(2) Window Operations  
None

## ☐ [ASR Control] Window

The conditions for executing automatic restart of the partition on the [ASR (Automatic Server Restart) Control] can be set.

FIGURE 1.53 [ASR (Automatic Server Restart) Control] Window

Model: PRIMEQUEST2800E  
Part Number: MCXXXXXX  
Serial Number: 000000001  
Status: Normal

Active:MMB#0

System Partition User Administration Network Configuration Maintenance Logout

>Partition >Partition#0 >ASR Control

**ASR(Automatic Server Restart) Control** Help

Click the Apply Button to apply all changes.

**ASR**

Number of Restart Tries	5
Action after exceeding Restart tries	Stop rebooting and Power Off
Retry Counter	5

**Boot Watchdog**

Boot Watchdog	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
Timeout time (seconds)	900
Action when watchdog expires	Reset

**Software Watchdog**

Software Watchdog	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
Timeout time (seconds)	300
Action when watchdog expires	Continue

Apply Cancel

TABLE 1.77 Display Items and Set Items of [ASR (Automatic Server Restart) Control] Window

Items	Description
<b>ASR</b>	
Number of Restart Tries	Set the number of retries for restarting the operating system when there is time out by Boot Watchdog, or Software Watchdog of SVAS, or the hardware error occurs and OS shuts down. The number of times can be set up to 0-10 times. When 0 is specified, it does not retry. Default is five times.
Action after exceeding Restart tries	Repeat the restart by Watchdog Timeout and sets the action when the above-mentioned retry number is exceeded. The actions are as below. <ul style="list-style-type: none"> <li>Stop rebooting and Power Off: Reboot process is stopped, power supply of partition is cut off.</li> <li>Stop rebooting: Reboot process is stopped, and the partition is stopped.</li> <li>Diagnostic Interrupt assert: Reboot process is stopped, instructs the NMI interruption for partition. Tries to collect the data for investigation (damp) for the investigating the cause of stoppage, of the partition which has stopped.</li> </ul> Default setting is 'Stop rebooting and Power Off'
Retry Counter	Displays the number of actual possible retries.
<b>Boot Watchdog</b>	
Boot Watchdog	Enable/disable of the Boot Watchdog function of ServerView is set.  The start of OS is observed when setting it to Enable. After OS starts, Boot Watchdog is stopped by ServerView. Default is Disable.
Timeout time (seconds)	Time until Boot Watchdog does timeout is set.

Items	Description
	The range of 1-6000 can be set. Default is 6000 seconds (=100 minutes).
Action when watchdog expires	Action when Boot Watchdog does timeout is set. In Action, there is the following. <ul style="list-style-type: none"> <li>• Continue</li> <li>• Reset</li> <li>• Power Cycle</li> </ul>
<b>Software Watchdog</b>	
Software Watchdog	Enable/disable of the Software Watchdog function of ServerView is set.  After OS starts, the operation of OS is observed by ServerView when setting it to Enable. Default is Disable.
Timeout time (seconds)	Time until Software Watchdog does timeout is set. The range of 1-6000 can be set.  Default is 300 seconds (=5 minutes).
Action when watchdog expires	Action when Software Watchdog does timeout is set. In Action, there is the following. <ul style="list-style-type: none"> <li>• Continue</li> <li>• Reset</li> <li>• Power Cycle</li> <li>• NMI</li> </ul>

TABLE 1.78 [ASR (Automatic Server Restart) Control] Window Buttons

Buttons	Description
Apply	Sets the information if [Number of Restart Tries] [Action after exceeding Restart tries] are specified. If [Cancel Boot Watchdog] is selected as On, Boot Watchdog is cancelled.
Cancel	Does not set the information and returns to the original state.

(1) Menu Operation  
[Partition] - [Partition#x] - [ASR Control]

(2) Window Operations  
1. Every item is set.  
2. [Apply] button is clicked.  
Specified information is set. Also, if the [Cancel Boot Watchdog] check box is selected as On, Boot Watchdog is cancelled.

### ☐ [Console Redirection] Window

If the Console Redirection screen is selected when it enabled, the Video Redirection screen on the BMC is displayed in another window.

If the settings in [Console Redirection setup] Window are Disabled, check box cannot be Checked.

FIGURE 1.54 [Console Redirection] Window




TABLE 1.79 Display Items of [Console Redirection] Window

Items	Description
Video Redirection	Displays the Video Redirection on the BMC side. On the Console Redirection Setup window, selection is possible only when Enabled; when Disabled, the check box cannot be checked.

- (1) Menu Operation  
[Partition] - [Partition#x] - [Console Redirection]
- (2) Window Operations  
None

**[Message]**

This section describes the messages to be displayed on this window.

Message Number	Message
I_00222	Unable to %aa the Partition#%aa because this Partition is under maintenance.
I_00417	Are you sure?
W_00413	Nothing is selected.
W_00472	Unable to get the reserved WEB Session information due to WEB Session Max over.
W_00473	Unable to check the Video Redirection check box due to the Video Redirection option is disabled.
W_00541	Nothing is checked.
W_00550	Unable to select the option due to this Partition is not connected to VGA/USB2/rKVMs.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

## □ [Mode] Window

Various modes can be set for partition in [Mode] window. In order to reflect the set value, turn Off the power of partition and then it is necessary to turn On the Power of partition once again.

FIGURE 1.55 [Mode] Window



When the [Apply] button is clicked while the partition is powered on, a warning dialog box "W\_00487 Unable to change the mode, because this partition is powered on" is displayed.

When the partition is already powered off, the settings are reflected without displaying the dialog box.

When SB with DIMM configuration that does not satisfy requirements of Mirror Mode configures the Mirror Mode for the partition configured in a Reserved SB, a confirmation dialogue box is displayed. At the time of switching to the Reserved SB, a warning message of Mirror Mode cancellation is displayed and to confirm whether to proceed with the setting or not.

The LAN Device Mode is displayed in IOU Unit comprised in the partition specified by the LAN Device Mode. For settings, select LAN Device Mode in the IOU Unit, with the radio button and click the [Apply] button.

TABLE 1.80 Display Items and Setting Items in [Mode] Window

Items	Description
Memory Operation Mode (Current)	Displays the currently enabled Memory Operation Mode. <ul style="list-style-type: none"> <li>Performance Mode: Displays the settings to the Performance Mode.</li> <li>Normal Mode: Displays the settings to the Normal Mode.</li> <li>Partial Mirror Mode: Displays the settings to the Partial Mirror Mode.</li> <li>Full Mirror Mode: Displays the settings to the Full Mirror Mode.</li> <li>Spare Mode: Displays the settings to the Spare Mode.</li> </ul>
Memory Operation Mode (setting)	Sets the Memory Operation Mode for partition. <ul style="list-style-type: none"> <li>Performance Mode</li> <li>Normal Mode</li> <li>Partial Mirror Mode</li> <li>Full Mirror Mode</li> <li>Spare Mode</li> </ul> <p>Enables the settings after rebooting the partition.</p> <p>Default setting is Normal Mode.</p>



Items	Description
Memory Mirror RAS Mode (current status)	Displays the Memory operation of currently enabled Mirror Mode. <ul style="list-style-type: none"> <li>• Mirror Keep Mode: Shows the maintenance of Mirror Mode.</li> <li>• Capacity Keep Mode: Shows maintenance of memory capacity.</li> </ul>
Memory Mirror RAS Mode (setting)	Sets the Memory Operations for Mirror Mode for partition. <ul style="list-style-type: none"> <li>• Mirror Keep Mode</li> <li>• Capacity Keep Mode</li> </ul> <p>Enables the settings after rebooting the partition.</p> <p>As these items are enabled only when the Mirror mode is set, when Mirror Mode is not set, they are disabled.</p> <p>Default setting is Mirror Keep Mode.</p>
PCI Address Mode (current status)	Shows the currently set PCI Bus number allocation Mode. <ul style="list-style-type: none"> <li>• PCI Bus Mode</li> <li>• PCI Segment Mode</li> </ul> <p>The setting of PCI Address Mode is decided depending on the following conditions.</p> <ul style="list-style-type: none"> <li>• When the Dynamic Reconfiguration function is made effective, it is necessary to set it to Segment Mode.</li> <li>• When OS does not correspond to Segment Mode, it is necessary to set PCI Address Mode to Bus Mode.</li> <li>• When the TXT function is used, it is necessary to set PCI Address Mode it to Bus Mode.</li> </ul> <p>It is recommended to set PCI Address Mode to Segment Mode though it is possible to set in both Bus Mode and Segment Mode when OS corresponds to Segment Mode.</p> <p>Please refer to "Appendix of General Description (C122-B025-01EN)" for whether OS corresponds to Segment Mode.</p>
PCI Address Mode (setting)	Sets the PCI Bus number allocation Mode for partition. <ul style="list-style-type: none"> <li>• PCI Bus Mode</li> <li>• PCI Segment Mode</li> </ul> <p>Enables the settings after rebooting the partition.</p> <p>Default setting is PCI Segment Mode.</p>
Dynamic Partitioning (current status)	Displays whether Dynamic Reconfiguration Function is enabled or disabled. <ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Dynamic Partitioning (setting)	Sets whether the Dynamic Reconfiguration Function is enabled or not. <ul style="list-style-type: none"> <li>• Enable: Enables the Dynamic Reconfiguration Function.</li> <li>• Disable: Disables the Dynamic Reconfiguration Function.</li> </ul> <p>Enables the settings after rebooting the partition.</p> <p>Settings can be done in the following conditions.</p> <ul style="list-style-type: none"> <li>• When it is on at Flexible I/O mode..</li> <li>• When the TXT/TPM function is disabled.</li> </ul> <p>Default setting is Disable.</p>
TPM (chip status)	Displays whether TPM function is Enabled or Disabled. <ul style="list-style-type: none"> <li>• Enabled (TPM is enabled)</li> <li>• Disabled (TPM is disabled)</li> </ul> <p><b>Remarks</b></p> <p>When Home SB of partition is 'without TPM mode', this field is not displayed.</p>
TPM (current status)	Displays the TPM status.

Items	Description
	<ul style="list-style-type: none"> <li>Activated</li> <li>Deactivated</li> </ul> <p><b>Remarks</b> When Home SB of partition is 'without TPM mode', this field is not displayed.</p>
TPM (ownership)	<p>Displays ownership of TPM.</p> <ul style="list-style-type: none"> <li>Yes (having Ownership)</li> <li>No (not having Ownership)</li> </ul> <p><b>Remarks</b> When Home SB of partition is without TPM mode, this field is not displayed.</p>
On board LAN Mode	
IOU	Displays the IOU that belongs to the partition.
On board LAN Mode (current status)	<p>Displays the On board LAN Mode in IOU Unit.</p> <ul style="list-style-type: none"> <li>Enabled (WOL enabled): Onboard LAN can be used at AC On status.</li> <li>Enabled (WOL disabled): Onboard LAN comprised in the partition can be used at Power On status.</li> <li>Disabled: Onboard LAN cannot be used every time.</li> </ul>
On board LAN Mode (setting)	<p>Sets On board LAN Device Mode in IOU Unit. Select the Mode to be set by using the radio button.</p> <ul style="list-style-type: none"> <li>Enabled(WOL enabled)</li> <li>Enabled(WOL disabled)</li> <li>Disabled</li> </ul> <p>Default setting is Enabled (WOL disabled).</p> <p>On board LAN Mode is displayed only at the PPAR Partition (Partition #0~3). Please start Partition once, and reflect the setting of WOL when you assume the Enabled(WOL enabled) On board LAN Mode again after the setting is changed to Disable or Enabled(WOL disabled).</p>

(1) Menu Operation  
[Partition] - [Partition#x] - [Mode]

- (2) Window Operations
- Specify respective Mode and click the [Apply] button.  
Confirmation dialog box is displayed.
  - Click the [Ok] button.

#### [Message]

This section describes the messages to be displayed on this window.

Message Number	Message
E_00089	Mirror Mode setting failed.
E_00090	Power Control [Reset] setting failed.
E_00461	Unable to register the specified Partition#%s as Mirror Mode enable because the DIMM does not satisfy requirements of Mirror Mode.
W_00487	Unable to change the mode, because this partition is powered on.
E_00497	Unable to register the specified Partition#%s as Mirror Mode enable because the CPU mismatch between SBs.
E_00498	Unable to register the specified Partition#%s as Mirror Mode enable because the unsupported CPU configuration.
E_00499	Unable to register the specified Partition#%s as Mirror Mode enable because of abnormal CPU composition.
E_00500	Unable to register the specified Partition#%s as Mirror Mode enable because of abnormal DIMM composition.

I_00501	The SB with DIMM that does not satisfy requirements of Mirror Mode is registered as a Reserved SB. If you register this partition as a Mirror Mode, Mirror Mode will be disabled when switching to Reserved SB. Are you sure to continue?
W_00507	Unable to set the OS Installation Mode because Mirror Mode or POST setting is modified.
W_00508	Unable to set the OS Installation Mode.
E_00521	Unable to register the specified Partition#%s as Mirror Mode enable because of abnormal SB composition.
E_00526	Unable to register the specified Partition#%s as Mirror Mode enable because of abnormal VRM composition.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference \(C122-E178EN\)](#).

## 1.4 [User Administration] Menu

You can manage user accounts from the [User Administration] menu.

### 1.4.1 [User List] window

The [User List] window displays information on the registered user accounts. Only users with Administrator privileges can view this window.

FIGURE 1.56 [User List] Window

The screenshot shows the MMB Web-UI interface. At the top, there's a header with the Fujitsu logo and system information: Model: PRIMEQUEST2800E, Part Number: MCXXXXXX, Serial Number: XXXXXXXX, Status: Normal. A navigation bar includes System, Partition, User Administration (selected), Network Configuration, and Maintenance. A 'Logout' button is in the top right. Below the navigation bar, a sidebar on the left contains 'User List' (selected), 'Change Password', and 'Who'. The main content area is titled 'User List' and includes instructions: 'Click the Add User button to add a new user. Select a user, then click the Edit/Remove User button to edit or remove the user.' Below this is a table with the following data:

User Name	Full Name	Privilege	Status	Operable Partition (for Partition Operator)
<input type="radio"/> Administrator	Default Administrator	Admin	Enabled	

At the bottom of the window, there are four buttons: 'Add User', 'Edit User', 'Remove User', and 'Cancel'.

The users set to Disabled are grayed out.

TABLE 1.81 Display items in the [User List] window

Items	Description
User Name	Displays the user name. The user name must consist of a total of 8 to 32 characters.
Full Name	Used to enter the user's real name or other related information. You can enter up to 32 characters.
Privilege	Displays the privileges of the user account.
Status	Displays the current status of this account. <ul style="list-style-type: none"> <li>Enabled</li> <li>Disabled</li> </ul>
Operable Partition	Displays the partitions that the user is permitted to operate. The window displays them only if the user account has Partition Operator privileges.

TABLE 1.82 Buttons in the [User List] window

Buttons	Description
Add User	Displays the [Add User] window.
Edit User	Displays the [Edit User] window.
Remove User	Deletes the user.
Cancel	Restores the original information and does not set the specified information.

**[Message]**

The following table lists the messages displayed in this window.

Message Number	Message
E_00031	Same name already exists. User addition failed.
E_00032	No more User addition.
E_00034	Unable to change the status to Disable because the specified user is last Administrator.
E_00035	The user is logging. User deletion failed.
I_00041	User addition was completed
I_00042	User information editing was completed.
I_00043	User deletion was completed.
W_00463	Select a User Name.
I_00464	%aa will be removed. Are you sure?
W_00404	Password differs from the re-password.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

**☐ [Add User] window**

Clicking the [Add User] button in the [User List] window displays the [Add User] window.

You can register new users in the [Add User] window.

It is possible to register up to 16 users or less.

FIGURE 1.57 [Add List] Window

Model: PRIMEQUEST2800E  
Part Number: MCXXXXXX  
Serial Number: J000000000  
Status: Normal

Active:MMB#0

System Partition User Administration Network Configuration Maintenance Logout

>User Administration >User List >Add User

User List  
Change Password  
Who

### Add User

Click the Apply Button to apply all changes.

User Name				
Password				
Confirm Password				
Privilege	<input checked="" type="radio"/> Admin <input type="radio"/> Operator <input type="radio"/> User <input type="radio"/> CE <input type="radio"/> Partition Operator			
Status	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled			
Full Name				
Operable Partition (for Partition Operator)	0	1	2	3
	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

(optional)

Apply Cancel

For details on the setting and display items in the [Add User] window, see [TABLE 1.83 Setting and display items in the \[Add User\] and \[Edit User\] windows](#).

### □ [Edit User] window

Selecting a user and clicking the [Edit User] button in the [User List] window displays the [Edit User] window.

You can change management information on user accounts in the [Edit User] window.

Changes in the administrative information of User other than User Name can be done.

FIGURE 1.58 [Edit List] Window

Model: PRIMEQUEST2800E  
Part Number: MCXXXXXX  
Serial Number: -0000-00000-  
Status: Normal

System Partition User Administration Network Configuration Maintenance Logout

>User Administration >User List >Edit User

User List  
Change Password  
Who

### Edit User

Click the Apply Button to apply all changes.

User Name	Administrator			
Current Password				
Password				
Confirm Password				
Privilege	<input checked="" type="radio"/> Admin <input type="radio"/> Operator <input type="radio"/> User <input type="radio"/> OE <input type="radio"/> Partition Operator			
Status	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled			
Full Name	Default Administrator (optional)			
Operable Partition (for Partition Operator)	0	1	2	3
	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Apply Cancel

TABLE 1.83 Setting and display items in the [Add User] and [Edit User] windows

Items	Description
User Name	Sets the user name. You can enter a total of 8 to 32 characters. You can enter the following characters in a user name: [0-9], [a-z], [A-Z], - (hyphen), _ (underscore). However, the first character of the user name must be a letter from a to z or A to Z.
Current Password	Used to enter the current password. <b>Remark</b> This item is not displayed in case of Add User windows.
Password	Sets the password. You can enter a total of 8 to 32 characters. You can specify the following characters in a password: [0-9], [a-z], [A-Z], and special characters: ! " # \$ % & ' ( ) = - ^ ~ ¥ @ ` [ ] { } : * ; + ? < . > , _
Confirm Password	Used to reenter a password for confirmation.
Privilege	Sets the privileges of the user account.
Status	Sets the current status of this account. • Enabled • Disabled
Full Name	Used to enter the user's real name or other related information. You can enter a total of up to 32 characters.
Operable Partition (for Partition Operator)	Sets the partitions that the user is permitted to operate. You can specify this only if [Partition Operator] is selected for [Privilege]. If the user privilege selected in [Privilege] is other than [Partition Operator], the window grays out the check boxes.

Items	Description
	<b>Remark</b> This item is not displayed in case of PRIMEQUEST 2800B model.

TABLE 1.84 Buttons in the [Add User] and [Edit User] windows

Buttons	Description
Apply	Adds or updates the user account, and returns to the [User List] window.
Cancel	Returns to the [User List] window without adding or updating the user account.

**[Message]**

The following table lists the messages displayed in this window.

Message Number	Message
I_00410	%aa will be added. Are you sure?
E_00032	No more User addition.
E_00409	Unable to change the privilege because the specified user is last Administrator.
I_00410	%aa will be changed. Are you sure?
W_00401	Username is too short.
W_00402	Password is too short.
W_00406	Invalid character is included in User Name.
W_00403	Invalid character is included in Password.
W_00462	The specified password is invalid.
W_00405	Invalid character is included in Full Name.
W_00407	Input characters are too long.
W_00408	Partitions are not selected. Please select at least one partition.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

**☐ [Remove User] button**

To delete a user account, select a user in the [User List] window, and then click the [Remove User] button. A deletion confirmation dialog box appears. Click the [OK] button to delete it. Click the [Cancel] button to cancel processing.

## 1.4.2 [Change Password] window

You can change the password of a logged-in user in the [Change Password] window.



FIGURE 1.59 [Change Password] window

Model: PRIMEQUEST2800E  
Part Number: MCXXXXXX  
Serial Number: XXXXXXXX  
Status: Normal

Active:MMB#0

System Partition User Administration Network Configuration Maintenance Logout

>User Administration >Change Password

☒ User List  
☒ Change Password  
☐ Who

### Change Password

Enter the new Password for "Administrator" in the New Password and Confirm New Password fields.

Current Password	
New Password	
Confirm New Password	

Apply Cancel

**Remarks**

The entered password must consist of at least eight characters. The message to the effect that should be input by eight characters or more is displayed for eight characters or less. The password that can be analogized cannot be set again.

TABLE 1.85 Buttons in the [Change Password] window

Buttons	Description
Apply	Registers the changed password.
Cancel	Restores the original information and does not change the password.

**[Message]**

The following table lists the messages displayed in this window.

Message Number	Message
E_00012	One or more errors occurred while setting.
E_00018	Information acquisition failed.
E_00036	Changing Password failed.
I_00037	Changing Password completed.
W_00404	Password differs from the re-password.
W_00402	Password is too short.
W_00403	Invalid character is included in Password.
I_00417	Are you sure?
W_00462	The specified password is invalid.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

### 1.4.3 [Who] window

The [Who] window lists the users who connect to the MMB through the serial port, Telnet/SSH or the Web-UI.

FIGURE 1.60 [Change Password] window




TABLE 1.86 Display items in the [Who] window

Items	Description
User Name	Displays the name of the user logged in to the MMB through the serial port, Telnet/SSH, or the Web-UI.
Login Time	Displays the user's login time.
By	Displays whether the Web-UI or Telnet/SSH was used for the login. If the serial port was used for the login, this field displays "-" (hyphen).
From	Displays the host name or the IP address (IPv4 or IPv6 address) of a remote host if the user logged in remotely.  If the host name can be identified from the DNS set on the MMB at the login time, this field displays the host name. Otherwise, it displays the IP address. If the serial port of the MMB was used for the login, the field displays "-" (hyphen).  If the user logged in from the Web-UI, the field displays only the IP address using the DNS.

#### [Message]

The following table lists the messages displayed in this window.

Message Number	Message
E_00098	Failed to get login user information

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

## 1.5 [Network Configuration] Menu

The [Network Configuration] menu is available only to users who have Administrator privileges.

### 1.5.1 [Date/Time] window

You can set the date and time of the MMB in the [Date/Time] window.

FIGURE 1.61[Date/Time] window

The screenshot shows the MMB Web-UI interface. At the top, there's a header with the Fujitsu logo, model information (PRIMEQUEST2800E), and user status (Active:MMB#0). Below this is a navigation bar with tabs: System, Partition, User Administration, Network Configuration, and Maintenance. The 'Network Configuration' tab is active, and the 'Date/Time' sub-tab is selected. On the left, a sidebar menu lists various configuration options, with 'Date/Time' highlighted. The main content area is titled 'Date/Time' and includes a 'Refresh' and 'Help' button. Below the title, there's a message: 'Click the Apply Button to apply all changes.' The configuration fields are as follows:

Date	2013 - 4 - 16
Time	<input type="checkbox"/> Modify the Time 16 : 29 : 54
Time zone	Asia / Tokyo
NTP	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
NTP Time Correction Mode	<input checked="" type="radio"/> Step <input type="radio"/> Slew
NTP Server1	66.178.233.4
NTP Server2	2001:1010:2020:3030:1111:2222:3333:4444
NTP Server3	10.30.20.40
Current Sync Status	

At the bottom right, there are 'Apply' and 'Cancel' buttons.

TABLE 1.87 Setting and display items in the [Date/Time] window

Items	Description
Date	<p>Displays and sets the date.</p> <p>If only a date is specified and [Modify the Time] is unchecked, the specified date is set.</p> <p>The time is defined as the instant when the [Apply] button is clicked.</p> <p>For example, if you change the date to August 1 (during daylight savings time) at 13:00 on January 1 (outside daylight savings time), processing assumes that the specified time and date are 13:00 on August 1.</p>
Time	<p>Displays the [Date/Time] window display time (hh:mm:ss). This time is shown in 24-hour format.</p> <p>To update the displayed time, the window must be refreshed.</p> <p>If automatic refresh is set, the displayed time is the window refresh time.</p> <p>To set a time, check the [Modify the Time] check box. With this check box checked, the [hh:mm:ss] field can be set. With the check box unchecked, the [hh:mm:ss] field in</p>

Items	Description
	the window is grayed out.
Time zone	Used to select a time zone from the pull-down menu.
NTP	<p>Sets whether to enable or disable the NTP function.</p> <ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul> <p>With [Enable] selected, the MMB synchronizes with the time of the NTP server specified below in [NTP1] to [NTP3]. It is synchronized with immediately after the Enable setting at the time of the server side regardless of the setting of NTP Time Correction Mode.</p> <p>The default is Disable.</p>
NTP Time Correction Mode	<p>Sets an NTP time correction mode. (This item is valid only if [NTP] is [Enable]. If it is set to [Disable], the item is grayed out.)</p> <ul style="list-style-type: none"> <li>- [Step]: If the time difference with the NTP server is less than 128 milliseconds, the MMB uses Slew mode (0.0005 seconds per second) to correct the time. The MMB corrects the time as soon as the difference reaches 128 milliseconds. If the time difference is outside a range of -1000 to +1000 seconds (16 minutes and 40 seconds), the NTP function stops.</li> <li>- [Slew]: The following action is taken depending on the time difference with the NTP server: <ul style="list-style-type: none"> <li>• If the difference is within a range of -600 to +600 seconds (10 minutes), the NTP executes Slew adjustment, which corrects the time at a rate of up to 0.0005 seconds per second without reversal.</li> <li>• If the difference is outside a range of -600 to +600 seconds (10 minutes) and within a range of -1000 to +1000 seconds (16 minutes and 40 seconds), the NTP executes Step adjustment. (In this case, the clock may be reversed.)</li> <li>• If the difference is outside a range of -1000 to +1000 seconds (16 minutes and 40 seconds), the NTP function stops.</li> </ul> </li> </ul> <p>The default is Step.</p>
NTP 1	<p>Sets the IPv4 or IPv6 IP address of the Primary NTP server. (This item is valid only if [NTP] is [Enable]. If it is set to [Disable], the item is grayed out.)</p>
NTP 2	<p>Sets the IPv4 or IPv6 IP address of the Secondary NTP server. (This item is valid only if [NTP] is [Enable]. If it is set to [Disable], the item is grayed out.)</p>
NTP 3	<p>Sets the IPv4 or IPv6 IP address of the Third NTP server. (This item is valid only if [NTP] is [Enable]. If it is set to [Disable], the item is grayed out.)</p>
Current Sync Status	<p>Displays the synchronous status with the current NTP server.</p> <ul style="list-style-type: none"> <li>• When synchronized: Displays the latest synchronous time together with the IP address as follows: xxx.xxx.xxx.xxx yyyy-mm-dd -dd:mm:ss</li> <li>• When not synchronized: Displays "No Sync."</li> </ul>

TABLE 1.88 Buttons in the [Date/Time] window

Buttons	Description
Apply	Sets the specified information.

Cancel	Restores the original information and does not set the specified information, such as the date and time zone.
--------	---

## (1) Menu Operation

[Network Configuration] - [Date/Time]

## (2) Window Operations

1. Specify information such as the date and time zone. Then, click the [Apply] button.  
This sets the information such as the date and time zone.

**[Message]**

The following table lists the messages displayed in this window.

Message Number	Message
I_00013	Setting completed.
E_00020	The IP address overlaps.
E_00100	Failed to set Date/Time information
W_00414	Invalid Date Format
W_00434	Invalid Time Format
W_00433	The duplicate IP address was found.
W_00432	Invalid IP Address specified.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

**Time synchronization with NTP**

This section describes the operational specifications for the NTP client.

- When starting time synchronization:  
The NTP client on the MMB synchronizes the time at the start of operation, irrespective of the time difference with the NTP server.  
The NTP client on the MMB starts operation:
  - when the NTP services on the MMB are enabled (i.e., when [Enable] in the [NTP] field is checked and the [Apply] button is clicked in the [Network Configuration] - [Date/Time] window), or
  - when the MMB is reset, the MMB redundancy is switched, and the AC power is turned from OFF to ON while the NTP services on the MMB are enabled.
- When starting time synchronization:  
The time-adjusting method on the NTP varies depending on the NTP operation mode (Step mode or Slew mode).  
In Step mode, if the time difference between the synchronized NTP servers and the MMB is:
  - (1) within a range of -0.128 to +0.128 seconds, the NTP executes Slew adjustment, which corrects the time at a rate of up to 0.0005 per second without reversal.
  - (2) outside a range of -0.128 to +0.128 seconds and within a range of -1000 to +1000 seconds, the NTP executes Step adjustment. (In this case, the clock may be reversed.)
  - (3) outside a range of -1000 to +1000 seconds, the NTP function stops.  
In Slew mode, if the time difference between the synchronized NTP servers and the MMB is:
  - (1) within a range of -600 to +600 seconds (10 minutes) , the NTP executes Slew adjustment, which corrects the time at a rate of up to 0.0005 per second without reversal.
  - (2) outside a range of -600 to +600 seconds (10 minutes) and within a range of -1000 to +1000 seconds (16 minutes and 40 seconds) , the NTP executes Step adjustment. (In this case, the clock may be reversed.)
  - (3) outside a range of -1000 to +1000 seconds (16 minutes and 40 seconds) , the NTP function stops.
- Time synchronization interval  
The NTP client synchronizes at an interval of 64 to 1024 seconds. The initial synchronization interval is 64 seconds. As the synchronization accuracy becomes stable, this interval gradually doubles from 64 seconds to 128 seconds, then to 256 seconds, then to 512 seconds, and finally to 1024 seconds.

This increment algorithm for the synchronization interval conforms to RFC 1305. For details, see Sections 3.4.2 to 3.4.9 in RFC 1305.

- Stratum of the NTP servers on the MMB  
The stratum of the NTP servers on the MMB is the value of stratum + 1 of the synchronized external NTP servers. Unless the NTP servers synchronize with external NTP servers, the stratum is 5.
- Support for leap seconds  
The NTP on the MMB has no function for inserting leap seconds. Therefore, if you want to associate the MMB time with leap seconds, you need to synchronize it with an external NTP server that supports leap seconds.  
If the NTP client on the MMB is set to Step mode, and the external NTP server slowly changes the time for the leap second adjustment, the MMB time may be adjusted with the Step adjustment when a time difference outside a range of -0.128 to +0.128 second occurs. To prevent the leap second adjustment from using Step adjustment, use Slew mode.

## 1.5.2 [Network Interface] window

The [Network Interface] menu has the following windows:

[IPv4 Interface] window

[IPv6 Interface] window

### ☐ [IPv4 Interface] window

You can set the IPv4 IP address for MMB access and other related items in the [IPv4 Interface] window.

FIGURE 1.62 [IPv4 Interface] window (PRIMEQUEST 2400E/2800E) (1)

**FUJITSU** Model: PRIMEQUEST2800E Active:MMB#0  
 Part Number: MCXXXXXXX  
 Serial Number: 0000000001  
 Status: Normal

System Partition User Administration Network Configuration Maintenance Logout

>Network Configuration >Network Interface >IPv4 Interface

**IPv4 Interface**

Click the Apply button for all changes to take effect.

**MMB Virtual/Physical IP Address**

Virtual IP Address	
Hostname	PRIMEQUESTSWBG4
IP Address	10 . 124 . 240 . 110
Subnet Mask	255 . 255 . 255 . 0
Gateway address	10 . 124 . 240 . 1
MMB#0 IP Address	
Interface	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
Hostname (optional)	
IP Address	0 . 0 . 0 . 0
Subnet Mask	255 . 255 . 255 . 255
Gateway address	0 . 0 . 0 . 0
DNS (optional)	
DNS	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
DNS Server 1	0 . 0 . 0 . 0

Apply Cancel

FIGURE 1.63 [IPv4 Interface] window (PRIMEQUEST 2400E/2800E) (2)

Model: PRIMEQUEST2800E  
Part Number: MCXXXXXXX  
Serial Number: 0000000001  
Status: Normal

Active:MMB#0

System Partition User Administration Network Configuration Maintenance Logout

>Network Configuration >Network Interface >IPv4 Interface

**IPv4 Interface**

DNS Server 1: 0 . 0 . 0 . 0 . 0  
DNS Server 2: 0 . 0 . 0 . 0 . 0  
DNS Server 3: 0 . 0 . 0 . 0 . 0  
Management LAN  
Dualization: ☐ Enable ☒ Disable

**Maintenance IP Address**

Interface: ☐ Enable ☒ Disable  
IP Address: 0 . 0 . 0 . 0 . 0  
Subnet Mask: 0 . 0 . 0 . 0 . 0  
Gateway address: 0 . 0 . 0 . 0 . 0  
SMTP address: 0 . 0 . 0 . 0 . 0

**Internal IP Address**

Interface: ☒ Enable ☐ Disable  
IP Address: 172 . 30 . 0 . 1  
Subnet Mask: 255 . 255 . 255 . 0

Apply Cancel

TABLE 1.89 Setting and display items in the [IPv4 Interface] window (PRIMEQUEST 2400E/2800E)

Items	Description
<b>MMB Virtual/Physical IP Address</b>	
Virtual IP Address	Sets the virtual IPv4 IP address for Web-UI access. If the MMB has a redundant configuration, the switched MMB will take over this virtual IP address.
Hostname	Sets the host name in FQDN format. You can enter the following characters: [a-z], [A-Z], [0-9], - (hyphen), . (period). Only the above characters can be specified. Also, the following restrictions apply: <ul style="list-style-type: none"> <li>The character string must begin with an alphabetic character.</li> <li>The character string cannot begin or end with the following character specified: <ul style="list-style-type: none"> <li>- (hyphen) or . (period).</li> </ul> </li> </ul> The default is "PRIMEQUEST" + Product Serial Number. For example, if the serial number is 1020516004, the character string is "PRIMEQUEST1020516004".  <b>Remarks</b> The setting in FQDN format is not required if you are not operating on the domain.
IP Address	Sets the IP address.
Subnet Mask	Sets the subnet mask.
Gateway address	Sets the gateway IP address.
MMB#0 IP Address	Sets the physical IP address assigned to the MMB#0 interface.



Items	Description
	This item is available only if the system has MMB#0. You cannot access the Web-UI from this interface. Unless MMB#0 is mounted, the window does not display the [MMB#0 IP Address] table.
Interface	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Hostname (optional)	Sets the host name in FQDN format.
IP Address	Sets the IP address.
Subnet Mask	Sets the subnet mask.
Gateway address	Sets the gateway IP address.
MMB#1 IP Address	Sets the physical IP address assigned to the MMB#1 interface. This item is available only if the system has MMB#1. You cannot access the Web-UI from this interface. Unless MMB#0 is mounted, the window does not display the [MMB#1 IP Address] table.
Interface	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Hostname (optional)	Sets the host name in FQDN format.
IP Address	Sets the IP address.
Subnet Mask	Sets the subnet mask.
Gateway address	Sets the gateway IP address.
DNS (optional)	Sets whether to use the DNS server
DNS	Sets whether to use the DNS server. To use the DNS, select Enable. The default is Disable.
DNS Server 1	Sets the IP address of the Primary DNS server.
DNS Server 2	Sets the IP address of the Secondary DNS server.
DNS Server 3	Sets the IP address of the Third DNS server.
Management LAN	Duplicates the management LAN.
Dualization	Duplicates the management LAN. The default is Disable.
Maintenance IP Address	
Interface	Sets whether to enable or disable the CE/REMCS LAN interface. The default is Disable.
IP Address	Sets the IP address.
Subnet Mask	Sets the subnet mask.
Gateway address	Sets the gateway IP address.
SMTP address	Sets the SMTP IP address.
Internal IP Address	
Interface	Sets whether to enable or disable the Internal LAN interface. The default is Disable.
IP Address	Sets the IP address.
Subnet Mask	Sets the subnet mask.

FIGURE 1.64 [IPv4 Interface] window (PRIMEQUEST 2800B) (1)

Model: PRIMEQUEST 2800B  
Part Number: MCF3AC111  
Serial Number:   
Status: Normal

System User Administration Network Configuration Maintenance Logout  
>Network Configuration >Network Interface >IPv4 Interface

**IPv4 Interface** Help

Click the Apply button for all changes to take effect.

**MMB IP Address**

IP Address				
Hostname	PRIMEQUEST1541346003			
IP Address	10	24	141	130
Subnet Mask	255	255	255	0
Gateway address	10	24	141	1
DNS (optional)				
DNS	<input type="radio"/> Enable <input checked="" type="radio"/> Disable			
DNS Server 1	0	0	0	0
DNS Server 2	0	0	0	0
DNS Server 3	0	0	0	0
Management LAN				
Dualization	<input type="radio"/> Enable <input checked="" type="radio"/> Disable			

**Maintenance IP Address**

Apply Cancel

FIGURE 1.65 [IPv4 Interface] window (PRIMEQUEST 2800B) (2)

Model: PRIMEQUEST 2800B  
Part Number: MCF3AC111  
Serial Number:   
Status: Normal

System User Administration Network Configuration Maintenance Logout  
>Network Configuration >Network Interface >IPv4 Interface

**IPv4 Interface** Help

Click the Apply button for all changes to take effect.

**Maintenance IP Address**

Interface	<input type="radio"/> Enable <input checked="" type="radio"/> Disable			
IP Address	0	0	0	0
Subnet Mask	0	0	0	0
Gateway address	0	0	0	0
SMTP address	0	0	0	0

**Internal IP Address**

Interface	<input type="radio"/> Enable <input checked="" type="radio"/> Disable			
IP Address	172	30	0	1
Subnet Mask	255	255	255	0

Apply Cancel

TABLE 1.90 Setting and display items in the [IPv4 Interface] window (PRIMEQUEST 2800B)

Items	Description
MMB IP Address	
IP Address	
Hostname	<p>Sets the host name in FQDN format.            You can enter the following characters:            [a-z], [A-Z], [0-9], - (hyphen), . (period).            Only the above characters can be specified.            Also, the following restrictions apply:</p> <ul style="list-style-type: none"> <li>• The character string must begin with an alphabetic character.</li> <li>• The character string cannot begin or end with the following character specified:              - (hyphen) or . (period).</li> </ul> <p>The default is "PRIMEQUEST" + Product Serial Number.            For example, if the serial number is 1020516004, the character string is "PRIMEQUEST1020516004".</p> <p><b>Remarks</b>            The setting in FQDN format is not required if you are not operating on the domain.</p>
IP Address	Sets the IP address.
Subnet Mask	Sets the subnet mask.
Gateway address	Sets the gateway IP address.
DNS (optional)	
DNS	<p>Sets whether to use the DNS server.            To use the DNS, select Enable.            The default is Disable.</p>
DNS Server 1	Sets the IP address of the Primary DNS server.
DNS Server 2	Sets the IP address of the Secondary DNS server.
DNS Server 3	Sets the IP address of the Third DNS server.
Management LAN	
Dualization	<p>Duplicates the management LAN.            The default is Disable.</p>
Maintenance IP Address	
Interface	<p>Sets whether to enable or disable the CE/REMCS LAN interface.            The default is Disable.</p>
IP Address	Sets the IP address.
Subnet Mask	Sets the subnet mask.
Gateway address	Sets the gateway IP address.
SMTP address	Sets the SMTP IP address.
Internal IP Address	
Interface	<p>Sets whether to enable or disable the Internal LAN interface.            The default is Disable.</p>
IP Address	Sets the IP address.
Subnet Mask	Sets the subnet mask.

TABLE 1.91 Buttons in the [IPv4 Interface] window

Buttons	Description
Apply	Sets the entered information.
Cancel	Restores the original information and does not set the specified information, such as the IP address.

## (1) Menu Operation

[Network Configuration] - [Network Interface] - [IPv4 Interface]

## (2) Window Operations

1. Select or enter the IP address, or other items of network interface information. Then, click the [Apply] button.

This sets the specified information, such as the IP address.

**[IPv6 Interface] window**

You can set the IP address for MMB access and other related items in the [IPv6 Interface] window.

FIGURE 1.66 [IPv6 Interface] window (PRIMEQUEST 2400E/2800E) (1)

**FUJITSU** Model: PRIMEQUEST2800E Active:MMB#0  
Part Number: MCXXXXXXX  
Serial Number: 0000000001  
Status: Normal

System Partition User Administration **Network Configuration** Maintenance Logout

>Network Configuration >Network Interface >IPv6 Interface

☐ Date/Time  
☐ Network Interface  
☐ IPv4 Interface  
☒ IPv6 Interface  
☐ Management LAN Port Conf  
☐ Network Protocols  
☐ Refresh Rate  
☐ SNMP Configuration  
☐ SSL  
☐ SSH  
☐ Remote Server Management  
☐ Access Control  
☐ Alarm E-Mail

### IPv6 Interface

Click the Apply button for all changes to take effect.

#### MMB Virtual/Physical IP Address

Virtual IP Address	
Hostname	PRIMEQUESTSWBG4
Automatic Acquisition	Auto
IP Address	::
Prefix Length	0
Gateway address	::
MMB#0 IP Address	
Interface	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
Hostname (optional)	
Automatic Acquisition	Auto
IP Address	::
Prefix Length	0
Gateway address	::
DNS (optional)	

Apply Cancel

FIGURE 1.67 [IPv6 Interface] window (PRIMEQUEST 2400E/2800E) (2)

**FUJITSU**

Model: PRIMEQUEST2800E  
Part Number: MCXXXXXXX  
Serial Number: 0000000001  
Status: Normal

Active:MMB#0

System Partition User Administration Network Configuration Maintenance Logout

>Network Configuration >Network Interface >IPv6 Interface

☐ Date Time  
☐ Network Interface  
    ☐ IPv4 Interface  
    ☒ IPv6 Interface  
☐ Management LAN Port Control  
☐ Network Protocols  
☐ Refresh Rate  
☐ SNMP Configuration  
☐ SSL  
☐ SSH  
☐ Remote Server Management  
☐ Access Control  
☐ Alarm E-Mail

### IPv6 Interface

IP Address	:::.....
Prefix Length	0
Gateway address	:::.....
DNS (optional)	
DNS	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
DNS Server 1	:::.....
DNS Server 2	:::.....
DNS Server 3	:::.....
Management LAN	
Dualization	<input type="radio"/> Enable <input checked="" type="radio"/> Disable

### Maintenance IP Address

Interface	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
IP Address	:::.....
Prefix Length	0
Gateway address	:::.....
SMTP address	:::.....

Apply Cancel

TABLE 1.92 Setting and display items in the [IPv6 Interface] window (PRIMEQUEST 2400E/2800E)

Items	Description
MMB Virtual/Physical IP Address	
Virtual IP Address	Sets the virtual IPv6 IP address for Web-UI access. If the MMB has a redundant configuration, the switched MMB will take over this virtual IP address.
Hostname	<p>Sets the host name in FQDN format. You can enter the following characters: [a-z], [A-Z], [0-9], - (hyphen), . (period). Only the above characters can be specified. Also, the following restrictions apply:</p> <ul style="list-style-type: none"> <li>• The character string must begin with an alphabetic character.</li> <li>• The character string cannot begin or end with the following character specified: - (hyphen) or . (period).</li> </ul> <p>The default is "PRIMEQUEST" + Product Serial Number. For example, if the serial number is 1020516004, the character string is "PRIMEQUEST1020516004".</p> <p><b>Remarks</b> The setting in FQDN format is not required if you are not operating on the domain.</p>
Automatic Acquisition	Automatically acquires data with a click of the [Auto] button. The global address, prefix length, and gateway IP address are automatically acquired to overwrite existing data.
IP Address	Sets the IP address.
Prefix Length	Sets the prefix length.
Gateway address	Sets the gateway IP address.
MMB#0 IP Address	<p>Sets the physical IP address assigned to the MMB#0 interface. This item is available only if the system has MMB#0. You cannot access the Web-UI from this interface. Unless MMB#0 is mounted, the window does not display the [MMB#0 IP Address] table.</p>
Interface	<p>Sets whether to enable or disable the MMB#1 physical IP address. The default is Disable.</p>
Hostname (optional)	Sets the host name in FQDN format.
Automatic Acquisition	Automatically acquires data with a click of the [Auto] button. The global address, prefix length, and gateway IP address are automatically acquired to overwrite existing data.
IP Address	Sets the IP address.
Prefix Length	Sets the prefix length.
Gateway address	Sets the gateway IP address.
MMB#1 IP Address	<p>Sets the physical IP address assigned to the MMB#1 interface. This item is available only if the system has MMB#1. You cannot access the Web-UI from this interface. Unless MMB#0 is mounted, the window does not display the [MMB#1 IP Address] table.</p>
Interface	<p>Sets whether to enable or disable the MMB#1 physical IP address. The default is Disable.</p>
Hostname (optional)	Sets the host name in FQDN format.
Automatic Acquisition	Automatically acquires data with a click of the [Auto] button. The global address, prefix length, and gateway IP address are automatically acquired to overwrite

Items	Description
	existing data.
IP Address	Sets the IP address.
Prefix Length	Sets the prefix length.
Gateway address	Sets the gateway IP address.
DNS (optional)	Sets whether to use the DNS server
DNS	Sets whether to use the DNS server. To use the DNS, select Enable. The default is Disable.
DNS Server 1	Sets the IP address of the Primary DNS server.
DNS Server 2	Sets the IP address of the Secondary DNS server.
DNS Server 3	Sets the IP address of the Third DNS server.
Management LAN	Duplicates the management LAN.
Dualization	Duplicates the management LAN. The default is Disable.
Maintenance IP Address	
Interface	Sets whether to enable or disable the CE/REMCS LAN interface. The default is Disable.
IP Address	Sets the IP address.
Prefix Length	Sets the prefix length.
Gateway address	Sets the gateway IP address.
SMTP address	Sets the SMTP IP address.
Internal IP Address	
Interface	Sets whether to enable or disable the Internal LAN interface. The default is Disable.
IP Address	Sets the IP address.
Prefix Length	Sets the prefix length.

FIGURE 1.68 [IPv6 Interface] window (PRIMEQUEST 2800B) (1)

Model: PRIMEQUEST 2800B  
Part Number: MCF3AC111  
Serial Number: ~~XXXXXXXXXX~~  
Status: Normal

System User Administration Network Configuration Maintenance Logout

>Network Configuration >Network Interface >IPv6 Interface

**IPv6 Interface**

Click the Apply button for all changes to take effect.

MMB IP Address

IP Address	
Hostname	PRIMEQUEST1541346003
Automatic Acquisition	(Auto)
IP Address	::
Prefix Length	0
Gateway address	::
DNS (optional)	
DNS	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
DNS Server 1	::
DNS Server 2	::
DNS Server 3	::
Management LAN	
Dualization	<input type="radio"/> Enable <input checked="" type="radio"/> Disable

Apply Cancel

FIGURE 1.69 [IPv6 Interface] window (PRIMEQUEST 2800B) (2)

Model: PRIMEQUEST 2800B  
Part Number: MCF3AC111  
Serial Number:   
Status: Normal

System User Administration Network Configuration Maintenance Logout

>Network Configuration>Network Interface>IPv6 Interface

**IPv6 Interface**

DNS Server 1  
DNS Server 2  
DNS Server 3  
Management LAN  
Dualization ☐ Enable ☒ Disable

**Maintenance IP Address**

Interface ☐ Enable ☒ Disable  
IP Address  
Prefix Length  
Gateway address  
SMTP address

**Internal IP Address**

Interface ☐ Enable ☒ Disable  
IP Address  
Prefix Length

Apply Cancel

TABLE 1.93 Setting and display items in the [IPv6 Interface] window (PRIMEQUEST 2800B)

Items	Description
MMB IP Address	
IP Address	Sets the virtual IPv6 IP address for Web-UI access.
Hostname	<p>Sets the host name in FQDN format. You can enter the following characters: [a-z], [A-Z], [0-9], - (hyphen), . (period). Only the above characters can be specified. Also, the following restrictions apply:</p> <ul style="list-style-type: none"> <li>The character string must begin with an alphabetic character.</li> <li>The character string cannot begin or end with the following character specified: - (hyphen) or . (period).</li> </ul> <p>The default is "PRIMEQUEST" + Product Serial Number. For example, if the serial number is 1020516004, the character string is "PRIMEQUEST1020516004".</p> <p><b>Remarks</b> The setting in FQDN format is not required if you are not operating on the domain.</p>
Automatic Acquisition	Automatically acquires data with a click of the [Auto] button. The global address, prefix length, and gateway IP address are automatically acquired to overwrite existing data.
IP Address	Sets the IP address.
Prefix Length	Sets the prefix length.
Gateway address	Sets the gateway IP address.
DNS (optional)	
DNS	<p>Sets whether to use the DNS server. To use the DNS, select Enable. The default is Disable.</p>



Items	Description
DNS Server 1	Sets the IP address of the Primary DNS server.
DNS Server 2	Sets the IP address of the Secondary DNS server.
DNS Server 3	Sets the IP address of the Third DNS server.
Management LAN	
Dualization	Duplicates the management LAN. The default is Disable.
Maintenance IP Address	
Interface	Sets whether to enable or disable the CE/REMCS LAN interface. The default is Disable.
IP Address	Sets the IP address.
Prefix Length	Sets the prefix length.
Gateway address	Sets the gateway IP address.
SMTP address	Sets the SMTP IP address.
Internal IP Address	
Interface	Sets whether to enable or disable the Internal LAN interface. The default is Disable.
IP Address	Sets the IP address.
Prefix Length	Sets the prefix length.

TABLE 1.94 Buttons in the [IPv6 Interface] window

Buttons	Description
Auto	A global address and the prefix length, etc. are automatically acquired.
Apply	Sets the entered information.
Cancel	Restores the original information and does not set the specified information, such as the IP address.

(1) Menu Operation  
[Network Configuration] - [Network Interface] - [IPv6 Interface]

(2) Window Operations  
1. Select or enter the IP address, or other items of network interface information. Then, click the [Apply] button.  
This sets the specified information, such as the IP address.

### 1.5.3 [Management LAN Port Configuration] window

You can make the Speed/Duplex setting for each port on the MMB in the [Management LAN Port Configuration] window.

FIGURE 1.70 [Management LAN Port Configuration] window(PRIMEQUEST 2400E/2800E)

**FUJITSU** Model: PRIMEQUEST 2800E Active:MMB#1  
Part Number: [REDACTED]  
Serial Number: [REDACTED]  
Status: Normal

System Partition User Administration **Network Configuration** Maintenance Logout  
>Network Configuration >Management LAN Port Configuration

☐ Date Time  
☐ Network Interface  
☒ Management LAN Port Configuration  
☐ Network Protocols  
☐ Refresh Rate  
☐ SNMP Configuration  
☐ SSL  
☐ SSH  
☐ Remote Server Management  
☐ Access Control  
☐ Alarm E-Mail

### Management LAN Port Configuration

Click the Apply button for all changes to take effect.

**Speed/Duplex for MMB#0**

User port	Auto
Maintenance port	Auto
REMCS port	Auto

**Speed/Duplex for MMB#1**

User port	Auto
Maintenance port	Auto
REMCS port	Auto

Apply Cancel

FIGURE 1.71 [Management LAN Port Configuration] window(PRIMEQUEST 2800B)

**FUJITSU** Model: PRIMEQUEST 2800B  
Part Number: MCF3AC111  
Serial Number: [REDACTED]  
Status: Normal

System User Administration **Network Configuration** Maintenance Logout  
>Network Configuration >Management LAN Port Configuration

☐ Date Time  
☐ Network Interface  
☒ Management LAN Port Configuration  
☐ Network Protocols  
☐ Refresh Rate  
☐ SNMP Configuration  
☐ SSL  
☐ SSH  
☐ Remote Server Management  
☐ Access Control  
☐ Alarm E-Mail

### Management LAN Port Configuration

Click the Apply button for all changes to take effect.

**Speed/Duplex for MMB**

User port	Auto
Maintenance port	Auto

Apply Cancel

TABLE 1.95 Setting and display items in the [Management LAN Port Configuration] window in case of PRIMEQUEST 2400E/2800E

Items	Description
Speed/Duplex for MMB#0	
User port	<p>Sets Speed/Duplex for the MMB#0 User port.</p> <ul style="list-style-type: none"> <li>• Auto</li> <li>• 1G/Full</li> <li>• 100M/Full</li> <li>• 100M/Half</li> <li>• 10M/Full</li> <li>• 10M/Half</li> </ul> <p>The default is Auto.</p> <p>Remarks The window displays this item only if MMB#0 is mounted.</p>
Maintenance port	<p>Sets Speed/Duplex for the MMB#0 Maintenance port.</p> <ul style="list-style-type: none"> <li>• Auto</li> <li>• 100M/Full</li> <li>• 100M/Half</li> <li>• 10M/Full</li> <li>• 10M/Half</li> </ul> <p>The default is Auto.</p> <p>Remarks The window displays this item only if MMB#0 is mounted.</p>
REMCS port	<p>Sets Speed/Duplex for the MMB#0 REMCS port.</p> <ul style="list-style-type: none"> <li>• Auto</li> <li>• 100M/Full</li> <li>• 100M/Half</li> <li>• 10M/Full</li> <li>• 10M/Half</li> </ul> <p>The default is Auto.</p> <p>Remarks The window displays this item only if MMB#0 is mounted</p>
Speed/Duplex for MMB#1	
User port	<p>Sets Speed/Duplex for the MMB#1 User port.</p> <ul style="list-style-type: none"> <li>• Auto</li> <li>• 1G/Full</li> <li>• 100M/Full</li> <li>• 100M/Half</li> <li>• 10M/Full</li> <li>• 10M/Half</li> </ul> <p>The default is Auto.</p> <p>Remarks The window displays this item only if MMB#1 is mounted.</p>
Maintenance port	<p>Sets Speed/Duplex for the MMB#1 Maintenance port.</p> <ul style="list-style-type: none"> <li>• Auto</li> <li>• 100M/Full</li> <li>• 100M/Half</li> <li>• 10M/Full</li> <li>• 10M/Half</li> </ul>

Items	Description
	<p>The default is Auto.</p> <p><b>Remarks</b> The window displays this item only if MMB#1 is mounted.</p>
REMCS port	<p>Sets Speed/Duplex for the MMB#1 Maintenance port.</p> <ul style="list-style-type: none"> <li>• Auto</li> <li>• 100M/Full</li> <li>• 100M/Half</li> <li>• 10M/Full</li> <li>• 10M/Half</li> </ul> <p>The default is Auto.</p> <p><b>Remarks</b> The window displays this item only if MMB#1 is mounted.</p>
Item for PRIMEQUEST 2800B	
Speed/Duplex for MMB	<p>Sets Speed/Duplex for the MMB port.</p> <ul style="list-style-type: none"> <li>• Auto</li> <li>• 1G/Full</li> <li>• 100M/Full</li> <li>• 100M/Half</li> <li>• 10M/Full</li> <li>• 10M/Half</li> </ul> <p>The default is Auto.</p> <p><b>Remarks</b> REMCS port is not displayed. Only the USER port can have the setting of 1G/Full.</p>

TABLE 1.96 Setting and display items in the [Management LAN Port Configuration] window in case of PRIMEQUEST 2800B

Items	Description
Speed/Duplex for MMB	
User port	<p>Sets Speed/Duplex for the MMB User port.</p> <ul style="list-style-type: none"> <li>• Auto</li> <li>• 1G/Full</li> <li>• 100M/Full</li> <li>• 100M/Half</li> <li>• 10M/Full</li> <li>• 10M/Half</li> </ul> <p>The default is Auto.</p>
Maintenance port	<p>Sets Speed/Duplex for the MMB Maintenance port.</p> <ul style="list-style-type: none"> <li>• Auto</li> <li>• 100M/Full</li> <li>• 100M/Half</li> <li>• 10M/Full</li> <li>• 10M/Half</li> </ul> <p>The default is Auto.</p>

TABLE 1.97 Buttons in the [Management LAN Port Configuration] window

Buttons	Description
Apply	Sets the entered information.

Cancel	Restores the original information and does not set the specified information for the Speed/Duplex setting.
--------	--

- (1) Menu Operation  
[Network Configuration] - [Management LAN Port Configuration]
- (2) Window Operations
  1. Specify Speed/Duplex. Then, click the [Apply] button.  
This sets Speed/Duplex.

## 1.5.4 [Network Protocols] window

You can configure the network protocols of the MMB in the [Network Protocols] window.

FIGURE 1.72 [Network Protocols] window

The screenshot shows the Fujitsu MMB Web-UI interface. At the top, it displays the model (PRIMEQUEST2800E), part number (MCXXXXXX), serial number, and status (Normal). The active MMB is 0. The navigation menu on the left includes System, Partition, User Administration, Network Configuration, and Maintenance. The 'Network Configuration' menu is expanded, showing options like Date Time, Network Interface, Management LAN Port Configuration, Network Protocols (selected), Refresh Rate, SNMP Configuration, SSL, SSH, Remote Server Management, Access Control, and Alarm E-Mail. The main content area is titled 'Network Protocols' and includes a 'Help' button. Below the title, there is a message: 'Click the Apply Button to apply all changes.' The configuration is organized into four sections: Web (HTTP/HTTPS), Telnet, SSH, and SNMP. Each section contains a table of settings with 'Enable' and 'Disable' radio buttons, a port number input field, and a timeout input field. The 'Web' section is currently active, showing HTTP and HTTPS settings. The 'Telnet' section shows Telnet settings. The 'SSH' section shows SSH settings. The 'SNMP' section shows SNMP Agent and Trap settings. At the bottom right, there are 'Apply' and 'Cancel' buttons.

Items	Description
Web (HTTP/HTTPS)	
HTTP	Sets Enable or Disable for HTTP. The default is Disable.
HTTP Port#	Sets the port number used for HTTP. The default is 8081.
HTTPS	Sets Enable or Disable for HTTPS. The default is Disable.

TABLE 1.98 Setting and display items in the [Network Protocols] window

Items	Description
Web (HTTP/HTTPS)	
HTTP	Sets Enable or Disable for HTTP. The default is Disable.
HTTP Port#	Sets the port number used for HTTP. The default is 8081.
HTTPS	Sets Enable or Disable for HTTPS. The default is Disable.

Items	Description
HTTPS Port#	Sets the port number used for HTTPS. The default is 432.
Timeout	Sets the length of time before a time-out due to no input causes the termination of an HTTP or HTTPS connection. You can specify 0 or a value in a range of 60 to 9999. 0 means there is no time-out. The default is 600 seconds.
Telnet	
Telnet	Sets Enable or Disable for Telnet. The default is Disable.
Telnet Port#	Sets the port number used for Telnet. The default is 23.
Timeout	Sets the length of time before a time-out due to no input causes the termination of a Telnet connection. You can specify 0 or a value in a range of 60 to 9999. 0 means there is no time-out. The default is 600 seconds.
SSH	
SSH	Sets Enable or Disable for SSH. The default is Disable.
SSH Port#	Sets the port number used for SSH. The default is 22.
Timeout	Sets the length of time before the SSH connection is timed out. You can specify 0 or a value in a range of 60 to 9999. 0 means there is no time-out. The default is 600 seconds.
SNMP	
SNMP Agent	Sets Enable or Disable for SNMP Agent. The default is Disable.
Agent Port#	Sets the port number used for SNMP Agent. The specifiable port numbers are 161 and integers from 1024 to 65535. The default is 161.
SNMP Trap	Sets Enable or Disable for SNMP Trap. The default is Disable.
Trap Port#	Sets the port number used for SNMP Trap. The specifiable port numbers are 162 and integers from 1024 to 65535. The default is 162.

**Remarks**

To set HTTPS to [Enable], a valid SSL certificate must be registered.

If you set HTTPS to [Enable] when no valid SSL certificate has been registered, an error message appears.

TABLE 1.99 Buttons in the [Network Protocols] window

Buttons	Description
Apply	Sets the specified information.
Cancel	Restores the original information and does not set the specified information, such as port numbers and the time-out time.

(1) Menu Operation  
[Network Configuration] - [Network Protocols]

(2) Window Operations

1. Specify the port numbers, time-out time, or other items to set as protocol information. Then, click the [Apply] button.  
This sets the specified information, such as the port numbers and time-out time.

### [Message]

The following table lists the messages displayed in this window.

Message Number	Message
I_00013	Setting completed.
E_00044	The Port number overlaps.
W_00435	Invalid Port number.
W_00436	Invalid Timeout value.
W_00437	The duplicate Port number was found.
W_00438	Timeout setting is invalid.
E_00439	SSL Server Certificate is not found.
I_00440	HTTP Connection will be lost. You will need to login again. Are you sure?

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

## 1.5.5 [Refresh Rate] window

You can set automatic refresh for those Web-UI windows that display dynamic content, from the [Refresh Rate] window. Each user can make and manage this setting.

FIGURE 1.73 [Refresh Rate] window




TABLE 1.100 Setting and display items in the [Refresh Rate] window

Items	Description
Refresh Rate	Sets whether to automatically refresh the Web-UI windows that display dynamic content. With [Enable] specified, you can set the time interval of the automatic refresh in units of seconds. The specifiable time interval for [Refresh Rate] is in a range of 5 to 999 seconds.  The default is Disable for automatic refresh.

TABLE 1.101 Buttons in the [Refresh Rate] window

Buttons	Description
Apply	Sets the specified information on refresh.
Cancel	Restores the original information and does not set the specified refresh information.

(1) Menu Operation  
[Network Configuration] - [Refresh Rate]

- (2) Window Operations
1. Specify [Enable] or [Disable] in [Refresh Rate].  
If you select [Enable], enter the time interval.
  2. Click the [Apply] button.  
This sets the information for automatic refresh.

**[Message]**

The following table lists the messages displayed in this window.

Message Number	Message
I_00013	Setting completed.
W_00441	Range over error.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

## 1.5.6 [SNMP Configuration] window

The [SNMP Configuration] menu has the following windows:

[SNMP Community] window

[SNMP Trap] window

[SNMP v3 Configuration] window

### ☐ [SNMP Community] window

You can configure SNMP in the [SNMP Community] window.

You can specify up to 16 items for [Community/User] from the MMB.





Items	Description
IP Address/MASK	<ul style="list-style-type: none"><li>• To specify an IP address: Enter the IP address.</li><li>• To specify a subnet: Enter the subnet and mask.</li></ul>
SNMP Version	Sets the SNMP version. (1, 2, 3)
Access	Sets whether to permit only reading or both reading and writing. <ul style="list-style-type: none"><li>• Read Only</li><li>• Read Write</li></ul>
Auth	Sets the security level. You can specify this only if [3] is selected for [SNMP Version]. <ul style="list-style-type: none"><li>• noauth: Do not use the authentication function.</li><li>• auth: Use the authentication function.</li><li>• priv: Use the authentication function and "privacy" function (data encryption).</li></ul> With [1] or [2] selected for [SNMP Version], this item is grayed out and disabled. In this case, the only available security level is noauth.

TABLE 1.103 Buttons in the [SNMP Community] window

Buttons	Description
Apply	Sets the specified information.
Cancel	Restores the original information and does not set the specified information, such as the community or the IP address permitted access.

(1) Menu Operation  
[Network Configuration] - [SNMP Configuration] - [Community]

- (2) Window Operations
- Configuring information such as the community
    1. Enter information such as the community, the IP address permitted access, the SNMP version, the access permission, and the authentication. Then, click the [Apply] button.  
This sets the entered information.
  - Deleting information such as the community
    1. Delete the community and the IP address permitted access. Then, click the [Apply] button.  
This clears the specified information.

#### [Message]

The following table lists the messages displayed in this window.

Message Number	Message
I_00013	Setting completed.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

#### ☐ [SNMP Trap] window

You can set SNMP trap destinations in the [SNMP Trap] window.

You can set up to 16 trap destinations.

FIGURE 1.75 [SNMP Trap] window

Model: PRIMEQUEST2800E  
Part Number: MCXXXXXXX  
Serial Number: 000000000  
Status: Normal

System Partition User Administration Network Configuration Maintenance Logout

>Network Configuration>SNMP Configuration>Trap

### SNMP Trap

Click the Apply Button to apply all changes.

#### Trap Destination

Community/User	IP Address	SNMP Version	Auth	Auth Type	Auth passphrase Priv passphrase
<input type="checkbox"/>		1	noauth	MD5	
<input type="checkbox"/>		1	noauth	MD5	
<input type="checkbox"/>		1	noauth	MD5	
<input type="checkbox"/>		1	noauth	MD5	
<input type="checkbox"/>		1	noauth	MD5	
<input type="checkbox"/>		1	noauth	MD5	
<input type="checkbox"/>		1	noauth	MD5	
<input type="checkbox"/>		1	noauth	MD5	
<input type="checkbox"/>		1	noauth	MD5	
<input type="checkbox"/>		1	noauth	MD5	

Apply Cancel Test Trap

TABLE 1.104 Setting and display items in the [SNMP Trap] window

Items	Description
Community/User	Sets the SNMP community string for SNMP v1 and v2. Alternatively, it sets the user name for SNMP v3.
IP Address	Sets the IPv4 or IPv6 IP address of the trap destination.
SNMP Version	Sets the SNMP version. (1, 2, 3)
Auth	Sets the security level. You can specify this only if [3] is selected in [SNMP Version]. <ul style="list-style-type: none"> <li>noauth: Do not use the authentication function.</li> <li>auth: Use the authentication function.</li> <li>priv: Use the authentication function and "privacy" function (data encryption).</li> </ul> With [1] or [2] selected for [SNMP Version], this item is grayed out and disabled. In this case, the available security level will be only noauth.
Auth Type	Sets the hash function to encrypt passwords. <ul style="list-style-type: none"> <li>MD5</li> <li>SHA</li> </ul> This item takes effect only if [3] is selected for [SNMP Version]. With [1] or [2] selected for [SNMP Version], this item is grayed out and disabled.
Auth passphrase	Sets a passphrase for authentication. This item takes effect only if [3] is selected for [SNMP Version] and [auth] or [priv] is selected for [Auth].
Priv passphrase	Sets a passphrase for encryption. This item takes effect only if [3] is selected for [SNMP Version] and [priv] is selected

Items	Description
	for [Auth].

TABLE 1.105 Buttons in the [SNMP Trap] window

Buttons	Description
Apply	Sets the specified information.
Cancel	Restores the original information and does not set the specified information, such as the community or user name, and the IP address of a trap destination.
Test Trap	Sends a test trap to the specified trap destination.

## (1) Menu Operation

[Network Configuration] - [SNMP Configuration] - [SNMP Trap]

## (2) Window Operations

## - Configuring SNMP trap information

1. Enter the community or user name, the IP address of a trap destination, the SNMP version, and the authentication level. Then, click the [Apply] button.  
This sets the entered information.

## - Sending a test trap

1. Click the [Test Trap] button.  
This sends a test trap.

**[Message]**

The following table lists the messages displayed in this window.

Message Number	Message
I_00013	Setting completed.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

**□ [SNMP v3 Configuration] window**

You can set a unique Engine ID and users for SNMP v3 in the [SNMP v3 Configuration] window.

You can register a maximum of 16 users for SNMP v3. The window displays the user names of registered users.

**Remarks**

If you change the Engine ID or IP address, you need to reconfigure all the settings for the users set for SNMP v3 access.

The changes for the specified users take effect only after the SNMP Service is stopped and restarted. For this reason, clicking the [Apply] button temporarily stops SNMP Service and then automatically restarts it.

FIGURE 1.76 [SNMP v3 Configuration] window

Model: PRIMEQUEST2800E  
Part Number: MCXXXXXX  
Serial Number: 0000000000  
Status: Normal

System Partition User Administration Network Configuration Maintenance Logout

>Network Configuration >SNMP Configuration >SNMPv3 Configuration

**SNMP v3 Configuration**

Click the Apply Button to apply all changes.

Engine ID:

User	User Name	Auth Type	Auth passphrase Auth passphrase (confirm)	Priv passphrase Priv passphrase (confirm)
<input type="checkbox"/>	<input type="text"/>	<input checked="" type="radio"/> MD5 <input type="radio"/> SHA	<input type="text"/>	<input type="text"/>
<input type="checkbox"/>	<input type="text"/>	<input checked="" type="radio"/> MD5 <input type="radio"/> SHA	<input type="text"/>	<input type="text"/>
<input type="checkbox"/>	<input type="text"/>	<input checked="" type="radio"/> MD5 <input type="radio"/> SHA	<input type="text"/>	<input type="text"/>
<input type="checkbox"/>	<input type="text"/>	<input checked="" type="radio"/> MD5 <input type="radio"/> SHA	<input type="text"/>	<input type="text"/>
<input type="checkbox"/>	<input type="text"/>	<input checked="" type="radio"/> MD5 <input type="radio"/> SHA	<input type="text"/>	<input type="text"/>
<input type="checkbox"/>	<input type="text"/>	<input checked="" type="radio"/> MD5 <input type="radio"/> SHA	<input type="text"/>	<input type="text"/>
<input type="checkbox"/>	<input type="text"/>	<input checked="" type="radio"/> MD5 <input type="radio"/> SHA	<input type="text"/>	<input type="text"/>
<input type="checkbox"/>	<input type="text"/>	<input checked="" type="radio"/> MD5 <input type="radio"/> SHA	<input type="text"/>	<input type="text"/>
<input type="checkbox"/>	<input type="text"/>	<input checked="" type="radio"/> MD5 <input type="radio"/> SHA	<input type="text"/>	<input type="text"/>
<input type="checkbox"/>	<input type="text"/>	<input checked="" type="radio"/> MD5 <input type="radio"/> SHA	<input type="text"/>	<input type="text"/>

Apply Cancel

TABLE 1.106 Setting and display items in the [SNMP v3 Configuration] window

Items	Description
Engine ID	<p>Sets the Engine ID.</p> <p>You can use alphanumeric characters, spaces, and the following characters: ! " # \$ % &amp; ' ( ) = - ^ ~ ¥ @ ` [ ] { } ; , * + ? &lt; &gt; . , / _  </p> <p>However, the following restrictions apply:</p> <ul style="list-style-type: none"> <li>The character string cannot begin with a space or #.</li> <li>The character string cannot end with a space.</li> </ul>

For an explanation of the setting and display items other than [Engine ID], see [TABLE 1.104 Setting and display items in the \[SNMP Trap\] window](#).

TABLE 1.107 Buttons in the [SNMP v3 Configuration] window

Buttons	Description
Apply	Sets the specified information.
Cancel	Restores the original information and does not set the specified information.

## (1) Menu Operation

[Network Configuration] - [SNMP Configuration] - [SNMPv3 Configuration]

## (2) Window Operations

- Correcting the information on the selected user

1. Check the check box of the user. Then, enter any necessary information. Finally, click the [Apply] button.

This enables the information on the selected user. Meanwhile, the SNMP Service stops once and then restarts.

- Disabling the selected user
  1. Check the check box of the user to set to disable. Leave the [User Name] blank. Then, click the [Apply] button.  
This disables the selected user.

#### **[Message]**

The following table lists the messages displayed in this window.

Message Number	Message
I_00013	Setting completed.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

## **1.5.7 [SSL] menu**

The [SSL] menu has the following windows:

[Create CSR] window

[Export Key/CSR] window

[Import Certificate] window

[Create Selfsigned Certificate] window

### **☐ [Create CSR] window**

You can create a secret key and the corresponding CSR (certificate signing request) in the [Create CSR] window.

The following input items follow the guidelines issued by each certificate authority independently. Therefore, enter these items in accordance with the guidelines of the certificate authority selected as the destination.

FIGURE 1.77 [Create CSR] window

Model: PRIMEQUEST2800E  
Part Number: MCXXXXXX  
Serial Number: 3000000000  
Status: Normal

System Partition User Administration Network Configuration Maintenance Logout

>Network Configuration>SSL>Create CSR

**Create CSR**

Click the Create CSR Button for creating a new Key and a CSR(Certificate Signing Request).

SSL certificate status:No certificate is installed.

Key length: ☒ 1024 ☐ 2048

Country Name(ISO ex. [JP][US]):

State or Province Name:

Locality Name:

Organization Name:

Organization Unit Name:

Common Name:

E-Mail Address:

Create CSR Cancel

TABLE 1.108 Setting and display items in the [Create CSR] window

Items	Description
SSL certificate status	Displays the current installation status of a SSL certificate. <ul style="list-style-type: none"> <li>No certificate is installed.</li> <li>CSR has been generated.</li> <li>A signed certificate is installed.</li> </ul>
Key length	Used to select the length of the secret key to be created (in bits). <ul style="list-style-type: none"> <li>1024</li> <li>2048</li> </ul>
Country Name	Sets the ISO country code for the owner specified in the created CSR. The country code must be two alphabetic characters. Example: Japan: JP; USA: US
State or Province Name	Sets the state or province name of the owner specified in the created CSR. The name must consist of up to 56 specifiable characters.
Locality Name	Sets the locality name of the owner specified in the created CSR. The name must consist of up to 56 specifiable characters.
Organization Name	Sets the organization name (company name) of the owner specified in the created CSR. The name must consist of up to 56 specifiable characters.
Organization Unit Name	Sets the organization unit name of the owner specified in the created CSR. The name must consist of up to 56 specifiable characters.
Common Name	Sets the FQDN of the server of the owner specified in the created CSR. The FQDN must consist of up to 56 specifiable characters (e.g., www.mycompany.com). The browser uses this information to identify the website. To establish secure connections, some browsers reject an electronic certificate if the Common Name in it does not match the server name. [Common Name] cannot include an http:// protocol specifier, port number, or path name. Also, IP addresses and wildcard characters



Items	Description
	such as * or ? are prohibited.
E-Mail Address	Sets the e-mail address of the owner specified in the created CSR. The address must consist of up to 40 specifiable characters.

TABLE 1.109 Buttons in the [Create CSR] window

Buttons	Description
Create CSR	Creates a secret key and a CSR.
Cancel	Restores the original information and does not set the specified information.

## (1) Menu Operation

[Network Configuration] - [SSL] - [Create CSR]

## (2) Window Operations

- Specify information such as the length of a secret key and the ISO country code of the owner. Then, click the [Create CSR] button.  
A dialog box appears with a message stating that the previous secret key will be unusable once a new secret key is created.
- Click the [OK] button in the dialog box.  
This creates a new secret key and CSR. They can take a few minutes to create. When creation is completed, a confirmation dialog box appears.

FIGURE 1.78 Confirmation dialog box



- Click the [OK] button in the confirmation dialog box to set the new secret key.  
After the new secret key is set, the [Export Key/CSR] window appears.

**[Message]**

The following table lists the messages displayed in this window.

Message Number	Message
W_00426	Invalid values specified.
I_00444	Previous private key will be overwritten with new private key. Are you sure?
I_00465	A new Key and a CSR are generated successfully. To use the new Key, click "OK" button.
E_00012	One or more errors occurred while setting.
E_00018	Information acquisition failed.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference \(C122-E178EN\)](#).

**□ [Export Key/CSR] window**

You can export a secret key or CSR (certificate signing request) stored on the MMB from the [Export Key/CSR] window.

**Remarks**

For security reasons, be careful with the storage of a secret key.



Also, you need this secret key to use the electronic certificate for the key. We recommend you create a backup of the secret key.

FIGURE 1.79 [Export Key/CSR] window




TABLE 1.110 Buttons in the [Export Key/CSR] window

Buttons	Description
Export Key	Exports the secret key.
Export CSR	Exports the CSR.

## (1) Menu Operation

[Network Configuration] - [SSL] - [Export Key/CSR]

## (2) Window Operations

- Exporting the secret key
  1. Click the [Export Key] button.  
A dialog box appears.
  2. Specify the save path.  
This saves the secret key to the specified path.
- Exporting the CSR
  1. Click the [Export CSR] button.  
A dialog box appears.
  2. Specify the save path.  
This saves the CSR to the specified path.

**[Message]**

The following table lists the messages displayed in this window.

Message Number	Message
I_00013	Setting completed.
I_00445	Private Key is exported. Are you sure?

I_00446	CSR is exported. Are you sure?
W_00447	Private Key doesn't exist.
W_00448	CSR doesn't exist.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

## □ [Import Certificate] window

You can import a signed electronic certificate from a certificate authority to the MMB in the [Import Certificate] window.

FIGURE 1.80 [Import Certificate] window




TABLE 1.111 Buttons in the [Import Certificate] window

Buttons	Description
[Browse...]	Displays the window used to select an imported electronic certificate.
Import	Imports the electronic certificate.
Cancel	Cancels importing.

(1) Menu Operation  
[Network Configuration] - [SSL] - [Import certificate]

(2) Window Operations  
1. Click the [Browse...] button to select an imported file. Then, click the [Import] button.  
This imports the electronic certificate.

### [Message]

The following table lists the messages displayed in this window.

Message Number	Message
I_00013	Setting completed.

I_00046	Importing has completed.
E_00047	Importing failed.
W_00449	A certificate file is not selected yet.
I_00450	%aa is imported. Are you sure?

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

## □ [Create Selfsigned Certificate] window

You can create a selfsigned certificate in the [Create Selfsigned Certificate] window.

### Remarks

Before creating a selfsigned certificate, confirm that [HTTPS] is set to [Disable] in the [Network Protocols] window. If it is set to [Enable], change it to [Disable]. Then, proceed to the operations in this window.

FIGURE 1.81 [Create Selfsigned Certificate] window

TABLE 1.112 Display items in the [Create Selfsigned Certificate] window

Items	Description
Term	Sets the valid term of a selfsigned certificate as a number of days.

For details on other items, see [Create CSR] window.

TABLE 1.113 Buttons in the [Create Selfsigned Certificate] window

Buttons	Description
Create Selfsigned Certificate	Creates a selfsigned certificate.
Cancel	Cancels the creation of the certificate.

(1) Menu Operation

**[Network Configuration] - [SSL] - [Create Selfsigned Certificate]****(2) Window Operations**

1. Before creating a selfsigned certificate, confirm that [HTTPS] is set to [Disable] in the [Network Protocols] window.
2. Specify information such as the length of the secret key and the ISO country code of the owner. Then, click the [Create Selfsigned Certificate] button.  
A confirmation dialog box appears.
3. Click the [OK] button in the dialog box.  
This creates the selfsigned certificate. It takes a few minutes to create. When creation is completed, the window is updated. This updated window displays the message "SSL certificate status: A signed certificate is installed."

**[Message]**

The following table lists the messages displayed in this window.

Message Number	Message
I_00013	Setting completed.
W_00426	Invalid values specified.
I_00444	Previous private key will be overwritten with new private key. Are you sure?

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

## 1.5.8 [SSH] menu

The [SSH] menu has the [Create SSH Server Key] window.

### ☐ [Create SSH Server Key] window

You can create a private key for the SSH server in the [Create SSH Server Key] window.

\*Private Key necessary to make the SSH function of MMB effective is made.

FIGURE 1.82 [Create SSH Server Key] window




TABLE 1.114 Buttons in the [Create SSH Server Key] window

Buttons	Description
Create SSH Server Key	Creates a private key for the SSH server.

## (1) Menu Operation

[Network Configuration] - [SSH] - [Create SSH Server Key]

## (2) Window Operations

- Before you create a private key, confirm that [SSH] is set to [Disable] in the [Network Protocols] window.
- Click the [Create SSH Server Key] button.  
This creates the private key. It can take a few minutes to create. When creation is completed, a confirmation dialog box appears.
- To register the newly created private key, click the [OK] button. This registers the new private key.  
To cancel registration of the new private key, click the [Cancel] button. This discards the new private key.

**[Message]**

The following table lists the messages displayed in this window.

Message Number	Message
I_00013	Setting completed.
I_00453	SSH Server Key is generated successfully. To install this new SSH Server Key click "OK" button.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

## 1.5.9 [Remote Server Management] window

You can specify the users who need to remotely manage the MMB via RMCP, in the [Remote Server Management] window.

Up to 24 users can be registered.

The default settings for all users are [Disabled] status and [No Access]. Also, a default user name from [User1] to [User24] is assigned to each user.

For remote management of the MMB via RMCP, you need to specify [User Name], [Password], and [Privilege] to place the users of the managed MMB in the [Enabled] status.

Remote access authentication uses the user name and password of a user in the [Enabled] status.

FIGURE 1.83 [Remote Server Management] window

The screenshot shows the Fujitsu MMB Web-UI interface. At the top, it displays system information: Model: PRIMEQUEST2800E, Part Number: MCXXXXXX, Serial Number: XXXXXXXX, and Status: Normal. The 'Active:MMB#0' indicator is in the top right. A navigation menu on the left includes options like Date Time, Network Interface, Management LAN Port Configuration, Network Protocols, Refresh Rate, SNMP Configuration, SSL, SSH, Remote Server Management (highlighted), Access Control, and Alarm E-Mail. The main content area is titled 'Remote Server Management' and contains the instruction: 'Select a user from the list, then click the Edit button to edit the user.' Below this is a table with three columns: User Name, Privilege, and Status. The table lists 20 users: ADMINISTRATOR (Admin, Enabled) and User1 through User19 (No Access, Disabled). At the bottom right of the table are 'Edit' and 'Cancel' buttons.

User Name	Privilege	Status
<input type="radio"/> ADMINISTRATOR	Admin	Enabled
<input type="radio"/> User1	No Access	Disabled
<input type="radio"/> User2	No Access	Disabled
<input type="radio"/> User3	No Access	Disabled
<input type="radio"/> User4	No Access	Disabled
<input type="radio"/> User5	No Access	Disabled
<input type="radio"/> User6	No Access	Disabled
<input type="radio"/> User7	No Access	Disabled
<input type="radio"/> User8	No Access	Disabled
<input type="radio"/> User9	No Access	Disabled
<input type="radio"/> User10	No Access	Disabled
<input type="radio"/> User11	No Access	Disabled
<input type="radio"/> User12	No Access	Disabled
<input type="radio"/> User13	No Access	Disabled
<input type="radio"/> User14	No Access	Disabled
<input type="radio"/> User15	No Access	Disabled
<input type="radio"/> User16	No Access	Disabled
<input type="radio"/> User17	No Access	Disabled
<input type="radio"/> User18	No Access	Disabled
<input type="radio"/> User19	No Access	Disabled

TABLE 1.115 Display and setting items in the [Remote Server Management] window

Items	Description
User Name	Displays a user name. The name can have a total of 8 to 16 characters.
Privilege	Displays the privileges of the user account. <ul style="list-style-type: none"> <li>Admin</li> <li>Operator</li> <li>User</li> <li>CE</li> <li>No Access (Users for which [No Access] is selected will no longer have the capability of remote access.)</li> </ul>
Status	Displays the current status of the account. <ul style="list-style-type: none"> <li>Enabled</li> </ul>

Items	Description
	• Disabled

TABLE 1.116 Buttons in the [Remote Server Management] window

Buttons	Description
Edit	Displays the [Edit User] window.
Cancel	Restores the original information and does not set the management information for the selected user.

## (1) Menu Operation

[Network Configuration] - [Remote Server Management]

## (2) Window Operations

1. Click the radio button of the user you want to specify. Then, click the [Edit] button.  
you want to specify. Then, click the [Edit] button.
2. Specify the user management information in the [Edit User] window.

**[Message]**

The following table lists the messages displayed in this window.

Message Number	Message
E_00053	Failed to get user status. Retry 60 seconds later.
W_00413	Nothing is selected.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

**☐ [Edit User] window**

You can change the management information on a user in the [Edit User] window.

FIGURE 1.84 [Edit User] window

The screenshot shows the 'Edit User' window in the MMB Web-UI. At the top, there is a header bar with the Fujitsu logo and system information: Model: PRIMEQUEST2800E, Part Number: MCXXXXXX, Serial Number: XXXXXXXX, and Status: Normal. Below this is a navigation bar with tabs for System, Partition, User Administration, Network Configuration, and Maintenance. The 'User Administration' tab is active, and the 'Edit User' sub-tab is selected. The main content area is titled 'Edit User' and contains a form with the following fields:

- User Name: ADMINISTRATOR
- Password: (empty)
- Confirm Password: (empty)
- Privilege: Admin (dropdown menu)
- Status: ☒ Enabled ☐ Disabled

At the bottom of the form, there are 'Apply' and 'Cancel' buttons. A 'Help' button is also visible in the top right corner of the main content area.

TABLE 1.117 Display and setting items in the [Edit User] window

Items	Description
User Name	Specifies a user name. The name can have a total of 8 to 16 characters. The user name can contain the following characters: 0 to 9, a to z, and A to Z (alphanumeric characters only).
Password	Specifies a password. The name can have a total of 8 to 16 characters. The password can contain the following characters: 0 to 9, a to z, and A to Z (alphanumeric characters only).
Confirm Password	Used to reenter a password for confirmation.
Privilege	Specifies the privileges of the user account. <ul style="list-style-type: none"> <li>Admin</li> <li>Operator</li> <li>User</li> <li>CE</li> <li>No Access (Users for which [No Access] is selected will no longer have the capability of remote access.)</li> </ul>
Status	Specifies the current status of the account. <ul style="list-style-type: none"> <li>Enabled</li> <li>Disabled</li> </ul>

TABLE 1.118 Buttons in the [Edit User]

Buttons	Description
Apply	Sets the specified management information.



Cancel	Restores the original information and does not set the specified information, such as a user name and password.
--------	---

(1) Menu Operation

[Network Configuration] - [Remote Server Management] - [Edit] button

(2) Window Operations

1. Specify the user management information, such as a user name and password. Then, click the [Apply] button.

This sets the user management information.

**[Message]**

The following table lists the messages displayed in this window.

Message Number	Message
I_00013	Setting completed.
W_00401	Username is too short.
W_00402	Password is too short.
W_00454	%aa is duplicated.
W_00406	Invalid character is included in User Name.
W_00403	Invalid character is included in Password.
W_00455	Both passwords are mismatched. Please try again.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference \(C122-E178EN\)](#).

## 1.5.10 [Access Control] window

You can control access through network protocols to ensure MMB security in the [Access Control] window.

You can configure up to 64 filters. These filters are displayed alphabetically by protocol name.

**Remarks**

You can register multiple access control filters with the same configuration. These filters do not affect operation.

FIGURE 1.85 [Access Control] window




TABLE 1.119 Setting and display items in the [Access Control] window

Items	Description
Select	Used to select the filter for which you want to change the setting.
Protocol	Displays the protocol for IP filtering. <ul style="list-style-type: none"> <li>• HTTP</li> <li>• HTTPS</li> <li>• Telnet</li> <li>• SSH</li> <li>• SNMP</li> </ul>
IP Address	Displays the IP address permitted to connect.
Subnet Mask/Prefix Length	For IPv4, the subnet mask of the IP address that has permission to connect is displayed. For IPv6, the prefix length is displayed.

TABLE 1.120 Buttons in the [Access Control] window

Buttons	Description
Add Filter	Displays the [Add Filter] window to add a new filter.
Edit Filter	Displays the [Edit Filter] window to edit a filter.
Remove Filter	Deletes the selected filter.
Cancel	Restores the original information and does not set the specified information.

(1) Menu Operation  
[Network Configuration] - [Access Control]

(2) Window Operations  
- Adding a new filter  
1. Click the [Add Filter] button.  
The [Add Filter] window appears.

2. Configure the filter in the [Add Filter] window. Then, click the [Apply] button.  
This adds the new filter.
- Editing a filter
  1. Click the radio button of a filter in the [Select] column so that you can edit the filter. Then, click the [Edit Filter] button.  
The [Edit Filter] window appears.
  2. Specify the save path.  
Edit the filter in the [Edit Filter] window. Then, click the [Apply] button.
- Deleting a filter
  1. Click the radio button of a filter in the [Select] column so that you can delete the filter. Then, click the [Remove Filter] button.  
A deletion confirmation dialog box appears.
  2. Click the [OK] button.  
This deletes the filter. The browser returns to the [Access Control] window.

**[Message]**

The following table lists the messages displayed in this window.

Message Number	Message
I_00013	Setting completed.
E_00412	You need an empty entry.
W_00413	Nothing is selected.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

**☐ [Add Filter]/[Edit Filter] window**

Click the [Add Filter] button or [Edit Filter] button in the [Access Control] window to display the [Add Filter] window or [Edit Filter] window, respectively.

Although the [Add Filter] window and [Edit Filter] window have different window titles, their setting items are the same. This section describes these items in the [Add Filter] window.

FIGURE 1.86 [Add Filter] window

The screenshot shows the MMB Web-UI interface. At the top, there's a header with the Fujitsu logo and system information: Model: PRIMEQUEST2800E, Part Number: MCXXXXXX, Serial Number: 300000000, Status: Normal. Below this is a navigation bar with tabs: System, Partition, User Administration, Network Configuration (selected), and Maintenance. A 'Logout' link is on the right. The left sidebar contains a tree view of configuration options: Date Time, Network Interface, Management LAN Port Configuration, Network Protocols, Refresh Rate, SNMP Configuration, SSL, SSH, Remote Server Management, Access Control (highlighted), and Alarm E-Mail. The main content area is titled 'Add Filter' and includes a 'Help' button. Below the title, it says 'Click the Apply Button to apply all changes.' The form contains four fields: 'Protocol' with a dropdown menu showing 'SSH', 'Access Control' with radio buttons for 'Enable' (selected) and 'Disable', 'IP Address' with the value '192.168.10.30', and 'Subnet Mask Prefix Length' with the value '255.255.255.0'. At the bottom right, there are 'Apply' and 'Cancel' buttons.

TABLE 1.121 Setting and display items in the [Add Filter] window

Items	Description
Protocol	<p>Sets the protocol for the IP filtering. You can select one of the following items from the pull-down menu:</p> <ul style="list-style-type: none"> <li>• HTTP</li> <li>• HTTPS</li> <li>• Telnet</li> <li>• SSH</li> <li>• SNMP</li> </ul>
Access Control	<p>Sets whether to execute access control.</p> <ul style="list-style-type: none"> <li>• Disable: Permits access by all IP addresses via the protocol selected in [Protocol]. Selecting this disables input to [IP Address] and [Subnet Mask].</li> <li>• Enable: Specifies [IP Address] and [Subnet Mask] to permit access via the protocol selected in [Protocol].</li> </ul>
IP Address	<p>Sets the IP address (for IPv4 or IPv6) that will have permission to connect.</p> <p><b>Remarks</b></p> <p>For IPv4, to permit connection by only a specific IP address in a subnet, specify the IP address and then "255.255.255.255" in [Subnet Mask]. For IPv6, the prefix length is displayed.</p> <p>Example: Permitting access from a specific IP address range (e.g., 192.168.60.60/255.255.255.0)</p> <p>IP Address: 192.168.60.60</p> <p>Subnet Mask: 255.255.255.0</p> <p>(because the IP address is used with a 24-bit subnet mask)</p> <ul style="list-style-type: none"> <li>• The above setting will enable access not only from the IP address 192.168.60.60, but also from IP addresses within the subnet 192.168.60.0/24.</li> </ul>

Items	Description
Subnet Mask/ Prefix Length	For IPv4, the subnet mask of the IP address that has permission to connect is displayed. For IPv6, the prefix length is displayed.

TABLE 1.122 Buttons in the [Add Filter] window

Buttons	Description
Apply	Sets the specified information.
Cancel	Restores the original information and does not set the specified information, such as protocols and access control.

## (1) Menu Operation

[Network Configuration] - [Access Control] - [Add Filter] button/[Edit Filter] button

## (2) Window Operations

1. Specify [Protocol] and [Access Control].
2. If you specify [Enable] in [Access Control], enter values for [IP Address] and [Subnet Mask]. Then, click the [Apply] button.  
If you specify [Disable] in [Access Control], simply click the [Apply] button.  
This adds or edits the filter.

**[Message]**

The following table lists the messages displayed in this window.

Message Number	Message
I_00013	Setting completed.
W_00432	Invalid IP Address specified.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

## 1.5.11 [Alarm E-Mail] window

You can set e-mail notification for when an event occurs in the PRIMEQUEST 2000 series server in the [Alarm E-Mail] window.

FIGURE 1.87 [Alarm E-Mail] window

**FUJITSU** Model: PRIMEQUEST2800E Active:MMB#0  
 Part Number: MCXXXXXXX  
 Serial Number: 600000000  
 Status: Normal

System Partition User Administration Network Configuration Maintenance Logout

>Network Configuration>Alarm E-Mail

**Alarm E-Mail** Help

Click the Apply Button to apply all changes.

Alarm E-Mail ☒ Enable ☐ Disable

From:

☐ Use envelope "from" address

To: john@smith.com

SMTP Server 192.168.10.50

Subject test alarm

Apply Cancel Filter Test E-Mail

TABLE 1.123 Setting and display items in the [Alarm E-Mail] window

Items	Description
Alarm E-Mail	Sets whether to send Alarm E-Mail notification for an event that has occurred. <ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
From:	Sets the e-mail address of the sender. If the [Use envelope "from" address] check box is checked, the [From:] address is set as the sender's e-mail address used when sending an e-mail. The default is unchecked. Upon receiving an alarm e-mail, the mail server sets the set [From:] address for Return-Path in the e-mail header. Also, if a mailing list is used, the Return-Path setting is the administrator's address on the mailing list instead of the set [From:] address. However, the Return-Path setting depends on the mail server settings. Therefore, Return-Path may not be set.
To:	Sets the e-mail address of the recipient. To specify multiple e-mail addresses, delimit them with a comma (,).
SMTP Server	Sets the IP address or FQDN of the SMTP server. You can set the FQDN only if a DNS is set. (After selecting [Network Configuration] - [Network Interface], you can specify a DNS server.)
Subject	Sets an e-mail title.

The e-mail address consists of "user name"@"domain name". The specifiable characters in "user name" and "domain name" conform to RFC 2822 and RFC 1034.

#### Examples:

- "user name" can contain alphanumeric characters and the following symbols: !# \$ % & ' \* + - / = ? ^ \_ ` { | } ~ .

- However, "#" cannot be used for the heading character. "." (period) cannot be used for the heading character and the last character. Moreover, "." cannot be used 2 pieces continuously. For details, see RFC 2822.

The "domain name" can contain alphanumeric characters and "-" (hyphen) only. However, it must begin with an alphabetic character and end with an alphanumeric character. For details, see RFC 1034.

The "Subject" can contain alphanumeric characters, blank spaces, and the following symbols:  
! # " \$ % & ' ( ) \* + - . / \_ ~

TABLE 1.124 Buttons in the [Alarm E-Mail] window

Buttons	Description
Apply	Sets the specified information.
Cancel	Restores the original information and does not set the specified information, such as the [Enable] or [Disable] setting in [Alarm E-Mail] or the e-mail address of the sender.
Filter	Displays the [Alarm E-Mail Filtering Condition] window for setting conditions for the events for which alarm e-mail is sent.
Test E-Mail	Sends a test alarm e-mail to the specified destination.

#### (1) Menu Operation

[Network Configuration] - [Alarm E-Mail]

#### (2) Window Operations

1. Specify information such as the sender's e-mail address and whether to enable or disable Alarm E-Mail.
2. To set a filter for an event for which alarm e-mail is sent, click the [Filter] button.  
The [Alarm E-Mail Filtering Condition] window appears.
3. Specify the filter in the [Alarm E-Mail Filtering Condition] window.
4. To send a test alarm e-mail, click the [Test E-Mail] button.  
This sends a test alarm e-mail to the specified sender.
5. Click the [Apply] button.  
This sets the items specified in the window.

#### [Message]

The following table lists the messages displayed in this window.

Message Number	Message
I_00001	Command Completed
I_00013	Setting completed.
W_00456	Invalid E-Mail address format.
W_00457	Invalid SMTP server address.
I_00458	Please check a Subject.
W_00459	Alarm E-Mail is disabled.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

### ☐ [Alarm E-Mail Filtering Condition] window

Clicking the [Filter] button in the [Alarm E-Mail] window displays the [Alarm E-Mail Filtering Condition] window. The display item is different depending on the model.

You can set the filtering conditions for the events for which alarm e-mail is sent, in the [Alarm E-Mail Filtering Condition] window.

Each item is evaluated with the AND condition.

FIGURE 1.88 [Alarm E-Mail Filtering Condition] window(PRIMEQUEST 2400E/2800E)

**FUJITSU** Model: PRIMEQUEST2800E Active:MMB#0  
Part Number: MCXXXXXXX  
Serial Number: 0000000001  
Status: **Normal**

System Partition User Administration Network Configuration Maintenance Logout  
>Network Configuration >Alarm E-Mail

### Alarm E-Mail Filtering Condition

Select the filtering conditions and click the Apply Button.

1)Severity: ☒ Error ☒ Warning ☒ Info

2)Partition: ☒ All  
☐ Specified ☒ 0 ☒ 1 ☒ 2 ☒ 3

3)Unit: ☒ All  
☐ Specified ☒ PSUs ☒ Fans ☒ SB#0 ☒ SB#1 ☒ SB#2 ☒ SB#3  
☒ IOU#0 ☒ IOU#1 ☒ IOU#2 ☒ IOU#3  
☒ DU#0 ☒ DU#1  
☒ OPL  
☒ MMB#0 ☒ MMB#1  
☒ PCI\_Box#0 ☒ PCI\_Box#1 ☒ PCI\_Box#2 ☒ PCI\_Box#3

4)Source: ☒ All  
☐ Specified ☒ CPU ☒ DIMM ☒ Chipset  
☒ Voltage ☒ Temperature ☒ Other

Apply Cancel

FIGURE 1.89 [Alarm E-Mail Filtering Condition] window(PRIMQUEST 2800B)

**FUJITSU** Model: PRIMEQUEST 2800B  
Part Number: MCF3AC111  
Serial Number:   
Status: **Normal**

System User Administration Network Configuration Maintenance Logout  
>Network Configuration >Alarm E-Mail

### Alarm E-Mail Filtering Condition

Select the filtering conditions and click the Apply Button.

1)Severity: ☒ Error ☒ Warning ☒ Info

2)Unit: ☒ All  
☐ Specified ☒ PSUs ☒ Fans ☒ SB#0 ☒ SB#1 ☒ SB#2 ☒ SB#3  
☒ IOU#0 ☒ IOU#1 ☒ IOU#2 ☒ IOU#3  
☒ DU#0 ☒ DU#1  
☒ OPL  
☒ MMB

3)Source: ☒ All  
☐ Specified ☒ CPU ☒ DIMM ☒ Chipset  
☒ Voltage ☒ Temperature ☒ Other

Apply Cancel



TABLE 1.125 Setting and display items in the [Alarm E-Mail Filtering Condition] window

Items	Description
Severity	<p>Sets the severity level to be displayed. Multiple options can be selected.</p> <ul style="list-style-type: none"> <li>· Error</li> <li>· Warning</li> <li>· Info</li> </ul> <p>Everything is selected by default.</p>
Partition	<p>Sets the partitions to be displayed. Multiple options can be selected.</p> <p>Everything is selected by default.</p> <p><b>Remark</b></p> <p>This item is not displayed in case of PRIMEQUEST 2800B model.</p>
Unit	<p>Sets the units to be displayed.</p> <p>The selected radio button is either [All] or [Specified].</p> <p>All: Filtering by unit is not applied.</p> <p>Specified: Filtering by unit can be set. Check the check boxes for the units to be displayed.</p> <p>The default is All.</p> <p><b>Remark</b></p> <p>In case of PRIMEQUEST 2400E model, the Unit display is as follows: SB : SB#0, SB#1</p> <p>In case of PRIMEQUEST 2800B model, the Unit display is as follows: MMB : MMB</p> <p>In case of PRIMEQUEST 2800B model, PCI_Box is not displayed.</p>
Source	<p>Used to select the sources to be displayed.</p> <p>The selected radio button is either [All] or [Specified].</p> <p>All: Filtering by [Source] is not applied.</p> <p>Specified: Filtering by source can be set. Check the check boxes of the sources to display.</p> <p>The default is All.</p> <p>Remarks</p> <p>Specify both CPU and Chipset when filtering as Source with the unit of CPU.</p>

TABLE 1.126 Buttons in the [Alarm E-Mail Filtering Condition] window

Buttons	Description
Apply	Sets the filtering conditions.
Cancel	Restores the original information and does not set the specified information, such as [Severity], [Partition], and [Unit].

## (1) Menu Operation

[Network Configuration] - [Alarm E-Mail] - [Filter] button

## (2) Window Operations

1. Specify the items such as [Severity], [Partition], and [Unit]. Then, click the [Apply] button.  
This sets the specified filtering conditions.

## 1.6 [Maintenance] Menu

You can perform maintenance on the PRIMEQUEST 2000 series server from the [Maintenance] menu.

### 1.6.1 [Firmware Update] menu

The [Firmware Update] menu has the following window:

[Unified Firmware Update] window

#### ☐ [Unified Firmware Update] window

You can unify a firmware update in the [Unified Firmware Update] window.

The firmware complete set is up-loaded to MMB, and the firmware in the new publication is maintained.


Confirm the version of each firmware. Update the firmware only if those versions are not the same.

The online firmware update does not update the same version number situation.

#### Note

If the MMB or SB has failed, perform maintenance on it before updating the firmware. Do not update the firmware in a configuration that has a faulty MMB or SB.

FIGURE 1.90 [Unified Firmware Update] window



(1) Menu Operation  
[Maintenance] - [Firmware Update] - [Unified Firmware Update]

## (2) Window Operations

1. Click the [Browse...] button to select a unified firmware update file.
2. Click the [Update] button.  
This displays the window for confirming the versions for the unified firmware update.
3. To perform the update, click the [OK] button.

**[Message]**

The following table lists the messages displayed in this window.

Message Number	Message
W_00477	Select the file of update.
W_00478	Unable to execute the update. Standby MMB is fault or disable.
W_00479	Unable to execute the update. TPM is effective.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

## 1.6.2 [Backup/Restore Configuration] menu

The [Backup/Restore Configuration] menu has the following windows:

[Backup/Restore MMB Configuration] window

[Backup BIOS Configuration] window for PRIMEQUEST 2400E/2800E


[Restore BIOS Configuration] window for PRIMEQUEST 2400E/2800E

[Backup/Restore BIOS Configuration] window for PRIMQUEST 2800B

### ☐ [Backup/Restore MMB Configuration] window

You can back up and restore the MMB configuration information from the Backup/Restore MMB Configuration window.

FIGURE 1.91 Backup/Restore MMB Configuration window



## (1) Menu Operation

[Maintenance] - [Backup/Restore Configuration] - [Backup/Restore MMB Configuration]

## (2) Window Operations

- Backing up MMB configuration information
  1. Click the [Backup] button.  
The save destination dialog box of the browser appears.
  2. Select the save destination path in the save destination dialog box. Then, click the [OK] button.  
This downloads the MMB configuration file.  
The default name of the backup file of the MMB configuration information is as follows:  
MMB\_(backup date)\_(MMB version).dat
- Restoring MMB configuration information
  1. Confirm that the system has completely stopped.
  2. Click the [Browse...] button to select the backup file of the MMB configuration.
  3. Click the [Restore] button.  
This sends the file to the MMB. To confirm restoration, the [MMB Configuration File Information:] dialog box appears.
  4. Click the [OK] button in the [MMB Configuration File Information:] dialog box.  
This restores the MMB configuration information.
  5. The MMB is rebooted to enable the restored data.

**[Message]**

The following table lists the messages displayed in this window.

Message Number	Message
I_00054	Restore completed. Now rebooting.
I_00486	Select a file.
E_00055	Failed to restore the MMB Configuration.
E_00056	Failed to backup the MMB Configuration.
E_00057	Specified file can not restore.

Message Number	Message
I_00054	Restore completed. Now rebooting.
I_00486	Select a file.
E_00058	File format error.
E_00060	Specified file is the one of another machine.
E_00061	Failed to get serial number.
E_00062	Can't restore the MMB Configuration. Please power off the chassis.
E_00063	Failed to reset the MMB. Please turn off the breaker to enable the settings.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

## ❑ [Backup BIOS Configuration] window for PRIMEQUEST 2400E/2800E

This window is displayed only in PRIMEQUEST 2400E/2800E.

You can back up BIOS configuration information to the PC running the browser, from the [Backup BIOS Configuration] window.

FIGURE 1.92 Backup BIOS Configuration window




TABLE 1.127 Buttons in the [Backup BIOS Configuration] window

Buttons	Description
Backup	Backs up the BIOS configuration information.
Cancel	Cancels backup of the BIOS configuration information.

### (1) Menu Operation

[Maintenance] - [Backup/Restore Configuration] - [Backup BIOS Configuration]

### (2) Window Operations

1. Select the radio button of the partition to which to back up BIOS configuration information. Then, click the [Backup] button.

- A save destination dialog box appears.
2. Select the save destination path in the save destination dialog box. Then, click the [OK] button. This downloads the BIOS configuration information file. The default name of the backup file of the BIOS configuration information is as follows: (partition number)\_(backup date)\_(BIOS version).dat

**[Message]**

The following table lists the messages displayed in this window.

Message Number	Message
I_00066	Failed to backup the BIOS Configuration.
I_00427	Select a partition.
E_00006	Authorization required.
E_00040	Partition not defined.
E_00098	Failed to get the partition status.
E_00098	Failed to get the screen information.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

## ☐ [Restore BIOS Configuration] window for PRIMEQUEST 2400E/2800E

This window is displayed only in PRIMEQUEST 2400E/2800E.

You can restore BIOS configuration information in the [Restore BIOS Configuration] window.

FIGURE 1.93 [Restore BIOS Configuration] window (1)




FIGURE 1.94 [Restore BIOS Configuration] window (2)

Model: PRIMEQUEST  
Part Number: MCD3AC111  
Serial Number: 1480935001  
Status: Normal

Active:MMB#0

System Partition User Administration Network Configuration Maintenance

>Maintenance >Backup Restore Configuration >Restore BIOS Configuration

Log out

Restore BIOS Configuration

Select partition(s) then click the Restore button.

Configuration File Information

Partition#: 0  
Partition Name: W08\_HS\_138  
Saved Date: 2009-11-02  
BIOS Version: 0.63

☐ Select All defined partition(s)

	#	Partition Name	BIOS Version
<input type="checkbox"/>	0	W08_HS_138	0.63
<input checked="" type="checkbox"/>	1	WS03_101	0.64
<input checked="" type="checkbox"/>	2	RedHat_104	0.63
<input type="checkbox"/>	3	WS08_107	0.63

Restore Cancel

TABLE 1.128 Setting and display items in the [Restore BIOS Configuration] window (2)

Items	Description
Select All defined partitions(s)	Restores the BIOS configuration information in all the partitions if this check box is checked.
#	Displays a partition identification number (0 to 3). You can select a partition for restoration by checking a check box on the left.
Partition Name	Displays the name assigned to the partition.
BIOS Version	Displays the current BIOS version installed on the partition.

TABLE 1.129 Buttons in the [Restore BIOS Configuration] window (2)

Buttons	Description
Restore	Restores the BIOS configuration information file.
Cancel	Cancels restoration of the BIOS configuration file.

## (1) Menu Operation

[Maintenance] - [Backup/Restore Configuration] - [Restore BIOS Configuration]

## (2) Window Operations

- Click the [Browse...] button in the [Restore BIOS Configuration] window (1). Select the BIOS configuration backup file stored on a remote PC.
- Click the [Upload] button.  
This sends the BIOS configuration file to the MMB and displays the [Restore BIOS Configuration] window (2).
- Select the partition for restoration in the [Restore BIOS Configuration] window (2). Then, click the [Restore] button.  
This restores the BIOS configuration information file.

## [Message]

The following table lists the messages displayed in this window.

Message Number	Message
I_00064	Restore completed.

I_00486	Select a file.
W_00258	Unable to restore the BIOS configuration because a BIOS configuration information file is being restored by another user in the same partition now.
W_00485	Home SB not defined.
E_00024	Installing failed.
E_00027	Installing failed. Size of uploaded file is zero.
E_00039	Uploading failed.
E_00057	Specified file can not restore.
E_00058	File format error.
E_00065	Failed to restore the BIOS Configuration.
E_00067	Can't restore the BIOS Configuration. Please power off the partition(s).


For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

## □ [Backup/Restore BIOS Configuration] window for PRIMEQUEST 2800B

This window is displayed only in PRIMEQUEST 2800B.

You can back up and restore the BIOS configuration information from the Backup/Restore BIOS Configuration window.

FIGURE 1.95 Backup/Restore BIOS Configuration window



### (1) Menu Operation

[Maintenance] - [Backup/Restore Configuration] - [Backup/Restore BIOS Configuration]

### (2) Window Operations

- Backing up BIOS configuration information
  1. Click the [Backup] button.  
The save destination dialog box of the browser appears.
  2. Select the save destination path in the save destination dialog box. Then, click the [OK] button.  
This downloads the BIOS configuration file.  
The default name of the backup file of the BIOS configuration information is as follows:  
BIOS\_(backup date)\_(BIOS version).dat
- Restoring BIOS configuration information
  1. Confirm that the system has completely stopped.



2. Click the [Browse...] button to select the backup file of the BIOS configuration.
3. Click the [Restore] button.  
This sends the file to the MMB. To confirm restoration, the [BIOS Configuration File Information:] dialog box appears.
4. Click the [OK] button in the [BIOS Configuration File Information:] dialog box.  
This restores the BIOS configuration information.
5. The BIOS is rebooted to enable the restored data.

**[Message]**

The following table lists the messages displayed in this window.

Message Number	Message
E_00057	Specified file can not restore.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

### 1.6.3 [Maintenance Wizard] window

The [Maintenance Wizard] window has a wizard to support maintenance of units. This window is designed for maintenance personnel.

(1) Menu Operation  
[Maintenance] - [Maintenance Wizard]

### 1.6.4 [REMCS] menu

You can operate and configure REMCS from the [REMCS] menu.

For details on REMCS, see the [PRIMEQUEST 2000 Series REMCS Installation Manual](#) (C122-E180EN).

## 1.7 [System] Menu for PRIMEQUEST 2800B

In [System] menu, it is possible to display and set the status of all the hardware components in the PRIMEQUEST PRIMEQUEST 2800B system.

A display and a set item of [System] menu are different in PRIMEQUEST 2400E and PRIMEQUEST 2800E. Refer to Chapter 1.3 for details.

### Remarks

If "Read Error" is displayed for [Part Number] and [Serial Number] on MMB Web-UI (contents area and information area), confirm the problem by referring to "11.2 Troubleshooting" of *PRIMEQUEST 2000 Series Administration Manual* (C122-E175EN). If the error could not be resolved, contact your sales representative or repairs assistance service.


Confirm the model name and serial number shown on the label affixed on the main unit and report it.

### 1.7.1 [System Status] window

[System Status] window shows the status of entire PRIMEQUEST 2800 model. The contents displayed may differ depending on the configuration of the unit.

You can also display details of each unit by clicking the link displayed in the frame.



FIGURE 1.96 [System Status] window



The contents which are displayed as the status of unit are as follows.

- [OK] : It is shown for the unit which operates normally without any trouble.
- [Not-present] : It is shown for the unit which is not mounted. It is shown in gray colored background.
- [Warning] : Though it is not serious, it shows the unit where a problem may occur. It is shown by ⚠ icon.
- [Failed] : It shows the unit, where failure has occurred, and it must be disconnected. It is shown by ❌ icon.
- [Degraded] : It shows that a failure has occurred in the component of a certain unit, and the unit is operated without disconnecting the failed component. It is shown by ⚠ icon.

TABLE 1.130 Status of Unit and its Icons

Status	Display Color	Icon
Normal (Normal state)	Green	None
Warning, Degraded	Yellow	Black '!' mark in yellow triangle. 
Failed	Red	White 'X' in red circle. 

Each unit is linked with the window showing the detailed status. However, for units which are not mounted, there is no window showing the details. Therefore, these units are not linked.

TABLE 1.131 Items displayed in [System Status] Window

Items	Description
Power Supply	Shows the status of PSU
Fans	Shows the status of FAN
Temperature	Shows the status of temperature sensor
SB#0 ~ SB#3	Shows the status of system board
IOU#0 ~ IOU#3	Shows the status of IOU
DU#0 ~ DU#1	Shows the status of DU
OPL	Shows the status of OPL
MMB	Shows the status of MMB

(1) Menu Operation

[System] – [System Status]

(2) Window Operations

1. Click the link corresponding to each unit when the detailed status of unit is to be confirmed. The window showing detailed status of each unit appears.

## 1.7.2 [System Event Log] Window

Among the events generated in the PRIMEQUEST 2800B model, events of MMB and BMC stored in the current MMB system event log are displayed on the [System Event Log] window in chronological order.

Maximum 32000 events can be stored in system event log. When the entries in the system event log are full, oldest event log is deleted, and latest event log is stored in system event log.

FIGURE 1.97 [System Event Log] window

Model: PRIMEQUEST 2800B  
Part Number: MCF3AC111  
Serial Number: [REDACTED]  
Status: Normal

System User Administration Network Configuration Maintenance Logout

>System >System Event Log

System Event Log

Severity	Date/Time	Unit	Source	Event ID	Description	Detail
Info	2014-01-17 11:34:54	System	PSU Redundancy	090B00FF	Fully Redundant	<a href="#">Detail</a>
Info	2014-01-17 11:34:53	System	PSU Redundancy	090B03FF	Non-redundant: Sufficient Resource	<a href="#">Detail</a>
Error	2014-01-17 11:34:53	PSU#4	PSU#4	086F0602	Configuration error in excess unit	<a href="#">Detail</a>
Error	2014-01-17 11:33:50	System	PSU Redundancy	090B05FF	Non-redundant: Insufficient Resource	<a href="#">Detail</a>
Error	2014-01-17 11:33:36	System	PSU Redundancy	090B05FF	Non-redundant: Insufficient Resource	<a href="#">Detail</a>
Error	2014-01-17 11:33:36	System	PSU Redundancy	090B05FF	Non-redundant: Insufficient Resource	<a href="#">Detail</a>
Error	2014-01-17 11:33:35	PSU#5	PSU#5	086F0601	Configuration error	<a href="#">Detail</a>
Error	2014-01-17 11:33:35	PSU#2	PSU#2	086F0601	Configuration error	<a href="#">Detail</a>
Info	2014-01-17 11:29:41	System	PSU Redundancy	090B03FF	Non-redundant: Sufficient Resource	<a href="#">Detail</a>

Clear All Events Download Filter

In the [System Event Log] Window, only the contents and not the title in the table can be scrolled. When there are no events to be displayed, a message showing "There is no Event Logs." is displayed instead of the table.

TABLE 1.132 Items displayed in [System Event Log] Window

Items	Description
Severity	Displays the severity of the event and error <ul style="list-style-type: none"> <li>Error : Severe errors like hardware error</li> <li>Warning : Not a severe error, but an error is likely in future</li> <li>Info : Shows the information like 'Partition power ON'</li> </ul>
Date/Time	Displays the local time when an event or error occurred. Format: YYYY-MM-DD HH:MM:SS
Source	Displays the name of the sensor where an event or error occurred.
Unit	Displays the unit with the sensor where an event or error occurred. For example, displays [SB#0] if an error occurs in CPU#0 of SB#0. This unit retrieves FRU with this sensor from Entity ID of the sensor, and also retrieves Parent Entity from Entity Association Record. It displays Board/Unit name described in FRU Record of parent entry. It is linked to the window (Window on which part number and serial number of each unit can be referenced) showing detailed status of each unit.
Part Number	Displays the part number stored in system event log. If part number is not stored, "[ ]" is displayed.
Event ID	Displays the ID (8 digits in hexadecimal system) for identifying contents of Event. For details on the allocation of the Event ID, see "Chapter 2 MMB Message" of <a href="#">PRIMEQUEST 2000 Series Message Reference</a> (C122-E178EN).
Description	Displays the contents of Events and Errors. <b>Remarks</b> For the event of insertion/removal of the board, part number and serial number of board are displayed.

TABLE 1.133 Buttons on [System Event Log] Window

Buttons	Description
Clear All Events	When you click [Clear All Events] button, all the events saved in system event log, are cleared. This is used only if Field engineer instructs to do so.
Download	After the confirmation message is displayed, [System Event Log (Collect)] window appears.
Filter	When you click [Filter] button, [System Event Log Filtering Condition] window for entering filter conditions appears.
Detail	When you click [Detail] button, the details of corresponding event are displayed on [System Event Log (Detail)] window.


## (1) Menu Operation

[System] – [System Event Log]

## (2) Window Operations

- When the event data saved in system event log is downloaded (if the system event log collected in advance does not exist)
  1. When you click [Download] button, a message showing [I\_00417 Are you sure?] is displayed. Click [OK] button.
  2. The collection of system event log information is starts automatically; [Progress] window appears.
  3. [System Event Log (Collect)] window appears, and the link to event data which is collected, is displayed with date information. When you click the link, dialog box appears. By specifying the file name and path name, event data can be downloaded to the PC which displays Web-UI.
- When the event data saved in system event log is downloaded (if the system event log which is collected in advance, exists)
  1. When you click [Download] button, a message showing [I\_00417 Are you sure?] is displayed. Click [OK] button.
  2. [System Event Log (Collect)] window appears, and the link to system event log information collected in advance, is displayed.
  3. Click [Collect] button to collect the latest system event log. A message showing [I\_00417 Are you sure?] is displayed. Click [OK] button. [Progress] window appears while the system event log information is collected.
  4. [System Event Log (Collect)] window appears, and the link to event data which is collected, is displayed with date information. When you click the link, a dialog box appears. By specifying the file name and path name, event data can be downloaded to the PC which displays Web-UI.

FIGURE 1.98 [System Event Log (Collect)] Window



- Narrowing down the events displayed in the window
  1. Click the [Filter] button.  
The [System Event Log Filtering Condition] window for entering filtering conditions appears.
  2. Enter the conditions in the [System Event Log Filtering Condition] window. Then, click the [Apply] button. The browser returns to the [System Event Log] window. The window displays the events that satisfy the specified conditions.

## ☐ [System Event Log Filtering Condition] Window

Click [Filter] button on the [System Event Log] window. The [System Event Log Filtering Condition] window for entering filtering conditions appears.

The filtering conditions of events which are displayed in [System Event Log] window can be set in the [System Event Log Filtering Condition] window.

FIGURE 1.99 [System Event Log Filtering Condition] Window

**Fujitsu** Model: PRIMEQUEST 2800B  
Part Number: MCF3AC111  
Serial Number: [REDACTED]  
Status: Normal

System User Administration Network Configuration Maintenance Logout

>System >System Event Log

**System Event Log Filtering Condition** [Help]

Select the filtering conditions and click the Apply button to take effect.  
Note : The followings are AND conditions.

1)Severity: ☒ Error ☒ Warning ☒ Info

2)Unit: ☒ All  
☐ Specified ☐ PSUs ☐ Fans  
☐ SB#0 ☐ SB#1 ☐ SB#2 ☐ SB#3  
☐ IOU#0 ☐ IOU#1 ☐ IOU#2 ☐ IOU#3  
☐ DU#0 ☐ DU#1  
☐ OPL  
☐ MMB

3)Source: ☒ All  
☐ Specified ☐ CPU ☐ DIMM ☐ Chipset  
☐ Voltage ☐ Temperature ☐ Other

4)Sort by Date/Time: ☒ New event first ☐ Old event first

5)Start Date/Time: ☒ First event ☐ Specified Time 2013 - 1 - 1 0 : 0 : 0

6)End Date/Time: ☒ Last event ☐ Specified Time 2013 - 1 - 1 0 : 0 : 0

7)Number of events to display (Max 3000): 100 / 99

[Apply] [Cancel] [Default Setting]

TABLE 1.134 Display and Setting Items on [System Event Log Filtering Condition] Window

Items	Description
Severity	<p>Check the Severity check box. Multiple selections are possible.</p> <ul style="list-style-type: none"> <li>Error</li> <li>Warning</li> <li>Info</li> <li>Monitor</li> </ul> <p>All are ON by default.</p> <p><b>Note</b> [Monitor] check box is displayed only when login is done with CE privilege.</p>
Source	<p>Select target source to be displayed. Select [All] or [Specified] by Radio button.</p> <ul style="list-style-type: none"> <li>All: Filtering is not done by Source.</li> <li>Specified: Filtering of Source unit can be set. Select the Source to be displayed.</li> </ul> <p>Default setting is All.</p>
Unit	<p>Select the target unit to be displayed. Select [All] or [Specified] by Radio button.</p> <ul style="list-style-type: none"> <li>All: Filtering is not done by Unit.</li> <li>Specified: Filtering of Unit can be set. Select the Source to be displayed.</li> </ul> <p>Default setting is All.</p>
Sort by Date/ Time	<p>Specifies either display by new order or display by old order by using the radio button.</p> <ul style="list-style-type: none"> <li>New event first</li> </ul>

Items	Description
	<ul style="list-style-type: none"> <li>Old event first</li> </ul> The default setting is New event first.
Start Date/ Time	Specifies either display from recent event or specify the time, by using the radio button. <ul style="list-style-type: none"> <li>First event: Display by recent event</li> <li>Specified Time: Specify the time. In case of Specified Time, enter the Start Date and Time.</li> </ul> The default setting is First event.
End Date/ Time	Specifies either display till last event or specify the time, by using the radio button. <ul style="list-style-type: none"> <li>Last event: Display till Last event</li> <li>Specified Time: Specify the time. In case of Specified Time, enter the End Date and Time.</li> </ul> The default setting is Last event.
Number of events to display	Specifies the number of log to be displayed. As for the denominator, display the total number of events that are logged. A maximum of 3000 events can be specified. The default setting is 100 events.

TABLE 1.135 [System Events Log Filtering Condition] Window Buttons

Buttons	Description
Apply	Log which matches with the specified conditions will be listed on [System Event Log] window by clicking the [Apply] button.
Cancel	Returns to [System Event Log] window by clicking the [Cancel] button.
Default Setting	Selected value returns to the default value.

**[Message]**

This section describes the messages to be displayed on this window.

Message Number	Message
W_00413	Nothing is selected.
W_00414	Invalid Date Format.
W_00426	Invalid Values Specified.
W_00434	Invalid Time Format.
W_00441	Range over error.
I_00417	Are you sure?
I_00468	Are you sure you want to clear the SEL?

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

### 1.7.3 [Operation Log] Window

As for the display, the operation is the same as the PRIMEQUEST 2400E/2800E model. Refer to chapter 1.2.3.

### 1.7.4 [System Information] Window

[System Information] window displays the information, such as name of the systems and name of the products etc., related to the PRIMEQUEST 2800B model.

Moreover, names and Asset Tag (Property management number) corresponding to the PRIMEQUEST 2800B model(Chassis) can be set.



FIGURE 1.100 [System Information] Window

Model: PRIMEQUEST 2800B  
Part Number: MCF3AC111  
Serial Number: 1541346003  
Status: Normal

System Information

Click the Apply Button to apply all changes.

System Name	PRIMEQUEST1541346003
Product Name	PRIMEQUEST 2800B
Part Number	MCF3AC111
Serial Number	1541346003
Asset Tag	
Core / Max Core	48 / 48
Physical Memory Size	512GB

Apply Cancel

TABLE 1.136 Display and Set Items of [System Information] window

Items	Description
System Name	<p>System name of PRIMEQUEST 2000 series is displayed. User with Administrator privilege can change system name. Maximum 64 characters can be entered.</p> <p><b>Remarks</b></p> <ul style="list-style-type: none"> <li>Characters which can be entered: Alphanumeric characters, half-width space. The following characters can also be entered. ! " # \$ % &amp; ' ( ) = - ^ _ ` @ [ ] { } ; * + ? &lt; &gt; . / _  </li> <li>However, there is a limitation.</li> <li># and half-width space cannot be used as first character.</li> <li>Half-width space cannot be used as last character.</li> </ul> <p>Default is &lt; PRIMEQUEST +Product serial number&gt;. When [system Name] is blank, it becomes system name of default.</p>
Product Name	Product name of PRIMEQUEST 2000 series is displayed.
Part Number	Model name of PRIMEQUEST 2000 series is displayed.
Serial Number	Serial number of PRIMEQUEST 2000 series is displayed.
Asset Tag	<p>Property administration information (Asset Tag) is displayed. User with the administrator privilege can change Asset Tag information. Maximum 32 characters can be entered. No default value.</p>
Core / Max Core	<p>Display the CPU core number and Max Core number included in the system. The Max Core number contains the number of Disable core.</p> <p><b>Remarks</b> Degenerated CPU is not included in the number.</p>
Physical Memory Size	<p>Displays the physical memory volume that is included in the system.</p> <p><b>Remarks</b> The memory size does not include degraded DIMMs.</p>

TABLE 1.137 Buttons on the [System Information] Window

Buttons	Description
Apply	When the characters are entered in the [System Name] or [Asset Tag] fields and click the [Apply] button is clicked, the entered information is set.
Cancel	When the [Cancel] button is clicked, the system is restored to the original condition without setting the information entered in the [System Name] or [Asset Tag]

(1) Menu Operation

[System] – [System Information]

(2) Window Operations

1. Change the items of [System Name] or [Asset Tag] and click the [Apply] button.  
Information in each field is set.

### [Message]

This section describes the messages to be displayed on this window.

Message Number	Message
I_00013	Setting completed.
W_00431	Invalid character included.
W_00407	Input characters are too long.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

In the [Operation Log] window, only the table contents can be scrolled without scrolling the title of the table. When there is no event to be displayed, a message “There is no Event Logs”; would be displayed instead of table.

## 1.7.5 [Firmware Information] Window

Latest version number of applied Firmware, information of the Firmware version which is operating inside the system and the information of the Firmware version with backup is displayed on the [Firmware Information] window.

FIGURE 1.101 [Firmware Information] Window

Model: PRIMEQUEST 2800B  
Part Number: MCF3AC111  
Serial Number: [REDACTED]  
Status: Normal

System Administration Network Configuration Maintenance Logout

>System >Firmware Information

**Firmware Information**

Unified Firmware Version BA14012

**Current Firmware**

Unit	Firmware	active bank	Unified Firmware Version
		Version(bank1) Version(bank2)	
SB#0	BMC	bank2 0.60F 0.68F	BA14012
		bank1 1.23 1.12	
	BIOS	bank2 0.60F 0.68F	BA14012
		bank1 1.23 1.12	
SB#1	BMC	bank2 0.60F 0.68F	BA14012
		bank1 1.23 1.12	
	BIOS	bank2 0.60F 0.68F	BA14012
		bank1 1.23 1.12	
SB#2	BMC	bank2 0.60F 0.68F	BA14012
		bank1	

TABLE 1.138 Display Item of [Firmware Information] Window

Items	Description
Unified Firmware Version	Latest version number of applied Firmware.
<b>Current Firmware</b>	
Unit	Target unit mounted with Firmware is displayed. <ul style="list-style-type: none"> <li>SB#n</li> <li>MMB</li> </ul>
Firmware	Type and Current version (Active) of Firmware are displayed. <ul style="list-style-type: none"> <li>BMC</li> <li>BIOS</li> <li>MMB</li> <li>Not-present: It shows that Unit is not mounted. Gray color background is displayed.</li> </ul>
active bank	Bank (bank1 or bank2) of the memory that is operating now is displayed.. After start/restart of the partition, latest Firmware information is reflected in this display.
Version (bank1)	Firmware Version of bank1 is displayed. [Version display format] Firmware maintains Version information in the following format. <ul style="list-style-type: none"> <li>Major Version=1Byte data (Binary format)</li> <li>Minor Version=1Byte data (BCD format)</li> </ul> <p>This data is displayed as follows.</p> <p>X.YY</p> <p>X displays Major version in decimal (0~255)</p> <p>Y displays Minor version as it is by double digit in BCD format (Binary coded decimal) (00~99).</p>
Version (bank2)	Firmware Version of bank2 is displayed.

Items	Description
	[Version display format] Same as bank1
Unified Firmware version	Displays firmware version of target unit. Firmware maintains version information in the following format. <ul style="list-style-type: none"><li>• Model identification XX=1 byte data (01h=SA)</li><li>• Last two digits of the year YY=1 byte data (BCD format) 09-99</li><li>• Month MM=1 byte data (BCD format) 01-12</li><li>• Serial number N=1 byte data (Binary format) 1-9</li></ul> This data is displayed as below. XXYYMMN Example: BA13012 In case of uncertain version number “-” is displayed.

After start/restart of the system is executed by the system administrator, the latest written Firmware is reflected.

#### Remarks

After executing Firmware update, it is recommended to reflect in the Firmware by prompt start/restart of the system.

(1) Menu Operation  
[System] – [System Information]

(2) Window Operations  
None

### 1.7.6 [System Setup] Window

In [System Setup] window, Power supply of PRIMEQUEST 2800B model and restoration action etc. can be set.

FIGURE 1.102 [System Setup] Window

Model: PRIMEQUEST 2800B  
Part Number: MCF3AC111  
Serial Number: [REDACTED]  
Status: Normal

System User Administration Network Configuration Maintenance Logout

>System >System Setup

System Setup

Click the Apply Button to apply all changes.

Input Voltage	200V
Power Feed Mode	<input checked="" type="radio"/> Single <input type="radio"/> Dual
Power Restoration Policy	<p>Always ON - chassis always powers up after AC is restored. Always OFF - chassis remains powered off after AC is restored. Restore - power is returned to the state that was in effect before AC was removed or lost. Schedule Sync - Synchronize with the schedule.</p> <p>Restore</p>
System Power on Delay	0 sec
Altitude	Altitude < 1000m
PSU Redundant Mode	<input checked="" type="radio"/> Redundant <input type="radio"/> Non-Redundant
System Power Save Control	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
System Power Saving Threshold	8640 W (3200W - 8640W)

Apply Cancel

TABLE 1.139 Display Items and Setting Items in [System Setup] Window

Items	Description
Input Voltage	<p>Displays input voltage.</p> <ul style="list-style-type: none"> <li>100V</li> <li>200V</li> </ul> <p>When information cannot be acquired, it is displayed as 200V.</p>
Power Feed Mode	<p>Whether power supply of PRIMEQUEST 2000 system is configured in primary power feed mode or dual power feed mode is set.</p> <ul style="list-style-type: none"> <li>Single: primary power feed mode</li> <li>Dual: dual power feed mode</li> </ul> <p>Default setting is Single.</p>
Power Restoration Policy	<p>Sets the display of the restoration action after power failure.</p> <ul style="list-style-type: none"> <li>Always off: Maintains the power-off status after the power restoration.</li> <li>Always on: Regardless of the condition at the time of power failure, the partition is powered on after the power restoration.</li> <li>Restore: Restores the status immediately before the power failure. If the power was on when the power failure occurred, it restores the power-on status of the partition. If the power was off, the partition power stays off.</li> <li>Schedule Sync: If the partition is in the operating time zone, power of partition turns on automatically depending on the schedule operations at the time of restoration of power. (attention) The schedule set with Special is applied only on the specified day.</li> </ul> <p>Default setting is Restore.</p>
System Power On Delay	<p>Sets the standby time until power on of system is specified as per the restoration power policy that is set after the AC power is On (also includes restoration power). Specifies within the range of 0~9999 seconds.</p>

Items	Description
	<p>Default value is 0 seconds. (attention) Other start processing is not executed until the processing of system Power On Delay ends.</p>
Altitude	<p>Sets the altitude where PRIMEQUEST 2800B model is installed or placed.</p> <ul style="list-style-type: none"> <li>Altitude &lt; 1000 m</li> <li>1000 m &lt;= Altitude &lt; 1500 m</li> <li>1500 m &lt;= Altitude &lt; 2000 m</li> <li>2000 m &lt;= Altitude</li> </ul> <p>Default value is Altitude &lt; 1000 m. Setting error of altitude condition is possible up to <math>\pm 100</math>m.</p>
PSU Redundant Mode	<p>Sets whether PSU is redundantly operated.</p> <ul style="list-style-type: none"> <li>Redundant</li> <li>Non-redundant</li> </ul> <p>When Power Feed Mode is Single, it is by default Non-Redundant. When Power Feed Mode is Dual, it is always Redundant.</p>
System Power Save Control	<p>Sets enable/disable for Power Saving function for entire system.</p> <ul style="list-style-type: none"> <li>Enable</li> <li>Disable</li> </ul> <p>Power Saving function supports only PSU_P 200V. Default is Disable.</p>
System Power Saving Threshold	<p>Sets the power consumption threshold (Limit value) of entire system. Minimum value is 300W. Maximum value is as shown below.</p> <ul style="list-style-type: none"> <li>PRIMEQUEST 2400E : 8640W</li> <li>PRIMEQUEST 2800E/B : 8640W</li> </ul> <p>Setting is possible only when System Power Save Control is Enable, gray-out at the time of disable. Default value is the maximum value of each model.</p>

TABLE 1.140 [System Setup] window button

Buttons	Description
Apply	When items such as [Power Feed Mode] and [Power Restore Policy] are specified and [Apply] button is clicked, the information is set.
Cancel	When [Cancel] button is clicked, returns to the original status without setting the changed or input items.

## (1) Menu Operation

[System] – [System Setup]

## (2) Window Operations

Specify the items such as [Power Feed Mode] and [Power Restoration Policy] and click on the [Apply] button.

Respective information is set.

**[Message]**

This section describes the messages to be displayed on this window.

Message Number	Message
----------------	---------

Message Number	Message
I_00013	Setting completed.
E_00100	Failed to set the System Setup
W_00426	Invalid values specified.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

## 1.7.7 [Power Control] Window

[Power Control] window displays the power control of the system.

### Remarks

When the operating system supports ACPI (Advanced Configuration and Power Interface), the power can be turned Off after the operating system is Shutdown by Power Off operation. If ACPI is not supported, power can be Off without the Shutdown of the operating system. Moreover, even if the operating system supports ACPI, and applications running on the operating system are not supported, sometimes power Off is not possible. Since these depend on the specifications of the operating system and applications, for details, refer to the operating system and application specifications.

FIGURE 1.103 [Power Control] Window

**FUJITSU** Model: PRIMEQUEST 2800B  
Part Number: MCF3AC111  
Serial Number: [REDACTED]  
Status: Normal

System User Administration Network Configuration Maintenance Logout

>System >Power Control

**Power Control** Refresh Help

Select a Power Control option, then click the Apply button to take effect.

Status	Normal
Power Status	Standby
System Progress	Power Off
Power Control	(Not specified) ▼
Force Power Off Delay	<input type="checkbox"/> <input type="checkbox"/> min
Boot Selector	No Override ▼

Apply Cancel

1. Select the process executed for the system from Pull-down menu of [Power Control]. Then, click the [Apply] button. Dialog box for confirmation appears.
2. Click the [OK] button to execute the process. Click the [Cancel] button to cancel the process.

When sytem Power is On, or when Power is Off, and when the specified control is failed, Warning dialog box appears.

When the CPU mounted on the SB of system is not matched at the time of specifying the Power On of syetm, Warning dialog box appears. Error occurs in the Power On operation.

TABLE 1.141 Display Items and Set Items of [Power Control] Window

Items	Description
Status	<p>Displays the Status of the System.</p> <ul style="list-style-type: none"> <li>• Normal</li> <li>• Warning</li> <li>• Error</li> </ul>
Power Status	<p>Displays the Power Status of the System.</p> <ul style="list-style-type: none"> <li>• On</li> <li>• Standby</li> </ul>
System Progress	<p>The status of the partition progress is displayed.</p> <ul style="list-style-type: none"> <li>• Power Off: The partition power is off.</li> <li>• Power On In Progress: Partition power on is in process.</li> <li>• Reset: The status of the partition from the beginning of reset till the completion of the operating system boot.</li> <li>• EFI: The UEFI menu screen is displayed.</li> <li>• Boot: Operating system is being booted.</li> <li>• Operating system Running: Operating system running state</li> <li>• Operating system Shutdown: Operating system shutting down.</li> <li>• Panic: Panic (Only in RHEL)</li> <li>• Power Off In Progress: Partition power off is in process.</li> <li>• Fatal: Stopped.</li> <li>• Dumping: The dumping is being output.</li> <li>• Halt: Halting.</li> <li>• Stop Error: Stop error. (Only in Windows)</li> </ul> <p><b>Remarks</b></p> <ul style="list-style-type: none"> <li>• When SVAS (Server View Agentless Service) is not installed to system, the display is not switched over in 'Operating system Running' even if Operating system is working. Moreover, for 'Operating system shutdown', 'Panic' commanded by SVAS if SVAS (Server View Agentless Service) is not installed, there is no display. SVAS : Specifies the piece of software running on the OS in managed nodes to help BMC with management. Unless SVAgent, it does not provide management interface to the outside.</li> </ul>
Power Control	<p>Selects power control specified for the system. However, for the system which is already in power-on state, [Power On] is not displayed. On the contrary, for the system which is already in powered off, [Power Off], [Reset], [NMI], [Power Cycle], [Force Power Off] and [sadump] are not displayed.</p> <ul style="list-style-type: none"> <li>• Power On: System is the powered on.</li> <li>• Power Off: System is powered off.</li> </ul> <p>From the view point of Operating system, it is same as that the power button of the device is on. Therefore, when the operating system supports the ACPI, power can be turned off after the operating system is shutdown. For details, see Power Specifications (ACPI) of the operating system. When the operating system does not support the ACPI, the power can be turned off without shutting down the operating system.</p> <ul style="list-style-type: none"> <li>• Power Cycle: Powered on again after the partition is forcibly powered on.</li> <li>• Reset: Resets the partition.</li> <li>• NMI: Produces the NMI interruption for the system.</li> </ul>



Items	Description
	<ul style="list-style-type: none"> <li>Force Power Off: Turns off the power forcefully.</li> <li>sadump: Specifies the SADUMP for the system.</li> <li>(Not specified): There is no instruction for this system.</li> </ul>
Force Power Off Delay	<p>Specifies whether to enforce power off, when power off is done without proper operation of the shutdown instruction for the operating system by [Power Off] on the partition. In case enforced power off has been specified, the specified time (1~9 minutes) can be set. The system is forcibly powered off when the specified time has lapsed.</p> <p>The default setting of check box is Off.</p>
Boot Selector	<p>Specifies the boot device for which the Boot Manager setting of BIOS is Override temporarily. Select the device to be boot from pull-down menu.</p> <ul style="list-style-type: none"> <li>No Override: Boots by the EFI Boot Manager settings.</li> <li>Force boot into EFI Boot Manager: Waiting for input by the EFI Boot Manager. Boot by selecting the boot device from the EFI Boot Manager</li> <li>Force PXE/iSCSI: Overrides the EFI Boot Manager settings, forcibly tries the PXE.</li> <li>Force boot from DVD: Overrides the EFI Boot Manager settings, and forcibly tries the booting from the System DVD.</li> </ul> <p>Default setting is 'No Override'.</p> <p>This setting is applied only for the first system boot setting the value. After the system boots, this setting automatically returns to 'No Override'. Therefore, it is necessary to set the boot for system. In case of constant setting, it is set in the Boot Manager of the UEFI.</p>

TABLE 1.142 [Power Control] Window Buttons

Buttons	Description
Apply	When you click the [Apply] button, the information of power control items is set. Confirm the setting contents if dialog box prompts for Confirmation.
Cancel	When you click the [Cancel] button, returns to source without setting the information of power control items corresponding to partition,.

**Remarks**

When the operating system supports the ACPI, the operating system can be shutdown by the above mentioned Power Off operation and the power can be turned off. When the operating system is not supported by the ACPI, the power is turned off without shutting down the operating system. Moreover, when the application which is operating in the operating system is not supported even if the operating system is supported by the ACPI, the power cannot be turned off. Since this is according to the operating system and application specifications, for details, see the Operating System and Application Manual.

(1) Menu Operation  
[System] – [Power Control]

- (2) Window Operations
- Click the [Status Clear] button. Selects the power control items related to each partition from the pull-down list of [Power Control]. Then click the [Apply] button.  
Dialog box for setting confirmation appears.
  - Click [OK] button to execute the settings.

**[Message]**

This section describes the messages to be displayed on this window.

Message Number	Message
E_00141	Unable to power on the System.

Message Number	Message
E_00142	Unable to power off the System.
E_00002	Command Failed
E_00144	Unable to power off/on the System.
E_00145	Unable to reset the System.
E_00146	Unable to generate an NMI interrupt in the System.
E_00143	Unable to forcibly power off the System.
E_00091	Force Power Off Delay setting failed.
E_00xxx	Unable to power on the system due to CPU mismatch between SBs.
E_00154	Unable to power on due to mismatch between supply voltage and input voltage.
I_00151	Unable to control system power because maintenance is in progress. Release maintenance mode first.
E_00xxx	Unable to power on the system due to CPU composition abnormal.
E_00xxx	Unable to power on the system due to DIMM composition abnormal.
E_00xxx	Unable to power on the system due to DIMM does not satisfy requirements of Mirror Mode.
W_00504	The Power On failed, because of switching the Home SB. Please execute it after a while again.
E_00xxx	Unable to power on the system due to abnormal SB composition.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

### 1.7.8 [Schedule] Menu

The [Schedule] menu has the [Schedule Control] and [Schedule List] windows. This section describes the windows and the operation.

#### Note

As mentioned below, there may be a delay in the time recorded in SEL compared to the time reserved for scheduled operations.

- After checking the configuration and after performing the start up preparation process, it takes some time until the power is ON. In this case, the SEL display is delayed about from six seconds up to 8 seconds than the time reserved for the scheduled operations.
- The shutdown instructions from MMB to OPERATING SYSTEM take certain time from the set time. However, the following interval times may be changed under the various conditions like setting and the configuration.
- Interval time until shutdown instructions reaches OS from MMB.
- Interval time until MMB notifies SEL begin shutdown after OS begins shutdown.
- Even if the [Power on Delay] is 0 seconds, it takes about 30 seconds ~ 70 seconds from starting the power on up to the reset.

#### ☐ [Schedule Control] window

In the [Schedule Control] window, the setting related to the schedule can be set for system.

FIGURE 1.104 [Schedule Control] Window

Model: PRIMEQUEST 2800B  
Part Number: MCF3AC111  
Serial Number: [REDACTED]  
Status: Normal

System: User Administration Network Configuration Maintenance Logout  
>System >Schedule >Schedule Control

**Schedule Control** Help

Select Schedule Control then click the Apply button to take effect.

Schedule Control	<input type="radio"/> On <input checked="" type="radio"/> Off
Number of schedules	0

Apply Cancel

If the maintenance work (Either Hot System Maintenance, Warm System Maintenance or Cold System Maintenance) of the system executed in the schedule execution time, the scheduled operation does not execute the power operation of the system.

If the schedule overlaps on the same day, it is processed according to the following priority levels.

Special > Monthly > Weekly > Daily

- Daily: Schedule executed every day
- Weekly: Schedule executed every week
- Monthly: Schedule executed every month
- Special: Schedule executed on specific day every year

Moreover, if the Power On and Power Off is specified at the same time, the priority is given to Power Off.

Because System does not do Power On in Power On Delay, Schedule Power Off is disregarded. Moreover, when OS does not accept the Shutdown demand, Power Off is not done.

TABLE 1.143 Display Items and Setting Items of [Schedule Control] Window

Items	Description
Schedule Control	Sets whether schedule operation is done for system. <ul style="list-style-type: none"> <li>• On</li> <li>• Off</li> </ul> Default setting is Off.
Number of schedules	Displays the number of schedules that are set.

TABLE 1.144 [Schedule Control] Window Buttons

Buttons	Description
Apply	When the [Apply] button is clicked, the schedule operation information for the system is set.
Cancel	When the [Cancel] button is clicked, the browser returns to the original status without setting the schedule operation information for the system.

(1) Menu Operation

[System] - [Schedule] - [Schedule Control]

(2) Window Operations

1. Specifies whether schedule operation has to be carried out by Radio button for system.
2. Click the [Apply] button.

## □ [Schedule list] Window

Up to 1000 instances of system power On / Off schedule can be recorded in the [Schedule list] Window.

FIGURE 1.105 [Schedule List] Window

Model: PRIMEQUEST 2800B  
Part Number: MCF3AC111  
Serial Number: [REDACTED]  
Status: Normal

System User Administration Network Configuration Maintenance Logout

>System >Schedule >Schedule List

**Schedule List** Help

Select a schedule then click the Edit/Remove button to edit or remove the schedule.  
Click Add button to add a new schedule.

Type	Pattern	Term	On Time	Off Time
-	-	-	-	-

Add Edit Remove Cancel

Schedule will appear in chronological order of the start date of the period.

If the start date are the same, the schedule appears in the sequence in which it is listed.

### Remarks

If the Type is Weekly, the start date is considered to be "Oneday".

TABLE 1.145 Display Items and Set Items of [Schedule List] Window

Items	Description
	Select the schedule to be edited or removed.
Type	<p>Displays the type of schedule set in the system.</p> <ul style="list-style-type: none"> <li>• Daily: Select when you want to execute every day</li> <li>• Weekly: Select when you want to execute every week</li> <li>• Monthly: Select when you want to execute every month</li> <li>• Special: Select when you want to execute on a particular day every year.</li> </ul> <p>If the schedule overlaps on the same day, it is processed according to the following priority order. Special &gt; Monthly &gt; Weekly &gt; Daily</p>
Pattern	<p>Displays the schedule pattern corresponding to the type of the schedule.</p> <p>Days of week in Weekly (Sun ~ Sat)</p> <p>The period in Monthly</p> <p>The specific month and day in Special</p>
Term	<p>Displays the period of the schedule according to the type and the pattern of the schedule.</p> <ul style="list-style-type: none"> <li>• Daily: Starting month and date and ending month and date.</li> <li>• Weekly: Starting month and ending month.</li> <li>• Monthly: Starting month and ending month.</li> </ul> <p>Default setting is as follows</p> <ul style="list-style-type: none"> <li>• Daily: From: Jan / 1 To: Jan / 1 Note --- It is executed only on January 1.</li> <li>• Weekly: From: Jan To: Jan Note --- It is executed only in January.</li> <li>• Monthly: From: Jan To: Jan Note --- It is executed only in January.</li> </ul>
On Time	Displays the time when the process of Power On is executed on the specified execution day. Time specifies 24 hours. Minute indicates the interval of 10 minutes, as 00, 10, 20, 30, 40, and 50.
Off Time	Displays the time when the process of Power Off is executed on the specified execution day. Time indicates 24 hours. Minute indicates the interval of 10 minutes, as 00, 10, 20, 30, 40, and 50.

TABLE 1.146 [Schedule List] Window Buttons

Buttons	Description
Add	If [Add] button is clicked, [Add Schedule] window appears and the schedule can be added.
Edit	If [EDIT] button is clicked, [Edit Schedule] window appears and the schedule can be changed.
Remove	If [Remove] button is clicked, the selected schedule can be deleted.
Cancel	If [Cancel] button is clicked, the browser returns to the previous window.

## (1) Menu Operation

[System] - [Schedule] - [Schedule List]

## (2) Window Operations

- If the schedule is to be added newly
1. Click [Add] button.  
[Add/Edit Schedule] window appears.
  2. Add the schedule to the [Add/Edit Schedule] window.

- If the schedule is to be changed
  1. Select an existing schedule with [Radio] button.
  2. Click [Edit] button.  
[Add/Edit Schedule] window appears.
  3. Changes an existing schedule in [Add/Edit Schedule] window.
- If the schedule is to be deleted
  1. Select the schedule with [Radio] button.
  2. Click [Remove] button.  
The confirmation dialog box appears.
  3. Click [OK] button.  
Deletes the schedule.

### [Message]

This section describes the messages to be displayed on this window.

Message Number	Message
I_00013	Setting completed.
E_00412	You need an empty entry.
W_00413	Nothing is selected.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

## □ [Add Schedule] window/ [Edit Schedule] window

In [Add Schedule] window, the schedule of Power On / Off for each partition, can be added newly.  
In [Edit Schedule] window, an existing schedule can be changed.

The window items of [Add Schedule] window and [Edit Schedule] window are common.

In this section, an explanation is given by using the [Add Schedule] window.

FIGURE 1.106 [Schedule List] Window

Model: PRIMEQUEST 2800B  
Part Number: MCF3AC111  
Serial Number: [redacted]  
Status: Normal

System User Administration Network Configuration Maintenance Logout  
>System >Schedule >Schedule List

**Add Schedule** Help

Input a schedule, then click the Apply button to take effect.

Type	Pattern	Term
<input type="radio"/> Daily	-	From: Jan 1 To: Jan 1
<input type="radio"/> Weekly	<input type="checkbox"/> Sun <input type="checkbox"/> Mon <input type="checkbox"/> Tue <input type="checkbox"/> Wed <input type="checkbox"/> Thu <input type="checkbox"/> Fri <input type="checkbox"/> Sat	From: Jan To: Jan
<input type="radio"/> Monthly	From: 1 To: 1	From: Jan To: Jan
<input type="radio"/> Special	Jan 1	-

☐ On Time Hour: 0 Min: 0  
☐ Off Time Hour: 0 Min: 0

Apply Cancel

TABLE 1.147 Display Items and Set Items of [Add Schedule] Window

Items	Description
Type	<p>Select the types of schedule to be set in the syetm.</p> <ul style="list-style-type: none"> <li>• Daily: Select when you want to execute every day</li> <li>• Weekly: Select when you want to execute every week</li> <li>• Monthly: Select when you want to execute every month</li> <li>• Special: Select when you want to execute on a particular day every year. (The useful range of Special becomes only a specified day.)</li> </ul> <p>If the schedule overlaps on the same day, it is processed according to the following priority order. Special &gt; Monthly &gt; Weekly &gt; Daily By default, it is not selected.</p>
Pattern	<p>Specify the schedule pattern corresponding to the types of the schedule.</p> <ul style="list-style-type: none"> <li>• Weekly : Day in a week (Sun ~ Sat)</li> <li>• Monthly: Period in a month</li> <li>• Special: Specified month</li> </ul> <p>Default settings are as follows.</p> <ul style="list-style-type: none"> <li>• Day in a week: Not selected</li> <li>• Period: From : 1 To: 1</li> <li>• Specified date: Jan/1</li> </ul>
Term	<p>Specify the period of the schedule according to the type and pattern of the schedule.</p> <ul style="list-style-type: none"> <li>• Daily: Starting month and date, and ending month and date</li> <li>• Weekly: Starting month and ending month</li> <li>• Monthly: Starting month and ending month</li> </ul> <p>Default settings are as follows.</p> <ul style="list-style-type: none"> <li>• Daily: From: Jan / 1 To: Jan / 1</li> <li>• Weekly: From: Jan To: Jan</li> <li>• Monthly: From: Jan To: Jan</li> </ul>
On Time	<p>On the specified execution date, set whether the power-supply is to be turned ON.</p> <p>If the power-supply is to be ON, set the time.</p> <p>Time is specified in 24 hours. Minute specifies the interval of 10 minutes as 00, 10, 20, 30, 40, and 50.</p>
Off Time	<p>Set whether the power-supply is OFF on the specified execution date.</p> <p>If the power-supply is OFF, set the time.</p> <p>Time is specified in 24 hours. Minute is specified in the interval of 10 minutes, as 00, 10, 20, 30, 40, and 50.</p>

TABLE 1.148 [Add Schedule] Window Buttons

Buttons	Description
Apply	If the [Apply] button is clicked, the schedule information specified in each item is applied to the partition.
Cancel	If the [Cancel] button is clicked, returns to the original sate without applying the schedule information specified in each item.

**[Message]**

This section describes the messages to be displayed on this window.

Message Number	Message
I_00013	Setting completed.
W_00414	Invalid Date Format
W_00415	The duplicate On/Off Time is found.
W_00416	Both On/ Off Time are disabled.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference \(C122-E178EN\)](#).

## 1.7.9 [Console Redirection Setup] Menu

There are following windows in the [Console Redirection Setup] menu.

- ☐ [IPv4 Console Redirection Setup] window
- ☐ [IPv6 Console Redirection Setup] window

### ☐ [IPv4 Console Redirection Setup] window

The IP address settings for accessing Console Redirection Setup of IPv4, subnet mask, video redirection and enable/disable settings of virtual media can be done in the [IPv4 Console Redirection Setup] window.

FIGURE 1.107 [IPv4 Console Redirection Setup] Window

Model: PRIMEQUEST 2800B  
Part Number: MCF3AC111  
Serial Number: [REDACTED]  
Status: Normal

System User Administration Network Configuration Maintenance Logout

>System>Console Redirection Setup >IPv4 Console Redirection Setup

**IPv4 Console Redirection Setup** Help

Click the Apply Button to apply all changes.

IP Address	0 . 0 . 0 . 0
Subnet Mask	255 . 255 . 255 . 255
Video Redirection	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
Virtual Media	<input type="radio"/> Enable <input checked="" type="radio"/> Disable

Apply Cancel

TABLE 1.149 Display Items and Set Items of [IPv4 Console redirection Setup] Window

Items	Description
IP Address	Enters the IP address of the system permitted to connect. Specify an IP address of the same segment as the virtual IP address used to access the MMB Web-UI (see "1.5.2 [Network Interface] Menu"). Note that this IP address must be different from that virtual IP address. Default is 0.0.0.0.
Subnet Mask	Enters the subnet mask of IP address which is allowed for connection. Default is 255.255.255.255.
Video Redirection	Sets whether video redirection can be used. <ul style="list-style-type: none"> <li>Enable: Video redirection can be used.</li> <li>Disable: Video redirection cannot be used.</li> </ul>



Items	Description
	Default is Disable
Virtual Media	Sets whether virtual media can be used. <ul style="list-style-type: none"><li>· Enable: Virtual media can be used.</li><li>· Disable: Virtual media cannot be used.</li></ul> Default is Disable.

TABLE 1.150 [IPv4 Console redirection Setup] Window Buttons

Buttons	Description
Apply	When [Apply] button is clicked, video redirection, virtual media settings of the system are applied.
Cancel	When [Cancel] button is clicked, video redirection, virtual media settings are not applied and it returns to the original state.

## (1) Menu Operation

[System] - [Console Redirection Setup] - [IPv4 Console Redirection Setup]

## (2) Window Operations

1. IP address and the subnet mask are entered and it is set whether video redirection, virtual media can be used.
2. [Apply] button is clicked.

**[Message]**

This section describes the messages to be displayed on this window.

Message Number	Message
W_00432	Invalid IP Address specified
W_00433	The duplicate IP address was found.
I_00417	Are you sure?

**□ [IPv6 Console Redirection Setup] window**

The IP address settings for accessing Console Redirection LAN of IPv6, prefix length settings, video redirection and enable/disable settings of virtual media can be done in the [IPv6 Console Redirection Setup] window.

In case of automatic settings, when [Auto] button is clicked, IP address, prefix length are automatically acquired.

FIGURE 1.108 [IPv6 Console Redirection Setup] Window

Model: PRIMEQUEST 2800B  
Part Number: MCF3AC111  
Serial Number: MCF3AC111  
Status: Normal

System User Administration Network Configuration Maintenance Logout

>System >Console Redirection Setup >IPv6 Console Redirection Setup

**IPv6 Console Redirection Setup** [Help](#)

Click the Apply Button to apply all changes.

IP Address	<input type="text"/>
Prefix Length	<input type="text" value="0"/>
Video Redirection	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
Virtual Media	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
Automatic Acquisition	<input type="button" value="Auto"/>

TABLE 1.151 Display Items and Set Items of [IPv6 Console redirection Setup] Window

Items	Description
IP Address	Enters the global address for IPv6 which can be connected. In case of automatic acquisition, the acquired IP Address is displayed.
Prefix Length	Enters the prefix length for IPv6. In case of automatic acquisition, the acquired prefix length is displayed.
Video Redirection	Sets whether video redirection can be used. <ul style="list-style-type: none"> <li>Enable: Video redirection can be used.</li> <li>Disable: Video redirection cannot be used.</li> </ul> Default is Disable.
Virtual Media	Sets whether the virtual media can be used or not. <ul style="list-style-type: none"> <li>Enable: Virtual media can be used.</li> <li>Disable: Virtual media cannot be used.</li> </ul> Default is Disable.
Automatic acquisition	When IPv6 address is automatically acquired, the "Auto" button is clicked. IP address and prefix length are automatically acquired and overwritten.

TABLE 1.152 [IPv6 Console redirection Setup] Window Buttons

Buttons	Description
Auto	When you Click [Auto] button IP address and prefix length is automatically displayed.
Apply	When you click the [Apply] button, video direction of the ssystem, virtual media setting is applied.
Cancel	When you click the [Cancel] button, virtual media setting, video redirection is not applied and it returns to the original state.

## (1) Menu Operation

[System] - [Console Redirection Setup] - [IPv6 Console Redirection Setup]

## (2) Window Operations

1. Input the IP address, prefix length and sets whether video redirection and virtual media should be used.
2. Click the [Apply] button.

**[Message]**

This section describes the messages to be displayed on this window.

Message Number	Message
W_00432	Invalid IP Address specified
W_00433	The duplicate IP address was found.
I_00417	Are you sure?

## 1.7.10 [Power Management Setup] Window

In the [Power Management Setup] window, Power Saving can be set in the system.

Power Saving can be set only when the Power save Control as system is Enable.

When the System Power Save setting is Disable, then the display of this screen is shown as gray and cannot be set.

FIGURE 1.109 [Power management Setup] window

Model: PRIMEQUEST 2800E  
Part Number: MCF3AC111  
Serial Number: [REDACTED]  
Status: Normal

Active:MMB#0

System Partition User Administration Network Configuration Maintenance Logout

>Partition >Power Management Setup

Power Control  
Schedule  
Console Redirection Setup  
Partition Configuration  
Reserved SB Configuration  
Power Management Setup  
Partition#0

### Power Management Setup

Click the Apply Button to apply all changes.

#	Partition Name	Power Control Status	Power Save Control	Power Save Grace Period	Action reaching Power Save
0		Normal	<input type="radio"/> Enable <input checked="" type="radio"/> Disable	0 min	Partition Power Off

Apply Cancel Help

TABLE 1.153 Display Items and Set Items of [Power Management Setup] Window

Items	Description
Power Control Status	Displays the operating state of power control status of systemn. <ul style="list-style-type: none"> <li>Normal: Normal operating state. Shows that the operating rate suppression function for limitation of the electric power consumption is not working.</li> <li>Power Saving: Shows that the operating rate is being suppressed</li> </ul>
Power save Grace Period	Sets shutdown waiting time in Power Save Grace Period System when the Limit threshold is exceeded. Specified in the range of 0 ~ 99 minutes.

Items	Description
	Shows a valid item when Power Save Control of system is Enable and shows gray color when Disable.  Default is 5 minutes.
Action reaching Power Save	Executes the operation setting in the system after the Limit threshold excess stand-by time. <ul style="list-style-type: none"><li>• Continue: Continues operation for the system under operation.</li><li>• Power Off: Power Off is done for the system under operation.</li><li>• Force Power Off: Force Power Off is done for the system under operation.</li></ul> Displays a valid item when Power Save Control of system is Enable and displays gray color in case of Disable.  Default is Power Off

TABLE 1.154 [Power Management Setup] Window Buttons

Buttons	Description
Apply	The setting of the Power Management Setup is changed.
Cancel	Returns to the original state without changing the setting of the Power Management Setup.

(1) Menu Operation  
[System] - [Power Management Setup]

- (2) Window Operations
1. Set the items for changing the settings of the Power Management Setup and click the [Apply] button.  
Set the connection.

### 1.7.11 [ASR Control] Window

The conditions for executing automatic restart of the system on the [ASR (Automatic Server Restart) Control] can be set.

FIGURE 1.110 [ASR (Automatic Server Restart) Control] Window

Model: PRIMEQUEST 2800B  
Part Number: MCF3AC111  
Serial Number: [REDACTED]  
Status: Normal

System User Administration Network Configuration Maintenance Logout

>System >ASR Control

System Status  
System Event Log  
Operation Log  
System Information  
Firmware Information  
System Setup  
Power Control  
Schedule  
Console Redirection Setup  
ASR Control  
Console Redirection  
Mode  
LEDs  
Power Supply  
Fans  
Temperature  
SB  
IOU  
DU  
OPL  
MMB

### ASR(Automatic Server Restart) Control

Click the Apply Button to apply all changes.

**ASR**

Number of Restart Tries	5
Action after exceeding Restart tries	Stop rebooting and Power Off
Retry Counter	5

**Boot Watchdog**

Boot Watchdog	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
Timeout time (seconds)	6000
Action when watchdog expires	Continue

**Software Watchdog**

Software Watchdog	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
Timeout time (seconds)	300
Action when watchdog expires	Continue

Apply Cancel

TABLE 1.155 Display Items and Set Items of [ASR (Automatic Server Restart) Control] Window

Items	Description
Number of Restart Tries	Set the number of retries for restarting the operating system when there is time out by Boot Watchdog, or Software Watchdog of SVAS, or the hardware error occurs and OS shuts down. The number of times can be set up to 0-10 times. When 0 is specified, it does not retry. Default is five times.
Action after exceeding Restart tries	Repeat the restart by Watchdog Timeout and sets the action when the above-mentioned retry number is exceeded. The actions are as below. <ul style="list-style-type: none"> <li>Stop rebooting and Power Off: Reboot process is stopped, power supply of partition is cut off.</li> <li>Stop rebooting: Reboot process is stopped, and the system is stopped.</li> <li>Diagnostic Interrupt assert: Reboot process is stopped, instructs the NMI interruption for system. Tries to collect the data for investigation (damp) for the investigating the cause of stoppage, of the system which has stopped.</li> </ul> Default setting is 'Stop rebooting and Power Off'
Retry Counter	Displays the number of actual possible retries.
Cancel Boot Watchdog	Cancels operating system boot monitoring.  The operating system Boot monitoring is a function of ServerView, and the Boot Watchdog Timeout time is set and the monitoring is started on the screen of ServerView. However, if the timeout time of Boot Watchdog is mistaken and short time is set on the ServerView window, there is timeout before the start of the ServerView that stops the timer. There is a possibility that the problem such as repeating the reboot might occur. If this problem occurs, since the ServerView does not start, Boot Watchdog cannot

Items	Description
	<p>be cancelled without displaying the ServerView window that provides the Boot Watchdog function. When such problem occurs, if this check box is selected, Boot Watchdog can be cancelled without ServerView.</p> <p><b>Remarks</b></p> <p>After setting the Cancel Boot Watchdog, it is necessary to reset the Boot Watchdog in Server View.</p> <p>Default setting is OFF.</p> <p>Without retaining the status, if the setting is On, and the [Apply] button is clicked, Boot Watchdog is cancelled.</p>

TABLE 1.156 [ASR (Automatic Server Restart) Control] Window Buttons

Buttons	Description
Apply	<p>Sets the information if [Number of Restart Tries] [Action after exceeding Restart tries] are specified.</p> <p>If [Cancel Boot Watchdog] is selected as On, Boot Watchdog is cancelled.</p>
Cancel	<p>Does not set the information and returns to the original state.</p>

(1) Menu Operation  
[System] - [ASR Control]

(2) Window Operations

1. Every item is set.
2. [Apply] button is clicked.  
Specified information is set. Also, if the [Cancel Boot Watchdog] check box is selected as On, Boot Watchdog is cancelled.

## 1.7.12 [Console Redirection] Window

If the Console Redirection screen is selected when it enabled, the Video Redirection screen on the BMC is displayed in another window.

If the settings in [Console Redirection setup] Window are Disabled, check box cannot be Checked.

FIGURE 1.111 [Console Redirection] Window

Model: PRIMEQUEST 2800B  
Part Number: MCF3AC111  
Serial Number: [REDACTED]  
Status: Normal

System User Administration Network Configuration Maintenance Logout

>System >Console Redirection

System Status  
System Event Log  
Operation Log  
System Information  
Firmware Information  
System Setup  
Power Control  
Schedule  
Console Redirection Setup  
ASR Control  
Console Redirection  
Mode  
LEDs  
Power Supply  
Fans  
Temperature  
SB  
IOU  
DU  
OPL  
MMB

### Console Redirection

Check the operation and click the Apply button.

Operation  
☐ Video Redirection

Apply Cancel

TABLE 1.157 Display Items of [Console Redirection] Window

Items	Description
Video Redirection	Displays the Video Redirection on the BMC side. On the Console Redirection Setup window, selection is possible only when Enabled; when Disabled, the check box cannot be checked.

(1) Menu Operation  
[System] – [Console Redirection]

(2) Window Operations  
None

#### [Message]

This section describes the messages to be displayed on this window.

Message Number	Message
W_00413	Nothing is selected.
W_00472	Unable to get the reserved WEB Session information due to WEB Session Max over.
W_00473	Unable to check the Video Redirection check box due to the Video Redirection option is disabled.
I_00151	Unable to control system power because maintenance is in progress. Release maintenance mode first.
I_00417	Are you sure?
W_00541	Nothing is checked.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference \(C122-E178EN\)](#).

### 1.7.13 [Mode] Window

Various modes can be set for system in [Mode] window. In order to reflect the set value, turn Off the power of system and then it is necessary to turn On the Power of system once again.

FIGURE 1.112 [Mode] Window

Model: PRIMEQUEST 2800B  
Part Number: MCF3AC111  
Serial Number: [redacted]  
Status: Normal

System User Administration Network Configuration Maintenance Logout

>System >Mode

**Mode**

Select mode for the system, then click the Apply Button.  
Note : The system power off/on is required for the selections to become effective.

Memory Operation Mode	current status	Normal Mode
	setting	<input type="radio"/> Performance Mode <input checked="" type="radio"/> Normal Mode <input type="radio"/> Partial Mirror Mode <input type="radio"/> Full Mirror Mode <input type="radio"/> Spare Mode
Memory Mirror RAS Mode	current status	Mirror Keep Mode
	setting	<input checked="" type="radio"/> Mirror Keep Mode <input type="radio"/> Capacity Keep Mode
TPM	chip status	Disabled
	current status	Deactivated
	ownership	No

**On board LAN Mode**

IOU#0	current status	Enable(WOL disabled)
	setting	<input type="radio"/> Enable(WOL enabled) <input checked="" type="radio"/> Enable(WOL disabled) <input type="radio"/> Disable
IOU#1	current status	Enable(WOL disabled)

Apply Cancel

When the [Apply] button is clicked while the system is powered on, a warning dialog box "W\_00487 Unable to change the mode, because this system is powered on" is displayed.

When the system is already powered off, the settings are reflected without displaying the dialog box.

The LAN Device Mode is displayed in IOU Unit comprised in the partition specified by the LAN Device Mode. For settings, select LAN Device Mode in the IOU Unit, with the radio button and click the [Apply] button.

TABLE 1.158 Display Items and Setting Items in [Mode] Window

Items	Description
Memory Operation Mode (Current)	Displays the currently enabled Memory Operation Mode. <ul style="list-style-type: none"> <li>Performance Mode: Displays the settings to the Performance Mode.</li> <li>Normal Mode: Displays the settings to the Normal Mode.</li> <li>Partial Mirror Mode: Displays the settings to the Partial Mirror Mode.</li> <li>Full Mirror Mode: Displays the settings to the Full Mirror Mode.</li> <li>Spare Mode: Displays the settings to the Spare Mode.</li> </ul>
Memory Operation Mode (setting)	Sets the Memory Operation Mode for system. <ul style="list-style-type: none"> <li>Performance Mode</li> <li>Normal Mode</li> <li>Partial Mirror Mode</li> <li>Full Mirror Mode</li> <li>Spare Mode</li> </ul> Enables the settings after rebooting the system.



Items	Description
	Default setting is Normal Mode.
Memory Mirror RAS Mode (current status)	Displays the Memory operation of currently enabled Mirror Mode. <ul style="list-style-type: none"> <li>• Mirror Keep Mode: Shows the maintenance of Mirror Mode.</li> <li>• Capacity Keep Mode: Shows maintenance of memory capacity.</li> </ul>
Memory Mirror RAS Mode (setting)	Sets the Memory Operations for Mirror Mode for system. <ul style="list-style-type: none"> <li>• Mirror Keep Mode</li> <li>• Capacity Keep Mode</li> </ul> <p>Enables the settings after rebooting the system. As these items are enabled only when the Mirror mode is set, when Mirror Mode is not set, they are disabled.</p> <p>Default setting is Mirror Keep Mode.</p>
TPM (chip status)	Displays whether TPM function is Enabled or Disabled. <ul style="list-style-type: none"> <li>• Enabled (TPM is enabled)</li> <li>• Disabled (TPM is disabled)</li> </ul> <p><b>Remarks</b> When Home SB is 'without TPM mode', this field is not displayed.</p>
TPM (current status)	Displays the TPM status. <ul style="list-style-type: none"> <li>• Activated</li> <li>• Deactivated</li> </ul> <p><b>Remarks</b> When Home SB is 'without TPM mode', this field is not displayed.</p>
TPM (ownership)	Displays ownership of TPM. <ul style="list-style-type: none"> <li>• Yes (having Ownership)</li> <li>• No (not having Ownership)</li> </ul> <p><b>Remarks</b> When Home SB is without TPM mode, this field is not displayed.</p>
IOU	Displays the IOU that belongs to the system.
On board LAN Mode (current status)	Displays the On board LAN Mode in IOU Unit. <ul style="list-style-type: none"> <li>• Enabled (WOL enabled): Onboard LAN can be used at AC On status.</li> <li>• Enabled (WOL disabled): Onboard LAN comprised in the system can be used at Power On status.</li> <li>• Disabled: Onboard LAN cannot be used every time.</li> </ul>
On board LAN Mode (setting)	Sets On board LAN Device Mode in IOU Unit. Select the Mode to be set by using the radio button. <ul style="list-style-type: none"> <li>• Enabled(WOL enabled)</li> <li>• Enabled(WOL disabled)</li> <li>• Disabled</li> </ul> <p>Default setting is Enabled (WOL disabled).</p>

## (1) Menu Operation

[System] - [Mode]

## (2) Window Operations

1. Specify respective Mode and click the [Apply] button.  
Confirmation dialog box is displayed.
2. Click the [Ok] button.

**[Message]**

This section describes the messages to be displayed on this window.

Message Number	Message
E_00089	Mirror Mode setting failed.
E_00090	Power Control [Reset] setting failed.
E_00xxx	Unable to register the system as Mode enable because the DIMM does not satisfy requirements of Mode.
W_00xxx	Unable to change the mode, because the system is powered on.
E_00xxx	Unable to register the system as Mode enable because the CPU mismatch between SBs.
E_00xxx	Unable to register the system as Mode enable because the unsupported CPU configuration.
E_00xxx	Unable to register the system as Mode enable because of abnormal CPU composition.
E_00xxx	Unable to register the system as Mode enable because of abnormal DIMM composition.
E_00xxx	Unable to register the system as Mode enable because of abnormal SB composition.

For details on the messages displayed on the window, see [PRIMEQUEST 2000 Series Message Reference](#) (C122-E178EN).

## 1.7.14 [SB] Menu

[SB] Menu consists of the menus in each SB unit.

The menu of uninstalled SB is not displayed.

The format of window and operating method are same for each menu, therefore only one menu is explained here.

### □ [SB#x] Window

[SB#x] window displays the status of SB#x board and the settings of SB#x board can be carried out.

FIGURE 1.113 [SB#x] Window (1)

Model: PRIMEQUEST 2800B  
Part Number: MCF3AC111  
Serial Number:   
Status: Normal

System User Administration Network Configuration Maintenance Logout

>System >SB >SB#0

System Status  
System Event Log  
Operation Log  
System Information  
Firmware Information  
System Setup  
Power Control  
Schedule  
Console Redirection Setup  
ASR Control  
Console Redirection  
Mode  
LEDs  
Power Supply  
Fans  
Temperature  
SB  
SB#0  
SB#1  
SB#2  
SB#3  
IOU  
DU  
OPL

### SB#0 Status Clear

Click the Apply Button to apply all changes.

☒ Clear All Status  
☐ Clear Specified Status Select the appropriate "Status Clear" box.  
☐ Clear Status of common parts

CPUs

CPU#	Status	Status Clear
0	OK	<input type="checkbox"/>
1	OK	<input type="checkbox"/>

DIMMs

DIMM#	Status	Status Clear
0A0	OK	<input type="checkbox"/>
0A1	Not-present	<input type="checkbox"/>
0A2	Not-present	<input type="checkbox"/>
0A3	OK	<input type="checkbox"/>
0A4	Not-present	<input type="checkbox"/>
0A5	Not-present	<input type="checkbox"/>

Apply Cancel

FIGURE 1.114 [SB#x] Window (2)

**FUJITSU** Model: PRIMEQUEST 2800B  
Part Number: MCF3AC111  
Serial Number:   
Status: Normal

System User Administration Network Configuration Maintenance Logout  
>System >SB >SB#0

**SB#0** Refresh Help

**Mezzanine**

Mezzanine#	Status
0	OK
1	OK

**RAID Slot**

Power Status	Slot Status	Link Width	Seg/Bus/Dev
Standby	OK	Unknown	Unknown

**RAID Card**


Status	BBU Status	Vendor ID	Device ID	Physical Drives Count	Logical Drives Count	Serial Number	Firmware Version
-	-	-	-	-	-	-	-

**Physical Drives**

Slot#	Status	Vendor	Model	Capacity
0	-	-	-	-
1	-	-	-	-
2	-	-	-	-
3	-	-	-	-

Status Clear

FIGURE 1.115 [SB#x] Window (3)

**FUJITSU** Model: PRIMEQUEST 2800B  
Part Number: MCF3AC111  
Serial Number:   
Status: Normal

System User Administration Network Configuration Maintenance Logout  
>System >SB >SB#0

**SB#0** Refresh Help

**Logical Drives**

Sensor#	Status	RAID Level	Physical Drives assignment	Missing drives Count
-	-	-	-	-

**RAID Action Progress**

Drive Type	Slot#/Sensor#	Action	Progress	Estimated time remaining (hh:mm:ss)
-	-	-	-	-

**Chipsets**

Chipset	Status
Chipset	OK

**TPM**

TPM	Status
TPM	OK

**BMC**

BMC	Status
BMC	OK

**FBU**

FBU	Status
FBU	OK

**Clock**

Status Clear

FIGURE 1.116 [SB#x] Window (4)

**FUJITSU** Model: PRIMEQUEST 2800B  
Part Number: MCF3AC111  
Serial Number: XXXXXXXXXX  
Status: Normal

System | User Administration | Network Configuration | Maintenance | Logout

>System >SB >SB#0

**SB#0** Refresh Help

**Clock**  
Clock OK

**Voltage**

Sensor	Voltage	Threshold	
		Warning(Low/High)	Critical(Low/High)
P5VL	4.99 V	4.63/ 5.37 V	3.23/ 6.00 V
P1.1VL	- V	1.02/ 1.19 V	0.71/ 1.32 V
P1.8VL	1.80 V	1.67/ 1.93 V	1.16/ 2.17 V
P1.5VL	1.50 V	1.39/ 1.61 V	0.97/ 1.81 V
P1.0VL	0.99 V	0.92/ 1.08 V	0.64/ 1.21 V
P1.8V_CPU	- V	1.67/ 1.93 V	1.16/ 2.17 V
VDDQ_DIMM#1A	- V	1.25/ 1.61 V	0.87/ 1.81 V
P1.0V_JC#0A	- V	0.92/ 1.08 V	0.65/ 1.21 V
P1.5V_PCH	- V	1.39/ 1.61 V	0.97/ 1.80 V
P1.1V	- V	1.02/ 1.19 V	0.71/ 1.32 V
P0.9V_PCIEX#0	- V	0.83/ 0.97 V	0.58/ 1.09 V
P1.8V_PCIEX#0	- V	1.67/ 1.93 V	1.17/ 2.17 V
P0.9V_PCIEX#1	- V	0.83/ 0.97 V	0.58/ 1.09 V
P1.8V_PCIEX#1	- V	1.67/ 1.93 V	1.17/ 2.17 V

Status Clear

Left sidebar menu: System Status, System Event Log, Operation Log, System Information, System Setup, Power Control, Schedule, Console Redirection Setup, ASR Control, Console Redirection, Mode, LEDs, Power Supply, Fans, Temperature, SB (selected), SB#0 (selected), SB#1, SB#2, SB#3, IOU, DU, OPL, MMB.

FIGURE 1.117 [SB#x] Window (5)

**FUJITSU** Model: PRIMEQUEST 2800B  
Part Number: MCF3AC111  
Serial Number: XXXXXXXXXX  
Status: Normal

System | User Administration | Network Configuration | Maintenance | Logout

>System >SB >SB#0

**SB#0** Refresh Help

P1.8V_PCIEX#1	- V	1.67/ 1.93 V	1.17/ 2.17 V
P12V#0	- V	11.15/ 12.87 V	7.79/ 14.45 V
P5V	- V	4.65/ 5.38 V	3.25/ 6.02 V
P3.3V	- V	3.06/ 3.54 V	2.14/ 3.98 V
P1.35V_CPU#0	- V	1.25/ 1.45 V	0.87/ 1.63 V
P1.35V_CPU#1	- V	1.25/ 1.45 V	0.87/ 1.63 V
VCC_CPU#0	- V	0.55/ 1.45 V	0.38/ 1.63 V
VSA_CPU#0	- V	0.65/ 1.29 V	0.45/ 1.45 V
VTT_CPU#0	- V	0.92/ 1.08 V	0.64/ 1.21 V
VDDQ_DIMM#0A	- V	1.25/ 1.61 V	0.87/ 1.81 V
VDDQ_DIMM#0B	- V	1.25/ 1.61 V	0.87/ 1.81 V
P1.0V_JC#0B	- V	0.92/ 1.08 V	0.64/ 1.21 V
P1.5V_JC#0AB	- V	1.39/ 1.61 V	0.97/ 1.81 V
P1.35V_JC#0AB	- V	1.25/ 1.45 V	0.87/ 1.63 V
VCC_CPU#1	- V	0.55/ 1.45 V	0.38/ 1.63 V
VSA_CPU#1	- V	0.65/ 1.29 V	0.45/ 1.45 V
VTT_CPU#1	- V	0.92/ 1.08 V	0.64/ 1.21 V
VDDQ_DIMM#1B	- V	1.25/ 1.61 V	0.87/ 1.81 V
P1.0V_JC#1A	- V	0.92/ 1.08 V	0.64/ 1.21 V
P1.0V_JC#1B	- V	0.92/ 1.08 V	0.64/ 1.21 V

Status Clear

Left sidebar menu: System Status, System Event Log, Operation Log, System Information, System Setup, Power Control, Schedule, Console Redirection Setup, ASR Control, Console Redirection, Mode, LEDs, Power Supply, Fans, Temperature, SB (selected), SB#0 (selected), SB#1, SB#2, SB#3, IOU, DU, OPL, MMB.

FIGURE 1.118 [SB#x] Window (6)

Model: PRIMEQUEST 2800B  
Part Number: MCF3AC111  
Serial Number: [REDACTED]  
Status: Normal

System User Administration Network Configuration Maintenance Logout

>System >SB >SB#0

**SB#0**

Item	Unit	Current	Target
VTT_CPU#1	- V	0.92/ 1.08 V	0.64/ 1.21 V
VDDQ_DIMM#1B	- V	1.25/ 1.61 V	0.87/ 1.81 V
P1.0V_JC#1A	- V	0.92/ 1.08 V	0.64/ 1.21 V
P1.0V_JC#1B	- V	0.92/ 1.08 V	0.64/ 1.21 V
P1.5V_JC#1AB	- V	1.39/ 1.61 V	0.97/ 1.81 V
P1.35V_JC#1AB	- V	1.25/ 1.45 V	0.87/ 1.63 V
VDDQ_DIMM#0C	- V	1.25/ 1.61 V	0.87/ 1.81 V
VDDQ_DIMM#0D	- V	1.25/ 1.61 V	0.87/ 1.81 V
P1.0V_JC#0C	- V	0.92/ 1.08 V	0.64/ 1.21 V
P1.0V_JC#0D	- V	0.92/ 1.08 V	0.64/ 1.21 V
P1.5V_JC#0CD	- V	1.39/ 1.61 V	0.97/ 1.81 V
P1.35V_JC#0CD	- V	1.25/ 1.45 V	0.87/ 1.63 V
VDDQ_DIMM#1C	- V	1.25/ 1.61 V	0.87/ 1.81 V
VDDQ_DIMM#1D	- V	1.25/ 1.61 V	0.87/ 1.81 V
P1.0V_JC#1C	- V	0.92/ 1.08 V	0.64/ 1.21 V
P1.0V_JC#1D	- V	0.92/ 1.08 V	0.64/ 1.21 V
P1.5V_JC#1CD	- V	1.39/ 1.61 V	0.97/ 1.81 V
P1.35V_JC#1CD	- V	1.25/ 1.45 V	0.87/ 1.63 V

Refresh Help

Status Clear

The CPU and DIMM row that is not mounted is displayed in gray background.

The [Status clear] button and a message [Click the Status Clear Button to clear the status.] are not displayed for a user who does not have setting privileges.

TABLE 1.159 Display and Setting items on [SB#x] Window

Items	Description
Board Information	
Status	Displays the status of SB. <ul style="list-style-type: none"> <li>OK: No fault on the SB.</li> <li>Not-present: The SB is not mounted.</li> <li>Warning: Warning is detected by the voltage sensor on the SB.</li> <li>Degraded: Error has occurred in a component on the SB. However, the SB can be operated by disconnecting the faulty components.</li> <li>Failed: A fault has occurred in the SB, and the SB must be disconnected, or the SB has been disconnected.</li> <li>Unsupported: In case there is an SB which is not supported by the MMB.</li> </ul>
Power Status	Displays the power status of the SB. <ul style="list-style-type: none"> <li>On: On status</li> <li>Standby: Standby status</li> </ul>
Part Number	Displays the part number of the SB
Serial Number	Displays the serial number of the SB
Location LED	Indicates the display status of the Location LED. The display status consists of the following conditions. <ul style="list-style-type: none"> <li>On: The light is on</li> <li>Off: The light is off</li> </ul> On, Off and blinking of the Location LED can be controlled by clicking the respective [On], [Off], [Blink] buttons.

CPUs		
CPU#0 CPU#1	Status	Displays the status of the CPU. <ul style="list-style-type: none"><li>• OK</li><li>• Not-present</li><li>• Disabled</li><li>• Warning</li><li>• Failed</li><li>• Configuration error</li><li>• Unknown</li></ul>
	Core/Max Core	Displays Normal number of cores number/ maximum number of cores number. <ul style="list-style-type: none"><li>• Indicates the degeneracy status of the core.</li></ul> Maximum number of cores also includes the number of Disable cores.
	Model	Displays the product name of the CPU.
	Stepping	Displays the version number of the CPU.
	Part Number	Displays the part number of the CPU.
	Serial Number	Displays the serial number of the CPU.
DIMMs		
DIMM#0A0 ~ DIMM#1D5	Status	Displays the status of the DIMM. <ul style="list-style-type: none"><li>• OK</li><li>• Not-present</li><li>• Warning</li><li>• Uncorrectable error</li><li>• Disabled</li><li>• Configuration error</li><li>• Degraded Configuration</li><li>• Unknown</li></ul>
	Size	Displays the size of the DIMM. <ul style="list-style-type: none"><li>• 8GB</li><li>• 16GB</li><li>• 32GB</li><li>• 64GB</li></ul> There is no display when the DIMM status is Not-present, Not-supported, or Unknown.
	Rank	Displays number of DIMM Ranks(1 or 2 or 4). There is no display when the DIMM status is Not-present, Not-supported, or Unknown.
	Data Rate	Displays Data Rate of DIMM. <ul style="list-style-type: none"><li>• DDR3-1066, 1333, 1600</li></ul> There is no display when the DIMM status is Not-present, Not-supported, or Unknown.
	Part Number	Displays the part number of DIMM. There is no display when the DIMM status is Not-present, Not-supported, or Unknown.
	Serial Number	Displays the serial number of DIMM. There is no display when the DIMM status is Not-present, Not-supported, or Unknown.
Mezzanine		

Mezzanine#0 Mezzanine#1	Status <ul style="list-style-type: none"><li></li></ul>	Displays the status of the Mezzanine board. <ul style="list-style-type: none"><li>OK</li><li>Not-present</li><li>Failed</li></ul>
RAID Slot		
Power Status	Displays the power status of the RAID slot. <ul style="list-style-type: none"><li>On</li><li>Standby</li></ul>	
Slot Status	Displays the status of the RAID slot. <ul style="list-style-type: none"><li>OK</li><li>Warning</li><li>Not-present</li><li>Failed</li><li>Disabled</li></ul>	
Link Width	Displays Link Width of the RAID slot format. <ul style="list-style-type: none"><li>x1</li><li>x2</li><li>x4</li><li>x8</li></ul>	
Seg/Bus/Dev	Displays Segment#, Bus#, Device# of the RAID device.	
RAID Card		
BBU Status	The state of RAID BBU(Battery Backup Unit) is displayed. <ul style="list-style-type: none"><li>Online</li><li>On Battery</li><li>Charging</li><li>Discharging</li><li>Battery Low</li><li>Relearn Required</li><li>Failed</li><li>Not-present</li></ul>	
Vendor ID	Vendor ID of RAID Card is displayed. Remarks: ID uniquely allocated in manufacturer of card. For details of the ID, see the PRIMEQUEST 2000 Series Administration Manual(C122-E175EN)	
Device ID	Device ID of RAID Card is displayed. Remarks: ID uniquely allocated in device of manufacturer. For details of the ID, see the PRIMEQUEST 2000 Series Administration Manual(C122-E175EN)	
Physical Drives Count	The number of physical drives connected with RAID Card is displayed.	
Logical Drives Count	The number of logical drives composed under the control of RAID Card is displayed.	
Serial Number	The serial number of RAID Card is displayed.	
Firmware Version	The firmware version of RAID Card is displayed.	
Physical Drives		
Slot#	The slot number equipped with a physical drive is displayed.	



Status	<p>The state of a physical drive is displayed.</p> <ul style="list-style-type: none"> <li>Operational</li> <li>Available</li> <li>Failed</li> <li>Hot Spare</li> <li>Rebuilding</li> <li>SMART err</li> <li>Not-present</li> </ul>
Vendor	The vendor of a physical drive is displayed.
Model	The model name of a physical drive is displayed.
Capacity	The capacity of a physical drive is displayed.
Logical Drives	
Sensor#	The sensor number of a logical drive is displayed.
Status	The state of a logical drive is displayed.
RAID Level	The RAID level of a logical drive is displayed.
Physical Drives assignment	The slot number of a physical drive that composes a logical drive is displayed.
Missing drives Count	The number of physical drives missed to compose a logical drive at the RAID level is displayed.
RAID Action Progress	
Drive Type	<p>The drive type that the RAID action is executed is displayed.</p> <ul style="list-style-type: none"> <li>Physical : Hardware RAID</li> <li>Logical : Software RAID</li> </ul>
Slot#/Sensor#	Slot# from which the RAID action is executed is shown when Drive Type is Physical, and Sensor# from which the RAID action is executed is shown when Drive Type is Logical.
Action	<p>The RAID action under execution is displayed.</p> <ul style="list-style-type: none"> <li>Rebuilding : It is shown for a physical drive to execute the rebuild of the RAID drive.</li> <li>MDC Running : It is shown for a logical drive to execute MDC(Make Data Consistent).</li> </ul>
Progress	The progress rate of the RAID action under execution is displayed by the percentage.
Estimated time remaining (hh:mm:ss)	The remaining time that will be expected by the time the RAID action under execution is completed is displayed.
Chipset	
Chipset	<ul style="list-style-type: none"> <li>OK</li> <li>Warning</li> <li>Failed</li> </ul>
TPM	
TPM	<p>Displays the status of the TPM.</p> <ul style="list-style-type: none"> <li>OK</li> <li>Warning</li> <li>Failed</li> </ul> <p>Notes When the SB is 'without TPM mode', this field is not displayed.</p> <p>Remark The TPM is not displayed in the SB for China.</p>
BMC	



BMC	Displays the status of the BMC. <ul style="list-style-type: none"><li>• OK</li><li>• Warning</li><li>• Failed</li></ul>
FBU	
FBU	Displays the status of the FBU(Flash Backup Unit). <ul style="list-style-type: none"><li>• OK</li><li>• Failed</li></ul>
Clock	
Clock	Displays the status of the System Clock. <ul style="list-style-type: none"><li>• OK</li><li>• Failed</li></ul>
Voltage	

Sensor		Displays the Voltage sensor type. P5VL P1.1VL P1.8VL P1.5VL P1.0VL P1.8V_CPU VDDQ_DIMM#1A P1.0V_JC#0A P1.5V_PCH P1.1V P0.9V_PCIE#0 P1.8V_PCIE#0 P0.9V_PCIE#1 P1.8V_PCIE#1 P12V#0 P5V P3.3V P1.35V_CPU#0 P1.35V_CPU#1 VCC_CPU#0 VSA_CPU#0 VTT_CPU#0 VDDQ_DIMM#0A VDDQ_DIMM#0B P1.0V_JC#0B P1.5V_JC#0AB P1.35V_JC#0AB VCC_CPU#1 VSA_CPU#1 VTT_CPU#1 VDDQ_DIMM#1B P1.0V_JC#1A P1.0V_JC#1B P1.5V_JC#1AB P1.35V_JC#1AB VDDQ_DIMM#0C VDDQ_DIMM#0D P1.0V_JC#0C P1.0V_JC#0D P1.5V_JC#0CD P1.35V_JC#0CD VDDQ_DIMM#1C VDDQ_DIMM#1D P1.0V_JC#1C P1.0V_JC#1D P1.5V_JC#1CD P1.35V_JC#1CD
Voltage		Displays the current power voltage.
Threshold	Warning(Low/High)	Lower and upper limits of the warning-level voltage.  Displays “ – ”, when the threshold is not set. Displays the power voltage in the last two decimal places.
	Critical(Low/High)	Lower and upper limits of the critical-level voltage.  Displays “ – ”, when the threshold is not set. Displays the power voltage in the last two decimal places.

TABLE 1.160 [SB#x] Window Button

Buttons	Description
Status Clear	Clears the status of the SB.

## 1.7.15 [IOU] Menu

The IOU menu includes the following menus for each IOU.

- [IOU#0] ~ [IOU#3]

The menu is not displayed for the IOU which is not installed.

Since the window and the operating method are same for each menu, only one menu is described here.

### ☐ [IOU#x] Window

[IOU#x] window displays the status of the IOU installed in IOU#x slot. In addition, IOU can be set.

FIGURE 1.119 [IOU#x] Window (1)

The screenshot displays the MMB Web-UI interface for the [IOU#0] window. At the top, the Fujitsu logo is on the left, and system information (Model: PRIMEQUEST 2800B, Part Number: MCF3AC111, Serial Number: [REDACTED], Status: Normal) is on the right. A red navigation bar contains links for System, User Administration, Network Configuration, Maintenance, and Logout. Below this, a breadcrumb trail shows the path: >System >IOU >IOU#0.

A left-hand menu lists various system settings, with 'IOU' expanded to show 'IOU#0', 'IOU#1', 'IOU#2', and 'IOU#3'. The 'IOU#0' sub-menu is highlighted.

The main content area is titled 'IOU#0' and includes a 'Refresh' and 'Help' button. A note states: 'Click the Status Clear button to clear the status.'

The 'Board Information' section contains the following data:

Board Information	
Type	IOU_1GbE
Status	OK
Power Status	Standby
Part Number	CA07603-D013 A3
Serial Number	PP135200MH
Location LED	Off <input type="button" value="On"/> <input type="button" value="Off"/>

The 'On board LAN' section shows the following data:

LAN#	MAC Address
0	Unknown
1	Unknown

The 'DU connection' section shows the following data:

PCIC#	Status	Connector
0	Not-connected	

The 'PCI-Express Slots' section is currently empty. A 'Status Clear' button is located at the bottom right of the main content area.

FIGURE 1.120 [IOU#x] Window (2)

**FUJITSU** Model: PRIMEQUEST 2800B  
Part Number: MCF3AC111  
Serial Number:   
Status: Normal

System User Administration Network Configuration Maintenance Logout  
>System >IOU >IOU#0

☐ System Status  
☐ System Event Log  
☐ Operation Log  
☐ System Information  
☐ Firmware Information  
☐ System Setup  
☐ Power Control  
☐ Schedule  
☐ Console Redirection Setup  
☐ ASR Control  
☐ Console Redirection  
☐ Mode  
☐ LEDs  
☐ Power Supply  
☐ Fans  
☐ Temperature  
☐ SB  
☒ IOU  
    ☐ IOU#0  
    ☐ IOU#1  
    ☐ IOU#2  
    ☐ IOU#3  
☐ DU  
☐ OPL  
☐ MMB

**IOU#0** Refresh Help

**PCI-Express Slots**

PCI#	Power Status	Slot Status	Link Width	Seg/Bus/Dev	Vendor ID	Device ID
0	Standby	OK	Unknown	Unknown	-	-
1	Standby	OK	Unknown	Unknown	-	-
2	Standby	Not-present				
3	Standby	Not-present				

**PCIeSW**

PCIeSW	Status
PCIeSW#0	OK
PCIeSW#1	OK

**Voltage**

Sensor	Voltage	Threshold	
		Warning(Low/High)	Critical(Low/High)
P1.8VL	1.81 V	1.67/ 1.93 V	1.16/ 2.17 V
P1.0VL	0.99 V	0.92/ 1.08 V	0.65/ 1.20 V
P3.3V	- V	3.06/ 3.54 V	2.14/ 3.98 V
P1.8V_PCIEX#0	- V	1.67/ 1.93 V	1.16/ 2.17 V
P1.8V_PCIEX#1	- V	1.67/ 1.93 V	1.16/ 2.17 V
P0.9V_PCIEX#0	- V	0.83/ 0.97 V	0.58/ 1.09 V
P0.9V_PCIEX#1	- V	0.83/ 0.97 V	0.58/ 1.09 V

Status Clear

FIGURE 1.121 [IOU#x] Window (3)

**FUJITSU** Model: PRIMEQUEST 2800B  
Part Number: MCF3AC111  
Serial Number:   
Status: Normal

System User Administration Network Configuration Maintenance Logout  
>System >IOU >IOU#0

☐ System Status  
☐ System Event Log  
☐ Operation Log  
☐ System Information  
☐ Firmware Information  
☐ System Setup  
☐ Power Control  
☐ Schedule  
☐ Console Redirection Setup  
☐ ASR Control  
☐ Console Redirection  
☐ Mode  
☐ LEDs  
☐ Power Supply  
☐ Fans  
☐ Temperature  
☐ SB  
☒ IOU  
    ☐ IOU#0  
    ☐ IOU#1  
    ☐ IOU#2  
    ☐ IOU#3  
☐ DU  
☐ OPL  
☐ MMB

**IOU#0** Refresh Help

**PCI-Express Slots**

PCI#	Power Status	Slot Status	Link Width	Seg/Bus/Dev	Vendor ID	Device ID
0	Standby	OK	Unknown	Unknown	-	-
1	Standby	OK	Unknown	Unknown	-	-
2	Standby	Not-present				
3	Standby	Not-present				

**PCIeSW**

PCIeSW	Status
PCIeSW#0	OK
PCIeSW#1	OK

**Voltage**

Sensor	Voltage	Threshold	
		Warning(Low/High)	Critical(Low/High)
P1.8VL	1.81 V	1.67/ 1.93 V	1.16/ 2.17 V
P1.0VL	0.99 V	0.92/ 1.08 V	0.65/ 1.20 V
P3.3V	- V	3.06/ 3.54 V	2.14/ 3.98 V
P1.8V_PCIEX#0	- V	1.67/ 1.93 V	1.16/ 2.17 V
P1.8V_PCIEX#1	- V	1.67/ 1.93 V	1.16/ 2.17 V
P0.9V_PCIEX#0	- V	0.83/ 0.97 V	0.58/ 1.09 V
P0.9V_PCIEX#1	- V	0.83/ 0.97 V	0.58/ 1.09 V

Status Clear

TABLE 1.161 Display Items and Setting Items in [IOU#x] Window

Items	Description
Board Information	
Type	Displays types of IOUs. <ul style="list-style-type: none"> <li>• IOU_10GbE</li> <li>• IOU_1GbE</li> </ul>
Status	Displays status of the IOU <ul style="list-style-type: none"> <li>• OK</li> <li>• Not-present</li> <li>• Warning</li> <li>• Degraded</li> <li>• Failed</li> </ul>
Power Status	Displays the power status of the IOU. <ul style="list-style-type: none"> <li>• On</li> <li>• Standby</li> </ul>
Part Number	Displays the part number of the IOU.
Serial Number	Displays the serial number of the IOU.
Location LED	Shows the display status of the Location LED. Following are the display status. <ul style="list-style-type: none"> <li>• On: During ON</li> <li>• Off: During OFF</li> </ul> On/Off of the Location LED can be controlled by clicking [On], [Off] button.
On board LAN	
LAN	Displays the LAN number.
MAC Address	Displays the MAC Address for GbE that is being installed on the IOU. Displays "Unknown" when MAC Address is not clear.
DU connection	
PCIC#	Displays PCIC# for DU connection on the IOU.
Status	Displays the status of connection with the DU. <ul style="list-style-type: none"> <li>• OK</li> <li>• Not-connected</li> <li>• Incorrect connection</li> </ul>
Connector	Displays the destination Cconnector number of the DU. When not connected, background color is displayed in gray.
PCI-Express Slots	
PCIC#	Displays the number of the PCI_Express slot.
Power Status	Displays the power status of the IOU. <ul style="list-style-type: none"> <li>• On</li> <li>• Standby</li> </ul>
Slot Status	Displays the status of the PCI_Express slot. <ul style="list-style-type: none"> <li>• OK</li> <li>• Not-present</li> <li>• Failed</li> <li>• Disabled</li> </ul>
Link Width	Displays Link Width of PCI_Express slot format. <ul style="list-style-type: none"> <li>• x1</li> <li>• x2</li> <li>• x4</li> <li>• x8</li> </ul>
Seg/Bus/Dev	Displays Segment#, Bus#, Device# of PCI Device.
Vendor ID	Displays the Vender ID of the PCI Card. Remarks: ID uniquely allocated in manufacturer of card. For details of the ID, see the PRIMEQUEST 2000 Series Administration

Items	Description	
	Manual(C122-E175EN)	
Device ID	Displays the Device ID of the PCI Card. Remarks: ID uniquely allocated in device of manufacturer. For details of the ID, see the PRIMEQUEST 2000 Series Administration Manual(C122-E175EN)	
PCleSW		
PCleSW	Displays the number of PCleSW.	
Status	Displays the status of PCleSW. • OK • Warning • Failed	
PCleSW#1	Same as PCleSW#0	
Voltage		
Voltage		
Sensor	Displays the Voltage sensor type. P1.8VL(*1) P1.0VL(*1) P2.5VL(*2) P1.2VL(*2) P0.8VL(*2) P0.67VL(*2) P3.3V(*3) P1.8V_PCIEX#0(*1) P1.8V_PCIEX#1(*1) P1.8V(*2) P0.9V_PCIEX#0(*3) P0.9V_PCIEX#1(*3)  *1: IOUL,*2: IOUF,*3: IOUL/IOUF commonness	
Voltage	Displays the current power voltage.	
Threshold	Warning (Low/High)	Lower and upper limits of the warning-level voltage.  Displays “ – ”, when the threshold is not set. Displays the power voltage in the last two decimal places.
	Critical (Low/High)	Lower and upper limits of the critical-level voltage.  Displays “ – ”, when the threshold is not set. Displays the power voltage in the last two decimal places.

TABLE 1.162 Button of [IOB#x] Screen

Buttons	Description
Status Clear	Clears the error status of IOU#x

## 1.7.16 [DU] Menu

As for the display, the operation is the same as the PRIMEQUEST 2400E/2800E model. Refer to chapter 1.2.15.

### 1.7.17 [OPL] Window

As for the display, the operation is the same as the PRIMEQUEST 2400E/2800E model. Refer to chapter 1.2.16.

### 1.7.18 [MMB] Window

In [MMB] Window, information related to MMB can be displayed and the Location LEDs can be set.

FIGURE 1.122 [MMB#x] Window(1)

The screenshot displays the Fujitsu MMB Web-UI interface. At the top, the Fujitsu logo is on the left, and system information is on the right: Model: PRIMEQUEST 2800B, Part Number: MCF3AC111, Serial Number: [REDACTED], and Status: Normal. Below this is a navigation bar with tabs: System, User Administration, Network Configuration, and Maintenance. The 'System' tab is selected, and the breadcrumb path is '>System >MMB'. A left sidebar contains a tree view of system settings, with 'MMB' highlighted in green. The main content area is titled 'MMB' and includes a 'Help' button. Below the title, a message states: 'Click the Apply Button to apply all changes.' There are two tables. The first table contains MMB configuration details: Status (OK), Part Number (CA07603-D053 A3), Serial Number (PP13440495), MAC Address (2C:D4:44:F0:8F:78), User port (2C:D4:44:F0:16:F2), Maintenance port (2C:D4:44:F0:16:F2), Firmware Version (1.21), Location LED (Off, On, Off), and a 'Reset MMB' section with a checkbox and warning text. The second table, titled 'Voltage', shows sensor data: Sensor, Voltage, and Threshold (Warning/Low/High, Critical/Low/High). At the bottom right of the voltage table are 'Apply' and 'Cancel' buttons.

Model:		PRIMEQUEST 2800B	
Part Number:		MCF3AC111	
Serial Number:		[REDACTED]	
Status:		Normal	

System | User Administration | Network Configuration | Maintenance | Logout

>System >MMB

**MMB**

Click the Apply Button to apply all changes.

Status	OK		
Part Number	CA07603-D053 A3		
Serial Number	PP13440495		
MAC Address	User port	2C:D4:44:F0:8F:78	
	Maintenance port	2C:D4:44:F0:16:F2	
Firmware Version	1.21		
Location LED	Off <input type="radio"/> On <input type="radio"/> Off <input type="radio"/>		
Reset MMB	<input type="checkbox"/> Reset the MMB All existing network connections will be lost. You will need to login again.		

**Voltage**

Sensor	Voltage	Threshold	
		Warning(Low/High)	Critical(Low/High)
P3.3VL	3.34 V	3.16/ 3.64 V	2.20/ 4.10 V
P1.5VL	1.49 V	1.39/ 1.61 V	0.97/ 1.81 V
P1.5VL_CPLD	1.49 V	1.39/ 1.61 V	0.98/ 1.81 V
P1.2VL	1.19 V	1.11/ 1.29 V	0.77/ 1.45 V

Apply Cancel

FIGURE 1.123 [MMB#x] Window(2)

Model: PRIMEQUEST 2800B  
Part Number: MCF3AC111  
Serial Number: 4444444444  
Status: Normal

System User Administration Network Configuration Maintenance Logout

>System >MMB

System Status  
System Event Log  
Operation Log  
System Information  
Firmware Information  
System Setup  
Power Control  
Schedule  
Console Redirection Setup  
ASR Control  
Console Redirection  
Mode  
LEDs  
Power Supply  
Fans  
Temperature  
SB  
IOU  
DU  
OPL  
MMB

### MMB

Serial Number PP13440495

MAC Address	User port	2C:D4:44:F0:8F:78
	Maintenance port	2C:D4:44:F0:16:F2

Firmware Version 1.21

Location LED Off

Reset MMB ☐ Reset the MMB  
All existing network connections will be lost.  
You will need to login again.

### Voltage

Sensor	Voltage	Threshold	
		Warning(Low/High)	Critical(Low/High)
P3.3VL	3.34 V	3.16/ 3.64 V	2.20/ 4.10 V
P1.5VL	1.49 V	1.39/ 1.61 V	0.97/ 1.81 V
P1.5VL CPLD	1.49 V	1.39/ 1.61 V	0.98/ 1.81 V
P1.2VL	1.19 V	1.11/ 1.29 V	0.77/ 1.45 V
P1.0VL	0.99 V	0.92/ 1.08 V	0.64/ 1.21 V
P0.75VL	0.74 V	0.69/ 0.81 V	0.48/ 0.91 V

Apply Cancel

TABLE 1.163 Display of [MMB] Window / setting items

Items		Description
Board Information		
Status		Displays the status of the MMB. <ul style="list-style-type: none"> <li>OK</li> <li>Not-present</li> <li>Warning</li> <li>Degraded</li> <li>Failed</li> </ul>
Part Number		Displays part number of the MMB.
Serial Number		Displays the serial number of the MMB.
MAC address	User port	Displays MAC address of the MMB management port. 00:00:00:00:00:00
	Maintenance Port	Displays MAC address of the MMB port. 00:00:00:00:00:00
Firmware Version		Firmware Version
Location LED		Displays the status of the Location LED. The following are the various display status. <ul style="list-style-type: none"> <li>On: During power on.</li> <li>Off: During power off</li> </ul> On/ Off of the Location LED can be controlled by clicking [On], [Off] buttons.
Reset MMB		Resets the MMB if this check box is checked.
Voltage		Displays the current power voltage.
Threshold	Warning (Low/High)	Lower and upper limits of the warning-level voltage.  Displays “ – ”, when the threshold is not set. Displays the power voltage in the last two decimal places.
	Critical (Low/High)	Lower and upper limits of the critical-level voltage.



Items		Description
		Displays “ – ”, when the threshold is not set. Displays the power voltage in the last two decimal places.

TABLE 1.164 [MMB#x] Window button

Buttons	Description
Apply	Click the [Apply] button to set the specified control information.
Cancel	Click the [Cancel] button to restore the original information and not set the specified information.

# CHAPTER 2 MMB CLI (Command Line Interface) Operations

This chapter describes the CLI (command line interface) provided by the MMB.

## 2.1 Basic Operations with the CLI

You can access the CLI in the following two ways:

- 
- Access via the serial port on the MMB
- Access via the management LAN of the MMB from a remote PC

### Remarks

Similar to the GUI, the CLI also enables up to 16 users to log in to the CLI concurrently.

### 2.1.1 Access to the CLI via the serial interface

You can access the CLI of the MMB via the serial interface by using the following procedure.

1. Connect your terminal (e.g., laptop PC) to the MMB with an RS-232C crossover cable.
2. Start the terminal software (e.g., Windows HyperTerminal) on the terminal. Then, configure the terminal software as follows.

TABLE 2.1 Terminal software setting values

Parameter	Value
Bits/second	19200
Data bits	8
Parity	None
Stop bits	1
Flow control	None
Emulation	VT100

3. The login prompt appears. Enter your user name and password to log in.

### 2.1.2 Access via the management LAN interface

You can access the CLI of the MMB via the management LAN interface by using the following procedure.

1. Connect a remote PC to the MMB with a straight LAN cable.
2. Start the telnet or SSH client on the remote PC. Establish a connection between the remote PC and the MMB by specifying the IP address (IPv4 or IPv6) of the MMB and the telnet port number or SSH port number.
3. Enter the account and password to log in.

### Remarks

The MMB provides connection features that work only with the SSH V2 protocol.

This means you need to be running SSH V2-compatible terminal software to connect the MMB.

## 2.1.3 CLI command list

This section describes the functions of the CLI commands.

- Setting commands
- Display commands
- Update commands
- Other commands

The following tables list the account privileges required for individual commands.

"Permitted" in an account privilege column indicates the command can be used with those account privileges.

- [TABLE 2.2 MMB CLI commands \(Administrator\)](#)
- [TABLE 2.3 MMB CLI commands \(Operator\)](#)
- [TABLE 2.4 MMB CLI commands \(Partition Operator\)](#)
- [TABLE 2.5 MMB CLI commands \(User\)](#)
- [TABLE 2.6 MMB CLI commands \(CE\)](#)

TABLE 2.2 MMB CLI commands (Administrator)

Command	Administrator	Outline
Power control		
power off	Permitted	Turns the power off.
power on	Permitted	Turns the power on.
Partition control		
sadump	Permitted	sadump instruction
reset	Permitted	Hard Reset instruction
nmi	Permitted	NMI interrupt instruction
Partition connection		
console	Permitted	Text Console connection to partition
Partition creation		
add partition	Permitted	Adds a partition component.
remove partition	Permitted	Removes a partition component.
show partition configuration	Permitted	Displays the partition configuration.
set partition home	Permitted	Sets the Home SB.
show partition home	Permitted	Displays the Home SB.
set partition memory_operation_mode	Permitted	Sets Memory operation mode.
show partition memory_operation_mode	Permitted	Displays Memory operation mode.
set partition memory_mirror_ras_mode	Permitted	Sets Memory operation at mirror mode.
show partition memory_mirror_ras_mode	Permitted	Displays Memory operation at mirror mode.
set partition pci_address_mode	Permitted	Sets PCI bus number allocation mod.
show partition pci_address_mode	Permitted	Displays PCI bus number allocation mod.
set partition lan_device_mode	Permitted	Sets LAN device mode.
show partition lan_device_mode	Permitted	Displays LAN device mode.
show partition mirror_mode	Permitted	Displays the Mirror mode setting.
set partition name	Permitted	Sets the partition name.
show partition name	Permitted	Displays the partition name.
Time-related		
set date	Permitted	Sets the date and time.
show date	Permitted	Displays the date and time.
set timezone	Permitted	Sets the time zone.
show timezone	Permitted	Displays the time zone.

Command	Administrator	Outline
Network-related		
set ip	Permitted	Sets the management LAN address.
set ipv6	Permitted	Sets the IPv6 management LAN address.
show ip	Permitted	Displays the management LAN address.
show ipv6	Permitted	Displays the IPv6 management LAN address.
set hostname	Permitted	Sets the MMB host name.
show hostname	Permitted	Displays the MMB host name.
set gateway	Permitted	Sets the gateway address.
set gateway_ipv6	Permitted	Sets the IPv6 gateway address.
show gateway	Permitted	Displays the gateway address.
show network	Permitted	Displays the management LAN interface.
show gateway_ipv6	Permitted	Displays the IPv6 gateway address.
set http	Permitted	Sets whether to enable http service.
set https	Permitted	Sets whether to enable https service.
set ssh	Permitted	Sets whether to enable ssh service.
set telnet	Permitted	Sets whether to enable telnet service.
show http	Permitted	Displays the http service enabling setting.
show https	Permitted	Displays the https service enabling setting.
show ssh	Permitted	Displays the ssh service enabling setting.
show telnet	Permitted	Displays the telnet service enabling setting.
set http_port	Permitted	Sets the http port number.
set https_port	Permitted	Sets the https port number.
set ssh_port	Permitted	Sets the ssh port number.
set telnet_port	Permitted	Sets the telnet port number.
show http_port	Permitted	Displays the http port number.
show https_port	Permitted	Displays the https port number.
show ssh_port	Permitted	Displays the ssh port number.
show telnet_port	Permitted	Displays the telnet port number.
clear access_control	Permitted	Clears the access control setting.
show access_control	Permitted	Displays the access control setting.
clear ssh_key		Clears the SSH public key.
download ssh_key		Downloads the SSH public key.
ping	Permitted	Pings the target.
show ntpq	Permitted	NTP inquiry (ntpq – p executed)
Account management		
passwd	Permitted	Changes a password.
who	Permitted	Displays the login user.
Firmware update		
update ALL	Permitted	Batch-updates the firmware (new).
MMB configuration and other		
set active_mmb	Permitted	Sets the active MMB.
show active_mmb	Permitted	Displays the active MMB.
exit	Permitted	Logs out from the MMB.
help	Permitted	Help information
Command termination code display		

Command	Administrator	Outline
show exit_code	Permitted	Displays the termination code for the last command executed.
Firmware revision status/version check		
show update_status	Permitted	Displays the batch firmware update progress.
Network survey commands		
netck traceroute	Permitted	Displays a list of network routes.
netck arptbl	Permitted	Displays the physical Ethernet address.
netck arping	Permitted	Displays the physical Ethernet address.
netck ifconfig	Permitted	Displays the network environment setup status.
netck stat	Permitted	Displays a list of port numbers being used.
REMCS-related commands		
set maintenance_ip	Permitted	Sets the REMCS network.
show maintenance_ip	Permitted	Displays the REMCS network setting.
DR-related		
hotadd partition	Permitted	Dynamic Partiiton HotAdd.
hotremove partition	Permitted	Dynamic Reconfiguration HotRemove.
set partition dynamic_partitioning	Permitted	Sets DR state of partition.
show partition dynamic_partitioning	Permitted	Displays DR state of partition.

TABLE 2.3 MMB CLI commands (Operator)

Command	Operator	Outline
Power control		
power off	Permitted	Turns the power off.
power on	Permitted	Turns the power on.
Partition control		
sadump	Permitted	sadump instruction
reset	Permitted	Hard Reset instruction
nmi	Permitted	NMI interrupt instruction
Partition connection		
console	Permitted	Text Console connection to partition
Partition creation		
add partition		Adds a partition component.
remove partition		Removes a partition component.
show partition configuration	Permitted	Displays the partition configuration.
set partition home		Sets the Home SB.
show partition home	Permitted	Displays the Home SB.
set partition memory_operation_mode	Permitted	Sets Memory operation mode.
show partition memory_operation_mode	Permitted	Displays Memory operation mode.
set partition memory_mirror_ras_mode	Permitted	Sets Memory operation at mirror mode.
show partition memory_mirror_ras_mode	Permitted	Displays Memory operation at mirror mode.
set partition pci_address_mode	Permitted	Sets PCI bus number allocation mod.
show partition pci_address_mode	Permitted	Displays PCI bus number allocation mod.
set partition lan_device_mode	Permitted	Sets LAN device mode.
show partition lan_device_mode	Permitted	Displays LAN device mode.
show partition mirror_mode	Permitted	Displays the Mirror mode setting.
set partition name		Sets the partition name.

Command	Operator	Outline
show partition name	Permitted	Displays the partition name.
Time-related		
set date		Sets the date and time.
show date	Permitted	Displays the date and time.
set timezone		Sets the time zone.
show timezone	Permitted	Displays the time zone.
Network-related		
set ip		Sets the management LAN address.
set ipv6		Sets the IPv6 management LAN address.
show ip	Permitted	Displays the management LAN address.
show ipv6	Permitted	Displays the IPv6 management LAN address.
set hostname		Sets the MMB host name.
show hostname	Permitted	Displays the MMB host name.
set gateway		Sets the gateway address.
set gateway_ipv6		Sets the IPv6 gateway address.
show gateway	Permitted	Displays the gateway address.
show network	Permitted	Displays the management LAN interface.
show gateway_ipv6	Permitted	Displays the IPv6 gateway address.
set http		Sets whether to enable http service.
set https		Sets whether to enable https service.
set ssh		Sets whether to enable ssh service.
set telnet		Sets whether to enable telnet service.
show http	Permitted	Displays the http service enabling setting.
show https	Permitted	Displays the https service enabling setting.
show ssh	Permitted	Displays the ssh service enabling setting.
show telnet	Permitted	Displays the telnet service enabling setting.
set http_port		Sets the http port number.
set https_port		Sets the https port number.
set ssh_port		Sets the ssh port number.
set telnet_port		Sets the telnet port number.
show http_port	Permitted	Displays the http port number.
show https_port	Permitted	Displays the https port number.
show ssh_port	Permitted	Displays the ssh port number.
show telnet_port	Permitted	Displays the telnet port number.
clear access_control		Clears the access control setting.
show access_control		Displays the access control setting.
clear ssh_key		Clears the SSH public key.
download ssh_key		Downloads the SSH public key.
ping	Permitted	Pings the target.
show ntpq	Permitted	NTP inquiry (ntpq – p executed)
Account management		
passwd	Permitted	Changes a password.
who	Permitted	Displays the login user.
Firmware update		
update ALL		Batch-updates the firmware (new).

Command	Operator	Outline
MMB configuration and other		
set active_mmb		Sets the active MMB.
show active_mmb	Permitted	Displays the active MMB.
exit	Permitted	Logs out from the MMB.
help	Permitted	Help information
Command termination code display		
show exit_code	Permitted	Displays the termination code for the last command executed.
Firmware revision status/version check		
show update_status		Displays the batch firmware update progress.
Network survey commands		
netck traceroute	Permitted	Displays a list of network routes.
netck arptbl	Permitted	Displays the physical Ethernet address.
netck arping	Permitted	Displays the physical Ethernet address.
netck ifconfig	Permitted	Displays the network environment setup status.
netck stat	Permitted	Displays a list of port numbers being used.
REMCS-related commands		
set maintenance_ip		Sets the REMCS network.
show maintenance_ip	Permitted	Displays the REMCS network setting.
Thotadd partition		Dynamic Partiiton HotAdd.
hotremove partition		Dynamic Reconfiguration HotRemove.
set partition dynamic_partitioning	Permitted	Sets DR state of partition.
show partition dynamic_partitioning	Permitted	Displays DR state of partition.

TABLE 2.4 MMB CLI commands (Partition Operator)

Command	Partition Operator (*) (Same partition)	Partition Operator (*) (Other partition)	Outline
Power control			
power off	Permitted		Turns the power off.
power on	Permitted		Turns the power on.
Partition control			
sadump	Permitted		sadump instruction
reset	Permitted		Hard Reset instruction
nmi	Permitted		NMI interrupt instruction
Partition connection			
console	Permitted		Text Console connection to partition
Partition creation			
add partition			Adds a partition component.
remove partition			Removes a partition component.
show partition configuration	Permitted	Permitted	Displays the partition configuration.
set partition home			Sets the Home SB.
show partition home	Permitted	Permitted	Displays the Home SB.
set partition memory_operation_mode	Permitted		Sets Memory operation mode.
show partition memory_operation_mode	Permitted	Permitted	Displays Memory operation mode.
set partition memory_mirror_ras_mode	Permitted		Sets Memory operation at mirror mod

Command	Partition Operator (*) (Same partition)	Partition Operator (*) (Other partition)	Outline
			e.
show partition memory_mirror_ras_mode	Permitted	Permitted	Displays Memory operation at mirror mode.
set partition pci_address_mode	Permitted		Sets PCI bus number allocation mod.
show partition pci_address_mode	Permitted	Permitted	Displays PCI bus number allocation mod.
set partition lan_device_mode	Permitted		Sets LAN device mode.
show partition lan_device_mode	Permitted	Permitted	Displays LAN device mode.
show partition mirror_mode	Permitted	Permitted	Displays the Mirror mode setting.
set partition name			Sets the partition name.
show partition name	Permitted	Permitted	Displays the partition name.
Time-related			
set date			Sets the date and time.
show date	Permitted	Permitted	Displays the date and time.
set timezone			Sets the time zone.
show timezone	Permitted	Permitted	Displays the time zone.
Network-related			
set ip			Sets the management LAN address.
set ipv6			Sets the IPv6 management LAN address.
show ip	Permitted	Permitted	Displays the management LAN address.
show ipv6	Permitted	Permitted	Displays the IPv6 management LAN address.
set hostname			Sets the MMB host name.
show hostname	Permitted	Permitted	Displays the MMB host name.
set gateway			Sets the gateway address.
set gateway_ipv6			Sets the IPv6 gateway address.
show gateway	Permitted	Permitted	Displays the gateway address.
show network	Permitted	Permitted	Displays the management LAN interface.
show gateway_ipv6	Permitted	Permitted	Displays the IPv6 gateway address.
set http			Sets whether to enable http service.
set https			Sets whether to enable https service.
set ssh			Sets whether to enable ssh service.
set telnet			Sets whether to enable telnet service.
show http	Permitted	Permitted	Displays the http service enabling setting.
show https	Permitted	Permitted	Displays the https service enabling setting.
show ssh	Permitted	Permitted	Displays the ssh service enabling setting.
show telnet	Permitted	Permitted	Displays the telnet service enabling setting.
set http_port			Sets the http port number.
set https_port			Sets the https port number.
set ssh_port			Sets the ssh port number.
set telnet_port			Sets the telnet port number.
show http_port	Permitted	Permitted	Displays the http port number.



Command	Partition Operator (*) (Same partition)	Partition Operator (*) (Other partition)	Outline
show https_port	Permitted	Permitted	Displays the https port number.
show ssh_port	Permitted	Permitted	Displays the ssh port number.
show telnet_port	Permitted	Permitted	Displays the telnet port number.
clear access_control			Clears the access control setting.
show access_control			Displays the access control setting.
clear ssh_key			Clears the SSH public key.
download ssh_key			Downloads the SSH public key.
ping	Permitted	Permitted	Pings the target.
show ntpq	Permitted	Permitted	NTP inquiry (ntpq – p executed)
Account management			
passwd	Permitted	Permitted	Changes a password.
who	Permitted	Permitted	Displays the login user.
Firmware update			
update ALL			Batch-updates the firmware (new).
MMB configuration and other			
set active_mmb			Sets the active MMB.
show active_mmb	Permitted	Permitted	Displays the active MMB.
exit	Permitted	Permitted	Logs out from the MMB.
help	Permitted	Permitted	Help information
Command termination code display			
show exit_code	Permitted	Permitted	Displays the termination code for the last command executed.
Firmware revision status/version check			
show update_status			Displays the batch firmware update progress.
Network survey commands			
netck traceroute	Permitted	Permitted	Displays a list of network routes.
netck arptbl	Permitted	Permitted	Displays the physical Ethernet address.
netck arping	Permitted	Permitted	Displays the physical Ethernet address.
netck ifconfig	Permitted	Permitted	Displays the network environment setup status.
netck stat	Permitted	Permitted	Displays a list of port numbers being used.
REMCS-related commands			
set maintenance_ip			Sets the REMCS network.
show maintenance_ip	Permitted	Permitted	Displays the REMCS network setting.
DR-related			
hotadd partition			Dynamic Partiiton HotAdd.
hotremove partition			Dynamic Reconfiguration HotRemove.
set partition dynamic_partitioning	Permitted		Sets DR state of partition.
show partition dynamic_partitioning	Permitted		Displays DR state of partition.

TABLE 2.5 MMB CLI commands (User)

Command	User	Outline
Power control		
power off		Turns the power off.
power on		Turns the power on.
Partition control		
sadump		sadump instruction
reset		Hard Reset instruction
nmi		NMI interrupt instruction
Partition connection		
console		Text Console connection to partition
Partition creation		
add partition		Adds a partition component.
remove partition		Removes a partition component.
show partition configuration	Permitted	Displays the partition configuration.
set partition home		Sets the Home SB.
show partition home	Permitted	Displays the Home SB.
set partition memory_operation_mode		Sets Memory operation mode.
show partition memory_operation_mode	Permitted	Displays Memory operation mode.
set partition memory_mirror_ras_mode		Sets Memory operation at mirror mode.
show partition memory_mirror_ras_mode	Permitted	Displays Memory operation at mirror mode.
set partition pci_address_mode		Sets PCI bus number allocation mod.
show partition pci_address_mode	Permitted	Displays PCI bus number allocation mod.
set partition lan_device_mode		Sets LAN device mode.
show partition lan_device_mode	Permitted	Displays LAN device mode.
show partition mirror_mode	Permitted	Displays the Mirror mode setting.
set partition name		Sets the partition name.
show partition name	Permitted	Displays the partition name.
Time-related		
set date		Sets the date and time.
show date	Permitted	Displays the date and time.
set timezone		Sets the time zone.
show timezone	Permitted	Displays the time zone.
Network-related		
set ip		Sets the management LAN address.
set ipv6		Sets the IPv6 management LAN address.
show ip	Permitted	Displays the management LAN address.
show ipv6	Permitted	Displays the IPv6 management LAN address.
set hostname		Sets the MMB host name.
show hostname	Permitted	Displays the MMB host name.
set gateway		Sets the gateway address.
set gateway_ipv6		Sets the IPv6 gateway address.
show gateway	Permitted	Displays the gateway address.
show network	Permitted	Displays the management LAN interface.
show gateway_ipv6	Permitted	Displays the IPv6 gateway address.
set http		Sets whether to enable http service.

Command	User	Outline
set https		Sets whether to enable https service.
set ssh		Sets whether to enable ssh service.
set telnet		Sets whether to enable telnet service.
show http	Permitted	Displays the http service enabling setting.
show https	Permitted	Displays the https service enabling setting.
show ssh	Permitted	Displays the ssh service enabling setting.
show telnet	Permitted	Displays the telnet service enabling setting.
set http_port		Sets the http port number.
set https_port		Sets the https port number.
set ssh_port		Sets the ssh port number.
set telnet_port		Sets the telnet port number.
show http_port	Permitted	Displays the http port number.
show https_port	Permitted	Displays the https port number.
show ssh_port	Permitted	Displays the ssh port number.
show telnet_port	Permitted	Displays the telnet port number.
clear access_control		Clears the access control setting.
show access_control		Displays the access control setting.
clear ssh_key	Permitted	Clears the SSH public key.
download ssh_key	Permitted	Downloads the SSH public key.
ping	Permitted	Pings the target.
show ntpq	Permitted	NTP inquiry (ntpq – p executed)
Account management		
passwd	Permitted	Changes a password.
who	Permitted	Displays the login user.
Firmware update		
update ALL		Batch-updates the firmware (new).
MMB configuration and other		
set active_mmb		Sets the active MMB.
show active_mmb	Permitted	Displays the active MMB.
exit	Permitted	Logs out from the MMB.
help	Permitted	Help information
Command termination code display		
show exit_code	Permitted	Displays the termination code for the last command executed.
Firmware revision status/version check		
show update_status		Displays the batch firmware update progress.
Network survey commands		
netck traceroute	Permitted	Displays a list of network routes.
netck arptbl	Permitted	Displays the physical Ethernet address.
netck arpinfo	Permitted	Displays the physical Ethernet address.
netck ifconfig	Permitted	Displays the network environment setup status.
netck stat	Permitted	Displays a list of port numbers being used.
REMCS-related commands		
set maintenance_ip		Sets the REMCS network.
show maintenance_ip	Permitted	Displays the REMCS network setting.
DR-related		

Command	User	Outline
hotadd partition		Dynamic Partiiton HotAdd.
hotremove partition		Dynamic Reconfiguration HotRemove.
set partition dynamic_partitioning		Sets DR state of partition.
show partition dynamic_partitioning	Permitted	Displays DR state of partition.

TABLE 2.6 MMB CLI commands (CE)

Command	CE	Outline
Power control		
power off		Turns the power off.
power on		Turns the power on.
Partition control		
sadump		sadump instruction
reset		Hard Reset instruction
nmi		NMI interrupt instruction
Partition connection		
console		Text Console connection to partition
Partition creation		
add partition		Adds a partition component.
remove partition		Removes a partition component.
show partition configuration	Permitted	Displays the partition configuration.
set partition home		Sets the Home SB.
show partition home	Permitted	Displays the Home SB.
set partition memory_operation_mode		Sets Memory operation mode.
show partition memory_operation_mode	Permitted	Displays Memory operation mode.
set partition memory_mirror_ras_mode		Sets Memory operation at mirror mode.
show partition memory_mirror_ras_mode	Permitted	Displays Memory operation at mirror mode.
set partition pci_address_mode		Sets PCI bus number allocation mod.
show partition pci_address_mode	Permitted	Displays PCI bus number allocation mod.
set partition lan_device_mode		Sets LAN device mode.
show partition lan_device_mode	Permitted	Displays LAN device mode.
show partition mirror_mode	Permitted	Displays the Mirror mode setting.
set partition name		Sets the partition name.
show partition name	Permitted	Displays the partition name.
Time-related		
set date		Sets the date and time.
show date	Permitted	Displays the date and time.
set timezone		Sets the time zone.
show timezone	Permitted	Displays the time zone.
Network-related		
set ip		Sets the management LAN address.
set ipv6		Sets the IPv6 management LAN address.
show ip	Permitted	Displays the management LAN address.
show ipv6	Permitted	Displays the IPv6 management LAN address.
set hostname		Sets the MMB host name.
show hostname	Permitted	Displays the MMB host name.

Command	CE	Outline
set gateway		Sets the gateway address.
set gateway_ipv6		Sets the IPv6 gateway address.
show gateway	Permitted	Displays the gateway address.
show network	Permitted	Displays the management LAN interface.
show gateway_ipv6	Permitted	Displays the IPv6 gateway address.
set http		Sets whether to enable http service.
set https		Sets whether to enable https service.
set ssh		Sets whether to enable ssh service.
set telnet		Sets whether to enable telnet service.
show http	Permitted	Displays the http service enabling setting.
show https	Permitted	Displays the https service enabling setting.
show ssh	Permitted	Displays the ssh service enabling setting.
show telnet	Permitted	Displays the telnet service enabling setting.
set http_port		Sets the http port number.
set https_port		Sets the https port number.
set ssh_port		Sets the ssh port number.
set telnet_port		Sets the telnet port number.
show http_port	Permitted	Displays the http port number.
show https_port	Permitted	Displays the https port number.
show ssh_port	Permitted	Displays the ssh port number.
show telnet_port	Permitted	Displays the telnet port number.
clear access_control		Clears the access control setting.
show access_control		Displays the access control setting.
clear ssh_key	Permitted	Clears the SSH public key.
download ssh_key	Permitted	Downloads the SSH public key.
ping	Permitted	Pings the target.
show ntpq	Permitted	NTP inquiry (ntpq – p executed)
Account management		
passwd	Permitted	Changes a password.
who	Permitted	Displays the login user.
Firmware update		
update ALL		Batch-updates the firmware (new).
MMB configuration and other		
set active_mmb		Sets the active MMB.
show active_mmb	Permitted	Displays the active MMB.
exit	Permitted	Logs out from the MMB.
help	Permitted	Help information
Command termination code display		
show exit_code	Permitted	Displays the termination code for the last command executed.
Firmware revision status/version check		
show update_status		Displays the batch firmware update progress.
Network survey commands		
netck traceroute	Permitted	Displays a list of network routes.
netck arptbl	Permitted	Displays the physical Ethernet address.
netck arping	Permitted	Displays the physical Ethernet address.

Command	CE	Outline
netck ifconfig	Permitted	Displays the network environment setup status.
netck stat	Permitted	Displays a list of port numbers being used.
REMCS-related commands		
set maintenance_ip		Sets the REMCS network.
show maintenance_ip	Permitted	Displays the REMCS network setting.
DR-related		
hotadd partition		Dynamic Partiiton HotAdd.
hotremove partition		Dynamic Reconfiguration HotRemove.
set partition dynamic_partitioning		Sets DR state of partition.
show partition dynamic_partitioning	Permitted	Displays DR state of partition.

**Notation of parameters in the command syntax**

- Multiple parameters are enclosed in brackets [ ] to indicate that one of them is to be selected.  
For example, [A|B|C] means that either A, B, or C is to be selected as specified.
- A parameter is enclosed in braces { } to indicate that it can be omitted.  
For example, {quiet} means that the quiet parameter can be omitted.

**Parameter specification range**

The parameters <partition#>, <SB#>, <IOB#>, and <GSPB#> may appear in the command syntax. You can specify values in the following ranges for these parameters.

TABLE 2.7 Parameter specification range

Parameter	PRIMEQUEST 2400E	PRIMEQUEST 2800B	PRIMEQUEST 2800E
<partition#>	0-1	Unsupported	0 - 11
<SB#>	0-1	0 - 3	0 - 3
<IOU#>	0-3	0 - 3	0 - 3

If the specified value falls outside the valid range, the system displays an error message and does not process the command.

**Messages**

The following messages are common to all the commands.

- If the specified CLI parameter character string is an incorrect parameter, the following message appears.  
Also, the CLI parameters are classified into command groups: "show," "set," "add," "remove," "clear," "power," "download," and "update." If the specified parameter does not belong to any of these command groups, this message appears.

The specified parameter is invalid.
-------------------------------------

The following message appears only if the specified command name is "show," "set," "add," "remove," "clear," "power," "download," or "update."

Parameter missing
-------------------

If the entered command is not "passwd," "ping," "who," or "help" and does not belong to any of the "show," "set," "add," "remove," "clear," "power," "download," and "update" command groups, the following message appears.

No such file or directory
---------------------------

## 2.2 Setting Commands

The information setting commands are as follows:

- 2.2.1 add partition
- 2.2.2 clear access\_control
- 2.2.3 clear ssh\_key
- 2.2.4 console
- 2.2.5 download ssh\_key
- 2.2.6 power off
- 2.2.7 power on
- 2.2.8 sadump
- 2.2.9 reset
- 2.2.10 nmi
- 2.2.11 remove partition
- 2.2.12 set active\_mmb
- 2.2.13 set date
- 2.2.14 set partition dynamic\_partitioning
- 2.2.15 set gateway
- 2.2.16 set gateway\_ipv6
- 2.2.17 set hostname
- 2.2.18 set http
- 2.2.19 set http\_port
- 2.2.20 set https
- 2.2.21 set https\_port
- 2.2.22 set ip
- 2.2.23 set ipv6
- 2.2.24 set maintenance\_ip
- 2.2.25 set partition home
- 2.2.26 set partition lan\_device\_mode
- 2.2.27 set partition memory\_mirror\_ras\_mode
- 2.2.28 set partition memory\_opration\_mode
- 2.2.29 set partition name
- 2.2.30 set partition pci\_address\_mode
- 2.2.31 set ssh
- 2.2.32 set ssh\_port
- 2.2.33 set telnet
- 2.2.34 set telnet\_port
- 2.2.35 set timezone
- 2.2.36 hotadd partition
- 2.2.37 hotremove partition

This section describes how to use these commands.

### 2.2.1 add partition

Adds specified SB, IOU in specified partition.

If specified SB, IOU are not in free status, they cannot be executed.

#### ■ Privilege: Administrator

(1) Input format

```
add partition < partition#> SB <SB#x> {quiet}
add partition < partition#> IOU <IOU#x> {quiet}
```

(2) Option

quiet: Executes the command without interacting with user.

## (3) Usage example

- Example: In PRIMEQUEST 2800E, when SB#3 is to be added in Partition #2  

```
#add partition 2 SB 3
Are you sure to continue adding SB#3 to Partition#2? [Y/N] Y
Adding SB#3 to Partition#2 has been completed successfully.
#
```
- Example: In PRIMEQUEST 2800E, when IOU#1 is to be added in Partition #2  

```
#add partition 2 IOU 1
Are you sure to continue adding IOU#1 to Partition#2? [Y/N] Y
Adding IOU#1 to Partition#2 has been completed successfully.
#
```

## (4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

Are you sure you want to add %s to partition #%d? [Y/N]:
Adding %s to Partition#%d has been completed successfully.
The specified partition number is invalid.
Parameter missing
The specified parameter is invalid.
The parameter [IOU] is not supported.
Unable to add the specified SB#x to the partition due to CPU mismatch between SBs.
Unable to execute this command on a standby MMB.
Failed to execute add partition command.
Failed to execute %s command.
Unable to add the specified SB to the partition due to CPU composition abnormal.
Unable to add the specified SB to the partition due to DIMM composition abnormal.
Unable to add the specified SB to the partition due to SB composition abnormal.
Unable to add the specified SB to the partition due to VRM composition abnormal.
Unable to add the specified SB to the partition due to DIMM does not satisfy requirements of Mirror Mode.
The specified command is not supported.(error=[%s])
Unable to execute this command because the system is under maintenance.
Unable to execute this command because the Partition#x is under maintenance.
Unable to set configuration because the power on/off is processing.
Please execute it after a while again.

## 2.2.2 clear access\_control

It clears the setting of Access Control.

### ■ Privilege: Administrator

## (1) Input format

clear access_control
----------------------

## (2) Option

None

## (3) Usage example

None

## (4) Message

The following table lists the messages which are displayed in this CLI.



For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

Unable to execute this command on a standby MMB.
The specified parameter is invalid.

### 2.2.3 clear ssh\_key

Clears the public key used for the SSH Public Key Authentication which is registered for the logged in user.

#### ■ Privilege: User

(1) Input format

clear ssh_key
---------------

(2) Option  
None

(3) Usage example  
None

(4) Message  
The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

Unable to execute this command on a standby MMB.
The specified parameter is invalid.

### 2.2.4 console

Login to the specified partition by telnet. Execute the Text Console connection of BMC.

The Text Console connection to BMC can be connected only by one command per BMC. However, the following messages are displayed when the following console command is executed when other users have already executed the console command, and the Text Console connection to BMC can be done compulsorily by inputting as 'Y'. In that case, the compulsion cutting is done as for the console command under the connection.

Console redirection already in use If needed, the current user can be disconnected  Do you really want to force disconnect current user? [Y N]:
--

#### ■ Privilege: Administrator, Operator

(1) Input format

console <partition#> {timeout xxxx} {quite}
---

(2) Option  
timeout: Sets timeout value.  
Set by 0 or within the range of 60~9999 seconds.

0 consists of the special meaning, it indicates no Timeout.

Default setting is 600 Seconds.

Perform the operation by default value when this option is not specified.

quiet: Executes the command without interactive operation with User.

(3) Usage example

Example: In case of Login to BMC of Partition#0

```
# console 0
```

```
# Example: When logged in to BMC of Partition#1 by timeout value of 1200 seconds
```

```
# console 1 timeout 1200
```

```
#
```

(4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified parameter is invalid.
Unable to execute this command on a standby MMB.
Unable to execute this command because the system is under maintenance.
Unable to execute this command because the Partition#x is under maintenance.
Unable to execute this command because you have not privileges to operate this partition.

## 2.2.5 download ssh\_key

Downloads the public key which is used in SSH Public Key Authentication of logged in users from the specified server and then registers the key.

Input method of URL is as follows.

http://host/path/file

ftp://host/path/file

### ■ Privilege: User

(1) Input format

```
download ssh_key <URL>
```

(2) Option

None

(3) Usage example

When server is not specified: As shown below, the message urging for the URL input displays. Waiting for URL input.

Example:

```
# download ssh_key
```

```
URL:
```

(4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified parameter is invalid.
Specified host does NOT respond.

## 2.2.6 power off

Turn off the power of entire system or specified partition.

When the partition which is specified by parameter is not configured, ignore such partition.

When the specified partition is already in power off state, any process will not be executed for that partition.

Only the partitions which are targeted for management can be operated for Partition Operator.

Error message displays when the parameter having partitions which are not targeted for management is specified. Specified partition cannot be operated.

### ■ Privilege: Administrator, Operator, Partition Operator (Partitions targeted for management only)

(1) Input format

<code>power off {partition} [all/ &lt;partition#&gt; [ , / -] &lt;partition#&gt;] {force}</code>
--

(2) Option

Partition: Shutdown the operating system of partition by which partition number is specified and turns off the power of partition. This parameter is optional.

The default parameter is processed as the specified partition parameter. Therefore, it is necessary to specify the partition.

Partitions are specified as follows.

- all (All defined partitions) specified
- Specifies Partition numbers by delimiting with comma
- Specifies with the range of partition number

force: Shows that the power of the partition turns off forcefully without shutting down the operating system of partition.

(3) Usage example

None

(4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified parameter is invalid.
The specified partition number is invalid.
Unable to execute this command because the system is under maintenance.
Unable to execute this command because the Partition#x is under maintenance.
Unable to power off the partition#%d.
Unable to force power off on the partition#%d.
Command Failed. Code=0x%04X, 0x%02X
Unable to power off the Partition#n because you have not authority to operate this partition.
Unable to execute this command on a standby MMB.
Unable to power off the partition(s) because the partition which does not have authority to you is included in the specified parameter.
The specified parameter is invalid.
Specified host does NOT respond.

## 2.2.7 power on

Turn on the power supply of the entire system or the specified partition.

When the partition specified by the parameter is not configured, the partition which is not configured is ignored.

When the power supply for the specified partition is already turned on, processing for such partitions is not done.

Partition Operator can operate only the partition to be managed.

When the parameter which contains the partitions other than those to be managed is specified, an error message is displayed and the specified partition cannot be operated.

■ **Privilege: Administrator, Operator, Partition Operator (Only the partition to be managed)**

(1) Input format

```
power on {partition} [ all | <partition#> [, | -] <partition#>]
```

(2) Option

Partition: Turn on the power of the partition which specifies the partition number.

When there is no power supply to the chassis, before turning on the power of the partition, turn on the power supply of the chassis and then turn on the power supply of the specified partition.

This parameter is optional. The default parameter is processed as the specified partition parameter. Therefore, it is necessary to specify the partition.

Partitions are specified as follows.

- all (All defined partitions) specified
- Specifies Partition numbers by delimiting with comma
- Specifies with the range of partition number

(3) Usage example

None

(4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified parameter is invalid.
The specified partition number is invalid.
Unable to power on the partition#%d due to CPU mismatch between SBs.
Unable to power on the partition#%d due to DIMM does not satisfy requirements of Mirror Mode.
Unable to power on due to mismatch between supply voltage and input voltage.
Unable to power on the partition#%d due to abnormal DIMM composition.
Unable to power on the partition#%d due to abnormal SB composition.
Unable to power on the partition#%d due to abnormal VRM composition.
Unable to power on the partition#%d.
Command Failed. Code=0x%04X, 0x%02X
Unable to execute this command on a standby MMB
Unable to execute this command because the system is under maintenance.
Unable to execute this command because the Partition#x is under maintenance.
The Power On failed, because of switching the Home SB. Please execute it after a while again.
Unable to power on the Partition#n because you have not authority to operate this partition.
Unable to power on the partition(s) because the partition which does not have authority to you is included in the specified parameter.

## 2.2.8 sadump

Specify sadump to specified partition.

When the partition which is specified by the parameter is not configured, the partition is ignored.

When the specified partition is not in Power On state, any kind of processing for such partition is not done.

Partition Operator can operate only the partition to be managed.

When the parameter which contains the partitions other than those to be managed is specified, an error message is displayed and the specified partition cannot be operated.

### ■ Privilege: Administrator, Operator, Partition Operator (Only the partition to be managed)

(1) Input format

sadump {partition} [<partition#> [,   -] <partition#>] {quiet}
--

(2) Option

partition: This option specifies a sadump of the partition identified by the specified partition number. This partition can be omitted.

partition#: Partition number. Even if the partition parameter is omitted, processing assumes that the partition parameter is specified. Therefore, a partition number must be specified.  
Partition is number specified as follows.

- Partition numbers are separated by comma
- Specifies with the range of partition number

quiet: The command is executed without interactive operation with the user.

(3) Usage example

Example: When sadump is specified to Partition#1 by Administrator Authority

```
Administrator> sadump partition 1
Are you sure you want to sadump to Partition#1? [Y/N]: Y
Administrator>
```

(4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

Are you sure you want to sadump to Partition#%d? [Y/N]:
The specified parameter is invalid.
The specified partition number is invalid.
Unable to sadump the partition#%d.
Command Failed. Code=0x%04X, 0x%02X
Unable to execute this command on a standby MMB.
Unable to execute this command because the system is under maintenance.
Unable to execute this command because the Partition#x is under maintenance.
Unable to sadump the Partition#n because you have not authority to operate this partition.
Unable to sadump the partition(s) because the partition which does not have authority to you is included in the specified parameter.

## 2.2.9 reset

Specify the Hard Reset to the specified partition.

When the partition specified by the parameter is not configured, the partition which is not configured is ignored.

When the specified partition is not in Power On state, any kind of processing for such partition is not done.

Partition Operator can operate only the partition to be managed.

When the parameter which contains the partitions other than those to be managed, is specified then error message is displayed and the specified partition cannot be operated.

## ■ **Privilege: Administrator, Operator, Partition Operator (Only the partition to be managed)**

### (1) Input format

reset {partition} [<partition#> [,   -] <partition#>] {quiet}
---

### (2) Option

partition: This option specifies a Hard Reset of the partition identified by the specified partition number. This partition can be omitted.

partition#: Partition number. Even if the partition parameter is omitted, processing assumes that the partition parameter is specified. Therefore, a partition number must be specified.  
Partition is number specified as follows.

- Partition numbers are separated by comma
- Specifies with the range of partition number

quiet: The command is executed without interactive operation with the user.

### (3) Usage example

Example: When reset is specified to Partition#1 by Administrator Authority

```
Administrator> reset partition 1
Are you sure you want to Reset to Partition#1? [Y/N]: Y
Administrator>
```

### (4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

Are you sure you want to Reset to Partition#%d? [Y/N]:
The specified parameter is invalid.
The specified partition number is invalid.
Unable to Reset the partition#%d.
Command Failed. Code=0x%04X, 0x%02X
Unable to execute this command on a standby MMB.
Unable to execute this command because the system is under maintenance.
Unable to execute this command because the Partition#x is under maintenance.
Unable to Reset the Partition#n because you have not authority to operate this partition.
Unable to Reset the partition(s) because the partition which does not have authority to you is included in the specified parameter.

## 2.2.10 nmi

Specify NMI interruption to specified partition.

The default parameter is processed as the specified partition parameter. Therefore, it is necessary to specify the partition.

When the specified partition is not in Power On state, any kind of processing for such partition is not done.

Partition Operator can operate only the partition to be managed.

When the parameter which contains the partitions other than those to be managed, is specified then error message is displayed and the specified partition cannot be operated.

■ **Privilege: Administrator, Operator, Partition Operator (Only the partition to be managed)**

(1) Input format

<code>nmi{partition} [&lt;partition#. [,   -] &lt;partition#&gt;] {quiet}</code>
--

(2) Option

partition: This option specifies a NMI of the partition identified by the specified partition number. This partition can be omitted.

partition#: Partition number. Even if the partition parameter is omitted, processing assumes that the partition parameter is specified. Therefore, a partition number must be specified.  
Partition is number specified as follows.

- Partition numbers are separated by comma
- Specifies with the range of partition number

quiet: The command is executed without interactive operation with the user.

(3) Usage example

Example: When NMI is specified in Partition #1 by Administrator privilege.

```
Administrator > nmi partition 1
Are you sure you want to NMI to Partition#1? [Y/N]: Y
Administrator >
```

(4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

Are you sure you want to NMI to Partition#%d? [Y/N]:
The specified parameter is invalid.
The specified partition number is invalid
Unable to NMI the partition#%d.
Command Failed. Code=0x%04X, 0x%02X
Unable to execute this command on a standby MMB.
Unable to execute this command because the system is under maintenance.
Unable to execute this command because the Partition#x is under maintenance.
Unable to NMI the Partition#n because you have not authority to operate this partition
Unable to NMI the partition(s) because the partition which does not have authority to you is included in the specified parameter.

## 2.2.11 remove partition

Remove the specified SB, IOU from the specified partition.

When the specified SB, IOU is not included in specified partition, then execution cannot be done.

■ **Privilege: Administrator**

(1) Input format

```
remove partition <partition#> SB <SB#x> {quiet}
remove partition <partition#> IOU <IOU#x> {quiet}
```

## (2) Option

quiet: Command is executed without interacting with the user.

## (3) Usage example

- Example: When removing SB#3 from Partition #2 in PRIMEQUEST 2800E  

```
# r remove partition 2 SB 3.
Are you sure to continue removing SB#3 from Partition#2? [Y/N] Y
Removing SB#3 from Partition#2 has been completed successfully.
#
```
- Example: When removing IOU#1 from Partition #2 in PRIMEQUEST 2800E  

```
# remove partition 2 IOU1.
Are you sure to continue removing IOU#1 from Partition#2? [Y/N] Y
Removing IOU#1 from Partition#2 has been completed successfully.
#
```

## (4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

Are you sure you want to remove %s from Partition#%d? [Y/N]:
Removing %s from Partition#%d has been completed successfully.
The specified partition number is invalid.
The specified [SB IOU] number is invalid.
The specified parameter is invalid.
Parameter missing
Partition#x does not include the [SB#x   IOU#x].
Unable to execute this command on a standby MMB.
Failed to execute remove partition command.
Failed to execute %s command.
The specified command is not supported.(error=[%s])
The parameter [IOU] is not supported.
Unable to execute this command because the system is under maintenance.
Unable to execute this command because the Partition#x is under maintenance.
Unable to set configuration because the power on/off is processing.
Please execute it after a while again.

## 2.2.12 set active\_mmb

By resetting Active MMB, switch over to Active MMB.

When this command is issued for MMB which is already in Active MMB, nothing is executed.

When this command is issued without parameter, the command assumes that the MMB connected to the CLI is specified as the active MMB.

**Remarks**

- This command can be executed by connecting to Standby MMB.
- It is different from Switch Over function of MMB Web-UI.

### ■ Privilege: Administrator, CE

## (1) Input format



set active_mmb {0   1} {quiet}
--------------------------------

## (2) Option

0: MMB#0 is specified

1: MMB#1 is specified

quiet: Command is executed without interacting with the user.

## (3) Usage example

None

## (4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified MMB#x is NOT present.
The specified MMB#x is disabled.
The specified parameter is invalid.
Are you sure to continue set active mmb? [y/n]:
set active_mmb failed.

## 2.2.13 set date

Set the date and time.

The set format is as following.

- MM : Month (01~12)
- DD : Date (1~28|29|30|31)
- hh : Time(00~23)
- mm : Minutes(00~59)
- CC : First two digits of the year (option)
- YY : Last two digits of the year (option)
- SS: Seconds (option)

### ■ Privilege: Administrator

## (1) Input format

set date MMDDhhmm{{CC}YY}{, SS}
---------------------------------

## (2) Option

None

## (3) Usage example

None

## (4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified date is invalid.
Unable to set date because NTP is enabled.
Time synchronization was requested to Standby MMB.
Unable to execute this command on a standby MMB.

## 2.2.14 set partition dynamic\_partitioning

Sets the enable/disable of Dynamic Reconfiguration of the specified partition.

When executing the settings by this command for the partition whose power is already on, message shown below is displayed, and settings cannot be done.

“Unable to change the mode while the partition is running.  
Please try to change the mode after the partition is shutdown.”

When settings of the partition for which power supply is already switched off are to be changed, it is not necessary to turn On / Off the power supply. The value set at that instant is reflected without displaying the above-mentioned message.

Moreover, when existing value and set value are same, it is not necessary to turn On / Off the power supply, and above mentioned message is not displayed.

### ■ Privilege: Administrator, Operator, Partition Operator (Only the Partition to be managed)

(1) Input format

set partition dynamic_partitioning<partition#>[disable enable]{quiet}
---

(2) Option

quiet: Does not display message.

(3) Usage example

· Example : When Dynamic Reconfiguration of partition #3 is enabled

# set partition dynamic\_partitioning 3 enable

(4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified partition number is invalid.
The specified parameter is invalid.
Unable to execute this command on a standby MMB
Failed to execute set partition dynamic_partitioning command.
Unable to change the mode while the partition is running.
Please try to change the mode after the partition is shutdown.
DP can't be enabled, because of no DP license.

## 2.2.15 set gateway

Default gateway is set

Set value is 0.0.0.0 by default.

### ■ Privilege: Administrator

(1) Input format

set gateway<ip address>
-------------------------

(2) Option  
None

(3) Usage example  
None

(4) Message  
The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified gateway address is invalid.
The specified parameter is invalid.
The specified IP address is duplicated.
The specified IP address is loopback address.
Unable to execute this command on a standby MMB.

## 2.2.16 set gateway\_ipv6

Default gateway of IPv6 is set

If automatic setting is executed, only "auto" is specified in option.

### ■ Privilege: Administrator

(1) Input format

- In case of manual setting

Set gateway_ipv6 <ip address>
-------------------------------

- In case of automatic setting

Set gateway_ipv6 auto
-----------------------

(2) Option

auto: IP address is set automatically.

(3) Usage example

- In case of manual setting  
# set gateway\_ipv6 fe80::1
- In case of automatic setting  
#set gateway\_ipv6 auto  
fe80::beef  
Are you sure to continue?[Y/N]

(4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified parameter is invalid.
Unable to execute this command on a standby MMB.
The specified gateway address is invalid
The specified IP address is duplicated.
The specified IP address is loopback address.

## 2.2.17 set hostname

Specifies the host name of MMB in FQDN format

Characters which can be entered, are as follows.

[a-z],[A-Z],[0-9],[\_] (Hyphen),[.] (Dot)

However, following conditions must be observed

- The first character must be alphanumeric character.
- [\_] (Hyphen),[.] (Dot) cannot be used as first character

Default value is "PRIMEQUEST" + Product Serial Number.

Example:

When serial number is 1020516004,  
"PRIMEQUEST1020516004"

### ■ Privilege: Administrator

(1) Input format

set hostname <hostname>.<domain name>
---------------------------------------

(2) Option  
None

(3) Usage example  
# set hostname hoge hoge.fujitsu.com  
#

(4) Message  
The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified hostname is invalid.
Unable to execute this command on a standby MMB.

## 2.2.18 set http

Enable/disable of HTTP server is set

Default value is disable (http is invalid)

### ■ Privilege: Administrator

(1) Input format

set http [enable disable]
---------------------------

(2) Option  
None

(3) Usage example  
None

## (4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

Unable to execute this command on a standby MMB.
--

## 2.2.19 set http\_port

Sets a port accepting HTTP session.8081 is the default.

The specifiable port numbers in <port> are in the range of 1024~65535, 80 is the standard port.

### ■ Privilege: Administrator

## (1) Input format

Set http_port <port>
----------------------

## (2) Option

None

## (3) Usage example

None

## (4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified port number is invalid.
The specified port number is duplicated.
Unable to execute this command on a standby MMB.

## 2.2.20 set https

Sets enable/disable the HTTP server.

Default value set is disable (http disabled).

### ■ Privilege: Administrator

## (1) Input format

Set https [enable   disable]
------------------------------

## (2) Option

None

## (3) Usage example

None

## (4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

Unable to execute this command on a standby MMB.
--

## 2.2.21 set https\_port

Sets a port accepting HTTPS messages.432 is the default.

432, 1024~65535 are specifiable port numbers by <port>, 443 is the standard port.

### ■ Privilege: Administrator

(1) Input format

Set https_port <port>
-----------------------

(2) Option  
None

(3) Usage example  
None

(4) Message  
The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified port number is invalid.
The specified port number is duplicated.
Unable to execute this command on a standby MMB.

## 2.2.22 set ip

Sets <IP address>, <netmask>,for management LAN interface.

Sets virtual IP address of MMB connected in Serial.

Sets point of default is 0.0.0.0.

### ■ Privilege: Administrator

(1) Input format

set ip <ip address> <netmask>
-------------------------------

(2) Option  
None

(3) Usage example  
None

(4) Message  
The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified IP address is invalid.
The specified netmask is invalid.
The specified IP address is duplicated.
The specified IP address is loopback address.
Unable to execute this command on standby MMB.

## 2.2.23 set ipv6

Sets the global address for IPv6 and prefix length for management LAN interface.

Sets virtual IP address of MMB.

When automatic setting is done, only "auto" is specified in the option.

### ■ Privilege: Administrator

(1) Input format

- In case of manual setting

set ipv6 <ip address/prefix>
------------------------------

- In case of automatic setting

set ipv6 auto
---------------

(2) Option

auto: IP address is set automatically.

(3) Usage example

- In case of manual setting

```
#set ipv6 2001:db8:caaf:beef:206:29ff:fele:482e/48
#
```
- In case of automatic setting

```
If GUID (Device serial number): "123456789abcdef0"
#set ipv6 auto
2001:xxxx:xxxx:xxxx:xxxx:1234.5678.9abc.def0/64
Are you sure to continue? [Y/N]
```

(4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

Unable to execute this command on a standby MMB.
The specified IP address is invalid.
The specified netmask is invalid.
The specified IP address is duplicate.
The specified IP address is loopback address.

## 2.2.24 set maintenance\_ip

### Remarks

Only IPv4 is supported.

Set IP address in Maintenance port.

Set point of default is 0.0.0.0, common in ip address, netmask, gateway address, smtp address.  
Sets virtual IP address of MMB connected in Serial.

Sets point of default is 0.0.0.0.

- <ip address>: IP address set in Maintenance port (when 0.0.0.0 is specified, settings are cleared)
- <subnet mask>: Subnet mask of IP address
- <gateway address>: Gateway
- <smtp address>: Mail server for REMCS notification

**Remarks**

- When you change SMTP Address by this command, it is necessary to change the settings of SMTP server in REMCS environment setting window. Moreover, before initializing REMCS, Routing should be set by this command.
- When REMCS is to be connected in P-P, <gateway address> and <SMTP address> are not required. In such case, <gateway address> and <SMTP address> are set to 0.0.0.0.
- When settings in this command are invalid, <ip address> is set to 0.0.0.0. Though the parameters other than <ip address> parameters are optional, they are recommended to be 0.0.0.0.

**■ Privilege: Administrator, CE****(1) Input format**

set maintenance_ip <ip address> <netmask> <gateway address> ¥ <smtp address>
---

¥: Indicates that there is no new line.

**(2) Option**

None

**(3) Usage example**

Examples: Setting the IP address of the Maintenance port by the following contents

- IP address: 192.168.1.10
- Subnetmask: 255.255.255.0
- Gateway: 192.168.1.1
- Mail server for REMCS acknowledgement: 172.128.1.2

# set maintenance\_ip 192.168.1.10 255.255.255.0 192.168.1.1 172.128.1.2

**(4) Message**

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified IP address is invalid.
The specified netmask is invalid.
The specified gateway address is invalid.
The specified smtp address is invalid.
Unable to execute this command on a standby MMB.

## 2.2.25 set partition home

It sets the Home SB of the specified partition.

It specifies the number of SB to be set in Home. If the specified SB does not exist, the process is not executed.



## ■ Privilege: Administrator

(1) Input format

set partition home <partition#> SB <SB#>
--

(2) Option  
None

(3) Usage example  
Example: When setting SB#2 as Home in Partition3

```
# set partition home 3 SB 2
#
```

(4) Message  
The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified partition number is invalid.
The specified SB number is invalid.
The specified SB#x is Not - present.
Unable to change the home SB while the partition is running. Please try to change the home SB after the partition is shutdown.
Unable to execute this command on a standby MMB.
The specified parameter is invalid.
Unable to execute this command because the system is under maintenance.
Unable to execute this command because the Partition#x is under maintenance.
Succeed to set partition home command.
Failed to execute set partition home command.
Failed to execute %s command.
The specified command is not supported.(error=[%s])

## 2.2.26 set partition lan\_device\_mode

LAN Device Mode is set by the IOU unit in the specified partition.  
Default value set is wol\_disable.

wol\_enable: Onboard LAN enabled with AC On.  
wol\_disable: Onboard LAN enabled with Partition On.  
device\_disable: Onboard LAN device disabled always.

For the partition which is already powered ON, when the settings are performed by this command, following message is displayed and settings cannot be performed.

“Unable to change the mode while the partition is running.  
Please try to change the mode after the partition is shutdown.”

For the partition which is already powered OFF, when the settings are changed by this command, power OFF/ON is not required. The value which is set is reflected instantly instead of displaying the above-mentioned message.

Moreover, also when values which are the same as the current values are set, power off/on is not required and the above-mentioned message is not displayed.

**■ Privilege: Administrator, Operator, Partition Operator (Only managed partition)**

(1) Input format

set partition lan_device_mode <partition#> <IOU#> [wol_enable]
--

(2) Option

quiet: Message is not displayed.

(3) Usage example

Example: When setting IOU#2 to Enable (WOL enabled) in the Partition3

```
# set partition lan_device_mode 3 2 enable_wol_enable
#
```

(4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The setting will become effective the next time the partition power off/on is performed.
The specified partition number is invalid.
The specified parameter is invalid.
Unable to execute this command on a standby MMB.
Failed to execute %s command.
Failed to execute set partition command.
Unable to change the mode while the partition is running. Please try to change the mode after the partition is shutdown.
Unable to execute this command because you have not authority to operate this partition.

## 2.2.27 set partition memory\_mirror\_ras\_mode

It sets the Memory Mirror RAS mode of the specified partition.

Memory Operation Mode can be set only at the time of Mirror Mode settings. Default value is set to mirror\_keep (RAS emphasized mode).

mirror\_keep: Mirror mode is maintained  
capacity\_keep: Capacity of the memory is maintained.

For the partition which is already powered ON, when the settings are performed by this command, following message is displayed and settings cannot be performed.

“Unable to change the mode while the partition is running.  
Please try to change the mode after the partition is shutdown.”

For the partition which is already powered OFF, when the settings are changed by this command, power OFF/ON is not required. The value which is set is reflected instantly instead of displaying the above-mentioned message.

Moreover, also when values which are the same as the current values are set, power ff/on is not required and the above-mentioned message is not displayed.

**■ Privilege: Administrator, Operator, Partition Operator (Only managed partition)**

(1) Input format

```
set partition memory_mirror_ras_mode <partition#> [mirror_keep |capacity_keep ] {quiet}
```

## (2) Option

quiet: Message is not displayed.

## (3) Usage example

Example: When setting Memory Mirror RAS Mode of the Partition3 to Mirror Keep Mode

```
# set partition memory_mirror_ras_mode 3 mirror_keep
The setting will become effective the next time the partition power off/on is performed
#
```

## (4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The setting will become effective the next time the partition power off/on is performed.
The specified partition number is invalid.
The specified parameter is invalid.
Unable to execute this command on a standby MMB.
Failed to execute %s command.
Failed to execute set partition command.
Unable to change the mode while the partition is running. Please try to change the mode after the partition is shutdown.
Unable to execute this command because you have not authority to operate this partition.

## 2.2.28 set partition memory\_opration\_mode

It sets the Memory Operation Mode of the specified partition.

By default normal (Mirror Mode invalid) is set.

```
performance : sets the Performance Mode
normal       : sets the Normal Mode
partial_mirror : sets the Partial Mirror Mode
full_mirror   : sets the Full Mirror Mode
spare        : sets the Spare Mode
```

For the partition which is already powered ON, when the settings are performed by this command, following message is displayed and settings cannot be performed.

“Unable to change the mode while the partition is running.  
Please try to change the mode after the partition is shutdown.”

When the partition is configured of or above 2SB, and when Reserved SB is set, also, when the settings other than the Memory Operation Mode satisfying the DIMM configuration requirement of SB is set as Reserved SB, following message is displayed and setting cannot be possible.

“The SB with DIMM that does not satisfy requirements of Mirror Mode is registered as a Reserved SB.  
If you register this partition as a Mirror Mode,  
Mirror Mode will be disabled when switching to Reserved SB.  
Are you sure to continue?[Y/N]”

For the partition which is already powered OFF, when the settings are changed by this command, power OFF/ON is not required. The value which is set is reflected instantly instead of displaying the above-mentioned message.

Moreover, also when the values which are the same as the current values are set, power off/on is not required and the above-mentioned message is not displayed.

## ■ Privilege: Administrator, Operator, Partition Operator (Only managed partition)

### (1) Input format

```
set partition memory_operation_mode <partition#> [performance | normal | partial_mirror | spare] {quiet}
```

### (2) Option

quiet: Message is not displayed.

### (3) Usage example

Example: When setting Memory Operation Mode of the Partition3 to performance

```
# set partition memory_operation_mode 3 performance
The setting will become effective the next time the partition power off/on is performed
#
```

here are cases when the partition is configured to 1SB, and, when Reserved SB is set, also when the settings other than the Memory Operation Mode of DIMM configuration satisfying SB requirement is registered as Reserved SB, a dialog box for conformation is displayed.

When the Memory Operation Mode is switched to the Reserved SB, a warning message indicating a change in Memory Operation Mode is displayed in the dialog box and whether this setting is to be continued is confirmed in the dialog box.

If this message is not displayed, the Memory Operation Mode is not changed even if it is switched to Reserved SB.

Example: When setting the Mirror Mode of the Partition 1 to enable

(The SB with DIMM that does not satisfy the Mirror Mode requirements is registered as the Reserved SB in Partition 1)

```
# set partition memory_operation_mode 1 partial_mirror
The SB with DIMM that does not satisfy requirements of Mirror Mode is registered as the Reserved SB.
If you register this partition as a Mirror Mode,
Mirror Mode will be disabled when switching to a Reserved SB.
Are you sure to continue? [Y/N] y
#
```

### (4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The setting will become effective the next time the partition power off/on is performed.
The SB with DIMM that does not satisfy requirements of Mirror Mode is registered as a Reserved SB. If you register this partition as a Mirror Mode, Mirror Mode will be disabled when switching to Reserved SB. Are you sure to continue? [Y/N]
The specified partition number is invalid.
The specified parameter is invalid.
Unable to register the specified Partition#%d as Mirror Mode enable because the CPU mismatch between SBs.
Unable to register the specified Partition#%d as Mirror Mode enable because the DIMM does not satisfy requirements of Mirror Mode.
Unable to register the specified Partition#%d as Mirror Mode enable because the unsupported CPU configuration.
Unable to register the specified Partition#%d as Mirror Mode enable because of abnormal CPU composition.
Unable to register the specified Partition#%d as Mirror Mode enable because of abnormal DIMM composition.

Unable to register the specified Partition#%s as Mirror Mode enable because of abnormal SB composition.
Unable to register the specified Partition#%s as Mirror Mode enable because of abnormal VRM composition.
Unable to execute this command on a standby MMB.
Failed to execute %s command.
Failed to execute set partition command.
Unable to change the mode while the partition is running.
Please try to change the mode after the partition is shutdown.
Unable to execute this command because you have not authority to operate this partition.

## 2.2.29 set partition name

It sets the name of the specified partition.

The name of the partition is up to 16 characters. The name that contains the characters exceeding the 16 characters cannot be set.

If the name contains space, it is enclosed within "".

The characters that can be used are as follows.

[a-z], [A-Z], [0-9], "-", (Under bar), "\_" (hyphen), "#" (Sharp), "" (Blank)

No default value is set.

### ■ Privilege: Administrator

(1) Input format

```
set partition name <partition#> <partition name>
```

(2) Option

None

(3) Usage example

Example: When setting the name "hoge hoge" to the Partition3

```
# set partition name 3 hoge hoge
#
```

(4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified partition number is invalid.
The specified partition name is invalid.
Partition#x is not defined.
Unable to execute this command on a standby MMB.
The specified parameter is invalid.
Unable to execute this command because the system is under maintenance.
Unable to execute this command because the Partition#x is under maintenance.
Succeed to set partition name command.
Failed to execute set partition name command.
Failed to execute %s command.
The specified command is not supported.(error=[%s])

## 2.2.30 set partition pci\_address\_mode

It sets the PCI Address Mode of the specified partition.

PCI Segment Mode is set as default.

bus: sets PCI Bus Mode

segment: sets PCI Segment Mode

For the partition which is already powered ON, when the settings are performed by this command, following message is displayed and settings cannot be performed.

“Unable to change the mode while the partition is running.  
Please try to change the mode after the partition is shutdown.”

For the partition which is already powered off, when the settings are changed by this command, power off/on is not required. The value which is set is reflected instantly instead of displaying the above-mentioned message.

Moreover, also when the values which are the same as the current values are set, power off/on is not required and the above-mentioned message is not displayed.

### ■ Privilege: Administrator, Operator, Partition Operator (Only managed partition)

(1) Input format

set partition pci_address_mode <partition#> [bus   segment ][{quiet}]
---

(2) Option

quiet: Message is not displayed.

(3) Usage example

Example: When setting PCI Address Mode of the Partition3 to Segment Mode

```
# set partition pc_address_mode 3 segment
#
```

(4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The setting will become effective the next time the partition power off/on is performed.
The specified partition number is invalid.
The specified parameter is invalid.
Unable to execute this command on a standby MMB.
Failed to execute %s command.
Failed to execute set partition command.
Unable to change the mode while the partition is running. Please try to change the mode after the partition is shutdown.
Unable to execute this command because you have not authority to operate this partition.

## 2.2.31 set ssh

Sets enable/disable of SSH.

Default setting is disable (SSH Disable).

- **Privilege: Administrator**

(1) Input format

set ssh [enable   disable]
----------------------------

(2) Option  
None

(3) Usage example  
None

(4) Message  
The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

Unable to execute this command on a standby MMB.
--

## 2.2.32 set ssh\_port

Set the port which receives the SSH session. Default setting is 22.

The port number which indicates the <port> are 22, 1024~65535.

- **Privilege: Administrator**

(1) Input format

set ssh_port <port>
---------------------

(2) Option  
None

(3) Usage example  
None

(4) Message  
The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified port number is invalid.
The specified port number is duplicated.
Unable to execute this command on a standby MMB.

## 2.2.33 set telnet

Sets enable/disable of Telnet.

Default setting is disable (Telnet Disable).

- **Privilege: Administrator**

## (1) Input format

set telnet [enable   disable]
-------------------------------

## (2) Option

None

## (3) Usage example

None

## (4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

Unable to execute this command on a standby MMB.
--

## 2.2.34 set telnet\_port

Sets the port which receives the telnet connection. Default setting is 23.

Port numbers which can be set are 23, 1024~65535.

### ■ Privilege: Administrator

## (1) Input format

set telnet_port <port>
------------------------

## (2) Option

None

## (3) Usage example

None

## (4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified port number is invalid.
The specified port number is duplicated.
Unable to execute this command on a standby MMB.

## 2.2.35 set timezone

Set the Timezone.

**Remarks**

It is necessary to reset the time by using set date command after the time zone is set.

### ■ Privilege: Administrator

## (1) Input format



```
set timezone <timezone>
```

(2) Option  
None

(3) Usage example  
None

(4) Message  
The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified port number is invalid.
Time synchronization was requested to Standby MMB.
Unable to execute this command on a standby MMB.

## 2.2.36 hotadd partition

The specified SB or IOU is dynamically added for the specified partition.

- A few minutes are required for the execution of this command.
- The SB parameter specifies physical SB number (It is not logical SB number).
- The execution of this command cannot be interrupted.
- When the partition will be started next time, the configuration change is reflected even if the command fails.

In the case of any of the following, the error is displayed and processing is interrupted.

- ① When the DP function of the specified partition is invalid
- ② When the specified partition is operated DR
- ③ When the specified partition is starting
- ④ When OS of the specified partition is DR off the subject
- ⑤ When the specified SB is not a free SB or it is not Reserved SB (At the SB specification)
- ⑥ When the specified IOU is not a free IOU (At the IOU specification)
- ⑦ When specified SB or IOU is not normal (When it does not exist or be abnormal)

### ■ Privilege: Administrator

(1) Input format

```
hotadd partition <partition#> SB <SB#x> {quiet}
hotadd partition <partition#> IOU <IOU#x> {quiet}
```

(2) Option  
quiet: The command is executed without interacting with the user.

(3) Usage example

- Example: When SB#3 is to be added to Partition#2
 

```
# hotadd partition 2 SB 3
Are you sure to continue adding SB#3 to partition#2? [Y/N] Y
DP operation start (1/5)
Assigning SB#3 to partition#2 (2/5)
Testing SB#3 (3/5)
Reconfiguring partition#2 (4/5)
Onlining added Memory/CPU (5/5)
Adding SB#3 to Partition#2 has been completed successfully.
#
```

- Example: When IOU#3 is to be added to Partition#2  

```
# hotadd partition 2 IOU 3
Are you sure to continue adding IOU#3 to Partition#2? [Y/N] Y
DP operation start (1/3)
Assigning IOU#$ to partition#$ (2/3)
Power on IOU#$(3/3)
Adding IOU#3 to Partition#2 has been completed successfully.
#
```

## (4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

Are you sure to continue adding [SB#%d IOU#%d] to partition#%d? [Y/N]:
DP operation start (1/5)
Assigning SB#%d to partition#%d (2/5)
Testing SB#%d (3/5)
Reconfiguring partition#%d (4/5)
Onlining added Memory/CPU (5/5)
DP operation start (1/3)
Assigning IOU#%d to partition#%d (2/3)
Power on IOU#%d(3/3)
Adding [SB#%d IOU#%d] to partition#%d has been completed successfully.
The specified [SB#%d IOU#%d] is not present.
The specified [SB#%d IOU#%d] is power-on.
The specified Partition#%d is no Home.
Hot-add [SB#%d IOU#%d] failure.
Unable to hot-add SB due to firmware mismatch.
Unable to hot-add SB due to SB revision mismatch.
Unable to hot-add SB due to CPU mismatch.
Unable to hot-add SB due to DIMM mismatch.
Unable to power on the DP test partition.
Unable to power off the DP test partition.
Chekc DP Unit Error
Unable to onlining the DP target bmc.
Unknown Error Code =0xXX
Failed to execute hotadd partition command.
Unable to execute this command on a standby MMB.
Hot-add [SB#%d IOU#%d] failed.
Failed to execute DP operation. Fatal error occurred.
Unable to power on the IOU.
Unable to power on the PCIBox.
Failed to create DP test partition.
Failed to execute DP operation. Partition is stopped.
DP sequence timeout: added SB power on failure
DP sequence timeout: SB hot-add OS failure
DP sequence timeout: SB hot-add request failure
DP sequence timeout: QPI connection failure
BIOS Error Code =0xXX
The specified [SB#%d IOU#%d] is not free or reserved.
DP can't be enabled, because of no DP license
DP feature is disabled.
Unable to execute DP command while other DP command is running
Unable to execute DP command due to previous failure.
Unable to execute DP command because OS is not ready for DP operation

## 2.2.37 hotremove partition

The specified SB or IOU is removed dynamically from the specified partition.

In the case of any of the following, the error is displayed and processing is interrupted.

- ① When the DR function of the specified partition is invalid
- ② When the specified partition is operated DR
- ③ When the specified partition is starting
- ④ When OS of the specified partition is DR off the subject
- ⑤ When the specified SB or IOU is not exist in the specified partition.
- ⑥ When specified SB is Home SB (At the SB specification)

### ■ Privilege: Administrator

(1) Input format

<pre>hotremove partition &lt;partition#&gt; SB &lt;SB#x&gt; {quiet} hotremove partition &lt;partition#&gt; IOU &lt;IOU#x&gt; {quiet}</pre>
--

(2) Option

quiet: The command is executed without interacting with the user.

(3) Usage example

- Example: When SB#3 is removed from Partition#2
 

```
# hotremove partition 2 SB 3
Are you sure to continue removing SB#3 from partition#2? [Y/N] Y
DP operation start (1/4)
Offlining removed Memory/CPU (2/4)
Reconfiguring partition#2 (3/4)
Releasing SB#3 (4/4)
Removing SB#3 from partition#2 has been completed successfully.
#
```
- Example: When IOU#3 is removed from Partition#2
 

```
# hotremove partition 2 IOU 3
Are you sure to continue adding IOU#3 to Partition#2? [Y/N] Y
Adding IOU#3 to Partition#2 has been completed successfully.
#
```

(4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

Are you sure to continue removing [SB#%d IOU#%d] from Partition#%d? [Y/N]:
DP operation start (1/4)
Offlining removed Memory/CPU (2/4)
Reconfiguring partition#%d (3/4)
Releasing SB#%d (4/4)
DP operation start (1/3)
Remove IOU#%d (2/3)
IOU#%d power-off (3/3)
Removing [SB#%d IOU#%d] from partition#%d has been completed successfully.
The specified [SB#%d IOU#%d] is not present.
The specified [SB#%d IOU#%d] is power-off.
The specified [SB#%d IOU#%d] is not in specified Partition.
The specified SB#%d is home SB.
Unknown Error Code =0xXX
Failed to execute hotremove partition command.
Unable to execute this command on a standby MMB.
Hot-remove [SB#%d IOU#%d] failed.

Failed to execute DP operation. Fatal error occurred.
Failed to execute DP operation. Configuration is unrecovered.
Failed to execute DP operation. Partition is stopped.
The specified IOU#%d has not stopped.
DP sequence timeout: QPI disconnection failure
DP sequence timeout: SB hot-remove OS failure
BIOS Error Code =0xXX
The specified [SB#%d IOU#%d] is free
DP can't be enabled, because of no DP license
DP feature is disabled.
Unable to execute DP command due to previous failure.
Unable to execute DP command while other DP command is running
Unable to execute DP command because OS is not ready for DP operation

## 2.3 Commands for Display

Command for displaying the information is as follows.

2.3.1 show access\_control  
 2.3.2 show active\_mmb  
 2.3.3 show date  
 2.3.4 show exit\_code  
 2.3.5 show partition configuration  
 2.3.6 show partition dynamic\_partitioning  
 2.3.7 show partition home  
 2.3.8 show partition lan\_device\_mode  
 2.3.9 show partition name  
 2.3.10 show partition memory\_mirror\_ras\_mode  
 2.3.11 show partition memory\_operation\_mode  
 2.3.12 show partition pci\_address\_mode  
 2.3.13 show timezone  
 2.3.14 show gateway  
 2.3.15 show gateway\_ipv6  
 2.3.16 show http  
 2.3.17 show http\_port  
 2.3.18 show https  
 2.3.19 show https\_port  
 2.3.20 show ip  
 2.3.21 show ipv6  
 2.3.22 show hostname  
 2.3.23 show maintenance\_ip  
 2.3.24 show ssh  
 2.3.25 show ssh\_port  
 2.3.26 show telnet  
 2.3.27 show telnet\_port  
 2.3.28 show network  
 2.3.29 show ntpq  
 2.3.30 who  
 2.3.31 help  
 2.3.32 netck traceroute  
 2.3.33 netck arptbl  
 2.3.34 netck arping  
 2.3.35 netck ifconfig  
 2.3.36 netck stat  
 2.3.37 show dynamic\_partitioning status

### 2.3.1 show access\_control

Setting value of current access control is displayed.

- **Privilege: Administrator**

(1) Input format

```
show access_control
```

(2) Option  
None

(3) Usage example  
# Administrator> show access\_control  
SSH: All  
Telnet:All  
HTTP:  
HTTPS:IP Address: 10.66.250.190: Netmask: 255.255.255.0  
SNMP: All  
#

(4) Message  
The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

```
The specified command is invalid
```

## 2.3.2 show active\_mmb

Displays current Active MMB.

- **Privilege: All**

(1) Input format

```
show active_mmb
```

(2) Option  
None

(3) Usage example  
#show active\_mmb  
SSH: AI Active MMB: 11  
#

(4) Message  
None

## 2.3.3 show date

Displays current date and time.

- **Privilege: All**

(1) Input format

`show date`

(2) Option  
None

(3) Usage example  
#show date  
2009-11-30 11:14:21 JST  
#

(4) Message  
None

## 2.3.4 show exit\_code

Displays the exit code of last execution command.

### ■ Privilege: All

(1) Input format

`show exit_code`

(2) Option  
None

(3) Usage example  
#power on all  
#  
#show exit\_code  
0  
#

(4) Message  
None

## 2.3.5 show partition configuration

Displays the SB and IOU included in the partition.

Output Format:

Information related to one partition is displayed in one line.  
Display contents of each row are as follows.

1st row: Partition number  
2nd row: Partition name  
3rd row: Home SB (Display in the format of SB#x)

The above mentioned rows are displayed in the ascending order of numbers in the SB, IOU.  
The Reserved SB is displayed as RSB#x, with "R" in front of SB # x.

### ■ Privilege: All

## (1) Input format

```
show partition configuration [all | free | <partition#> {[ , | -] ¥
<partition#>}]
```

¥: Indicates that there is no line feed.

## (2) Option

all: Displays SB/IOU which does not belong to all partitions and to any partition.

free: Displays SB/IOU which does not belong to any partition.

<partition#>: Displays the specified partition.

The specification method when multiple partitions are specified is as follows.

- The partition number is delimited by a comma and is specified.
- Partition number is specified within the range

**Remarks**

Specifications of comma-delimited and number range of can be mixed.

## (3) Usage example

- Example: When configuration information of partition of partition number 0~2 with PRIMEQUEST 2800E is displayed  
# show partition configuration 0-2

```
0 hogehoge      SB#0   SB#0   RSB#3   IOU#0
1 testserver    SB#1   SB#1   IOU#0
2               SB#2   SB#2   IOU#1
#
```

- Example: When all the specifications for the configuration which are the same as the above-mentioned are used  
# show partition configuration all

```
0 hogehoge      SB#0   SB#0   RSB#3   IOU#0
1 testserver    SB#1   SB#1   IOU#1
2               SB#2   SB#2   IOU#2
3 <Since nothing is registered, it is displayed as blank>
free            IOU#3
#
```

## (4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified partition number is invalid.
The specified parameter is invalid.
Unable to execute this command on a standby MMB.
Failed to execute show partition configuration command.

## 2.3.6 show partition dynamic\_partitioning

Displays the status of Dynamic Reconfiguration of the specified partition..

- **Privilege: All**

## (1) Input format

show partition dynamic_partitioning <partition#>
--

## (2) Option

None

## (3) Usage example

- Example: When the status of Dynamic Reconfiguration of Partition#3 is displayed

```
# show partition dynamic_partitioning 3
current: disabled
setting: enabled
#
```

## (4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified partition number is invalid.
The specified parameter is invalid.
Unable to execute this command on a standby MMB.
Failed to execute show partition dynamic_partitioning command.
DP can't be enabled, because of no DP license

## 2.3.7 show partition home

Displays Home SB of the specified partition.

### ■ Privilege: All

## (1) Input format

show partition home <partition#>
----------------------------------

## (2) Option

None

## (3) Usage example

When Home SB of partition 3 is displayed

```
#show partition home 3
SB#2
#
```

## (4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified partition number is invalid.
The specified parameter is invalid.
Unable to execute this command on a standby MMB.
Home SB is not set in Partition#x.
Failed to execute show partition home command.
Partition#x is not defined.



### 2.3.8 show partition lan\_device\_mode

Displays the setting (enable/disable) of LAN Device/WOL in IOU unit of the specified partition.

■ **Privilege: All**

(1) Input format

show partition lan_devoce_mode <partition#>
---

(2) Option  
None

(3) Usage example  
· Example: When LAN Device Mode of IOU (In example it is IOU#2 or IOU#3) from Partition#3 is displayed  
#show partition lan\_device\_mode 3  
iou#2: LAN Device: enable WOL: enable  
iou#3:LAN Device: disable WOL: disable  
#

(4) Message  
The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified partition number is invalid.
The specified parameter is invalid.
Unable to execute this command on a standby MMB.
Failed to execute %s command.
Failed to execute show partition command.

### 2.3.9 show partition name

Displays the name of the specified partition.

■ **Privilege: All**

(1) Input format

show partition name <partition#>
----------------------------------

(2) Option  
None

(3) Usage example  
When name of the partition 3 is displayed  
#show partition name 3  
hogehoge  
#

(4) Message  
The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified partition number is invalid.
The specified parameter is invalid.
Unable to execute this command on a standby MMB.
Failed to show partition name command.

### 2.3.10 show partition memory\_mirror\_ras\_mode

Displays Memory Mirror RAS Mode of the specified partition.

mirror\_keep: Sets the Mirror Keep Mode.  
capacity\_keep: Sets the Capacity Keep mode.

#### ■ Privilege: All

(1) Input format

show partition memory_mirror_ras_mode <partition#>
--

(2) Option  
None

(3) Usage example  
· Example: When Memory Mirror RAS Mode of partition 3 is displayed  
  #show partition memory\_mirror\_ras\_mode3  
  current: mirror\_keep  
  setting: capacity\_keep  
  #

(4) Message  
The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified partition number is invalid.
The specified parameter is invalid.
Unable to execute this command on a standby MMB.
Failed to execute %s command.
Failed to execute show partition command.
Partition#x is not defined.

### 2.3.11 show partition memory\_operation\_mode

Displays the Memory Operation Mode of the specified partition.

performance:	Shows the Performance Mode
normal:	Shows the Normal Mode
partial_mirror:	Shows the Partial Mirror Mode
full_mirror:	Shows the Full Mirror Mode
spare:	Shows Spare Mode.

#### ■ Privilege: All

(1) Input format

show partition memory_operation_mode <partition#>
---

(2) Option  
None

(3) Usage example  
· Example: When Memory Operation Mode of partition#3 is displayed  
  #show partition memory\_operation\_mode3  
  current: normal  
  setting: performance  
  #

(4) Message  
The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified partition number is invalid.
The specified parameter is invalid.
Unable to execute this command on a standby MMB.
Failed to execute %s command.
Failed to execute show partition command.
Partition#x is not defined.

## 2.3.12 show partition pci\_address\_mode

Displays the PCI Address Mode of the specified partition.

### ■ Privilege: All

(1) Input format

show partition pci_address_mode <partition#>
--

(2) Option  
None

(3) Usage example  
· Example: When PCI Address Mode of partition#3 is displayed  
  #show partition pci\_address\_mode 3  
  current: bus  
  setting: segment  
  #

(4) Message  
The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified partition number is invalid.
The specified parameter is invalid.
Unable to execute this command on a standby MMB.
Failed to execute %s command.
Failed to execute show partition command.
Partition#x is not defined.

### 2.3.13 show timezone

Displays timezone.

- **Privilege: All**

(1) Input format

```
show timezone
```

(2) Option  
None

(3) Usage example  
#show timezone  
Timezone is set to Asia/Tokyo  
#

(4) Message  
None

### 2.3.14 show gateway

Displays the IP address of default gateway set to the Management LAN Interface.

- **Privilege: All**

(1) Input format

```
show gateway
```

(2) Option  
None

(3) Usage example  
# show gateway  
Gateway Address: 10.1.2.1  
#

(4) Message  
None

### 2.3.15 show gateway\_ipv6

Displays the IP address of default gateway of IPv6 set to the Management LAN Interface.

- **Privilege: All**

(1) Input format

```
show gateway_ipv6
```

(2) Option

None

(3) Usage example  
# show gateway\_ipv6  
Gateway Address: fe80:: 1234:f3ff:fe03:5666  
#

(4) Message  
None

## 2.3.16 show http

Displays the status (enable/ disable) of current HTTP.

- **Privilege: All**

(1) Input format

show http

(2) Option  
None

(3) Usage example  
# show http  
HTTP: disabled  
#

(4) Message  
None

## 2.3.17 show http\_port

Displays the port to which HTTP session is currently connected.

- **Privilege: All**

(1) Input format

show http\_port

(2) Option  
None

(3) Usage example  
#show http\_port  
HTTP Port Number: 8081  
#

(4) Message  
None

### 2.3.18 show https

Displays the status (enable/ disable) of current HTTPS server.

- **Privilege: All**

(1) Input format

```
show https
```

(2) Option  
None

(3) Usage example  
#show https  
HTTPS: disabled  
#

(4) Message  
None

### 2.3.19 show https\_port

Displays the port to which HTTPS is currently connected.

- **Privilege: All**

(1) Input format

```
show https_port
```

(2) Option  
None

(3) Usage example  
# show https\_port  
HTTPS Port Number: 432  
#

(4) Message  
None

### 2.3.20 show ip

Displays the IP address, the net mask set in the management LAN interface.

- **Privilege: All**

(1) Input format

```
show ip
```

(2) Option

None

(3) Usage example  
# show ip  
IP Address: 10.1.2.124  
Netmask: 255.255.255.0  
#

(4) Message  
None

### 2.3.21 show ipv6

Displays the global address, the prefix length for IPv6 set in the management LAN interface.

- **Privilege: All**

(1) Input format

show ipv6

(2) Option  
None

(3) Usage example  
# show ipv6  
IP Address/Prefix: 2000:2002:2003:2004:2005:2006:2007:2008/64  
#

(4) Message  
None

### 2.3.22 show hostname

Displays host name of MMB.

- **Privilege: All**

(1) Input format

show hostname

(2) Option  
None

(3) Usage example  
# show hostname  
hogehoge.fujitsu.com  
#

(4) Message  
None

### 2.3.23 show maintenance\_ip

Displays the IP address of Maintenance port

- **Privilege: All**

(1) Input format

```
show maintenance_ip
```

(2) Option  
None

(3) Usage example  
# show maintenance\_ip  
IP Address: 192.168.1.10  
NetMask: 255.255.255.0  
Gateway Address: 192.168.1.1  
SMTP Address: 172.128.1.2  
#

(4) Message  
None

### 2.3.24 show ssh

Displays the status (enable/disable) of existing SSH server.

- **Privilege: All**

(1) Input format

```
show ssh
```

(2) Option  
None

(3) Usage example  
# show ssh  
SSH: disabled  
#

(4) Message  
None

### 2.3.25 show ssh\_port

Displays the port where SSH session is currently connected.

- **Privilege: All**

(1) Input format



```
show ssh_port
```

(2) Option  
None

(3) Usage example  
# show ssh\_port  
SSH Port Number: 22  
#

(4) Message  
None

## 2.3.26 show telnet

Displays the status (enable/disable) of existing Telnet server.

### ■ Privilege: All

(1) Input format

```
show telnet
```

(2) Option  
None

(3) Usage example  
# show telnet  
Telnet: disabled  
#

(4) Message  
None

## 2.3.27 show telnet\_port

Displays the port to which the Telnet session is currently connected.

### ■ Privilege: All

(1) Input format

```
show telnet_port
```

(2) Option  
None

(3) Usage example  
# show telnet\_port  
Telnet Port Number: 23  
#

(4) Message  
None

## 2.3.28 show network

Displays the network configuration configured in management LAN interface. Also displays IPv6 information when IPv6 is configured.

Displays the following information.

- Hostname
- IP Address
- Netmask
- Gateway Address
- IPv6 IP Address /Prefix length
- IPv6 Gateway Address
- MAC Address
- HTTP status
- HTTP Port Number
- HTTPS status
- HTTPS Port Number
- Telnet status
- Telnet Port Number
- SSH status
- SSH Port Number

### ■ Privilege: All

(1) Input format

`show telnet_port`

(2) Option

None

(3) Usage example

# show network

Hostname:hogehoge.fujitsu.com

IP Address:10.1.2.124

Netmask:255.255.255.0

Gateway Address: 10.1.2.1

IPv6 IP Address/Prefix: 2000:2002:2003:2004:2005:2006:2007:2008/64

IPv6 Gateway Address: fe80::1234:f3ff:fe03:5555

MAC Address:00:AA:00:12:34:55

HTTP:disabled

HTTP Port Number:8081

HTTPS:disabled

HTTPS Port Number:432

Telnet:disabled

Telnet Port Number:23

SSH:enabled

SSH Port Number:22

#

(4) Message

None

## 2.3.29 show ntpq

Displays the operating conditions of ntp.

### Remarks

Support of IPv4, IPv6

### ■ Privilege: All

(1) Input format

```
show ntpq
```

(2) Option

None

(3) Usage example

```
# show ntpq
```

```

remote      refid          st t    when    poll    reach    delay    offset    jitter
=====
*10.23.4.3   10.0.50.32     4 u    882     1024    377     0.941    -0.154    0.284
10.49.51.3   .INIT.         16 u    -        1024    0        0.000     0.000     0.000
LOCAL(0)     .LOCL.         5 l    23h     64      0        0.000     0.000     0.000
#
```

TABLE 2.8 Output Items of show ntpq

Item	Description
Symbols on the top of remote	Meanings of the symbols displayed on the top of a remote are listed below. Blank: reject. It is not referred when request is not attained or the distance is far (the period for to-fro communication to server is more than 16 seconds). x: false tick. The time, acquired from all other remote servers registered in MMB, deviates (The value of jitter is deviated more than the allowance range of deviation) as compared to the time acquired from more than two remotes. Therefore, it was excluded from the reference list. False tick cannot be detected when all the clocks are off. -: outlier. It is not referred because jitter value of this remote is greater than offset of remote during the current synchronization +: candidate. Can be synchronized any time. #: selected. It is possible to synchronize but as the distance is far (the to-fro communication period of the server is more than 1 second), it is departed from candidate. *: sys.peer. Synchronizing.
remote	Host name ("LOCAL" indicates MMB) referred as NTP Server (Server providing internal clock to other computers through ntp protocol).
refid	Indicates from where remote synchronizes the time. When it is not clear, 0.0.0.0.
st	A number showing the level of server. Generally, as this number gets larger, the reliability of time gets declined.
t	Type of remote server 1: Local server. Acquisition of internal clock of MMB (This type is considered only when remote is LOCAL). u: Unicast server. Executes time request for the remote from MMB and acquires the transmitted time.
when	Elapsed time from the time when packet is received for the last time from remote. (Unit: seconds).
poll	Interval to acquire time from remote (Unit: seconds).
reach	Flag of failure and success of time acquisition of past 8 times. (Octal numeral expression).

	The result of failure and success of time acquisition of past eight times is expressed in 8 bits (0: Failure, 1: Success) and it is octal numeral expression. Whenever time is acquired, bits are shifted to the left, the right most bit is the latest result of acquisition. For example, when this value is 356(8) =11, 101, 110(2), the latest acquisition among past eight acquisition results and fourth acquisition failed. If the next time acquisition succeeds, the value becomes 335(8) =11, 011, 101 (2).
delay	Communication time (Unit: milliseconds) pertaining to the network round trip for remote communication.
offset	Time deviation between a remote clock and an internal clock (Unit: milliseconds)
jitter	The error is generated due to the time which is an addition of previously acquired time and interval of poll, and error value of latest time which is actually acquired (Unit: milliseconds), accuracy of respective clocks and the network condition.

## (4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified parameter is invalid.
Unable to execute this command on a standby MMB.
Failed to ntpg command.

## 2.3.30 who

Displays the following information regarding the user logged in the current MMB.

- Login name
- Login time
- Remote host name (or, IP address of remote host)  
Displays remote host name when the remote host name is recognized by DNS configured in MMB at the time of login. Displays IP address when remote host name is not recognized. Moreover, "-" (Hyphen) is displayed when the user logs in from the serial port.  
Displays whether the user is connected to the Telnet/SSH, or to the Web-UI, or whether connected to the serial port.

### Remarks

Support of IPv4, IPv6

### ■ Privilege: All

#### (1) Input format

who
-----

#### (2) Option None

#### (3) Usage example

```
# who
Suzuki      2012-11-08 10:35:51 Telnet/SSH 10.24.6.94
takahashi   2012-11-08 10:38:02 Telnet/SSH 2001:2345::3dfb:dc43:4d75:5a71
tanaka      2012-11-08 10:34:26 WebUI 10.24.6.191
#
```

## (4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

Failed to get login information.
----------------------------------

## 2.3.31 help

Displays the help of enabled command.

### ■ Privilege: All

## (1) Input format

help
------

## (2) Option

None

## (3) Usage example

**[When the PRIMEQUEST 2800B model]**

- Example 1: For the Administrator privilege
 

```
#help
factory_default {-f}
add partition <partition#> [ SB <SB#> | IOU <IOU#> ] {quiet}
clear access_control
power off {partition} [ all | <partition#>[,|-]<partition#> ] {force}
power on {partition} [ all | <partition#>[,|-]<partition#> ]
remove partition <partition#> [ SB <SB#> | IOU <IOU#> ] {quiet}
set active_mmb {0 | 1} {quiet}
set date MMDDhhmm{{CC}YY}{,ss}
set timezone <timezone>
set gateway <ip address>
set gateway_ipv6 [auto | <ip address>]
set [ http | https | ssh | telnet ] [ enable | disable ]
set [ http_port | https_port | ssh_port | telnet_port ] <port>
set partition home <partition#> SB <SB#>
set partition name <partition#> <partition name>
set partition dynamic_partitioning <partition#> [disable | enable] {quiet}
set partition memory_operation_mode <partition#> [performance | normal | partial_mirror | spare]
{quiet}
set partition memory_mirror_ras_mode <partition#> [mirror_keep | capacity_keep] {quiet}
set partition pci_address_mode <partition#> [bus | segment] {quiet}
set partition pci_express_mode <partition#> [ flexible | fixed ]
set partition lan_device_mode <partition#> <IOU#> [wol_enable | wol_disable | device_disable] {quiet}
set ip <ip address> <netmask>
set ipv6 [auto | <ip address>/<prefix>]
set hostname <hostname>.<domain name>
set maintenance_ip <ip address> <netmask> <gateway address> <smtp address>
set sysconf power_feed_mode [single | dual] {quiet}
set sysconf power_restoration_policy [on | off | restore | sync] {quiet}
set sysconf power_on_delay <time> {quiet}
set sysconf altitude <altitude>
set sysconf psu_redundant_mode [redundant | non_redundant] {quiet}
set mmbcontrol reset [0 | 1] {quiet}
set mmbcontrol switch_over {quiet}
set reserved_sb <SB#> <partition#> {quiet}
```

```

set snmp sys_location <location> {quiet}
set snmp sys_contact <concat> {quiet}
set snmp community <community> <ip or mask> [1 | 2] [ro | rw] {quiet}
set snmp trap <community> <ip> [1 | 2] {quiet}
set snmp test_trap {quiet} show [access_control | active_mmb | date | timezone | gateway | gateway
ipv6 |
    http | http_port | https | https_port | ssh | ssh_port | telnet |
    telnet_port | ip | ipv6 | hostname | network | maintenance_ip | ntpq |
    sysconf power_feed_mode | sysconf power_restoration_policy |
    sysconf power_on_delay | sysconf altitude | sysconf psu_redundant_mode |
    sysconf input_voltage | reserved_sb | user_list |
update_status | firmware_version | exit_code |
    snmp sys_location | snmp sys_contact | snmp community | snmp trap]
show partition configuration [ all | free | <partition#>{[, | -]<partition#>}]
show partition [home | name | dynamic_partitioning | memory_operation_mode |
    memory_mirror_ras_mode | pci_address_mode |
    pci_express_mode | lan_device_mode] <partition#> add user <user name> <password>
<confirm password> [admin | operator | user | ce | partition_operator] {all | <partition#>{[, | -
]<partition#>}} {quiet}
netck [arptbl | ifconfig | stat | traceroute <ip> | arping <ip>]
console <partition#> {<timeout>} {quiet}
update ALL <url> {force} {quiet}
nmi {partition} [ <partition#> [, | -] <partition#>] {quiet}
reset {partition} [ <partition#> [, | -] <partition#>] {quiet}
sadump {partition} [ <partition#> [, | -] <partition#>] {quiet}
exit
passwd {USER}
ping {-c <count>} [<ip address> | <server name>]
who
help
#

```

- Example 2: For CE privilege

```

#help
factory_default {-f} set active_mmb {0 | 1} {quiet}
set maintenance_ip <ip address> <netmask> <gateway address> <smtp address>
set sysconf power_feed_mode [single | dual] {quiet}
set sysconf power_restoration_policy [on | off | restore | sync] {quiet}
set sysconf power_on_delay <time> {quiet}
set sysconf altitude <altitude>
set sysconf psu_redundant_mode [redundant | non_redundant] {quiet} show [active_mmb | date |
timezone | gateway | gateway_ipv6 | http | http_port |
    https | https_port | ssh | ssh_port | telnet | telnet_port | ip | ipv6 |
    hostname | network | maintenance_ip | ntpq |
    update_status | firmware_version | exit_code |
    sysconf power_feed_mode | sysconf power_restoration_policy |
    sysconf power_on_delay | sysconf altitude | sysconf psu_redundant_mode |
    sysconf input_voltage] show partition configuration [ all | free | <partition#>{[, | -] <partition#>}]
show partition [home | name | dynamic_partitioning | memory_operation_mode |
    memory_mirror_ras_mode | pci_address_mode |
    pci_express_mode | lan_device_mode] <partition#> netck [arptbl | ifconfig | stat | traceroute
<ip> | arping <ip>]
update ALL <url> {force} {quiet} exit
passwd {USER}
ping {-c <count>} [<ip address> | <server name>]
who
help
#

```

- Example 3: For Operator privilege

```

#help
power off {partition} [ all | <partition#>[,| -]<partition#>] {force}
power on {partition} [ all | <partition#>[,| -]<partition#>] set partition dynamic_partitioning <partition#>
[disable | enable] {quiet}

```

```

set partition memory_operation_mode <partition#> [performance | normal | partial_mirror | spare]
{quiet}
set partition memory_mirror_ras_mode <partition#> [mirror_keep | capacity_keep] {quiet}
set partition pci_address_mode <partition#> [bus | segment] {quiet}
set partition pci_express_mode <partition#> [flexible | fixed]
set partition lan_device_mode <partition#> <IOU#> [wol_enable | wol_disable | device_disable] {quiet}
show [active_mmb | date | timezone | gateway | gateway_ipv6 | http | http_port |
      https | https_port | ssh | ssh_port | telnet | telnet_port | ip | ipv6 |
      hostname | network | maintenance_ip | ntpq |
      sysconf power_feed_mode | sysconf power_restoration_policy |
      sysconf power_on_delay | sysconf altitude | sysconf psu_redundant_mode |
      sysconf input_voltage | reserved_sb | exit_code] show partition configuration [ all | free |
<partition#> {[, | -] <partition#>}]
show partition [home | name | dynamic_partitioning | memory_operation_mode |
               memory_mirror_ras_mode | pci_address_mode |
               pci_express_mode | lan_device_mode] <partition#> netck [arptbl | ifconfig | stat | traceroute
<ip> | arping <ip>] nmi {partition} [ <partition#> [, | -] <partition#>] {quiet}
reset {partition} [ <partition#> [, | -] <partition#>] {quiet}
sadump {partition} [ <partition#> [, | -] <partition#>] {quiet} exit
passwd {USER}
ping {-c <count>} [<ip address> | <server name>]
who
help
#

```

- Example 4: For User privilege

```

#help
clear ssh_key
download ssh_key <url> show [active_mmb | date | timezone | gateway | gateway_ipv6 | http |
http_port |
      https | https_port | ssh | ssh_port | telnet | telnet_port | ip | ipv6 |
      hostname | network | maintenance_ip | ntpq |
      sysconf power_feed_mode | sysconf power_restoration_policy |
      sysconf power_on_delay | sysconf altitude | sysconf psu_redundant_mode |
      sysconf input_voltage | reserved_sb | show exit_code]
show partition configuration [ all | free | <partition#> {[, | -] <partition#>}]
show partition [home | name | dynamic_partitioning | memory_operation_mode |
               memory_mirror_ras_mode | pci_address_mode |
               pci_express_mode | lan_device_mode] <partition#>
netck [arptbl | ifconfig | stat | traceroute <ip> | arping <ip>] exit
passwd {USER}
ping {-c <count>} [<ip address> | <server name>]
who
help
#

```

- Example 5: For Partition Operator privilege

```

#help
power off {partition} [ all | <partition#>[, | -]<partition#>] {force}
power on {partition} [ all | <partition#>[, | -]<partition#>] set partition dynamic_partitioning <partition#>
[disable | enable] {quiet}
set partition memory_operation_mode <partition#> [performance | normal | partial_mirror | spare]
{quiet}
set partition memory_mirror_ras_mode <partition#> [mirror_keep | capacity_keep] {quiet}
set partition pci_address_mode <partition#> [bus | segment] {quiet}
set partition pci_express_mode <partition#> [flexible | fixed]
set partition lan_device_mode <partition#> <IOU#> [wol_enable | wol_disable | device_disable] {quiet}
timezone | gateway | gateway_ipv6 | http | http_port |
      https | https_port | ssh | ssh_port | telnet | telnet_port | ip | ipv6 |
      hostname | network | maintenance_ip | ntpq |
      sysconf power_feed_mode | sysconf power_restoration_policy |
      sysconf power_on_delay | sysconf altitude | sysconf psu_redundant_mode |
      sysconf input_voltage | reserved_sb | exit_code]
show partition configuration [ all | free | <partition#> {[, | -] <partition#>}]
show partition [home | name | dynamic_partitioning | memory_operation_mode |

```

```

memory_mirror_ras_mode | pci_address_mode |
pci_express_mode | lan_device_mode] <partition#>
netck [arptbl | ifconfig | stat | traceroute <ip> | arping <ip>]
console <partition#> {<timeout>} {quiet} nmi {partition} [ <partition#> [, | -] <partition#>] {quiet}
reset {partition} [ <partition#> [, | -] <partition#>] {quiet}
sadump {partition} [ <partition#> [, | -] <partition#>] {quiet} exit
passwd {USER}
ping {-c <count>} [<ip address> | <server name>]
who
help
#

```

**[When the PRIMEQUEST 2800E model]**

- Example 1: For the Administrator privilege

```

#help
factory_default {-f}
add partition <partition#> [ SB <SB#> | IOU <IOU#> ] {quiet}
clear access_control
power off {partition} [ all | <partition#>[,| -]<partition#>] {force}
power on {partition} [ all | <partition#>[,| -]<partition#>]
remove partition <partition#> [ SB <SB#> | IOU <IOU#>] {quiet}
set active_mmb {0 | 1} {quiet}
set date MMDDhhmm{{CC}YY}{,ss}
set timezone <timezone>
set gateway <ip address>
set gateway_ipv6 [auto | <ip address>]
set [ http | https | ssh | telnet ] [ enable | disable ]
set [ http_port | https_port | ssh_port | telnet_port ] <port>
set partition home <partition#> SB <SB#>
set partition name <partition#> <partition name>
set partition dynamic_partitioning <partition#> [disable | enable] {quiet}
set partition memory_operation_mode <partition#> [performance | normal | partial_mirror | spare]
{quiet}
set partition memory_mirror_ras_mode <partition#> [mirror_keep | capacity_keep] {quiet}
set partition pci_address_mode <partition#> [bus | segment] {quiet}
set partition pci_express_mode <partition#> [ flexible | fixed ]
set partition lan_device_mode <partition#> <IOU#> [wol_enable | wol_disable | device_disable] {quiet}
set ip <ip address> <netmask>
set ipv6 [auto | <ip address>/<prefix>]
set hostname <hostname>.<domain name>
set maintenance_ip <ip address> <netmask> <gateway address> <smtp address>
set sysconf power_feed_mode [single | dual] {quiet}
set sysconf power_restoration_policy [on | off | restore | sync] {quiet}
set sysconf power_on_delay <time> {quiet}
set sysconf altitude <altitude>
set sysconf psu_redundant_mode [redundant | non_redundant] {quiet}
set mmbcontrol reset [0 | 1] {quiet}
set mmbcontrol switch_over {quiet}
set reserved_sb <SB#> <partition#> {quiet}
set snmp sys_location <location> {quiet}
set snmp sys_contact <concat> {quiet}
set snmp community <community> <ip or mask> [1 | 2] [ro | rw] {quiet}
set snmp trap <community> <ip> [1 | 2] {quiet}
set snmp test_trap {quiet} show [access_control | active_mmb | date | timezone | gateway | gateway
ipv6 |
http | http_port | https | https_port | ssh | ssh_port | telnet |
telnet_port | ip | ipv6 | hostname | network | maintenance_ip | ntpq |
sysconf power_feed_mode | sysconf power_restoration_policy |
sysconf power_on_delay | sysconf altitude | sysconf psu_redundant_mode |
sysconf input_voltage | reserved_sb | user_list |
update_status | firmware_version | exit_code |
snmp sys_location | snmp sys_contact | snmp community | snmp trap]
show partition configuration [ all | free | <partition#>[,| -]<partition#>]
show partition [home | name | dynamic_partitioning | memory_operation_mode |
memory_mirror_ras_mode | pci_address_mode |

```



```
pci_express_mode | lan_device_mode] <partition#>
netck [arptbl | ifconfig | stat | traceroute <ip> | arping <ip>]
console <partition#> {<timeout>} {quiet}
update ALL <url> {force} {quiet}
nmi {partition} [ <partition#> [, | -] <partition#>] {quiet}
reset {partition} [ <partition#> [, | -] <partition#>] {quiet}
sadump {partition} [ <partition#> [, | -] <partition#>] {quiet}
exit
passwd {USER}
ping {-c <count>} [<ip address> | <server name>]
who
help
#
```

- Example 2: For CE privilege

```
#help
factory_default {-f} set active_mmb {0 | 1} {quiet}
set maintenance_ip <ip address> <netmask> <gateway address> <smtp address>
set sysconf power_feed_mode [single | dual] {quiet}
set sysconf power_restoration_policy [on | off | restore | sync] {quiet}
set sysconf power_on_delay <time> {quiet}
set sysconf altitude <altitude>
set sysconf psu_redundant_mode [redundant | non_redundant] {quiet} show [active_mmb | date |
timezone | gateway | gateway_ipv6 | http | http_port |
https | https_port | ssh | ssh_port | telnet | telnet_port | ip | ipv6 |
hostname | network | maintenance_ip | ntpq |
update_status | firmware_version | exit_code |
sysconf power_feed_mode | sysconf power_restoration_policy |
sysconf power_on_delay | sysconf altitude | sysconf psu_redundant_mode |
sysconf input_voltage] show partition configuration [ all | free | <partition#>{[, | -] <partition#>}]
show partition [home | name | dynamic_partitioning | memory_operation_mode |
memory_mirror_ras_mode | pci_address_mode |
pci_express_mode | lan_device_mode] <partition#>
netck [arptbl | ifconfig | stat | traceroute <ip> | arping <ip>]
update ALL <url> {force} {quiet} exit
passwd {USER}
ping {-c <count>} [<ip address> | <server name>]
who
help
#
```

- Example 3: For Operator privilege

```
#help
power off {partition} [ all | <partition#>[,| -]<partition#>] {force}
power on {partition} [ all | <partition#>[,| -]<partition#>] set partition dynamic_partitioning <partition#>
[disable | enable] {quiet}
set partition memory_operation_mode <partition#> [performance | normal | partial_mirror | spare]
{quiet}
set partition memory_mirror_ras_mode <partition#> [mirror_keep | capacity_keep] {quiet}
set partition pci_address_mode <partition#> [bus | segment] {quiet}
set partition pci_express_mode <partition#> [flexible | fixed]
set partition lan_device_mode <partition#> <IOU#> [wol_enable | wol_disable | device_disable] {quiet}
timezone | gateway | gateway_ipv6 | http | http_port |
https | https_port | ssh | ssh_port | telnet | telnet_port | ip | ipv6 |
hostname | network | maintenance_ip | ntpq |
sysconf power_feed_mode | sysconf power_restoration_policy |
sysconf power_on_delay | sysconf altitude | sysconf psu_redundant_mode |
sysconf input_voltage | reserved_sb | exit_code] show partition configuration [ all | free |
<partition#> {[, | -] <partition#>}]
show partition [home | name | dynamic_partitioning | memory_operation_mode |
memory_mirror_ras_mode | pci_address_mode |
pci_express_mode | lan_device_mode] <partition#>
show xpar partition configuration [all | free | <partition#> {[, | -] <partition#>}]
netck [arptbl | ifconfig | stat | traceroute <ip> | arping <ip>] nmi {partition} [ <partition#> [, | -]
<partition#>] {quiet}
```

```
console <partition#> {<timeout>} {quiet}
reset {partition} [ <partition#> [, | -] <partition#>] {quiet}
sadump {partition} [ <partition#> [, | -] <partition#>] {quiet} exit
passwd {USER}
ping {-c <count>} [<ip address> | <server name>]
who
help
#
```

- Example 4: For User privilege

```
#help
clear ssh_key
download ssh_key <url> show [active_mmb | date | timezone | gateway | gateway_ipv6 | http |
http_port |
https | https_port | ssh | ssh_port | telnet | telnet_port | ip | ipv6 |
hostname | network | maintenance_ip | ntpq |
sysconf power_feed_mode | sysconf power_restoration_policy |
sysconf power_on_delay | sysconf altitude | sysconf psu_redundant_mode |
sysconf input_voltage | reserved_sb | show exit_code]
show partition configuration [ all | free | <partition#> {[, | -] <partition#>}]
show partition [home | name | dynamic_partitioning | memory_operation_mode |
memory_mirror_ras_mode | pci_address_mode |
pci_express_mode | lan_device_mode] <partition#>
netck [arptbl | ifconfig | stat | traceroute <ip> | arping <ip>] exit
passwd {USER}
ping {-c <count>} [<ip address> | <server name>]
who
help
#
```

- Example 5: For Partition Operator privilege

```
#help
power off {partition} [ all | <partition#>[,| -]<partition#>] {force}
power on {partition} [ all | <partition#>[,| -]<partition#>] set partition dynamic_partitioning <partition#>
[disable | enable] {quiet}
set partition memory_operation_mode <partition#> [performance | normal | partial_mirror | spare]
{quiet}
set partition memory_mirror_ras_mode <partition#> [mirror_keep | capacity_keep] {quiet}
set partition pci_address_mode <partition#> [bus | segment] {quiet}
set partition pci_express_mode <partition#> [flexible | fixed]
set partition lan_device_mode <partition#> <IOU#> [wol_enable| wol_disable | device_disable] {quiet}
timezone | gateway | gateway_ipv6 | http | http_port |
https | https_port | ssh | ssh_port | telnet | telnet_port | ip | ipv6 |
hostname | network | maintenance_ip | ntpq |
sysconf power_feed_mode | sysconf power_restoration_policy |
sysconf power_on_delay | sysconf altitude | sysconf psu_redundant_mode |
sysconf input_voltage | reserved_sb | exit_code]
show partition configuration [ all | free | <partition#> {[, | -] <partition#>}]
show partition [home | name | dynamic_partitioning | memory_operation_mode |
memory_mirror_ras_mode | pci_address_mode |
pci_express_mode | lan_device_mode] <partition#>
netck [arptbl | ifconfig | stat | traceroute <ip> | arping <ip>]
console <partition#> {<timeout>} {quiet} nmi {partition} [ <partition#> [, | -] <partition#>] {quiet}
reset {partition} [ <partition#> [, | -] <partition#>] {quiet}
sadump {partition} [ <partition#> [, | -] <partition#>] {quiet} exit
passwd {USER}
ping {-c <count>} [<ip address> | <server name>]
who
help
#
```

(4) Message  
None

## 2.3.32 netck traceroute

The network route from the specified IP address to the target host is displayed in the list.

### Remarks

Support only IPv4.

### ■ Privilege: All

(1) Input format

```
netck traceroute <ip>
```

(2) Option  
None

(3) Usage example  
# netck traceroute 10.2.3.4  
traceroute to 10.2.3.4 (10.2.3.4), 30 hops max, 40 byte packets  
1 10.2.4.1 (10.2.4.1) 0.822 ms 5.142 ms 0.59 ms  
2 10.2.5.1 (10.2.5.1) 0.923 ms 0.747 ms 0.679 ms  
3 10.2.6.1 (10.2.6.1) 0.955 ms 0.736 ms 0.71 ms  
4 10.3.2.1 (10.3.2.1) 1.023 ms 0.861 ms 0.837 ms  
5 10.3.2.2 (10.3.2.2) 1.049 ms 0.939 ms 0.887 ms  
6 10.2.3.5 (10.2.3.5) 1.285 ms 1.005 ms 0.997 ms  
7 10.2.3.4 (10.2.3.4) 0.976 ms 0.828 ms 0.891 ms  
#

(4) Message  
The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

```
The specified parameter is invalid.
```

(5) Process  
Executes "traceroute<ip>"

## 2.3.33 netck arptbl

Displays the physical address (MAC address) of the Ethernet from the specified IP address.

### ■ Privilege: All

(1) Input format

```
netck arptbl
```

(2) Option  
None

(3) Usage example  
# netck arptbl

IP address	HW type	Flags	HW address	Mask	Device
------------	---------	-------	------------	------	--------

```
10.1.2.3      0x1      0x2      00:21:A1:1A:32:45      *      bond0
#
```

(4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified parameter is invalid.
-------------------------------------

(5) Process

Displays only bond 0 of cat/proc/net/arp (Control LAN).

## 2.3.34 netck arping

Displays the physical address (MAC address) of the Ethernet from the specified IP address.

**Remarks**

Support only IPv4.

■ **Privilege: All**

(1) Input format

netck arping <ip>
-------------------

(2) Option

None

(3) Usage example

```
# netck arping 10.1.2.3
ARPING to 10.1.2.3 from 10.1.2.33 via bond0
Unicast reply from 10.1.2.3 [0:21:a1:1a:32:45] 1.253ms
Sent 1 probes (1 broadcast(s))
Received 1 reply
#
```

(4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified parameter is invalid.
-------------------------------------

(5) Process

Executes arping -I bond0 -c 1 <ip>

## 2.3.35 netck ifconfig

Displays the setting status of (IPv4 or IPv6) network environment.

■ **Privilege: All**

(1) Input format

```
netck ifconfig
```

(2) Option  
None

(3) Usage example  
#netck ifconfig  
bond0 Link encap:Ethernet HWaddr 00:17:42:9B:D9:78  
inet addr:10.24.77.80 Bcast:10.24.77.255 Mask:255.255.255.0  
inet6 addr:2001:2345::10/64 Scope: Global  
inet6 addr:fe80::217:42ff:fe9b:d978/64 Scope: Link  
UP BROADCAST RUNNING MASTER MULTICAST MTU:1500 Metric:1  
RX packets:4765 errors:0 dropped:0 overruns:0 frame:0  
TX packets:3438 errors:0 dropped:0 overruns:0 carrier:0  
collisions:0 txqueuelen:0  
RX bytes:637685 (622.7 KiB) TX bytes:1318710 (1.2 MiB)  
#

(4) Message  
The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

```
The specified parameter is invalid.
```

(5) Process  
Executes "ifconfig bond0"

## 2.3.36 netck stat

Displays the list of the port number which is used by the process during operation.

### ■ Privilege: All

(1) Input format

```
netck stat
```

(2) Option  
None

(3) Usage example  
#netck stat  
Active Internet connections (w/o servers)  

Proto	Recv-Q	Send-Q	Local Address	Foreign Address	State
tcp	0	0	PRIME123063:telnet	10.1.2.3:4015	TIME_WAIT

  
#

(4) Message  
The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

```
The specified parameter is invalid.
```

(5) Process  
Clears the internal information like Private-LAN etc. from netstat-tuwn.

## 2.3.37 show dynamic\_partitioning status

Displays the progress of Dynamic Reconfiguration

### ■ Privilege: All

(1) Input format

show dynamic_partitioning status
----------------------------------

(2) Option  
None

(3) Usage example  
· Example: When SB#3 is to be added to Partition#2  
  # show dynamic\_partitioning status  
  Adding SB#3 to Partition#2, running : 35%  
  #

(4) Message  
The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

Adding SB#%d to Partition#%d, completed
Adding IOU#%d to Partition#%d, completed
Removing SB#%d from Partition#%d, completed.
Removing IOU#%d from Partition#%d completed.
not executed.
The specified partition number is invalid.
The specified parameter is invalid.
Unable to execute this command on a standby MMB.
Failed to show dynamic_partitioning status command.
Adding SB#%d to Partition#%d,running xx%
Adding IOU#%d to Partition#%d,running xx%
Adding [SB#%d IOU#%d] to Partition#%d, Failed.
Removing SB#%d from Partition#%d,running xx%
Removing IOU#%d from Partition#%d,running xx%
Removing [SB#%d IOU#%d] from Partition#%d, Falied.

## 2.4 Update Command

Update Commands are as follows.

[2.4.1 Update ALL](#)

[2.4.2 show update\\_status](#)

This section describes operation procedure of these commands.

### 2.4.1 Update ALL

The update ALL command batch-downloads firmware from the specified URL and updates the MMB, BMC, and BIOS with the downloaded firmware.

Specify the URL as follows:

http://host/path/file  
ftp://host/path/file

The update sequence is as follows:

- (1) MMB firmware update (standby)
- (2) MMB firmware update (active)
- (3) BMC firmware update
- (4) BIOS firmware update

You can check the progress by using the show update\_status command.

#### Note

If the MMB or SB is faulty, perform maintenance on it before updating the firmware. Do not update the firmware in a configuration with a faulty MMB or SB.

#### ■ Privilege: Administrator or CE

- (1) Input format

```
update ALL <url> {force} {quiet}
```

- (2) Option

force: This option forcibly updates the firmware based on the applicable general firmware version.

quiet: This option updates the firmware without user interaction.

- (3) Usage example

```
# update ALL http://host/path/allfirm001
Downloading an unified firmware file.....
Extracting an unified firmware file.....
```

Current Unified Firmware Version: xxxxx

New Unified Firmware Version: yyyy

Are you sure to continue Firmware Update? [Y|N]: Y

#

- (4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

```
Are you sure to continue Firmware Update? [Y|N]:
```

The specified parameter is invalid
Unable to execute this command on a standby MMB.
Failed to get the firmware version.
The checksum of the firmware file is invalid.
The size of the firmware file is invalid.
The CRC of the firmware file is invalid.
Specified file is NOT a Firmware file.
Specified host does NOT respond.
Unable to execute the update under maintenance.
Current firmware is newer version.
Unable to execute the online update.
Please try the update after the system power off.
Unable to execute the update. TPM is effective.
Unable to execute the update. Standby MMB is fault or disable.
Unable to execute Firmware Update due to resource lock.
Please retry after waiting a while.
The firmware is being updated now.
The chassis information could not be retrieved.
The chassis information is invalid.

## (5) Process

MMB checks whether the firmware update of online is executable. When it is not possible to execute it, the error message is output and the update processing is interrupted.

The condition that firmware update of online becomes improper:

- MMB is an unredundant configuration.
  - There is no combination in the interchangeability table between the farm version numbers that can be updated firmware online.
- Without the force option specified:  
The general firmware version to be applied is compared with that in use. If the version to be applied is the same or older than that in use, the command does not update the firmware.  
Also, the versions of the individual firmware instances are checked. If the version to be applied is the same as that of a firmware instance, the command does not update the firmware instance. In other words, the command updates the firmware instance only if the versions are different.
- With the force option specified:  
The general firmware version to be applied is not compared with that in use. The command forcibly updates the current firmware with the applicable firmware version.  
The online firmware update cannot specify force for an option.

## 2.4.2 show update\_status

The show update\_status command displays the version of the firmware being batch-updated as well as the update progress.

The possible status is as follows:

- completed: Normal end
- failed: Abnormal end
- updating: Firmware update in progress (percentage displayed)
- being updated: Firmware update in progress (firmware being downloaded)
- not executed: Firmware update not started

### ■ Privilege: Administrator or CE

## (1) Input format

```
show update_status
```



(2) Option  
None

(3) Usage example  
#show update\_status  
Unified Firmware Version : BA13012, update status:updating 35%  
#

(4) Message  
The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

Unified Firmware Version : XX, update status:completed
Unified Firmware Version : XX, update status:not executed
Unable to execute this command on a standby MMB.
Failed to execute show update_status command.
Unified Firmware Version : XX, update status:being updated
Unified Firmware Version : XX, update status:updating YY%
Unified Firmware Version : XX, update status:failed

## 2.5 Other Commands

The following commands are not information configuration, display, or update commands:

[2.5.1 exit](#)  
[2.5.2 passwd](#)  
[2.5.3 ping](#)

This section describes how to use these commands.

### 2.5.1 exit

The exit command logs out the user.

#### ■ Privilege: All

(1) Input format

exit
------

(2) Option  
None

(3) Usage example  
None

(4) Message  
None

## 2.5.2 passwd

The passwd command changes the password of the specified user. Users without Administrator privileges can change only their own passwords. Users with Administrator privileges can change the password of any user.

If no user is specified, the command changes the password of the currently logged-in user.

For details on characters that can be entered and other conditions, see [TABLE 1.85 Setting and display items in the \[Add User\] and \[Edit User\] windows](#).

### ■ Privilege: All

(1) Input format

passwd {USER}
---------------

(2) Option

USER: This option sets the name of the user whose password is to be changed.

(3) Usage example

```
# passwd
Current password: *****
New password: *****
Re-enter new password: *****
Password changed.
#
```

(4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

This command cannot be executed on the standby MMB.
The specified parameter is invalid.
Password changed.
change passwd failed (code=0x%04x)
Could not set attributes
invalid passwd
password needs 8 characters at least
password needs 32 characters or less
Failed to the password authentication.
New password differs from Re-enter new password.

## 2.5.3 ping

The ping command sends an ICMP echo message to the recipient identified by <IP address> or <server name>.

### Remarks

Supported only for IPv4.

■ **Privilege: All**

(1) Input format

ping {-c <count> } [<IP address> <server name>]
---

(2) Option

-c <count>: This option ends the command after sending a certain number <count> of packets.  
The default is 1.

(3) Usage example

None

(4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified parameter is invalid.
-------------------------------------

If the parameter specification is incorrect, an ICMP ping error message may appear since ping in ICMP is used.

## 2.6 PRIMEQUEST2800B model Commands

### 2.6.1 PRIMEQUEST2800B model CLI command list

This chapter describes the functions of the PRIMEQUEST2800B model CLI commands. Follow Chapter 2.5 from Chapter 2.2 about the part not described in this chapter.

The following tables list the account privileges required for individual commands.

"Permitted" in an account privilege column indicates the command can be used with those account privileges.

- [TABLE 2.9 MMB CLI commands \(Administrator\)](#)
- TABLE 2.10 MMB CLI commands (Operator)
- TABLE 2.11 MMB CLI commands (User)
- TABLE 2.12 MMB CLI commands (CE)

TABLE 2.9 MMB CLI commands (Administrator)

Command	Administrator	Outline
Power control		
power off	Permitted	Turns the power off.
power on	Permitted	Turns the power on.
Partition creation		
add partition	-	Adds a partition component.
remove partition	-	Removes a partition component.
show partition configuration	-	Displays the partition configuration.
set reserved_sb	-	Sets the Reserved SB.
show reserved_sb	-	Displays the Reserved SB.
set partition home	-	Sets the Home SB.
show partition home	-	Displays the Home SB.
set partition dynamic_partitioning	-	Sets DR state of partition.
show partition dynamic_partitioning	-	Displays DR state of partition.
set memory_operation_mode	Permitted	Sets Memory operation mode.
show memory_operation_mode	Permitted	Displays Memory operation mode.
set memory_mirror_ras_mode	Permitted	Sets Memory operation at mirror mode.
show memory_mirror_ras_mode	Permitted	Displays Memory operation at mirror mode.
set pci_address_mode	-	Sets PCI bus number allocation mod.
show pci_address_mode	-	Displays PCI bus number allocation mod.
set lan_device_mode	Permitted	Sets LAN device mode.
show lan_device_mode	Permitted	Displays LAN device mode.
set pci_express_mode	-	Sets PCI-express mode.
show pci_express_mode	-	Displays PCI-express mode.
set partition name	-	Sets the partition name.
show partition name	-	Displays the partition name.
hotadd partition	-	Dynamic Partiiton HotAdd
hotremove partition	-	Dynamic Reconfiguration HotRemove
Partition control		
sadump	-	sadump instruction
reset	Permitted	Hard Reset instruction
nmi	Permitted	NMI interrupt instruction
Partition connection		

Command	Administrator	Outline
console	Permitted	Text Console connection to partition
DR-related	-	DR related commands
MMB configuration and other		
set active_mmb	-	Sets the active MMB.
show active_mmb	-	Displays the active MMB.
help	Permitted	Help information
System configuration		
set mmb control reset	Permitted	Resets the MMB.
set mmb control switch_over	-	Switch Over the MMB.
add user	Permitted	Adds User.
show user_list	Permitted	Displays Users.

TABLE 2.10 MMB CLI commands (Operator)

Command	Administrator	Outline
Power control		
power off	Permitted	Turns the power off.
power on	Permitted	Turns the power on.
Partition creation		
add partition	-	Adds a partition component.
remove partition	-	Removes a partition component.
show partition configuration	-	Displays the partition configuration.
set reserved_sb	-	Sets the Reserved SB.
show reserved_sb	-	Displays the Reserved SB.
set partition home	-	Sets the Home SB.
show partition home	-	Displays the Home SB.
set partition dynamic_partitioning	-	Sets DR state of partition.
show partition dynamic_partitioning	-	Displays DR state of partition.
set memory_operation_mode	Permitted	Sets Memory operation mode.
show memory_operation_mode	Permitted	Displays Memory operation mode.
set memory_mirror_ras_mode	Permitted	Sets Memory operation at mirror mode.
show memory_mirror_ras_mode	Permitted	Displays Memory operation at mirror mode.
set pci_address_mode	-	Sets PCI bus number allocation mod.
show pci_address_mode	-	Displays PCI bus number allocation mod.
set lan_device_mode	Permitted	Sets LAN device mode.
show lan_device_mode	Permitted	Displays LAN device mode.
set pci_express_mode	-	Sets PCI-express mode.
show pci_express_mode	-	Displays PCI-express mode.
set partition name	-	Sets the partition name.
show partition name	-	Displays the partition name.
hotadd partition	-	Dynamic Partiiton HotAdd
hotremove partition	-	Dynamic Reconfiguration HotRemove
Partition control		
sadump	-	sadump instruction
reset	Permitted	Hard Reset instruction
nmi	Permitted	NMI interrupt instruction

Command	Administrator	Outline
Partition connection		
console	Permitted	Text Console connection to partition
DR-related	-	DR related commands
MMB configuration and other		
set active_mmb	-	Sets the active MMB.
show active_mmb	-	Displays the active MMB.
help	Permitted	Help information
System configuration		
set mmb control reset	-	Resets the MMB.
set mmb control switch_over	-	Switch Over the MMB.
add user	-	Adds User.
show user_list	-	Displays Users.

TABLE 2.11 MMB CLI commands (User)

Command	Administrator	Outline
Power control		
power off	-	Turns the power off.
power on	-	Turns the power on.
Partition creation		
add partition	-	Adds a partition component.
remove partition	-	Removes a partition component.
show partition configuration	-	Displays the partition configuration.
set reserved_sb	-	Sets the Reserved SB.
show reserved_sb	-	Displays the Reserved SB.
set partition home	-	Sets the Home SB.
show partition home	-	Displays the Home SB.
set partition dynamic_partitioning	-	Sets DR state of partition.
show partition dynamic_partitioning	-	Displays DR state of partition.
set memory_operation_mode	-	Sets Memory operation mode.
show memory_operation_mode	Permitted	Displays Memory operation mode.
set memory_mirror_ras_mode	-	Sets Memory operation at mirror mode.
show memory_mirror_ras_mode	Permitted	Displays Memory operation at mirror mode.
set pci_address_mode	-	Sets PCI bus number allocation mod.
show pci_address_mode	-	Displays PCI bus number allocation mod.
set lan_device_mode	-	Sets LAN device mode.
show lan_device_mode	Permitted	Displays LAN device mode.
set pci_express_mode	-	Sets PCI-express mode.
show pci_express_mode	-	Displays PCI-express mode.
set partition name	-	Sets the partition name.
show partition name	-	Displays the partition name.
hotadd partition	-	Dynamic Partiiton HotAdd
hotremove partition	-	Dynamic Reconfiguration HotRemove
Partition control		
sadump	-	sadump instruction

Command	Administrator	Outline
reset	-	Hard Reset instruction
nmi	-	NMI interrupt instruction
Partition connection		
console	-	Text Console connection to partition
DR-related	-	DR related commands
MMB configuration and other		
set active_mmb	-	Sets the active MMB.
show active_mmb	-	Displays the active MMB.
help	Permitted	Help information
System configuration		
set mmb control reset	-	Resets the MMB.
set mmb control switch_over	-	Switch Over the MMB.
add user	-	Adds User.
show user_list	-	Displays Users.

TABLE 2.12 MMB CLI commands (CE)

Command	Administrator	Outline
Power control		
power off	-	Turns the power off.
power on	-	Turns the power on.
Partition creation		
add partition	-	Adds a partition component.
remove partition	-	Removes a partition component.
show partition configuration	-	Displays the partition configuration.
set reserved_sb	-	Sets the Reserved SB.
show reserved_sb	-	Displays the Reserved SB.
set partition home	-	Sets the Home SB.
show partition home	-	Displays the Home SB.
set partition dynamic_partitioning	-	Sets DR state of partition.
show partition dynamic_partitioning	-	Displays DR state of partition.
set memory_operation_mode	-	Sets Memory operation mode.
show memory_operation_mode	Permitted	Displays Memory operation mode.
set memory_mirror_ras_mode	-	Sets Memory operation at mirror mode.
show memory_mirror_ras_mode	Permitted	Displays Memory operation at mirror mode.
set pci_address_mode	-	Sets PCI bus number allocation mod.
show pci_address_mode	-	Displays PCI bus number allocation mod.
set lan_device_mode	-	Sets LAN device mode.
show lan_device_mode	Permitted	Displays LAN device mode.
set pci_express_mode	-	Sets PCI-express mode.
show pci_express_mode	-	Displays PCI-express mode.
set partition name	-	Sets the partition name.
show partition name	-	Displays the partition name.
hotadd partition	-	Dynamic Partiiton HotAdd
hotremove partition	-	Dynamic Reconfiguration HotRemove
Partition control		

Command	Administrator	Outline
sadump	-	sadump instruction
reset	-	Hard Reset instruction
nmi	-	NMI interrupt instruction
Partition connection		
console	-	Text Console connection to partition
DR-related	-	DR related commands
MMB configuration and other		
set active_mmb	-	Sets the active MMB.
show active_mmb	-	Displays the active MMB.
help	Permitted	Help information
System configuration		
set mmb control reset	-	Resets the MMB.
set mmb control switch_over	-	Switch Over the MMB.
add user	-	Adds User.
show user_list	-	Displays Users.

## 2.6.2 power off

Turn off the power of entire system.

When the entire system is already in power off state, any process will not be executed for entire system.

### ■ Privilege: Administrator, Operator

(1) Input format

```
power off {force}
```

(2) Option

force: Shows that the power of the system turns off forcefully without shutting down the operating system of system.

(3) Usage example

None

(4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified parameter is invalid.
Unable to power off the system.
Unable to force power off on the system.
Command Failed. Code=0x%04X, 0x%02X
Unable to execute this command because the system is under maintenance.
Unable to power off the System because you have not authority to operate this system.
System Configuration Failed.



### 2.6.3 power on

Turn on the power supply of the entire system.

When the power supply for the entire system is already turned on, processing for such system is not done.

- **Privilege: Administrator, Operator**

(1) Input format

power on
----------

(2) Option  
None

(3) Usage example  
None

(4) Message  
The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified parameter is invalid.
Unable to power on the partition#%d due to CPU mismatch between SBs.
Unable to power on the partition#%d due to DIMM does not satisfy requirements of Mirror Mode.
Unable to power on due to mismatch between supply voltage and input voltage.
Unable to power on the partition#%d due to abnormal DIMM composition.
Unable to power on the partition#%d due to abnormal SB composition.
Unable to power on the partition#%d due to abnormal VRM composition.
Unable to power on the system.
Command Failed. Code=0x%04X, 0x%02X
Unable to execute this command because the system is under maintenance.
The Power On failed, because of switching the Home SB. Please execute it after a while again.
Unable to power on the system because you have not authority to operate this system.
System Configuration Failed.

### 2.6.4 reset

Specify the Hard Reset to the system.

When the entire system is not in Power On state, any kind of processing for such system is not done.

- **Privilege: Administrator, Operator**

(1) Input format

reset {quiet}
---------------

(2) Option  
quiet: The command is executed without interactive operation with the user.

(3) Usage example  
Example: When reset is directed by the Administrator authority.

Administrator> reset

Are you sure you want to Reset? [Y/N]: Y  
Administrator>

(4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

Are you sure you want to Reset to system? [Y/N]:
The specified parameter is invalid.
Unable to Reset the system.
Command Failed. Code=0x%04X, 0x%02X
Unable to execute this command because the system is under maintenance.
Unable to Reset the System because you have not authority to operate this system.
System Configuration Failed.

## 2.6.5 nmi

Specify NMI interruption to the system.

When the entire system is not in Power On state, any kind of processing for such system is not done.

■ **Privilege: Administrator, Operator, Partition Operator (Only the partition to be managed)**

(1) Input format

nmi {quiet}
-------------

(2) Option

quiet: The command is executed without interactive operation with the user.

(3) Usage example

Example: When NMI is directed by the Administrator authority.

Administrator > nmi  
Are you sure you want to NMI? [Y/N]: Y  
Administrator >

(4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

Are you sure you want to NMI to System? [Y/N]:
The specified parameter is invalid.
Unable to NMI the system.
Command Failed. Code=0x%04X, 0x%02X
Unable to execute this command because the system is under maintenance.
Unable to NMI the System because you have not authority to operate this system.
System Configuration Failed.

## 2.6.6 set memory\_opration\_mode

It sets the Memory Operation Mode of the system.

By default normal (Mirror Mode invalid) is set.

performance : sets the Performance Mode  
normal : sets the Normal Mode  
partial\_mirror : sets the Partial Mirror Mode  
full\_mirror : sets the Full Mirror Mode  
spare : sets the Spare Mode

For the system which is already powered ON, when the settings are performed by this command, following message is displayed and settings cannot be performed.

“Unable to change the mode while the system is running.  
Please try to change the mode after the system is shutdown.”

For the system which is already powered OFF, when the settings are changed by this command, power OFF/ON is not required. The value which is set is reflected instantly instead of displaying the above-mentioned message.

Moreover, also when the values which are the same as the current values are set, power off/on is not required and the above-mentioned message is not displayed.

## ■ Privilege: Administrator, Operator

(1) Input format

set memory_operation_mode [performance   normal   partial_mirror   spare] {quiet}
---

(2) Option

quiet: Message is not displayed.

(3) Usage example

Example: When setting Memory Operation Mode of the system to performance

```
# set memory_operation_mode performance
The setting will become effective the next time the system power off/on is performed
#
```

(4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The setting will become effective the next time the system power off/on is performed.
The specified parameter is invalid.
Unable to register the System as Mirror Mode enable because the CPU mismatch between SBs.
Unable to register the System as Mirror Mode enable because the DIMM does not satisfy requirements of Mirror Mode.
Unable to register the System as Mirror Mode enable because the unsupported CPU configuration.
Unable to register the System as Mirror Mode enable because of abnormal CPU composition.
Unable to register the System as Mirror Mode enable because of abnormal DIMM composition.
Unable to register the System as Mirror Mode enable because of abnormal SB composition.
Unable to register the System as Mirror Mode enable because of abnormal VRM composition.
Failed to execute %s command.
Failed to execute set memory_operation_mode command.
Unable to change the mode while the system is running. Please try to change the mode after the system is shutdown.
Unable to execute this command because you have not authority to operate this system.
System Configuration Failed.

## 2.6.7 set memory\_mirror\_ras\_mode

It sets the Memory Mirror RAS mode of the system.

Memory Operation Mode can be set only at the time of Mirror Mode settings. Default value is set to mirror\_keep (RAS emphasized mode).

mirror\_keep : Mirror mode is maintained  
capacity\_keep : Capacity of the memory is maintained.

For the system which is already powered ON, when the settings are performed by this command, following message is displayed and settings cannot be performed.

“Unable to change the mode while the system is running.  
Please try to change the mode after the system is shutdown.”

For the system which is already powered OFF, when the settings are changed by this command, power OFF/ON is not required. The value which is set is reflected instantly instead of displaying the above-mentioned message.

Moreover, also when values which are the same as the current values are set, power off/on is not required and the above-mentioned message is not displayed.

### ■ Privilege: Administrator, Operator

#### (1) Input format

```
set memory_mirror_ras_mode [mirror_keep |capacity_keep ] {quiet}
```

#### (2) Option

quiet: Message is not displayed.

#### (3) Usage example

Example: When setting Memory Mirror RAS Mode of the system to Mirror Keep Mode

```
# set memory_mirror_ras_mode mirror_keep
The setting will become effective the next time the system power off/on is performed
#
```

#### (4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The setting will become effective the next time the system power off/on is performed.
The specified parameter is invalid.
Unable to register the System as Mirror Mode enable because the CPU mismatch between SBs.
Unable to register the System as Mirror Mode enable because the DIMM does not satisfy requirements of Mirror Mode.
Unable to register the System as Mirror Mode enable because the unsupported CPU configuration.
Unable to register the System as Mirror Mode enable because of abnormal CPU composition.
Unable to register the System as Mirror Mode enable because of abnormal DIMM composition.
Unable to register the System as Mirror Mode enable because of abnormal SB composition.
Unable to register the System as Mirror Mode enable because of abnormal VRM composition.
Failed to execute %s command.
Failed to execute set memory_mirror_ras_mode command.
Unable to change the mode while the system is running. Please try to change the mode after the system is shutdown.
Unable to execute this command because you have not authority to operate this system.
System Configuration Failed.

## 2.6.8 set lan\_device\_mode

LAN Device Mode is set by the IOU unit in the system.  
Default value set is wol\_disable.

wol_enable	: Onboard LAN enabled with AC On.
wol_disable	: Onboard LAN enabled with Partition On.
device_disable	: Onboard LAN device disabled always.

For the system which is already powered ON, when the settings are performed by this command, following message is displayed and settings cannot be performed.

“Unable to change the mode while the system is running.  
Please try to change the mode after the system is shutdown.”

For the system which is already powered OFF, when the settings are changed by this command, power OFF/ON is not required. The value which is set is reflected instantly instead of displaying the above-mentioned message.

Moreover, also when values which are the same as the current values are set, power off/on is not required and the above-mentioned message is not displayed.

### ■ Privilege: Administrator, Operator

(1) Input format

set lan_device_mode <IOU#> [wol_enable  wol_disable   device_disable ] {quiet}
--

(2) Option

quiet: Message is not displayed.

(3) Usage example

Example: When setting IOU#2 to Enable (WOL enabled) in the system.

```
# set lan_device_mode 2 wol_enable
#
```

(4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The setting will become effective the next time the system power off/on is performed.
The specified parameter is invalid.
Failed to execute %s command.
Failed to execute set lan_device_mode command.
Unable to change the mode while the system is running. Please try to change the mode after the system is shutdown.
Unable to execute this command because you have not authority to operate this system.
System Configuration Failed.

## 2.6.9 show memory\_operation\_mode

Displays the Memory Operation Mode of the system.

performance:	Shows the Performance Mode
normal:	Shows the Normal Mode
partial_mirror:	Shows the Partial Mirror Mode
full_mirror:	Shows the Full Mirror Mode

spare: Shows Spare Mode.

## ■ Privilege: All

(1) Input format

show memory_operation_mode
----------------------------

(2) Option  
None

(3) Usage example  
· Example: When Memory Operation Mode of system is displayed  
  #show memory\_operation\_mode  
  current: normal  
  setting: performance  
  #

(4) Message  
The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified parameter is invalid.
Failed to execute %s command.
Failed to execute show memory_operation_mode command.
System Configuration Failed.

## 2.6.10 show memory\_mirror\_ras\_mode

Displays Memory Mirror RAS Mode of the system.

mirror\_keep : Sets the Mirror Keep Mode.  
capacity\_keep : Sets the Capacity Keep mode.

## ■ Privilege: All

(1) Input format

show memory_mirror_ras_mode
-----------------------------

(2) Option  
None

(3) Usage example  
· Example: When Memory Mirror RAS Mode of system is displayed  
  #show memory\_mirror\_ras\_mode  
  current: mirror\_keep  
  setting: capacity\_keep  
  #

(4) Message  
The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified parameter is invalid.
-------------------------------------

Failed to execute %s command.
Failed to execute show memory_mirror_ras_mode command.
System Configuration Failed.

## 2.6.11 show lan\_device\_mode

Displays the setting (enable/disable) of LAN Device/WOL in IOU unit of the system.

### ■ Privilege: All

(1) Input format

show lan_devoce_mode
----------------------

(2) Option  
None

(3) Usage example

- Example: When LAN Device Mode of IOU (In example it is IOU#2 or IOU#3) from system is displayed  
#show lan\_device\_mode  
iou#2: LAN Device: enable WOL: enable  
iou#3: LAN Device: disable WOL: disable  
#

(4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified parameter is invalid.
Failed to execute %s command.
Failed to execute show lan_device_mode command.
System Configuration Failed.

## 2.6.12 set mmbcontrol reset

Specify the MMB reset.

This command execution is controlled at the time of the maintenance mode.

### ■ Privilege: Administrator

(1) Input format

set mmbcontrol reset {quiet}
------------------------------

(2) Option

quiet: The command is executed without interactive operation with the user.

(3) Usage example

# set mmbcontrol reset

(4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified parameter is invalid.
Unable to execute this command under maintenance.

## 2.6.13 add user

The user account is newly registered.

### ■ Privilege: Administrator

#### (1) Input format

add user <user name> <password> <confirm password> [admin   operator   user   ce] {quiet}
---

#### (2) Option

user name	: Sets the user name. You can enter a total of 8 to 32 characters. You can enter the following characters in a user name: [0-9], [a-z], [A-Z], - (hyphen), _ (underscore). However, the first character of the user name must be a letter from a to z or A to Z.
password	: Sets the password. You can enter a total of 8 to 32 characters. You can specify the following characters in a password: [0-9], [a-z], [A-Z], and special characters: ! " # \$ % & ' ( ) = - ^ ~ ¥ @ `[ ] { } : * ; + ? < . > , _
confirm password	: Used to reenter a password for confirmation.
privilege	: Sets the privileges of the user account. You can specify either admin, operator, user or ce.
Quiet	: The command is executed without interactive operation with the user.

#### (3) Usage example

Example: In case of admin authority.

```
# add user Aaaaaaaaa Bbbbbbbb Bbbbbbbb admin
```

Example: In case of operator authority.

```
# add user Aaaaaaaaa Bbbbbbbb Bbbbbbbb operator
```

#### (4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified parameter is invalid.
No more User addition
Same name already exists. User addition failed.

## 2.6.14 show user\_list

User account information registered in the system is displayed.



## ■ Privilege: Administrator

(1) Input format

```
show user_list
```

(2) Option  
None

(3) Usage example

```
# show user_list
user_name      privilege
Aaaaaaaa      Admin
Cccccccccc     Operator
Dddddddd       CE
```

(4) Message  
The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

```
The specified parameter is invalid.
```

## 2.6.15 console

Login to the system by telnet. Execute the Text Console connection of BMC.

The Text Console connection to BMC can be connected only by one command per BMC. However, the following messages are displayed when the following console command is executed when other users have already executed the console command, and the Text Console connection to BMC can be done compulsorily by inputting as 'Y'. In that case, the compulsion cutting is done as for the console command under the connection.

```
Console redirection already in use
If needed, the current user can be disconnected

Do you really want to force disconnect current user? [Y|N]:
```

## ■ Privilege: Administrator, Operator, CE

(1) Input format

```
console {<timeout>} {quite}
```

(2) Option  
timeout: Sets timeout value.  
Set by 0 or within the range of 1~120 minutes.  
0 consists of the special meaning, it indicates no Timeout.  
Default setting is 10 minutes.  
Perform the operation by default value when this option is not specified.  
quiet: Executes the command without interactive operation with User.

(3) Usage example  
Example: In case of Login to BMC.

```
# console
```

Example: When logged in to BMC by timeout value of 20 minutes.

```
# console 20  
#
```

#### (4) Message

The following table lists the messages which are displayed in this CLI.

For details of the messages, see the PRIMEQUEST 2000 Series Message Reference (C122-E178EN).

The specified parameter is invalid.
Failed to execute 'console' command.
Unable to execute this command because you have not authority to operate this system.
System Configuration Failed.

## CHAPTER 3 UEFI Menu Operations

This chapter describes about the UEFI menu operations.

The UEFI has a menu that offers operations including selective booting of the operating system, starting the UEFI shell, and changing the settings of boot options. To execute each function, move to the relevant menu from the front page of Boot Manager.

For details on [sadump Configuration], see “Chapter 6 Setting up the sadump Environment”.

### 3.1 Front page of Boot Manager

The Front page of Boot Manager is the top page of UEFI. In this window, you can move to Boot processing or can move to Boot Manager, Device Manager and Boot Maintenance Manager by using a relevant menu.


FIGURE 3.1 Display Example of Front page of Boot Manager



#### 3.1.1 Window area

The Front page of Boot Manager is divided into 4 parts as shown in “[FIGURE 3.2 Window area of Boot Manager Front Page](#)”

FIGURE 3.2 Window area of Boot Manager Front Page



(1) System Information display

Nothing is displayed

(2) Menu selection

Displays selection menu shown in “[TABLE 3.1 Display item of menu selection](#)”.

TABLE 3.1 Display item of menu selection

Item	Explanation
Continue	If you select ‘Continue’, boot is executed in the sequence that has presently been set.
Boot Manager	Displays “ <a href="#">3.3 [Boot Manager] Menu</a> ”
Device Manager	Displays “ <a href="#">3.4 [Device Manager] Menu</a> ”
Boot Maintenance Manager	Displays “ <a href="#">3.5 [Boot maintenance Manager] Menu</a> ”
BIOS Boot Diagnostic Test	Executes BIOS Boot Diagnostic Test. After execution, the power supply to the partition must be turned Off.

(3) Operation help display part

The help for operations mentioned on this page is shown in the “[TABLE 3.2 Display Items on Operation Help Display](#)”.

TABLE 3.2 Display Items on Operation Help Display

Item	Description
↑↓=Move Highlight	Moves the cursor in up and down directions.
<Enter> = Select Entry	Selects the item.

### 3.2 [Continue] Menu

In [Continue] Menu, the process is transited to automatic boot of operating system, and the system is booted in the existing boot order.

### 3.3 [Boot Manager] Menu

In [Boot Manager] Menu, device for boot can be specified. The [Boot Manager] menu, lists boot devices as shown in “FIGURE 3.3 Display example of [Boot Manager] Menu” Individual Boot device which is displayed in menu is called as Boot option.

FIGURE 3.3 Display example of [Boot Manager] Menu



#### 3.3.1 Boot Option

In boot option, there are two types such as boot type for UEFI Aware operating system and boot type for legacy operating system. The difference in these two types is given below.

- Method of specifying the boot device  
As for the boot device specification of UEFI Aware Operating System, the executable file can be specified up to the unit by the device path expression based on the UEFI specification. On the contrary, for the boot device specification of legacy operating system, the device can be specified up to the unit.

- Method of specifying boot priority  
Change of boot priority is possible by rearranging the boot option.  
It can be changed by [Change Boot Order] window of [Boot options]  
(See“■[Change Boot Order] menu”)

- Startup priority of Default  
The following table shows the boot order of initial state.


TABLE 3.3 Initial state of Default

Priority	Boot option
1	UEFI: Device name
2	UEFI: Device name n(n=0,1,2 ) However boot option for device which has been added is added at the end
3	Legacy Boot
4	UEFI Shell
5	UEFI: PXE Boot MAC(MAC Addr) However boot option for device which has been added is added at the end

### 3.3.2 Boot specification of UEFI

In boot manager menu boot option is displayed according to the boot priority. The boot option displayed at the top has highest priority option and the boot is tested first. [Windows Boot Manager] displayed in example shown in “[FIGURE 3.4 Boot Option of Boot Manager](#)” is created when Windows server of Windows Server 2008 (or later) which is UEFI Aware operating system, is installed. In this example, boot for Windows server 2008 (or later) of UEFI Aware operating system, is tested initially.

FIGURE 3.4 Boot Option of Boot Manager



If booting is successful, the operating system is booted. If the booting is failed, the following boot option is booted. In the example of “[FIGURE 3.4 Boot Option of Boot Manager](#)”, EFI Internal Shell is booted.

The priority level of the boot of UEFI Aware operating system can be changed by the [Change Boot Order] window of the [Boot Options] menu. (See “[■ \[Change Boot Order\] Menu](#)”.)


When the boot option is added, and deleted, the [Add Boot Option] menu (See “[■ \[Add Boot Option\] menu](#)”) of the [Boot Options] menu and the [Delete Boot Option] menu (See “[■ \[Delete Boot Option\] menu](#)”) are used.

### 3.3.3 About boot specification of legacy BIOS

Boot of legacy operating system is executed by specifying the legacy boot option (Boot option which displays device name without displaying EFI) from the [Boot Manager] menu.

In “[FIGURE 3.5 Execution of Legacy Boot Option](#)”, Fujitsu Virtual CDROM 1.00 which is under the control of Legacy CD ROM is a legacy boot option.

FIGURE 3.5 Execution of Legacy Boot Option



The priority level of starting the legacy operating system is changed from the [Change Boot Order] menu.

When the boot processing of legacy operating system is executed once, only the boot option of legacy operating system is executed. The boot option of the UEFI boot whose priority level is lower than the boot option of legacy operating system is not booted automatically. For example, boot of legacy operating system is executed when Legacy CD ROM is moved above Windows Boot Manager, and the boot of Windows is not executed automatically. Specifically, set according to the following procedures.

1. Decide the boot priority level by the [Change Boot Order] window of the [Boot Options] menu. (See “[■ \[Change Boot Order\] menu](#)”.)
2. Set startup priority level of multiple Floppy in the [Set Legacy Floppy Drive Order] menu of the Boot Options menu. (See “[■ \[Set Legacy Floppy Drive Order\] menu](#)”.)
3. Set startup priority level of multiple HDD in the [Set Legacy HardDisk Drive Order] menu of the Boot Options menu. (See “[■ \[Set Legacy HardDisk Drive Order\] menu](#)”.)

4. Decide priority level between multiple DVD/CD according to the [Set Legacy DVD/CD-ROM Drive Order] menu of the Boot Options menu. (See “■ [Set Legacy DVD/CD-ROM Drive Order] menu”.) In the boot specification of legacy BIOS, the priority level between multiple DVD/CD can be set in the DVD/CD type.

5. Decide priority level between multiple network ports according to the [Set Legacy NET Drive Order] menu of the [Boot Options] menu. (See “■ [Set Legacy NET Drive Order] menu”.) In the boot specification of legacy BIOS, the priority level between multiple network ports can be set in the network port type.

### 3.3.4 Boot processing

#### 1. Flow of startup of boot processing

The flow of the startup by the boot specification of the boot specification of UEFI and legacy BIOS is shown in “[TABLE 3.4 Flow of startup by boot specification of UEFI and boot specification of legacy BIOS](#)”.

TABLE 3.4 Flow of startup by boot specification of UEFI and boot specification of legacy BIOS

UEFI boot specification	Flow of startup
< Boot priority level of UEFI Aware operating system> Tries boot of UEFI Aware in the sequence of Boot Order.	
1 Windows Boot Manager:	Tries boot of Windows Boot Manager
2 EFI USB Device:	Tries boot of UEFI Aware operating system from USB Device.
3 EFI Network Device:	Tries boot of UEFI Aware operating system from network port.
The legacy boot option from each legacy device described as follows is an example. The UEFI boot option whose priority level is lower than the legacy boot option is not booted automatically.	
4 Fujitsu Virtual CDROM 1.00:	Tries legacy operating system boot from CD ROM of legacy.
5 EFI USB Device 2:	Priority is lower than the Legacy Boot Option thus unable to boot automatically.
6. Fujitsu Virtual Floppy 1.00:	Tries legacy operating system boot from Floppy drive of the legacy.
7. EFI Internal Shell:	Starts UEFI Shell.

#### 2. Flow of processing when boot processing success / fails

The flow of processing when success/fails in the boot processing of the each operating system is shown as follows.

- If booting of Windows Server 2008 which has UEFI Aware operating system is successful

TABLE 3.5 Boot success of Windows Server 2008

UEFI Boot specifications	Flow of start-up
1 Windows Boot Manager :	Tries the boot of Windows Boot Manager
	Boot success – Windows Boot
2 EFI USB Device	
3 EFI Network Device	
4 FujitsuVirtualCDROM01.00	
5 EFI USBDevice2	
6 Fujitsu Virtual Floppy0 1.00	
7 UEFI Internal Shell:	Starts UEFI Shell



■ If boot of Windows Server 2008 on UEFI Aware operating system fails or if UEFI is booted from USB Device

TABLE 3.6 Boot failure of Windows Server 2008 (UEFI Boot success of EFI USB Device)

UEFI Boot specifications	Flow of start-up
1 Windows Boot Manager : Tries the boot of Windows Boot Manager	
	- Boot Failure
2 EFI USB Device	
	- Boot Start up
3 UEFI Network Device	
4 Fujitsu Virtual CDROM0 1.00	
5 EFI USB Device 2	
6 Fujitsu Virtual Floppy0 1.00	
7 EFI Internal Shell: Starts UEFI Shell	

■ If boot of Windows Boot Manager, EFI Network Device and EFI USB Device fails or if booted from Legacy Floppy

TABLE 3.7 If boot of Windows Boot Manager, EFI Network Device and EFI USB Device fails or if booted from Legacy Floppy

UEFI Boot specifications	Flow of start-up
1 Windows Boot Manager : Tries the boot of Windows Boot Manager	
	- Boot Failure
2 EFI USB Device	
	- Boot Failure
3 EFI Network Device	
	- Boot Failure
4 Fujitsu Virtual CDROM0 1.00	Tries the Legacy operating system Boot from high priority Set Legacy CD-ROM Drive Order.
	- Boot Failure
5 EFI USB Device 2	Priority is lower than the Legacy Boot Option thus unable to boot automatically.
6 Fujitsu Virtual Floppy0 1.00	
	- Boot Failure
7 EFI Internal Shell: Starts UEFI Shell	

- If UEFI aware Operating System Boot and Legacy Operating System Boot fails and if UEFI Start up is successful

TABLE 3.8 If UEFI aware operating system Boot and Legacy operating system Boot fails and if UEFI Start up is successful

UEFI Boot specifications	Flow of start-up
1 Windows Boot Manager : Tries the boot of Windows Boot Manager	
	- Boot Failure
2 EFI USB Device	
	- Boot Failure
3 EFI Network Device	
	- Boot Failure
4 Fujitsu Virtual CDROM0 1.00	Tries the Legacy operating system Boot from high priority Set Legacy CD-ROM Drive Order.
	- Boot Failure
5 EFI USB Device 2	Priority is lower than the Legacy Boot Option thus unable to boot automatically.
6 Fujitsu Virtual Floppy0 1.00	
	- Boot Failure
7 EFI Internal Shell: Starts UEFI Shell	- UEFI Shell Start up

### 3. Definition of Boot failure

There are 2 types of failure for Booting process.

- Failure in which process can be shifted to the next boot option
  - Failure in which process cannot be shifted to the next boot option
- Failure in which process can be shifted to the next boot option
- Failure in which process can be shifted to the next boot option is the state where boot process fails because of the absence of boot target. Specifically, following failure patterns exist.

- In boot process of UEFI Aware operating system (such as Windows Boot Manager), the targeted device cannot be connected.
- In boot process of UEFI Aware operating system (Such as Windows Boot Manager), the targeted device cannot be recognized.
- In boot process of UEFI Aware operating system (Such as Windows Boot Manager), UEFI partition was not exist in targeted device.
- In boot of UEFI: Embedded DVD/CD, UEFI: DVD/CD n, media was not found in the corresponding DVD/CD device.
- In boot of UEFI: Embedded DVD/CD, UEFI: DVD/CD n, media which is mounted on the corresponding DVD/CD device was not a media which can perform booting.
- In HDD boot of Legacy Boot, HDD cannot be connected.
- In HDD boot of Legacy Boot, HDD cannot be recognized.
- In HDD boot of Legacy Boot, nothing can be written in HDD.
- In DVD/CD boot of Legacy Boot, DVD/CD device cannot be recognized.
- In DVD/CD boot of Legacy Boot, media was not found in the corresponding DVD/CD device
- In DVD/CD boot of Legacy Boot, media which is mounted in the corresponding DVD/CD device was a media which can perform booting.
- In PXE boot of Legacy Boot, LAN cable cannot be connected.
- In PXE boot of Legacy Boot, setting of server side could not be done.
- In boot of UEFI: PXE Boot MAC (MAC addr), LAN cable cannot be connected.
- In boot of UEFI: PXE Boot MAC (MAC addr), the server side could not be set.

•Failure by which processing cannot be moved to the following boot option

Failure by which processing cannot be moved to the following boot option is a case in which the boot processing fails after transferring the control to operating system. For example, the case is considered, in which operating system program stored in the device which is targeted for booting, fails.

“Example of displayed menu of [FIGURE 3.6 Example of displayed \[Boot Manager\] menu](#)” is an example of window immediately after the startup of the [Boot Manager] menu.

FIGURE 3.6 Example of displayed [Boot Manager] menu



(1)Page information display

Displayed as [Boot Manager]

(2) Menu selection

The boot device list is displayed by the priority of the startup. The cursor is set to operating system which is booted with [↑] key or with [↓] key, or the cursor is set to UEFI Shell, and the selection is done. If [Enter] key is pressed, the selected UEFI Aware operating system or legacy operating system tries a boot and UEFI shell tries a startup.

If booting fails, returns to the Boot Manager front page.

(3) Operation help display

The help for operations mentioned on this page is shown in the [“TABLE 3.9 Displayed contents of operation help display”](#).

TABLE 3.9 Displayed contents of operation help display

Items	Description
↑↓= Move Highlight	Moves the cursor to up and down
<Enter>=Select Entry	Selects the item.
Esc=Exit	Returns to “3.1 Boot Manager front page”

### 3.4 [Device Manager] Menu

Whether to allocate I/O space for each I/O device and whether to make PXE boot enable, are set in the [Device Manager] menu. The following window is window immediately after the startup of the [Device Manager] menu.

FIGURE 3.7 Example of displayed [Device Manager] menu



#### Remarks

Integrated firmware version can be checked in [Unified Firmware Version] of [System] → [Firmware Information] window of MMB Web-UI. For the details on [Firmware Information] window, see “ ”.

(1) Page information display

Displayed as [Device Manager]

(2) Menu selection

The menu shown in “[TABLE 3.10 Displayed contents of menu selection](#)” is displayed.

TABLE 3.10 Displayed contents of menu selection

Items	Description
System Information	Displays “ <a href="#">3.4.1 [System Information] Menu</a> ”
I/O Space Assignment Configuration	Displays “ <a href="#">3.4.2 [I/O Space Assignment Configuration] Menu</a> ”
LAN Remote Boot Configuration	Displays “ <a href="#">3.4.3 [LAN Remote Boot Configuration] Menu</a> ”
CPU Configuration	Displays “ <a href="#">3.4.4 [CPU Configuration] Menu</a> ”
PCI Bus Padding Configuration	Displays “ <a href="#">3.4.5 [PCI Bus Padding Configuration] Menu</a> ”
PCI Subsystem Configuration	Displays “ <a href="#">3.4.6 [PCI Subsystem Configuration] Menu</a> ”
iSCSI Configuration	Displays “ <a href="#">3.4.9 [iSCSI Configuration] menu</a> ”
Memory Configuration	Displays “ <a href="#">3.4.10 [Memory Configuration] menu</a> ”
USB Configuration	Displays “ <a href="#">3.4.11 [USB Configuration] menu</a> ”
Security Configuration	Displays “ <a href="#">3.4.12 [Security Configuration] menu</a> ”

**Remarks**

The sequence of the menu may be changed according to the device configuration. Besides the above-mentioned menu, the displayed items may be increased by the sadump menu and the installed I/O device. For the details on the method of operating the sadump menu, "CHAPTER 6 Setting of sadump environment". Moreover, for the method of operating I/O device menu, see the manual which is provided by the vender of I/O device.

**(3) Operation help display**

The description on operation key which is shown in the "TABLE 3.11 Displayed contents of operation help display" is displayed.

TABLE 3.11 Displayed contents of operation help display


Items	Description
↑↓= Move Highlight	Moves the cursor up and down.
<Enter>=Select Entry	Selects the item.
Esc=Exit	Returns to "3.1 Front page of Boot Manager"

**3.4.1 [System Information] Menu**

The information on the system is displayed in the System Information menu. There is no item which needs to be set in this menu.

The example of displayed window of [System Information] menu is shown below.

FIGURE 3.8 Example of displaying [System Information] menu

**(1) Page information display**

Displayed as System Information.

**(2) System information display**

The contents shown in "TABLE 3.12 Display Contents of the System Information Display" are displayed.

TABLE 3.12 Display Contents of the System Information Display

Items	Display Contents
<i>BIOS Revision</i>	Displays BIOS revision. Display example 00.44
<i>LAN N MAC Address</i> <i>N: 1, 2,...</i>	Displays the MAC address of Network Controller. Display example 0:19:99:81:F9:31
<i>Processor Type</i>	Displays processor type. Display example Genuine Intel(R) CPU @ 2.70GHz
<i>CPU - /Patch - ID</i>	Displays CPUID, Patch ID. Display example 206D6 / 00000610
<i>Processor Speed</i>	Displays processor speed. Display example 2700 MHz
<i>Cache Counts &amp; Sizes (*1)</i>	Displays cache size. Display example 8x8 KB / 8x32 KB / 1x 20 MB
<i>Active Package, Core &amp; Thread Count (maximum)</i>	Displays the number of CPU packages, numbers of cores, and numbers of threads. Display example 2(2) Package(s) 8(16) Core(s) 16(32) Thread(s)
<i>Memory Size / Frequency</i>	Displays memory size and frequency. Display example 32768 MB (1333 MHz)

**(3) Help Operation Display**

Explanation of the operation key shown in the “[TABLE 3.13 Display Contents of Help Operation Display](#)” is displayed.

TABLE 3.13 Display Contents of Help Operation Display

Items	Description
↑↓ = Move Highlight	Move the cursor up and down
Esc=Exit	Return to the “ <a href="#">3.1 Front page of Boot Manager</a> ”.

### 3.4.2 [I/O Space Assignment Configuration] Menu

I/O space assignment of various I/O devices in the system can be configured in [I/O Space Assignment Configuration] menu.


After resetting the system, UEFI assigns the I/O space to the I/O device for which [Auto] or [Force] are set in this menu.

There are 15 devices for which the I/O space can be assigned. However, when PCI card with Bridge function is used, assignable PCI slots are less than 15. If there are 16 or more devices for which [Auto] is set in this menu, I/O space cannot be assigned for those devices. To assign the I/O space, follow the process given below.

■ In this menu, there should be 15 or less devices for which [Auto] is set.

■ After resetting the system for which I/O space is assigned in this menu, open this menu once again and confirm that the I/O space is assigned for the relevant system.  
The settings changed in this menu are enabled after the system is reset.  
Following is the display of window immediately after start-up of [I/O Space Assignment Configuration] Menu.

FIGURE 3.9 Display example of [I/O Space Assignment Configuration] Menu



(1) Display of page information

[I/O Space Assignment Configuration] is displayed.

(2) Menu Selection

Items shown in "TABLE 3.14 Display Contents of Menu Selection" are displayed in Menu.

TABLE 3.14 Display Contents of Menu Selection

Items		Display contents
(I/O Device information)		
	Slot#	Displays [OnBoard] in case of ob board device. Displays PCI Slot number (Hexadecimal number) in case of Slot.
	Device	Displays a type of device.
	Status	Displays information about current I/O space assignment. Assigned: I/O space is assigned. N/a: I/O space is not assigned.
	Setting	Displays the setting value. Following are the setting items. Force: I/O space is assigned. I/O space is assigned to the device for which [Force] is set, in preference to the device for which [Auto] is set. However, an error message is displayed if no. of slots, which can be assigned, exceeds and is set to [Force]. Auto: I/O space is assigned to the extent that there is no shortage of I/O space. Disabled: I/O space is not assigned. Default setting is Auto.

Commit Changes and Exit	After saving the contents the setting of which are changed, exit from this menu.
Discard Changes and Exit	After cancelling the contents the setting of which are changed, exit from this menu.

(3) Display of Operation help

Description of operation key shown in “[TABLE 3.15 Display contents of Display of Operation help](#)” is displayed.

TABLE 3.15 Display contents of Display of Operation help

Item	Description
↑ ↓ =Move Highlight	Moves cursor up and down.
<Enter>=Select Entry	Selects item
Esc=Exit	Returns to “ <a href="#">3.1 Front page of Boot Manager</a> ” without saving the changed settings of this menu.

### 3.4.3 [LAN Remote Boot Configuration] Menu

Network port implementing PXE/iSCSI boot can be selected in [LAN Remote Boot Configuration] Menu. In the menu, PXE bootable network port is displayed. It is possible to boot PXE/iSCSI from the targeted device by setting Enable after selecting network port which enables PXE/iSCSI boot. By default, the setting is such that all network ports and PXE/iSCSI boot cannot be implemented (Disabled).

The settings changed in this menu are enabled after the system is set. For the contents set in this menu, see “[Table 3.16 Reflection of \[LAN Remote Boot Configuration\] Menu](#)”

TABLE 3.16 Reflection of [LAN Remote Boot Configuration] Menu

Setting contents	Reflected contents
UEFI (PXE/iSCSI) (*1)	Boot options of PXE boot are added in [Boot Manager]. Moreover, network ports are added to [iSCSI Configuration] Menu (See “ <a href="#">3.4.9 [iSCSI Configuration] menu</a> ”) of [Device Manager] menu.
Legacy PXE (*2)	Boot options of PXE boot are added to [Change Legacy PXE Boot Priority] Menu (“ <a href="#">Change in order of priority (Change Legacy PXE Boot Priority)</a> ”) of “ <a href="#">3.5.2 [Boot Options] menu</a> ”) of [Boot Maintenance Manager] Menu
Legacy iSCSI (*3)	“Press <Ctrl+D> to run setup” message is displayed at the time of boot. When Ctrl+D is pressed in accordance with that message, setting menu of Legacy iSCSI is displayed.
Disabled	Remote boot is disabled. Items added when [UEFI (PXE/iSCSI)], [Legacy PXE] or [Legacy iSCSI] is selected, are deleted.

\*1: Settings which Enable PXE/iSCSI boot of UEFI Aware Operating System.

\*2: Settings which Enable PXE boot of Legacy Operating System.

\*3: Settings which Enable iSCSI boot of Legacy Operating System.

Following is the display of [LAN Remote Boot Configuration] Menu.



FIGURE 3.10 Display of [LAN Remote Boot Configuration] Menu



(1) Display of page information

[LAN Remote Boot Configuration] is displayed.

(2) Menu Selection

Items shown in “[TABLE 3.17 Display contents of Menu Selection](#)” are displayed in Menu.

TABLE 3.17 Display contents of Menu Selection

Item	Display contents
(Network Port Information)	Each network port information in the following system, and PXE/ iSCSI boot setting information is displayed. Network port information is displayed in MAC address format.
Commit Changes and Exit	After saving the contents the setting of which are changed, exit from this menu.
Discard Changes and Exit	After cancelling the contents the setting of which are changed, exit from this menu.

(3) Display of Operation help

Description of operation key shown in “[TABLE 3.18 Display contents of Display of Operation help](#)” is displayed.

TABLE 3.18 Display contents of Display of Operation help


Item	Description
↑ ↓ =Move Highlight	Moves cursor up and down.
<Enter>=Select Entry	Selects item
Esc=Exit	Returns to “ <a href="#">3.1 Front page of Boot Manager</a> ” without saving the changed settings of this menu.

### ■ Change in Enable/Disable settings of PXE/iSCSI boot

The change in PXE/iSCSI boot settings of each network port is implemented by the following procedure.

1. Press “Enter” key placing the cursor on network port for which settings are to be changed.  
Pop-up window shown in “[FIGURE 3.11 Operation Window of PXE/iSCSI boot Enable Setting](#)” is displayed.

FIGURE 3.11 Operation Window of PXE/iSCSI boot Enable Setting”




2. Set PXE/iSCSI boot Enable/Disable.
  - When PXE boot of UEFI Aware Operating System is set to Enable, [UEFI (PXE/iSCSI)] is selected.
  - When PXE boot of Legacy Operation System is set to Enable, [Legacy PXE] is selected.
  - When iSCSI boot of Legacy Operation System is set to Enable, [Legacy iSCSI] is selected.
  - When PXE/iSCSI boot is set to Disable, [Disabled] is selected.  
By default all are [Disabled].
3. Press [Enter] key.
4. To exit from this menu after saving the changes in the settings, select [Commit Changes and Exit] and press [Enter] key.
5. To exit from this menu without saving the changes in the settings, select [Discard Changes and Exit] and press [Enter] key.
6. When UEFI (PXE/iSCSI) is selected, to confirm [Enable], [Boot Manager] Menu is activated after reset. Boot options are added is confirmed as in “[FIGURE 3.12 Display of \[Boot Manager\] Menu](#)”.

FIGURE 3.12 Display of [Boot Manager] Menu

**Remark**


If [MAC Selection] Menu is activated from [Add An Attempt] of [iSCSI Configuration] Menu in [Device Manager] Menu, network ports are added as in “[FIGURE 3.13 Display of \[MAC Selection\]](#)”.

FIGURE 3.13 Display of [MAC Selection]



7. When Legacy PXE is set to [Enable], if [Set Legacy NET Drive Order] Menu of [Boot Maintenance Manager] Menu is activated after reset, network ports are added as in “[FIGURE 3.14 Display of \[Set Legacy Net Drive Order\] Menu](#)” See (“[■\[Set Legacy Net Drive Order\] Menu](#)”).

FIGURE 3.14 Display of [Set Legacy Net Drive Order] Menu



3.4.4 [CPU Configuration] Menu

Enable/Disable of Power saving function and hyper threading function of CPU can be set in [CPU Configuration] Menu.  
Following is the display of window immediately after start-up of [CPU Configuration] Menu.

FIGURE 3.15 Display Example of [CPU Configuration] Menu



- (1) Page Information Display  
[CPU Configuration] is displayed.
- (2) Menu Selection  
The items shown in the “[TABLE 3.19 Display Contents of Menu Selection](#)” are displayed on the Menu.

TABLE 3.19 Display Contents of Menu Selection

Items	Display Contents
Hyper-threading	Sets the Hyper Threading function to enable or disable. • Enabled • Disabled Default setting is, Enabled.
Active Processor Cores	Set the core number to be enabled to each CPU socket. • All • 1 • 2 • 3 • 4 • 5 • 6 • 7 • 8 • 9 • 10 • 11 • 12 • 13 • 14  Default setting is, All. <b>Remarks</b> Maximum number displayed in setting items is a core number -1 for each CPU socket.
Hardware Prefetcher	Sets the Hardware Prefetcher function to enable or disable. • Enabled • Disabled Default setting is, Enabled.
Adjacent Cache Line Prefetch	Sets the Adjacent Cache Line Prefetch function to enable or disable. • Enabled • Disabled Default setting is, Enabled.
DCU Streamer Prefetcher	Sets the DCU Streamer Prefetcher function to enable or disable. • Enabled • Disabled Default setting is, Enabled.
DCU Ip Prefetcher	Sets the DCU Ip Prefetcher function to enable or disable. • Enabled • Disabled Default setting is, Enabled.
Execute Disable Bit	Sets the Execute Disable Bit function to enable or disable. • Enabled • Disabled Default setting is, Enabled.
Intel Virtualization Technology	Sets the Intel Virtualization Technology function to enable or disable. • Enabled • Disabled Default setting is, Enabled.
Intel(R) VT-d	Sets the Intel(R) VT-d function to enable or disable. • Enabled • Disabled Default setting is, Disabled.
Power Technology	Sets the CPU Power Management function. • Disabled • Energy Efficient • Custom Default setting is, Energy Efficient.

Enhanced Speed Step	<p>Sets the Power Saving function of CPU to enable or disable.</p> <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> <p>Default setting is, Enabled.</p> <p><b>Remarks</b> Displays only when [Custom] is selected in [Power Technology].</p>
Turbo Mode	<p>Sets the Intel (R) Turbo Boost Technology function to enable or disable.</p> <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> <p>Default setting is, Enabled.</p> <p><b>Remarks</b> Displays only when [Custom] is selected in [Power Technology].</p>
Energy Performance	<p>Selects the Energy Performance mode.</p> <ul style="list-style-type: none"><li>• Performance</li><li>• Balanced Performance</li><li>• Balanced Energy</li><li>• Energy Efficient</li></ul> <p>Default setting is, Performance.</p> <p><b>Remarks</b> Displays only when [Custom] is selected in [Power Technology].</p>
P-State Coordination	<p>Sets the coordination method of P-State of CPU.</p> <ul style="list-style-type: none"><li>• HW_ALL</li><li>• SW_ALL</li><li>• SW_ANY</li></ul> <p>Default setting is, HW_ALL.</p> <p><b>Remarks</b> Displays only when [Custom] is selected in [Power Technology].</p>
CPU C3 Report	<p>Sets the CPU C3 Report function to enable or disable.</p> <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> <p>Default setting is, Disabled.</p> <p><b>Remarks</b> Displays only when [Custom] is selected in [Power Technology].</p>
CPU C6 Report	<p>Sets the CPU C6 Report function to enable or disable.</p> <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> <p>Default setting is, Enabled.</p> <p><b>Remarks</b> Displays only when [Custom] is selected in [Power Technology].</p>
CPU C7 report	<p>Sets the CPU C7 Report function to enable or disable.</p> <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> <p>Default setting is, Enabled.</p> <p><b>Remarks</b> Displays only when [Custom] is selected in [Power Technology].</p>
Package C State limit	<p>Sets the function by which the transition of C-state of CPU is limited.</p> <ul style="list-style-type: none"><li>• C0: Allows transition till C0 state</li><li>• C2: Allows transition till C2 state</li><li>• C6: Allows transition till C6 state</li><li>• C7: Allows transition till C7 state</li><li>• No Limit: There is no limit for the transition of C state</li></ul> <p>Default setting is, No Limit.</p>
QPI Link Frequency Select	<p>Set the QPI Link Frequency.</p> <ul style="list-style-type: none"><li>• Auto</li><li>• 8.0GT/s</li><li>• 7.2GT/s</li><li>• 6.4GT/s</li></ul> <p>Default setting is, Aluto.</p>

Frequency Floor Override	Sets the Frequency Floor Override function to enable or disable. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> Default setting is, Disabled.
Perfmon and DFX devices	Sets the Perfmon and DFX devices function to enable or disable. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> Default setting is, Disabled.
Commit Changes and Exit	Exit from main menu after the changed contents of configuration are saved.
Discard Changes and Exit	Exit from main menu after the changed contents of configuration are cancelled.

## (3) Operation Help Display

Description of Operating Keys is shown in the "[TABLE 3.20 Display Contents of Operation Help Display](#)".

TABLE 3.20 Display Contents of Operation Help Display

Item	Description
↑↓= Move Highlight	Moves cursor up and down.
<Enter>=Select Entry	Selects item.
Esc=Exit	Returns to ' <a href="#">3.1 Front page of Boot Manager</a> ' without saving changes of this menu'.

### 3.4.5 [PCI Bus Padding Configuration] Menu

The PCI Bus number allocated to PCI Express Slot can be changed on [PCI Bus Padding Configuration] Menu. The default value allocated to PCI Express slot is 1. Changes done on this menu becomes enable after system is reset.

The example of contents displayed on screen immediately after the activation of [PCI Bus Padding Configuration] Menu is given below.

FIGURE 3.16 Example of Display on [PCI Bus Padding Configuration] Menu



(1) Page Information Display

[PCI Bus Padding Configuration] is displayed.

(2) Menu Selection

The items shown in "[TABLE 3.21 Display Contents of Menu Selection](#)" are displayed on menu.

TABLE 3.21 Display Contents of Menu Selection

Item	Display Contents
(Allocation of PCI bus number)	Specifies the bus number allocated to PCI Express slot. Default value is 1. Setting range is 1 ~ 4.
Commit Changes and Exit	Exit from main menu after the changed contents of configuration are saved.
Discard Changes and Exit	Exit from main menu after the changed contents of configuration are cancelled.

(3) Operation Help Display

Description of Operating Keys is shown in the "[TABLE 3.22 Display Contents of Operation Help Display](#)".



TABLE 3.22 Display Contents of Operation Help Display

Item	Description
↑↓= Move Highlight	Moves cursor up and down.
<Enter>=Select Entry	Selects item.
Esc=Exit	Returns to '3.1 Front page of Boot Manager' without saving changes of this menu'.

### 3.4.6 [PCI Subsystem Configuration] Menu

Option ROM of PCI card can be configured in [PCI Subsystem Configuration] menu.  
The example of contents displayed on screen immediately after the activation of [PCI Subsystem Configuration] Menu is given below.

FIGURE 3.17 Display Example on [PCI Subsystem Configuration] Menu



(1) Page Information Display  
[PCI Subsystem Configuration] is displayed.

(2) Menu Selection  
The items shown in "TABLE 3.22 Display Contents of Operation Help Display" are displayed.

TABLE 3.23 Display Contents of Menu Selection

Item	Display Contents
PCI ROM Priority	In case of Option ROM of EFI and Legacy, specifies the Option ROM to be start up. <ul style="list-style-type: none"> <li>• Legacy ROM: Selects when Legacy operating system is started.</li> <li>• EFI Compatible ROM: Selects when UEFI aware operating system is selected.</li> </ul> Default setting is, EFI Compatible ROM.
ASPM Support	Uses Active State Power Management (ASPM) as power management of PCI Express Link. However, even though ASPM is enabled, if PCI express adopter and on-board controller dose not supports ASPM, link will not be enabled. <ul style="list-style-type: none"> <li>• Disabled</li> <li>• Auto</li> <li>• Limit to L0s</li> </ul> Default setting is, Disabled.
Number of bus# Padded to slot	Changes the number of Bus allocated in PCI Express Slot. <ul style="list-style-type: none"> <li>• 1</li> <li>• 2</li> <li>• 3</li> </ul> Default setting is 1.
OpROM Scan Configuration	Opens [OpROM Scan Configuration] Menu.
I/O Space Assignment Configuration	Opens [I/O Space Assignment Configuration] Menu.
Commit Changes and Exit	Exit from main menu after the changed contents of configuration are saved.
Discard Changed and Exit	Exit from main menu after the changed contents of configuration are cancelled.

## (3) Operation Help Display

The help for operations mentioned on this page is shown in the "[TABLE 3.24 Display Contents of Operation Help Display](#)"

TABLE 3.24 Display Contents of Operation Help Display

Item	Description
↑↓= Move Highlight	Moves cursor up and down.
<Enter>=Select Entry	Selects item.
Esc=Exit	Returns to ' <a href="#">3.1 Front page of Boot Manager</a> ' without saving changes of this menu'.

### 3.4.7 [IOU OpROM Scan Configuration] Menu

The Option ROM of PCI card mounted on each IOU is configured on [IOU OpROM Scan Configuration] Menu.

Window display example of [IOU OpROM Scan Configuration] Menu shows in the following figure.

FIGURE 3.18 Display Example of [IOU OpROM Scan Configuration] Menu



TABLE 3.25 Display Contents of Menu Selection

Item	Display Contents	Remarks
Slot 1 OpROM (DU)	Sets enable/disable of Legacy OpROM of mounted PCI cards. • Enabled • Disabled Default setting is Disabled.	Settings for DU#0Slot#0
Slot 2 OpROM	Sets enable/disable of Legacy OpROM of mounted PCI cards. • Enabled • Disabled Default setting is Disabled.	Settings for PCI Express slot#0 of IOU#0
Slot 3 OpROM	Sets enable/disable of Legacy OpROM of mounted PCI cards. • Enabled • Disabled Default setting is Disabled.	Settings for PCI Express slot#1 of IOU#0
Slot 4 OpROM	Sets enable/disable of Legacy OpROM of mounted PCI cards.	Settings for PCI Express slot#2 of IOU#0

	<ul style="list-style-type: none"> <li>• Enabled</li> <li>• Disabled</li> </ul> Default setting is Disabled.	
Slot 5 OpROM	Sets enable/disable of Legacy OpROM of mounted PCI cards. <ul style="list-style-type: none"> <li>• Enabled</li> <li>• Disabled</li> </ul> Default setting is Disabled.	Settings for PCI Express slot#3 of IOU#0
Slot 17 OpROM (DU)	Sets enable/disable of Legacy OpROM of mounted PCI cards. <ul style="list-style-type: none"> <li>• Enabled</li> <li>• Disabled</li> </ul> Default setting is Disabled.	Settings for DU#0Slot#1
Slot 18 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"> <li>• Enabled</li> <li>• Disabled</li> </ul> By default, it is Disabled	Setting for PCI Express slot#0 of IOU#1
Slot 19 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"> <li>• Enabled</li> <li>• Disabled</li> </ul> By default, it is Disabled	Setting for PCI Express slot#1 of IOU#1
Slot 20 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"> <li>• Enabled</li> <li>• Disabled</li> </ul> By default, it is Disabled	Setting for PCI Express slot#2 of IOU#1
Slot 21 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"> <li>• Enabled</li> <li>• Disabled</li> </ul> By default, it is Disabled	Setting for PCI Express slot#3 of IOU#1
Slot 33 OpROM (DU)	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"> <li>• Enabled</li> <li>• Disabled</li> </ul> By default, it is Disabled	Setting for DU#1 Slot#0
Slot 34 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"> <li>• Enabled</li> <li>• Disabled</li> </ul> By default, it is Disabled	Setting for PCI Express slot#0 of IOU#2
Slot 35 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"> <li>• Enabled</li> <li>• Disabled</li> </ul> By default, it is Disabled	Setting for PCI Express slot#1 of IOU#2
Slot 36 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"> <li>• Enabled</li> <li>• Disabled</li> </ul> By default, it is Disabled	Setting for PCI Express slot#2 of IOU#2
Slot 37 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted.	Setting for PCI Express slot#3 of IOU#2

	<ul style="list-style-type: none"> <li>• Enabled</li> <li>• Disabled</li> </ul> By default, it is Disabled	
Slot 49 OpROM (DU)	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"> <li>• Enabled</li> <li>• Disabled</li> </ul> By default, it is Disabled	Setting for DU#1 Slot#1
Slot 50 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"> <li>• Enabled</li> <li>• Disabled</li> </ul> By default, it is Disabled	Setting for PCI Express slot#0 of IOU#3
Slot 51 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"> <li>• Enabled</li> <li>• Disabled</li> </ul> By default, it is Disabled	Setting for PCI Express slot#1 of IOU#3
Slot 52 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"> <li>• Enabled</li> <li>• Disabled</li> </ul> By default, it is Disabled	Setting for PCI Express slot#2 of IOU#3
Slot 53 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"> <li>• Enabled</li> <li>• Disabled</li> </ul> By default, it is Disabled	Setting for PCI Express slot#3 of IOU#3
Commit Changes and Exit	The contents having changes in the settings are saved and exit from this menu.	
Discard Changes and Exit	The contents having changes in the settings are cancelled and exit from this menu.	

Remarks:

Slot counting may differ depending on the type of IOUs in the system (IOU\_1GbE: 4 PCI slots, IOU\_10GbE: 3 PCI slots).

### (3) Operation help display

The help for the operations mentioned on this page is shown in [“TABLE 3.26 Display contents of operation help display”](#).

TABLE 3.26 Display contents of operation help display


Items	Description
↑↓ =Move Highlight	Moves the cursor up and down.
<Enter>=Select Entry	Selects the items.
Esc=Exit	Returns to <a href="#">“3.1 Front page of Boot Manager”</a> without saving the setting changes of this menu.

### 3.4.8 [PCI\_Box OpROM Scan Configuration] menu

The settings of Option ROM of the PCI card which is mounted on each PCI\_Box can be done in the [PCI\_Box OpROM Scan Configuration] menu.

The example of window displayed immediately after starting the [PCI\_Box OpROM Scan Configuration] menu is shown below.

FIGURE 3.19 Example of display of [PCI\_Box OpROM Scan Configuration] menu



(1) Page information display

It is displayed as [PCI\_Box OpROM Scan Configuration].

(2) Menu selection

The menu shown in “[TABLE 3.27 Display contents of menu selection](#)” is displayed.

TABLE 3.27 Display contents of menu selection

Items	Display contents	Remarks
Slot 65 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. · Enabled · Disabled By default, it is Disabled	Setting for PCI Express slot#0 of PCI_Box#0
Slot 66 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. · Enabled · Disabled By default, it is Disabled	Setting for PCI Express slot#1 of PCI_Box#0
Slot 67 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. · Enabled · Disabled By default, it is Disabled	Setting for PCI Express slot#2 of PCI_Box#0

Slot 68 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. • Enabled • Disabled By default, it is Disabled	Setting for PCI Express slot#3 of PCI_Box#0
Slot 69 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. • Enabled • Disabled By default, it is Disabled	Setting for PCI Express slot#4 of PCI_Box#0
Slot 70 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. • Enabled • Disabled By default, it is Disabled	Setting for PCI Express slot#5 of PCI_Box#0
Slot 71 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. • Enabled • Disabled By default, it is Disabled	Setting for PCI Express slot#6 of PCI_Box#0
Slot 72 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. • Enabled • Disabled By default, it is Disabled	Setting for PCI Express slot#7 of PCI_Box#0
Slot 73 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. • Enabled • Disabled By default, it is Disabled	Setting for PCI Express slot#8 of PCI_Box#0
Slot 74 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. • Enabled • Disabled By default, it is Disabled	Setting for PCI Express slot#9 of PCI_Box#0
Slot 75 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. • Enabled • Disabled By default, it is Disabled	Setting for PCI Express slot#10 of PCI_Box#0
Slot 76 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. • Enabled • Disabled By default, it is Disabled	Setting for PCI Express slot#11 of PCI_Box#0
Slot 81 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. • Enabled • Disabled By default, it is Disabled.	Setting for PCI Express slot #0 of PCI_Box#1
Slot 82 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. • Enabled • Disabled By default, it is Disabled.	Setting for PCI Express slot #1 of PCI_Box#1

Slot 83 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> By default, it is Disabled.	Setting for PCI Express slot #2 of PCI_Box#1
Slot 84 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> By default, it is Disabled	Setting for PCI Express slot #3 of PCI_Box#1
Slot 85 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> By default, it is Disabled	Setting for PCI Express slot #4 of PCI_Box#1
Slot 86 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> By default, it is Disabled	Setting for PCI Express slot #5 of PCI_Box#1
Slot 87 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> By default, it is Disabled	Setting for PCI Express slot #6 of PCI_Box#1
Slot 88 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> By default, it is Disabled	Setting for PCI Express slot #7 of PCI_Box#1
Slot 89 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> By default, it is Disabled	Setting for PCI Express slot #8 of PCI_Box#1
Slot 90 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> By default, it is Disabled	Setting for PCI Express slot #9 of PCI_Box#1
Slot 91 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> By default, it is Disabled.	Setting for PCI Express slot #10 of PCI_Box#1
Slot 92 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> By default, it is Disabled.	Setting for PCI Express slot #11 of PCI_Box#1
Slot 97 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> By default, it is Disabled.	Setting for PCI Express slot #0 of PCI_Box#2



Slot 98 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> By default, it is Disabled.	Setting for PCI Express slot #1 of PCI_Box#2
Slot 99 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> By default, it is Disabled.	Setting for PCI Express slot #2 of PCI_Box#2
Slot 100 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> By default, it is Disabled.	Setting for PCI Express slot #3 of PCI_Box#2
Slot 101 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> By default, it is Disabled.	Setting for PCI Express slot #4 of PCI_Box#2
Slot 102 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> By default, it is Disabled.	Setting for PCI Express slot #5 of PCI_Box#2
Slot 103 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> By default, it is Disabled.	Setting for PCI Express slot #6 of PCI_Box#2
Slot 104 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> By default, it is Disabled.	Setting for PCI Express slot #7 of PCI_Box#2
Slot 105 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> By default, it is Disabled.	Setting for PCI Express slot #8 of PCI_Box#2
Slot 106 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> By default, it is Disabled.	Setting for PCI Express slot #9 of PCI_Box#2
Slot 107 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> By default, it is Disabled.	Setting for PCI Express slot #10 of PCI_Box#2
Slot 108 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> By default, it is Disabled.	Setting for PCI Express slot #11 of PCI_Box#2

Slot 113 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> By default, it is Disabled.	Setting for PCI Express slot #0 of PCI_Box#3
Slot 114 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> By default, it is Disabled.	Setting for PCI Express slot #1 of PCI_Box#3
Slot 115 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> By default, it is Disabled.	Setting for PCI Express slot #2 of PCI_Box#3
Slot 116 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> By default, it is Disabled.	Setting for PCI Express slot #3 of PCI_Box#3
Slot 117 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> By default, it is Disabled.	Setting for PCI Express slot #4 of PCI_Box#3
Slot 118 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> By default, it is Disabled.	Setting for PCI Express slot #5 of PCI_Box#3
Slot 119 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> By default, it is Disabled.	Setting for PCI Express slot #6 of PCI_Box#3
Slot 120 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> By default, it is Disabled.	Setting for PCI Express slot #7 of PCI_Box#3
Slot 121 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> By default, it is Disabled.	Setting for PCI Express slot #8 of PCI_Box#3
Slot 122 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> By default, it is Disabled.	Setting for PCI Express slot #9 of PCI_Box#3
Slot 123 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> By default, it is Disabled.	Setting for PCI Express slot #10 of PCI_Box#3

Slot 124 OpROM	Enables/disables Legacy OpROM of the PCI card which is mounted. <ul style="list-style-type: none"><li>• Enabled</li><li>• Disabled</li></ul> By default, it is Disabled.	Setting for PCI Express slot #11 of PCI_Box#3
Commit Changes and Exit	The contents having changes in the settings are saved and exit from this menu.	
Discard Changes and Exit	The contents having changes in the settings are cancelled and exit from this menu.	

(3) Operation help display

The help for the operations mentioned on this page is shown in [“TABLE 3.28 Display contents of operation help display”](#).

TABLE 3.28 Display contents of operation help display

Items	Description
↑↓ =Move Highlight	Moves the cursor up and down.
<Enter>=Select Entry	Selects the items.
Esc=Exit	Returns to <a href="#">“3.1 Front page of Boot Manager”</a> without saving the setting changes of this menu.

### 3.4.9 [iSCSI Configuration] menu


In [iSCSI Configuration] menu, as for the IOU network port and expansion card network port which were set in UEFI(PXE/iSCSI) of [LAN Remote Boot Configuration] menu, the environment of iSCSI boot of UEFI Aware Operating System can be set.

The iSCSI boot capable network port is displayed in the menu. The network port which boots the iSCSI is selected and with various settings, iSCSI can be booted from the intended device.

The settings which are changed in the menu will become valid after system reset.

The display example of [iSCSI Configuration] menu is as follows.

FIGURE 3.20 Example of [iSCSI Configuration] menu window display



(1) Page information display  
Displayed as [iSCSI Configuration].

(2) Menu selection  
The items shown in "[TABLE 3.29 Display contents of Menu Selection](#)" are displayed in the menu.

TABLE 3.29 Display contents of Menu Selection

Items	Display contents
iSCSI Initiator Name	Sets iSCSI Initiator Name
Add an Attempt	Opens MAC Selection menu.
Attempt xxxx	As for xxxx, the name set in "iSCSI Attempt Name" of the [Attempt Configuration] menu is displayed. Opens Attempt Configuration menu.  Remarks Only number of LAN ports for which iSCSI is valid is displayed.
Delete Attempt	Opens Delete Attempt menu
Change Attempt Order	Opens Change Attempt Order menu.

(3) Operation help display  
Description of operation key shown in "[TABLE 3.30 Display contents of Operation Help Display](#)" is displayed.

TABLE 3.30 Display contents of Operation Help Display


Items	Description
↑↓= Move Highlight	Moves the cursor in up and down direction.
<Enter>=Select Entry	Selects the item
Esc=Exit	Return to " <a href="#">3.1 Front page of Boot Manager</a> " without saving the change setting of this menu.

#### ■ iSCSI Environment Setting

Setting of iSCSI environment is executed according to the following procedures.

1. To set Initiator Name, [iSCSI Initiator Name] is set.  
Number of characters which can be entered are within 4~223 characters.

FIGURE 3.21 iSCSI Environment Setting Operation Windows (1)

**Remarks**

- When the character string not related with IQN name is entered, Pop Up window of [Invalid iSCSI Name!] is displayed.
- When the number of characters which are entered are not enough, Pop Up window of [Please enter enough characters Press ENTER to continue] is displayed.
- Types of characters which can be entered here are as follows.  
0 - 9, A - Z, a - z, ! " # \$ % & ' ( ) \* + , - . / : ; < = > ? @ [ \ ] ^ \_ ` { | } ~

2. Attempt is created. Place the cursor on "Add an Attempt" of [iSCSI Configuration] menu and then press [Enter] key.

3. Displayed as per "FIGURE 3.22 iSCSI Environment Setting Operation Windows (2) [MAC Selection] menu. For details of [MAC Selection] menu, see "3.4.9.1 [MAC Selection] Menu"

FIGURE 3.22 iSCSI Environment Setting Operation Windows (2) [MAC Selection] menu.



Place the cursor on network port in which iSCSI booting is done, and then press "Enter" key.

4. Displayed as per "[FIGURE 3.23 iSCSI Environment Setting Operation Windows \(3\) \[Attempt Configuration\]menu](#)". For details of "[Attempt Configuration] menu", see "[3.4.9.2 \[Attempt Configuration\] Menu](#)".

FIGURE 3.23 iSCSI Environment Setting Operation Windows (3) [Attempt Configuration]menu

Attempt Configuration		
iSCSI Attempt Name	<input type="text" value="i"/>	The human name defined for this attempt.
iSCSI Mode	<Disabled>	
Internet Protocol	<IP4>	
Connection Retry Count	[0]	
Connection Establishing Timeout	[1000]	
ISID	2CD444F1444A	
Enable DHCP	[ ]	
Initiator IP Address	0.0.0.0	
Initiator Subnet Mask	0.0.0.0	

T4=Move Highlight	F9=Reset to Defaults	F10=Save
	<Enter>=Select Entry	Esc=Exit

Place the cursor position on the item which is to be set, and then set each.

5. To exit from this menu after saving the changes, select [Save Changes] and then press [Enter] key.

6. To exit from this menu without saving the changes, select [Back to Previous Page] and then press [Enter] key.

#### 3.4.9.1 [MAC Selection] Menu

Network port in which iSCSI booting is executed can be selected in [MAC selection] menu.

Example of window display immediately after the start up of [MAC Selection] menu is as follows.



FIGURE 3.24 Display example of [MAC Selection] menu



(1) Page information display

It is displayed as [MAC Selection].

(2) Menu selection

Selection menu shown in “[TABLE 3.31 Display contents of menu selection](#)” is displayed.

TABLE 3.31 Display contents of menu selection

Item	Display content
MAC xx:xx:xx:xx:xx:xx	Displays [] menu.  Remarks xx:xx:xx:xx:xx:xx is MAC address. iSCSI configurable device is displayed in MAC address format.
Commit Changes and Exit	Saves the content having the setting changes and exit from this menu.
Discard Changes and Exit	Cancels the content having the setting changes and exit from this menu.

(3) Operation help display

The help for operations mentioned on this page is shown in the “[TABLE 3.32 Display contents of operation help display](#)”.

TABLE 3.32 Display contents of operation help display

Item	Description
↑↓=Move Highlight	Moves cursor up and down
<Enter>=Select Entry	Selects the item.
Esc=Exit	Returns to “ <a href="#">3.4.9 [iSCSI Configuration] menu</a> ”.

### 3.4.9.2 [Attempt Configuration] Menu

As for the Attempt xxxx which is selected from “3.4.9 [iSCSI Configuration] menu” or the network port MAC xx:xx:xx:xx:xx:xx which is selected from “3.4.9.1 [MAC Selection] Menu”, various settings related to iSCSI Boot can be done in [Attempt Configuration] menu.

The settings which were changed in this menu are enabled after system reset.

The example of window displayed immediately after starting the [Attempt Configuration] menu is shown below.

FIGURE 3.25 Display example of [Attempt Configuration] Menu



(1) Page information display

It is displayed as [Attempt Configuration].

(2) Menu selection

Menu shown in “TABLE 3.33 Display contents of menu selection” is displayed.

TABLE 3.33 Display contents of menu selection

Item	Display contents
iSCSI Attempt Name	Sets the name of iSCSI setting. Types of characters that can be entered are given below. 0-9,A-Z,a-z,!"#%&'()*+,-./:;<=>?@[ \]^_`{ }
iSCSI Mode	Enables/disables the iSCSI boot setting. • Enabled for MPIO • Enabled • Disabled By default, it is Disabled.
Internet Protocol	Selects Internet Protocol. • IP4 • IP6 • Autoconfigure By default, it is IP4. Remarks When it is set to “Autoconfigure”, iSCSI boots with IPv4 and when it is failed, it is attempted to boot iSCSI with IPv6.

Connection Retry Count	<p>Sets number of retries.</p> <ul style="list-style-type: none"> <li>•0~16</li> </ul> <p>By default, it is 0</p>
Connection Establishing Timeout	<p>Sets time out value. Unit is millisecond</p> <p>By default, it is 1000.</p>
ISDI	<p>6 digits of ISID (ID used when initiator establishes session with target) are required for input.</p> <p>Default setting is generated by MAC address.</p> <p>Remarks</p> <ul style="list-style-type: none"> <li>• When the characters entered are insufficient, a pop-up window showing the message, "Please enter enough characters Press ENTER to continue" appears.</li> <li>• If more than 7 digits are entered in ISDI, a pop-up window showing the message, "Error! Input is incorrect, please input 6 hex numbers!" appears.</li> </ul> <p>If 6 digits contain the value other than the hexadecimal number, that number should be entered as 0.</p> <p>(Example)ABCXYZ→ABC000</p>
Enable DHCP	<p>Enables/disables DHCP with space key.</p> <p>When [Internet Protocol] is set to [Autoconfigure], this item is not displayed.</p> <ul style="list-style-type: none"> <li>•[ ]: Disabled</li> <li>•[X]: Enabled</li> </ul> <p>By default, it is Disabled.</p>
Initiation IP Address (*1)	<p>Sets IP Address of iSCSI Initiator side.</p> <p>This item is displayed when [Internet Protocol] is set to [IP4] or [IP6] and enabled DHCP.</p>
Initiator Subnet Mask (*1)	<p>Sets subnet mask of iSCSI Initiator side.</p> <p>This item is displayed when [Internet Protocol] is set to [IP4] or [IP6] and enabled DHCP.</p>
Gateway (*1)	<p>Sets IP address of gateway.</p> <p>This item is displayed when [Internet Protocol] is set to [IP4] or [IP6] and enabled DHCP.</p>
Get Target info via DHCP (*1)	<p>Sets the function to get the IP address, port of iSCSI Target from DHCP server with space key.</p> <p>This item is displayed when [Internet Protocol] is set to [IP4] or [IP6] and enabled DHCP.</p> <ul style="list-style-type: none"> <li>•[ ]: Disabled</li> <li>•[X]: Enabled</li> </ul> <p>By default, it is disabled.</p>
Target Name	<p>Enters the IQN name of target.</p> <p>Number of characters that can be entered are 4~223 characters.</p> <p>This item is displayed when [Internet Protocol] is set to [IP4] or [IP6] and disabled [Get Target info via DHCP].</p> <p>Remarks</p> <ul style="list-style-type: none"> <li>•When character string not related to the IQN name is entered, pop-up window of [Invalid iSCSI Name!] is displayed.</li> <li>•When number of entered character is not enough, pop-up window of [Please enter enough characters Press ENTER to continue] is displayed.</li> <li>•Types of characters that can be entered are given below.</li> </ul> <p>0-9,A-Z,a-z,!"#%&amp;'()*+,-./:;&lt;=&gt;?@[ ¥ ] ^ _ `{ }</p>
Target IP Address	<p>Sets IP Address of target.</p> <p>This item is displayed when [Internet Protocol] is set to [IP4] or [IP6] and disabled [Get Target info via DHCP].</p> <p>By default, it is 0.0.0.0</p>

	<p>Remarks</p> <p>If incorrect value is entered in IP address, subnet mask then pop-up window of [Invalid IP Address] is displayed.</p>
Target Port	<p>Sets TCP listening port of target.</p> <p>Numeric value which can be entered is in the range of 0~65535(decimal).</p> <p>This item is displayed when [Internet Protocol] is set to [IP4] or [IP6] and disabled [Get Target info via DHCP].</p> <p>By default, it is 0</p>
Boot LUN	<p>Sets LUN number of target.</p> <p>This item is displayed when [Internet Protocol] is set to [IP4] or [IP6] and disabled [Get Target info via DHCP].</p> <p>Numeric value is entered in the following format.</p> <p>x ~ xxxx - xxxx - xxxx - xxxx (hexadecimal)</p> <p>By default, it is 0</p>
Authentication Type	<p>Sets the Authentication Type.</p> <ul style="list-style-type: none"> <li>•None</li> <li>•CHAP</li> </ul> <p>By default, it is CHAP.</p>
CHAP Type	<p>Sets the CHAP Type.</p> <p>When [Authentication Type] is set to [None], this item is not displayed.</p> <ul style="list-style-type: none"> <li>•One way</li> <li>•Mutual</li> </ul> <p>By default, it is One way.</p>
CHAP Name	<p>Enters CHAP user name.</p> <p>When [Authentication Type] is set to [None], this item is not displayed.</p> <p>Number of characters that can be entered is 125.</p> <p>Remarks</p> <p>Types of characters that can be entered are given below.</p> <p>0-9, A-Z, a-z, !"#%&amp;'()*+,-./:;&lt;=&gt;?@[ ¥]^_`{ }~</p>
CHAP Secret	<p>Enters CHAP password.</p> <p>When [Authentication Type] is set to [None], this item is not displayed.</p> <p>Number of characters that can be entered is in the range of 12~16.</p> <p>Remarks</p> <ul style="list-style-type: none"> <li>•If number of characters are not enough then pop up window of [Please enter enough characters Press ENTER to continue] is displayed.</li> <li>• Types of characters that can be entered are given below</li> </ul> <p>0-9,A-Z,a-z,!"#%&amp;'()*+,-./:;&lt;=&gt;?@[ ¥]^_`{ }~</p>
Revers CHAP Name	<p>Enters CHAP user name.</p> <p>When [CHAP Type] is set to [One way], this item is not displayed, also when [Authentication Type] is set to [None], this item is not displayed.</p> <p>Number of characters that can be entered is 125.</p> <p>Remarks</p> <p>Types of characters that can be entered are given below.</p> <p>0-9, A-Z, a-z, !"#%&amp;'()*+,-./:;&lt;=&gt;?@[ ¥]^_`{ }~</p>
Revers CHAP Secret	<p>Enters CHAP password.</p> <p>When [CHAP Type] is set to [One way], this item is not displayed, also when [Authentication Type] is set to [None], this item is not displayed.</p> <p>Number of characters that can be entered is in the range of 12~16.</p> <p>Remarks</p> <ul style="list-style-type: none"> <li>•If number of characters are not enough then pop up window of [Please enter enough characters Press ENTER to continue] is displayed.</li> <li>• Types of characters that can be entered are given below</li> </ul> <p>0-9,A-Z,a-z,!"#%&amp;'()*+,-./:;&lt;=&gt;?@[ ¥]^_`{ }~</p>
Save Changes	Saves the changed contents.

Back to Previous Page	Cancels the changed contents which are set and exits from this menu.
-----------------------	--

\*1: When Internet Protocol is set to IP6, this item is not displayed.

### (3) Operation help display

The help for operations mentioned on this page is shown in the [“TABLE 3.34 Display contents of operation help display”](#).

TABLE 3.34 Display contents of operation help display

Item	Description
↑↓= Move Highlight	Moves cursor up and down.
<Enter>=Select Entry	Selects item.
Esc=Exit	Returns to '3.1 Front page of Boot Manager' without saving the changes of this menu.

3.4.9.3 [Delete Attempts] Menu

In [Delete Attempts] menu, Attempt can be cancelled and also SCSI settings set in that network port can be cancelled.  
Changes in this menu are enabled after the resetting the system.

FIGURE 3.26 Display example of [Delete Attempts] menu



(1) Page information display  
Displayed with [Delete Attempts]

(2)Menu selection  
Selection menu shown in 'TABLE 3.35 Display contents of Menu selection' is displayed.

TABLE 3.35 Display contents of Menu selection

Item	Display contents
Attempt xxxx	xxxx displays the name set in 'iSCSI Attempt Name' of '3.4.9.2 [Attempt Configuration] Menu' "X" appears when space key is pressed. If "Commit Changes and Exit" is selected in this state, iSCSI settings get cancelled. •[] •[X]: If "Commit Changes and Exit" is selected at this state, iSCSI settings get cancelled.

Commit Changes and Exit	Saves the changed contents and exits from this menu.
Discard Changes and Exit	Cancels the changed contents and exits from this menu.

(3) Operation help display

The help for operations mentioned on this page is shown in the "TABLE 3.36 Display Contents of Operation Help Display".


TABLE 3.36 Display Contents of Operation Help Display

Item	Description
↑↓= Move Highlight	Moves the cursor up and down.
<Enter>=Select Entry	Selects item.
Esc=Exit	Returns to '3.4.9 [iSCSI Configuration] menu.'

#### 3.4.9.4 [Change Attempt Order] menu

In [Change Attempt Order] menu, priority of boot of network which is booted with iSCSI, can be set. Changes in this menu are enabled after resetting the system.

FIGURE 3.27 Display example of [Change Attempt Order] Menu



(1) Page information display

Displayed with [Change Attempt Order]

(2) Menu selection

Selection menu is shown in 'TABLE 3.37 Display contents of Menu selection'.

TABLE 3.37 Display contents of Menu selection

Item	Display contents
Change Attempt Order	Priority level can be raised with '+ Key' after selecting Attempt xxxx. xxxx displays the name set in 'iSCSI Attempt Name' of <a href="#">'3.4.9.2 [Attempt Configuration] Menu'</a>
Commit Changes and Exit	Saves the changed contents and exits from this menu.
Discard Changes and Exit	Cancels the changed contents and exits from this menu.

(3) Operation help display

The help for operations mentioned on this page is shown in the ["TABLE 3.38 Display Contents of Operation Help Display"](#).

TABLE 3.38 Display Contents of Operation Help Display

Item	Description
↑↓= Move Highlight	Moves cursor up and down.
<Enter>=Select Entry	Selects item.
Esc=Exit	Returns to <a href="#">'3.4.9 [iSCSI Configuration] menu.'</a>

Remarks


"Table 3.39 Display Contents of Operation Help Display" and the contents displayed differ as ["FIGURE 3.27 Display example of \[Change Attempt Order\] Menu"](#) is the display example window after selecting Attempt. Contents displayed in ["TABLE 3.38 Display Contents of Operation Help Display"](#) are displayed immediately after the activation of [Change Attempt Order] menu.

### 3.4.10 [Memory Configuration] menu

In [Memory Configuration] menu, memory related settings are done.  
Changes in this menu are enabled after the system is reset.



FIGURE 3.28 Display Example of [Memory Configuration] Menu



The following section shows the window display example of [Memory Configuration] menu.

(1) Page information display

Displayed as [Memory Configuration]

(2) Menu selection

Items are shown in the "TABLE 3.39 Display Contents of Menu Selection" are shown in the menu.

TABLE 3.39 Display Contents of Menu Selection

Item	Description
DIMM Speed (*1)	Sets the operating speed of memory module. <ul style="list-style-type: none"> <li>• Performance Mode: Sets maximum possible operating frequency for this mode.</li> <li>• Normal Mode: Sets the maximum possible operating frequency that can be operated by 1.35V voltage for this mode.</li> </ul> Default setting is Normal mode.
Patrol Scrub (*1)	Scans memory module at regular interval. If CE is detected, the function which writes back the corrected data is enabled / disabled. <ul style="list-style-type: none"> <li>• Disabled</li> <li>• Enabled</li> </ul> Default setting is Enabled
Refresh Rate	Sets the refresh rate of the memory. <ul style="list-style-type: none"> <li>• Auto</li> <li>• 1x</li> </ul> Default setting is Auto
Commit Changes and Exit	Saves the changed contents and exits from this menu.
Discard Changes and Exit	Cancels the changed contents and exits from this menu.

(3) Operation help display

Description of help key is shown in the "TABLE 3.40 Display Contents of Operation Help Display".



TABLE 3.40 Display Contents of Operation Help Display

Item	Description
↑↓= Move Highlight	Moves cursor up and down.
<Enter>=Select Entry	Selects item.
Esc=Exit	Returns to “3.1 Front page of Boot Manager” without saving changes of this menu’.

### 3.4.11 [USB Configuration] menu

In [USB Configuration] menu, USB related settings are performed.

#### Remarks

The following figure shows the example of window which is displayed immediately after activation of [USB Configuration] menu.

FIGURE 3.29 Display example of [USB Configuration] menu



(1) Page information display  
Displayed with [USB Configuration]

(2) Menu selection  
Items shown in “TABLE 3.41 Display contents of Menu selection” are shown in the Menu.

TABLE 3.41 Display contents of Menu selection

Item	Display contents
USB Devices:	Displays the number of usable USB drive, USB keyboard, USB mouse and USB hub. <i>n Drive(s), n Keyboard(s), n Mouse(s), n Hub(s)</i>
Legacy USB Support	Specifies whether USB Legacy support can be used. • Disabled • Enabled • Auto Default setting is Enabled. Remarks When operating system needs to be started from USB drive, it is necessary to set this function to 'Enabled' or to 'Auto'.
USB Port Disable	Sets the usage method of USB port. Disabled USB port cannot be used during POST and also by the operating system. • Enabled • Disabled Default setting is Enabled.
Mass Storage Devices: "Connection device name"	Sets the emulation pattern of device. • Auto • Floppy • Forced FDD • Hard Disk • CD - ROM Default setting is Auto. Remarks When 'Auto' is selected, it is emulated according to the media format of device. Optical disk drive is emulated as 'CD-ROM', drive without media is emulated according to the drive type.
Commit Changes and Exit	Saves the changed contents and exits from this menu.
Discard Changes and Exit	Cancels the changed contents and exits from this menu.

## (3) Operation help display

Describes the operation key shown in "TABLE 3.42 Display Contents of Operation Help Display".

TABLE 3.42 Display Contents of Operation Help Display

Item	Description
↑↓= Move Highlight	Moves cursor up and down.
<Enter>=Select Entry	Selects item.
Esc=Exit	Returns to '3.1 Front page of Boot Manager' without saving changes of this menu'.

### 3.4.12 [Security Configuration] menu

In [Security Configuration] menu, settings related to TPM are performed.

#### Remarks

The TPM chip is not mounted, [Security Configuration] menu is not displayed.

The following figure shows the window display example of [Security Configuration] menu.

FIGURE 3.30 Display Example of [Security Configuration] Menu



(1) Page information display

Displayed as [Security Configuration] menu.

(2) Menu selection

Selection menu is shown in the "TABLE 3.43 Display Contents of Menu Selection".

TABLE 3.43 Display Contents of Menu Selection

Item	Display contents
TPM Support	Sets whether TPM is supported in BIOS. Disabled Enabled Default setting is Disabled.
TPM State	Performs the settings for status of TPM chip. • Disabled • Enabled Default setting is Disabled. Remarks Displayed when "Enabled" is selected in "TPM Support". Sets the value of "TPM Enabled Status" and "TPM Active Status" as per the set value of "TPM Status", as mentioned below. • When "Enabled" is selected TPM Enabled Status ⇒ Enabled

	TPM Activate Status ⇒ Activated • When 'Disabled' is selected TPM Enabled Status ⇒ Disabled TPM Activate Status ⇒ Deactivated
Pending TPM operation	Performs settings on other TPM chip. •None •Enable Take Ownership •Disable Take Ownership •TPM Clear Default setting is None. Remarks "Pending TPM operation" is displayed when "Enabled" is selected in "TPM Support". "TPM Enabled Status" of "Current TPM operation" is "Enabled" and selection is possible if "TPM Active Status" is "Activated". In other situations, gray out is displayed and selection is not possible.
Current Status Information	Current status of TPM chip is displayed. When TPM Support is set to Disabled, "SUPPORT TURNED OFF" is displayed.  Warning Following is the TPM Chip status displayed as TPM Enabled Status, TPM Activate Status, and TPM Owner Status. No item is set. However, as the TPM Chip status cannot be read immediately after changing the settings of [TPM SUPPORT] from [Disabled] to [Enabled], the default value is set to [Disabled],[Deactivated],[Unowned]
TPM Enabled Status	Values which can be set as [TPM State] are displayed as follows. •[Enabled]: When [Enabled] is set as [TPM State] •[Disabled]: When [Disabled] is set as [TPM State]
TPM Active Status	Values which can be set in [TPM State] are displayed as follows. •[Activated]: When [Enabled] is selected as [TPM State] •[Deactivated]: When [Disabled] is selected as [TPM State]
TPM Owner Status	Shows whether the TPM chip is authorized •[Owned] •[Unowned]
Commit Changes and Exit	Exit from this menu after saving the changes in the settings.
Discard Changes and Exit	Exit from this menu after cancelling the changes in the settings.

## (3) Operation Help Display

The help for the operations mentioned on this page is shown in "TABLE 3.44 Display contents of operation help display".

TABLE 3.44 Display contents of operation help display


Items	Description
↑↓ =Move Highlight	Moves the cursor up and down.
<Enter>=Select Entry	Selects the items.
Esc=Exit	Returns to "3.1 Front page of Boot Manager" without saving the setting changes of this menu.

### 3.5 [Boot maintenance Manager] Menu

Setting of boot mode, addition or removal of boot option, changes in the boot priority level and changes in the driver option are carried out in the [Boot maintenance manager] menu. Each menu can be displayed by placing the cursor on the menus for operation and by pressing the [Enter] key.

Following window is the window immediately after the activation of [Boot maintenance Manager] menu.

FIGURE 3.31 [Boot Maintenance manager] Menu



(1) Page Information Display  
Displays as [Boot maintenance Manager]

(2) Menu selection  
Displays the menu as shown in “[TABLE 3.45 Display Contents of Menu Selection](#)”

TABLE 3.45 Display Contents of Menu Selection

Items	Description
Boot Mode	Displays <a href="#">3.5.1 [Boot Mode] Menu</a>
Boot Options	Displays <a href="#">3.5.2 [Boot Options] menu</a>
Boot From File	Displays <a href="#">3.5.3 [Boot From File] Menu</a>
Set Boot Delay Time	Displays <a href="#">3.5.4 [Set Time out Value] Menu</a>
Reset System	Resets the setting

3) Operation Help Display  
The help for the operations mentioned on this page is shown in “[TABLE 3.46 Display Contents of Operation Help Display](#)”.


TABLE 3.46 Display Contents of Operation Help Display

Items	Description
↑↓ =Move Highlight	Moves the cursor up and down.
<Enter>=Select Entry	Selects the items.
Esc=Exit	Returns to “3.1 Front page of Boot Manager”.

3.5.1 [Boot Mode] Menu

Boot mode settings are done in the [Boot Mode] menu.

FIGURE 3.32 Example Display of [Boot Mode] Menu



(1) Page Information Display  
Displays as [Boot Mode]

(2) Menu Selection  
Displays the screen as shown in “Display Contents of the [TABLE 3.47 Display Contents of Menu Selection Section](#)”

TABLE 3.47 Display Contents of Menu Selection Section

Item	Display Contents
Boot Mode	Select the Boot Mode •UEFI and Legacy: Both the boot options UEFI and Legacy are enabled. •Only UEFI: Only the boot option UEFI is enabled. •Only Legacy: Only the boot option Legacy is enabled.  Default is UEFI and Legacy.
Commit Changes and Exit	Exit from this menu after saving the changes.
Discard Changes and Exit	Exit from this menu after cancelling the changes.



### 3) Operation Help Display

The help for the operations mentioned on this page is shown in “[TABLE 3.48 Display contents of operation help display](#)”.

TABLE 3.48 Display contents of operation help display

Items	Description
↑↓ =Move Highlight	Moves the cursor up and down.
<Enter>=Select Entry	Selects the items.
Esc=Exit	Returns to “ <a href="#">3.1 Front page of Boot Manager</a> ”

## 3.5.2 [Boot Options] menu

Addition or removal of boot option and changes in the boot priority level can be carried out in the [Boot Options] menu. Each menu can be displayed by placing the cursor on the menus for operation and by pressing the [Enter] key.

Following window is the window at the time of activation of the [Boot Options] menu

FIGURE 3.33 [Boot options] menu



(1) Display of Page information  
[Boot Options] are displayed.

(2) Menu Selection  
Menu shown in [TABLE 3.49 Display contents of Menu selection](#) is displayed.

TABLE 3.49 Display contents of Menu selection

Item	Description
Go Back To Main Page	"3.5 [Boot maintenance Manager] Menu" is displayed.
Add Boot Option	"■[Add Boot Option] Menu" is displayed.
Delete Boot Option	"■[Delete Boot Option] Menu" is displayed.
Change Boot Order	"■[Change Boot Order] Menu" is displayed.
Set Legacy Floppy Drive Order	"■[Set Legacy Floppy Drive Order] Menu" is displayed.
Set Legacy HardDisk Drive Order	"■[Set Legacy HardDisk Drive Order] Menu" is displayed.
Set Legacy CD-ROM Drive Order	"■[Set Legacy CD-ROM Drive Order] Menu" is displayed.
Set Legacy NET Drive Order	"■[Set Legacy NET Drive Order] Menu" is displayed.

## (3) Display of operation help

Description of operation key shown in "TABLE 3.50 Display contents of Display of operation help" is displayed.

TABLE 3.50 Display contents of Display of operation help

Item	Description
↑ ↓ =Move Highlight	Moves cursor up and down.
<Enter>=Select Entry	Selects item
Esc=Exit	Returns to "3.1 Front page of Boot Manager".


## ■ [Add Boot Option] Menu

[Add Boot Option] is used to add new boot option to [Boot Manager]. If Operating System boot loader is added and registered as boot option, as shown in the following figure, boot option registered in [Boot Manager] Menu is displayed.

Newly added and registered boot option is added at the tag end of [Boot Manager] Menu.

Example of addition of Test Boot Option is shown in "FIGURE 3.34 Display Example of [Boot Manager] Menu".

FIGURE 3.34 Display Example of [Boot Manager] Menu



“[FIGURE 3.35 Display Example of \[Add Boot Option\] Menu](#)” is a window shown immediately after the start-up of [Add Boot Option]. As shown in the figure, the list of device is shown in device path format. (Details of device path are mentioned in “[3.6 Device Path](#)”)

FIGURE 3.35 Display Example of [Add Boot Option] Menu



- (1) Display of Page information  
[File Explorer] is displayed.
- (2) Menu Selection  
A list of storage devices recognized by UEFI is displayed.
- (3) Display of Operation help  
Description of operation key shown in “[TABLE 3.51 Display contents of Display of Operation help](#)” is displayed.

TABLE 3.51 Display contents of Display of Operation help

Item	Description
↑ ↓ =Move Highlight	Moves cursor up and down.
<Enter>=Select Entry	Selects item
Esc=Exit	Returns to “ <a href="#">3.1 Front page of Boot Manager</a> ”.




**Addition of Boot Option**

The addition of Boot Option is implemented by the following procedure.

1. Place the cursor on the storage device in which the start-up files that are to be added, are stored, from the list of devices shown in “[FIGURE 3.36 A list of Devices](#)”,

FIGURE 3.36 A list of Devices




2. Press [Enter] key.

As shown in “[FIGURE 3.37 Display example of File Selection Window](#)”, a list of files in the selected storage device, is displayed. The matter enclosed in “< >” is a directory. Following is the display example when the disk installed by Windows Server 2012, is selected.

In case of Windows Server 2012, [¥EFI¥Microsoft¥Boot¥bootx64.efi] file is an Operative system loader.

FIGURE 3.37 Display example of File Selection Window



Following is the description of the example of creation of boot option specifying this file

**Remark**

Directory structure of the disk installed for Windows Server 2012


The disk installed for Windows Server 2012 has the following directory structure.

```

<EFI>
    <Microsoft>
    <Boot>
        Bootx64.efi      Operative System Boot Loader
    
```


3. Following the directory structure, [bootx64.efi], which is an Operative System boot loader, is displayed as shown in “[FIGURE 3.38 Windows Server 2012 Installed Disk Window](#)”.

FIGURE 3.38 Windows Server 2012 Installed Disk Window



4. Press [↑] key and [↓] key and select [bootx64.efi] which is an operating system loader registered additionally.
5. Press [Enter] key. Window showing “[FIGURE 3.39 Display Example of Boot Option Name Change Window](#)” is displayed.

FIGURE 3.39 Display Example of Boot Option Name Change Window



- Set Boot option name and set options when booting.
- a. Boot option name setting
 


Place the cursor on [Input the description], press [Enter] key. Enter name as Pop-up window for input is displayed.
  - b. Setting options when booting
 

Place the cursor on [Input Optional Data], press [Enter] key. Enter name as Pop-up window for input is displayed.

For details on the number of characters and types of character that can be entered, see “[Number of Characters and Types of Characters that can be entered](#)”
6. Exit from this menu by following operations.
- To exit from this menu after saving the changed setting, select [Commit Changes and Exit] and press [Enter] key.
  - To exit from this menu without saving the changed setting, select [Discard Changes and Exit] is and press [Enter] key.
7. Confirm that the boot option is added normally, by using the following procedure of [FIGURE 3.40 Display Example of \[Boot Manager\] Menu](#).
- a. Open the [Boot Manager] menu from Boot Manager front page.
 

Menu shown in “ ” is displayed.
  - b. It is confirmed that the added boot option is displayed at the footer.

FIGURE 3.40 Display Example of [Boot Manager] Menu



- Number of Characters and Types of Characters that can be entered  
Number of Characters and Types of Characters that can be entered in [Add Boot Option] Menu are shown in “TABLE 3.52 Number of Characters and Types of Characters that can be entered”.


TABLE 3.52 Number of Characters and Types of Characters that can be entered

Item	Number of Characters	Types of Character
Input the description	6 - 75	0 - 9, A - Z, a - z, ! " # \$ % & ' ( ) * +, - . / : ; < = > ? @ [ ¥ ] ^ _ ` {   } ~
Input Optional Data	0 - 120	0 - 9, A - Z, a - z, ! " # \$ % & ' ( ) * +, - . / : ; < = > ? @ [ ¥ ] ^ _ ` {   } ~

- Remarks
- Input is not possible if the number of characters exceeds the restricted value. Though the key exceeding the restricted value seems to be input temporarily, it is ignored, and is not reflected on the window.
  - Types of characters other than mentioned above cannot be entered. Even if it they are temporarily entered, they are ignored and are not reflected on window.
  - When the types of characters in [Input the description] are between 0-5, pop-up window appears containing a message as ‘Please enter enough characters Press Enter to continue’.

- [Delete Boot option] menu  
[Delete Boot option] menu, deletes the specified boot option from boot order. The following window shows the window display example of [Delete Boot option] menu.

FIGURE 3.41 Display example of [Delete Boot option] menu



- (1) Page information display  
It is displayed as [Delete Boot Option].
- (2) Menu selection  
The boot option with a high priority level of automatic boot is displayed in order from top.
- (3) Operation help menu  
Description of operation key is shown in 'TABLE 3.53 Display contents of operation help display'.

TABLE 3.53 Display contents of operation help display


Items	Description
↑↓= Move Highlight	Moves cursor in up and down direction.
<Enter>=Select Entry	Selects item.
Esc=Exit	Returns to "3.1 Front page of Boot Manager".

■ Boot option removal  
Removal of boot option is executed according to the following procedure.

1. Place the cursor on the boot option which is to be removed.
2. Press [Space] key. As shown in "Deletion screen (1) of FIGURE 3.42 boot option", [ ] is changed to [X].



FIGURE 3.42 Delete window (1) of boot option




Remarks

Press [Space] key again when 'delete' is cancelled.  
When “Space” key is pressed again, [ ] changes to [X].

3. To exit from this menu after saving the changed setting, select [Commit Changes and Exit] and press [Enter] key.  
To exit from this menu without saving the changed setting, select [Discard Changes and Exit] is and press [Enter] key.
4. Confirm that the boot option is deleted normally by using the following procedure.
  - a. Open the [Boot Manager] menu from Boot Manager front page.  
Menu shown in “[FIGURE 3.43 Boot Option Deletion Window \(2\)](#)” is displayed.
  - b. It is confirmed that the deleted boot option does not exist.

FIGURE 3.43 Boot Option Deletion Window (2)



### ■ [Change Boot Order] Menu

[Change Boot Order] menu is use to change the boot order.

Following window is displayed immediately after booting [Change Boot Order] menu.

FIGURE 3.44 [Change Boot Order] Menu



(1) Page Information Display

[Change Boot Order] is displayed.

(2) Menu Selection

Items shown in "TABLE 3.54 Display Contents of Menu Selection" are displayed.

TABLE 3.54 Display Contents of Menu Selection

Items	Description
Change the order	Displays boot option. Pop-up window is displayed when this command is executed, wherein the settings of boot order can be changed. As for the legacy boot option, boot option with highest boot priority level of each device is displayed. Legacy device consists of the following four devices. <ul style="list-style-type: none"> <li>• Floppy Device</li> <li>• HardDisk Device</li> <li>• DVD/CD-ROM Device</li> <li>• Network Device</li> </ul> Change method is explained in following " ■ Change in Priority Level (Change Boot Order)"
Commit Changes and Exit	Exit from main menu after the changed contents of settings are saved.
Discard Changes and Exit	Exit from main menu after the changed contents of settings are cancelled.

(3) Operation Help Display

Description of operation key is shown in the "TABLE 3.55 Display Contents of Operation Help Display"

TABLE 3.55 Display Contents of Operation Help Display

Item	Description
↑↓= Move Highlight	Moves cursor up and down.
<Enter>=Select Entry	Selects item.
Esc=Exit	Returns to '3.1 Front page of Boot Manager' without saving changes of this menu'.

The contents displayed when the Pop-up Window appears are shown in "TABLE 3.56 Display Contents of Operation Help Display when Pop-up Window appears."

TABLE 3.56 Display Contents of Operation Help Display when Pop-up Window appears


Item	Description
+ = Move Selection Up	Raise the boot priority level of .boot option by 1
- + Move Selection Down	Lower the boot priority level of .boot option by 1
<Enter>=Complete Entry	Selects item.
Esc=Exit	Exit from Pop-up Window

#### ■ Change in Priority Level (Change Boot Order)

The changes of boot order are executed according to the following procedure.


1. As shown in "FIGURE 3.45 Change Window of Priority Order (Change Boot Order) (1)", place the cursor to boot option displayed as [Change the order].

FIGURE 3.45 Change Window of Priority Order (Change Boot Order) (1)



2. Press [Enter] key. Pop-up window shown in "FIGURE 3.46 Change Window of Priority Order (Change Boot Order) (2)" appears.

FIGURE 3.46 Change Window of Priority Order (Change Boot Order) (2)



3. Place the cursor to boot option for which order is changed.
4. Change the priority order.
  - Press [+] key to raise the priority order.
  - Press [-] key to lowered the priority order
5. Exit from Pop-up window after changes is done.
  - Press [Enter] key, when you want to exit by saving the changes of configuration
  - Press [Esc] key, when you want to exit by discarding the changes of configuration.

FIGURE 3.47 Windows after setting of priority level is changed (Change Boot Order) (3)



6. To exit from the menu after saving the changes, select [Commit Changes and Exit] and then press [Enter] key.

To exit from this menu without saving the changes, select [Discard Changes and Exit] and then press [Enter] key.

#### ■ [Set Legacy Floppy Drive Order]Menu

When multiple DVD/CD drive exists, the [Set Legacy DVD/CD - ROM Drive Order] menu sets the priority level of the startup device.

Window at the time of startup of [Set Legacy Floppy Drive Order] menu is as follows.

The information on floppy drive is displayed on the window. Or, when “Disable” is displayed in Floppy Drive # N, the boot function of Floppy Drive #N is Disable is shown.

FIGURE 3.48 Display example of [Set Legacy Floppy Drive Order] menu



(1) Page information display

It is displayed as [Set Legacy Floppy Drive Order].

(2) Menu Selection

Selection menu shown in “[TABLE 3.57 Display contents of menu selection](#)” is displayed

TABLE 3.57 Display contents of menu selection

Items	Description
Floppy Drive #N (N: 0, 1...)	Switchover to change the order of Floppy boot. When this item is executed, pop-up window is displayed and the settings can be changed. After this, changing method is described in detail in “ <a href="#">■ Change in priority level (Set Legacy Floppy Drive Order)</a> ”.
Commit Changes and Exit	Exit from this menu, after saving the set contents.
Discard Changes and Exit	Exit from this menu, after cancelling the set contents.

(3) Operation help display

The help for operations mentioned on this page is shown in the "TABLE 3.58 Display contents of operation help display".

TABLE 3.58 Display contents of operation help display

Items	Description
↑↓= Move Highlight	Moves cursor in up and down direction.
<Enter>=Select Entry	Selects item.
Esc=Exit	Returns to "3.1 Front page of Boot Manager".

When pop-up window appears, display contents are shown in "TABLE 3.59 Display Contents of operation help display when pop-up window appears"


TABLE 3.59 Display Contents of operation help display when pop-up window appears

Items	Description
↑↓= Move Highlight	Moves cursor in up and down direction.
<Enter>=Select Entry	Selects item.
Esc=Exit Entry	Closes the pop-up window.

■ Change in priority level (Set Legacy Floppy Drive Order)  
Change in boot order is executed according to the following procedure.


1. In window shown in "FIGURE 3.49 Change in priority level (Set Legacy Floppy Drive Order) (1)", place the cursor on Floppy Drive# N in which device is to be changed. Select Floppy Drive #00 in "FIGURE 3.49 Change in priority level (Set Legacy Floppy Drive Order) (1)".

FIGURE 3.49 Change in priority level (Set Legacy Floppy Drive Order) (1)



2. Press [Enter] key. Pop-up window appears is shown in "FIGURE 3.50 Change in priority level (Set Legacy Floppy Drive Order) (2)".

FIGURE 3.50 Change in priority level (Set Legacy Floppy Drive Order) (2)



3. Place the cursor on the boot option that is to be set in Floppy Drive # N. Boot option for Floppy Drive #00 is set in “[FIGURE 3.50 Change in priority level \(Set Legacy Floppy Drive Order\) \(2\)](#)”.
4. Press [Enter] key. Boot option of Floppy Drive #00 is changed from Y-E DATAUSB-FDU 7.03 to Fujitsu Virtual Floppy 01.00 in “[FIGURE 3.50 Change in priority level \(Set Legacy Floppy Drive Order\) \(2\)](#)”.

“[FIGURE 3.51 Change of priority level \(Set Legacy Floppy Drive Order\) \(3\)](#)” is a window example when priority level of HDD is changed. When the boot option set in Floppy Drive #N is set in another Floppy Drive #M before setting, boot option set in Floppy Drive #N is set in Floppy Drive#M before changing. In “[FIGURE 3.51 Change of priority level \(Set Legacy Floppy Drive Order\) \(3\)](#)”, Y - E DATAUSB - FDU 7.03 is set in Floppy Drive #01 in which Fujitsu Virtual Floppy0 1.00 is set.

FIGURE 3.51 Change of priority level (Set Legacy Floppy Drive Order) (3)




5. Set Enable/Disable of the Floppy Drive #N.

- Select “Disable” to disable.
- Select the boot option to enable.

“[FIGURE 3.52 Change of the priority level \(Set Legacy Floppy Drive Order\) \(4\)](#)” is an example of the window in which Floppy Drive # 00 is set to Disable.

Disabled Floppy Drive #N is displayed as “Disable”.

FIGURE 3.52 Change of the priority level (Set Legacy Floppy Drive Order) (4)



6. To exit from this menu by saving changes in the setting, select [Commit Changes and Exit] and press [Enter] key. To exit from this menu without saving changes in the setting, select [Discard Changes and Exit] and press [Enter] key.


#### ■ [Set Legacy Hard Disk Order] Menu

[Set Legacy Hard Disk Order] menu sets the HDD to be activated in the legacy operating system. The window at the time of activation of [Set Legacy Hard Disk Order] menu is as shown below.

HDD information is displayed in this window. The HardDisk Drive is activated from #00. Moreover, when “Disable” is displayed in #N of the HardDisk Drive, the boot function of HardDisk Drive #N is shown to be Disabled.



FIGURE 3.53 Display Example of [Set Legacy HardDisk Drive Order] Menu



(1) Page Information Display

Displays as [Set Legacy HardDisk Drive Order]

(2) Menu Selection

Displays the items shown in the “[TABLE 3.60 Display Contents of Menu Selection](#)”

TABLE 3.60 Display Contents of Menu Selection

Item	Explanation
HardDisk Drive #N (N: 0, 1 ...)	<p>Following is displayed.</p> <ul style="list-style-type: none"> <li>•HDD information confirmed at the time of initialization after the power-on</li> <li>•Disable: Displayed when Disable is selected.</li> </ul> <p>Device for which the configuration is changed after initialization is not displayed. Hence the system should be reset after the device configuration changes. Further, the configuration change of the device indicates the case where the following operations are executed.</p> <ul style="list-style-type: none"> <li>•Swapping of USB devices</li> <li>•Activation of configuration display and update menu of Fibre channel and SAS RAID</li> </ul> <p>The change method is explained next in “<a href="#">Change of the Priority Level (Set Legacy HardDisk Drive Order)</a>”.</p>
Commit Changes and Exit	Exit from this menu after saving the changes.
Discard Changes and Exit	Exit from this menu after cancelling the changes.

(1) Operation Help Display

Displays the explanation of the operation key shown in “[TABLE 3.61 Display Contents of the Operation Help Display](#)”

TABLE 3.61 Display Contents of the Operation Help Display

Item	Explanation
↑↓ =Move Highlight	Moves the cursor up and down.
<Enter>=Select Entry	Selects the items.
Esc=Exit	Returns to “3.1 Front page of Boot Manager”.

“TABLE 3.62 Display Contents of the Operation Help Display when Pop-up Window appears” when pop-up window appears shows the display contents of the Operation Help Display when the pop-up window is appeared.

TABLE 3.62 Display Contents of the Operation Help Display when Pop-up Window appears


Item	Explanation
↑↓ =Move Highlight	Moves the cursor up and down.
<Enter>=Complete Entry	Selects the items.
Esc=Exit Entry	Closes the pop-up window.

#### ■ Change of the Priority Level (Set Legacy HardDisk Drive Order)

HDD which is targeted for activation is installed in the following sequence.

1. In the window shown in “FIGURE 3.54 Change of the Priority Level (Set Legacy HardDisk Drive Order) (1)”, place the cursor on HardDisk Drive #N which wants to change the device. In the “FIGURE 3.54 Change of the Priority Level (Set Legacy HardDisk Drive Order) (1)” HardDisk Drive #00 is selected.

FIGURE 3.54 Change of the Priority Level (Set Legacy HardDisk Drive Order) (1)



1. Press [Enter] key. A pop-up window shown in “FIGURE 3.55 Change in Priority Level (Set Legacy HardDisk Drive Order) (2)” appears.

FIGURE 3.55 Change in Priority Level (Set Legacy HardDisk Drive Order) (2)



3. The cursor is placed on the boot option which is to be set in HardDisk Drive #N.  
In the "FIGURE 3.55 Change in Priority Level (Set Legacy HardDisk Drive Order) (2)", the boot option is set for HardDisk Drive #00.
4. [Enter] key is pressed. In "FIGURE 3.55 Change in Priority Level (Set Legacy HardDisk Drive Order) (2)", the boot option of HardDisk Drive #00 is changed from (Bus 08 Dev 00) PCI RAID Adapter to Fujitsu HandyDrive100.

"FIGURE 3.56 Change in Priority Level (Set Legacy HardDisk Drive Order) (3)" is an example of window when the priority level of HDD is substituted.

When the boot option set in HardDisk Drive Order #N is set in another HardDisk Drive Order #M before setting, the boot option which had been set in HardDisk Drive Order #N before making changes, is set in HardDisk Drive Order #M. In "FIGURE 3.56 Change in Priority Level (Set Legacy HardDisk Drive Order) (3)", (Bus 08 Dev 00) PCIRAIID Adapter is set to HardDisk Drive Order#01 in which Fujitsu HandyDrive100 is set.

FIGURE 3.56 Change in Priority Level (Set Legacy HardDisk Drive Order) (3)




5. Enable/Disable of HardDisk Drive #N is set.

- Select “Disable” to make Disable.
- Select boot option to make Enable.

“FIGURE 3.57 Change in Priority Level (Set Legacy HardDisk Drive Order) (4)” is an example of window on which the HardDisk Drive #00 is set to Disable.  
The Disabled HardDisk Drive #N is displayed as “Disable”.

FIGURE 3.57 Change in Priority Level (Set Legacy HardDisk Drive Order) (4)



6. Select [Commit Changes and Exit] and press [Enter] key to exit from the menu by saving the set changes. Select [Discard Changes and Exit] and press [Enter] key to exit from the menu without saving the set changes.

#### ■ [Set Legacy CD-ROM Drive Order] Menu

When DVD/CD drives exist in multiple numbers, the [Set Legacy CD-ROM Drive Order] menu sets the priority level of the startup device.

The window at the time of starting menu [Set Legacy CD - ROM Drive Order] is indicated below.

The information on the DVD/CD drive is displayed on the window. Moreover, if “Disable” is displayed in ATAPI CDROM Drive# N the boot function of ATAPI CDROM Drive #N is Disable.

FIGURE 3.58 Example of Displayed [Set Legacy CD-ROM Drive Order] Menu



(1) Page Information Display

Displayed as [Set Legacy CD-ROM Drive Order]

(2) Menu Selection

The items indicated in "TABLE 3.63 Displayed Contents of Menu Selection" are displayed.

TABLE 3.63 Displayed Contents of Menu Selection

Items	Description
ATAPI CDROM Drive #N (N:0, 1, ...)	Moves to order change of DVD/CD boot. If the item is executed, the pop up window is displayed and then, the setting can be changed. The change method is explained in detailed by subsequent "■Change in priority level (Set Legacy CD - ROM Drive Order)" after this. Furthermore,
Commit Changes and Exit	After saving the contents for which the setting is changed, exit from the menu.
Discard Changes and Exit	After cancelling the contents for which the setting is changed, exit from the menu.

(3) Operation Help Display

Description of Operating Keys is shown in the "TABLE 3.64 Display Contents of Operation Help Display"

TABLE 3.64 Display Contents of Operation Help Display

Item	Description
↑↓= Move Highlight	Moves cursor up and down.
<Enter>=Select Entry	Selects item.
Esc=Exit	Returns to '3.1 Front page of Boot Manager'.

The contents displayed when the Pop-up Window appears are shown in “[TABLE 3.65 Display Contents of Operation Help Display when Pop-up Window appears.](#)”

TABLE 3.65 Display Contents of Operation Help Display when Pop-up Window appears


Item	Description
↑↓= Move Highlight	Moves cursor up and down.
<Enter>=Select Entry	Selects item.
Esc=Exit	Returns to ‘ <a href="#">3.1 Front page of Boot Manager</a> ’.

#### ■ Change in Priority Level (Set Legacy CD-ROM Drive Order)

The changes of boot order are executed according to the following procedure.

1. On the window, as shown in “[FIGURE 3.59 Change in priority level \(Set Legacy CD-ROM Drive Order \(1\)\)](#)”, place the cursor on ATAPI CDROM Drive# N for which device can be changed. Select ATAPI CDROM Drive#00 on “[FIGURE 3.59 Change in priority level \(Set Legacy CD-ROM Drive Order \(1\)\)](#)”.


FIGURE 3.59 Change in priority level (Set Legacy CD-ROM Drive Order (1))



2. Press [Enter] key

Pop-window showed in “[FIGURE 3.60 Change in priority level \(Set Legacy CD-ROM Drive Order \(2\)\)](#)” is displayed.

FIGURE 3.60 Change in priority level (Set Legacy CD-ROM Drive Order (2))




3. Place the cursor on the boot option which is to be set in the ATAPI CDROM Drive #N. In the “[FIGURE 3.60 Change in priority level \(Set Legacy CD-ROM Drive Order \(2\)\)](#)”, boot option with respect to ATAPI CDROM #00 is set.

4. Press [Enter] key and in the “[FIGURE 3.60 Change in priority level \(Set Legacy CD-ROM Drive Order \(2\)\)](#)”, change the boot option of ATAPI CDROM Drive #00, from Optiarc DVD RW AD -7543C1-U1 to Fujitsu Virtual CDROM01.00.

“[FIGURE 3.61 Change in priority level \(Set Legacy CD-ROM Drive Order\) \(3\)](#)”, is an example of the window when the priority level of the DVD/CD is interchanged. When the boot option set in the ATAPI CDROM Drive Order #N is set in the other HardDisk Drive Order #M before setting, boot option set in the ATAPI CDROM Drive Order #N before change is set in the ATAPI CDROM Drive Order #M.

In the “[FIGURE 3.61 Change in priority level \(Set Legacy CD-ROM Drive Order\) \(3\)](#)”, Optiarc DVD RW AD-7543C1-U1 is set in the ATAPI CDROM Drive Order #01 wherein Fujitsu Virtual CDROM01.00 is set.

FIGURE 3.61 Change in priority level (Set Legacy CD-ROM Drive Order) (3)




#### 5. Set Enable/Disable of ATAPI CDROM Drive #N

- Select "Disable", if you want to disable the drive.
- Select the boot option, if you want to enable the drive.

"[FIGURE 3.62 Change in priority level \(Set Legacy CD-ROM Drive Order\) \(4\)](#)", is an example of the window when the ATAPI CDROM Drive #00 is set to Disable.

Disabled ATAPI CDROM Drive #N is displayed as "Disable".

FIGURE 3.62 Change in priority level (Set Legacy CD-ROM Drive Order) (4)






6. When you want to exit from the menu by the saving the setting changes, select “Commit Changes and Exit” and press [Enter] key.  
When you want to exit from the menu without saving the setting changes, select “Discard Changes and Exit” and press [Enter] key.

■ [Set Legacy NET Drive Order] menu

[Set Legacy Net Drive Order] menu sets the priority level of the “Boot device” when multiple network ports exist.

Window at the time of booting the [Set Legacy NET Drive Order] menu is shown below.  
Information of network port is displayed on the window. Moreover, when “Disable” is displayed for the NET Drive #N, it indicates that, booting function of NET Drive #N is disable.

FIGURE 3.63 Display example of the [Set Legacy NET Drive Order] menu



- (1) Page information display  
Displayed as [Set Legacy NET Drive Order]
- (2) Menu selection  
Items shown in “[TABLE 3.66 Display contents of menu selection](#)” are displayed.

TABLE 3.66 Display contents of menu selection

Items	Description
NET Drive #N (N: 0, 1...)	Transited to order change of the NET boot. When this item is executed, pop-up window is displayed. Change method is explained in detail in the "■ Change in priority order (Set Legacy NET Drive Order)" which is described afterwards.
Commit Changes and Exit	Comes out from the menu after saving the setting changed contents.
Discard Changes and Exit	Comes out from the menu after cancelling the setting changed contents.

**(3) Operation help display**

Explanation of the operation key's shown in "TABLE 3.67 Display content of Operation Help Display" is displayed.

TABLE 3.67 Display content of Operation Help Display

Item	Explanation
↑↓= Move Highlight	Moves the cursor in up and down directions.
<Enter>=Select Entry	Selects the item.
Esc=Exit	Returns to "3.1 Front page of Boot Manager".

"TABLE 3.68 Display Content of Operation Help Display When Pop up Window Appears." shows the display contents when the pop-up window appears.

TABLE 3.68 Display Content of Operation Help Display When Pop up Window Appears


Item	Explanation
↑↓= Move Highlight	Moves the cursor in up and down directions.
<Enter>=Complete Entry	Selects the item.
Esc=Exit Entry	Close the pop up window.

**■ Change of priority level (Set Legacy NET Drive Order)**

Boot order is changed in the following sequence.

1. Place the cursor on NET Drive #N which wants to change the device on the screen shown in "FIGURE 3.64 Change (Set Legacy NET Drive Order) (1) of priority level". In "FIGURE 3.64 Change (Set Legacy NET Drive Order) (1) of priority level", NET Drive #00 has been selected.


FIGURE 3.64 Change (Set Legacy NET Drive Order) (1) of priority level



2. Press the [Enter] key.

A pop up window shown in "FIGURE 3.65 Change of Priority Level (Set Legacy NET Drive Order) (2)" appears.

FIGURE 3.65 Change of Priority Level (Set Legacy NET Drive Order) (2)




3. Place the cursor on the boot option which is to be set in NET Drive #N. In “FIGURE 3.65 Change of Priority Level (Set Legacy NET Drive Order) (2)”, the boot option is set in NET Drive #00.

4. Press the [Enter] key. In “FIGURE 3.65 Change of Priority Level (Set Legacy NET Drive Order) (2)”, the boot option of NET Drive #00 is changed from IBA GE Slot 0900 v1372 to IBA GE Slot 0901 v1372.

“FIGURE 3.66 Change of Priority Level (Set Legacy NET Drive Order) (3)” is an example of the window when the priority level of network port is changed. When the boot option set in NET Drive #N is set in another NET Drive #M before setting, the boot option which had been set in NET Drive #N before changes, is set in NET Drive #M. In “FIGURE 3.66 Change of Priority Level (Set Legacy NET Drive Order) (3)”, IBA GE Slot 0900 v1372 is set in NET Drive #01 in which IBA GE Slot 0901 v1372 was set.

FIGURE 3.66 Change of Priority Level (Set Legacy NET Drive Order) (3)




5. Set Enable/Disable of NET Drive #N.

- Select “Disable” to disable.
- Select boot option to enable.

“FIGURE 3.67 Change of Priority Level (Set Legacy NET Drive Order) (4)” is an example of window in which the NET Drive#01 is set to Disable.

The Disabled NET Drive #N is displayed as “Disable”.

FIGURE 3.67 Change of Priority Level (Set Legacy NET Drive Order) (4)



6. Select [Commit Changes and Exit] and press [Enter] key to exit from this menu by saving the set changes. Select [Discard Changes and Exit] and press [Enter] key to exit from this menu without saving the set changes.

### 3.5.3 [Boot From File] Menu

The [Boot From File] menu is used to boot immediately by specifying the boot loader file of operating system in the storage device which is recognized by UEFI.

The following window is window immediately after the activation of the [Boot From File] menu. A list of storage devices recognized by UEFI is displayed.

FIGURE 3.68 Display Example of [Boot From File] Menu



(1) Page Information Display  
[File Explorer] is displayed.

(2) Menu Selection  
Storage device list, by which UEFI is recognized, is displayed.


(3) Operation helps Display  
Description of operation key is shown in “[TABLE 3.69 Display Contents of Operation Help Display](#)”

TABLE 3.69 Display Contents of Operation Help Display

Items	Description
↑↓ =Move Highlight	Moves the cursor up and down.
<Enter>=Select Entry	Selects the items.
Esc=Exit	Returns to “ <a href="#">3.1 Front page of Boot Manager</a> ” .


- Specification of Boot File (Boot from File)
  1. Place the cursor to storage device which stores the Operating System Boot Loader File to be booted from the device list window shown in “[TABLE 3.69 Display Contents of Operation Help Display](#)”

FIGURE 3.69 Specifications of Boot File (1)



2. Press [Enter] key.  
As shown in “[FIGURE 3.70 Specifications of Boot File \(2\)](#)”, file list of storage device appears.  
Contents enclosed in [ < > ] is a directory. Following figure is a display example when the disk installed by Window Server 2012 is selected.

FIGURE 3.70 Specifications of Boot File (2)



3. Operating System Loader File to be booted appears as shown in “[FIGURE 3.71 Specifications of Boot File \(3\)](#)” by following the directory structure.

FIGURE 3.71 Specifications of Boot File (3)





4. Press [I] key or [L] key and select Operating System Loader File to be booted.
5. Press [Enter] key.  
File is loading and Operating System is activated.

### 3.5.4 [Set Time out Value] Menu

[Set Time out Value] Menu sets the standby time from the completion time of UEFI diagnosed process till the Operating System process transfer time, in seconds. Default setting is 10 Seconds. The time set in this menu is the standby time of key input. In the standby time of key input, as shown in “[FIGURE 3.72 Logo Window](#)”, the Logo Window appears. Except [Enter] key, if other key is input during the standby time of key input, then it transited to Boot Manager Front Page. Moreover, if [Enter] key is input, it immediately transit to Operating System activation process.

FIGURE 3.72 Logo Window



Following window is a display example of [Set Time out Value] Menu.

FIGURE 3.73 Display Example of [Set Time out Value] Menu



(1) Page Information Display  
[Set Time out Value] is displayed.

(2) Menu Selection  
Displayed selection menu is shown in "[TABLE 3.70 Display Content of Menu Selection Help Display](#)"

TABLE 3.70 Display Content of Menu Selection Help Display

Items	Description
Auto Boot Time-out	Sets the time out time of Logo Window. Unit is seconds • 0~65535 Default time is 10 Seconds
Commit Changes and Exit	Exit from main menu after the changed contents of configuration are saved.
Discard Changes and Exit	Exit from main menu after the changed contents of configuration are cancelled.

(3) Operation Help Display  
Describe of operation key is shown in "[TABLE 3.71 Display Contents of Operation Help Display](#)".

TABLE 3.71 Display Contents of Operation Help Display

Item	Description
↑↓= Move Highlight	Moves cursor up and down.
<Enter>=Select Entry	Selects item.
Esc=Exit	Returns to ' <a href="#">3.1 Front page of Boot Manager</a> '

The contents displayed when the Pop-up Window appears are shown in “[TABLE 3.72 Content of Operation Helps Display when Pop -up Window appears.](#)”

TABLE 3.72 Content of Operation Helps Display when Pop -up Window appears

Item	Description
0123456789 are valid inputs	“Timeout” settings are valid only for numerical keys.
<Enter>=Select Entry	Selects item.
Esc=Exit	Returns to ‘ <a href="#">3.1 Front page of Boot Manager</a> ’

## 3.6 Device Path

Device path shows the physical connection of device and also shows the relation of connection from PCI Route Bridge.

### 3.6.1 Parameter of Device Path

Each parameter of displayed device path is shown in the “[TABLE 3.73 Parameter of Device Path](#)”.

TABLE 3.73 Parameter of Device Path

Display	Description
Acpi (HID, UID)	ACPI device path HID is an abbreviation of Hardware ID. An ID by which ACPI specifications are conformed is given below. UID is an abbreviation of Unique ID.(Can be omitted)
Pci(Device, Function)	PCI Device Device is the device number of PCI device. 0-31 is shown with hexadecimal. Function is the function number of PCI device. It is shows with 0-7 digits.
Scsi(PUN, LUN)	Scsi Controller PUN is an abbreviation of Physical Unit Number. It means SCSI ID. 0-65535 is shown with hexadecimal. LUN is an abbreviation of Logical Unit Number. 0-65535 is shown with hexadecimal.
Fibre(WWN, LUN)	Fibre Controller WWN is an abbreviation of World Wide Name. It shows with numeric of 64 bit. LUN is an abbreviation of Logical Unit Number. It shows with numeric of 64 bit.
MAC(MacAddr, IfType)	Network MacAddr is an abbreviation of Mac Address. If Type is an abbreviation of Interface Type. 0-255 is shown with hexadecimal.
HD(Partition, Type, Signature, Start, Size)	Hard Drive Partition shows the partition number. Type shows Partition Type. (Can be omitted). Type is given below. GPT: Abbreviation of GUID Partition Table.

	<p>MBR: Abbreviation of Master Boot Record. Signature consists of the meaning of Partition Type as shown below GPT: Shows GUID MBR: Numeric value. Start shows the starting position of partition. It shows with numeric of 64 bit. Size shows the Partition Size. It shows with numeric of 64 bit.</p>
CDROM(Entry, Start, Size)	<p>CD/DVD Media Entry shows the boot entry number. (Can be omitted).It is usually shown with 0. Start shows the starting sector of boot entry. It shows with numeric of 64 bit. Size shows Partition Size. It shows with numbers of 64 bit.</p>
USB(Port, Interface)	<p>USB Port shows the port number of USB. 0-255 is shown with hexadecimal. Interface shows interface number. 0-255 is shown with hexadecimal.</p>
Ctrl(Controller)	<p>Controller Controller consists of the integers.</p>

### 3.6.2 Identification of Device Path


Description regarding the identification method of SAS disk built in SB, SAS disk built in DU, disk from Fibre card and device path of GigaLAN is shown below.

- **SAS Disk built in SB**

Specific method of SAS disk built in SB is described as an example.

Relation of connection from CPU to SAS disk built in SB is shown in “[FIGURE 3.74 Specification of SAS disk built in SB](#)” shows the device Node.

FIGURE 3.74 Specification of SAS disk built in SB




Device Path is as follows.

PcieRoot(0x0)/Pci(0x1C,0x0)/Pci(0x0,0x0)/Ctrl(0x0)/Scsi(0x0,0x0)/HD(1,GPT, 83B59636 - 996C - 4550 - A27A - EBEAA43820D0, 0x800, 0x32000)

- **SAS Disk built in DU**

Specific method of SAS disk built in DU#0 is described as an example.

FIGURE 3.75 Specification of SAS Disk built in DU#0




Device path of SAS device is as follows.

Pcieroot(0x0)/PCI(0x02,0x0)/PCI(0x0,0x0)/PCI(0x10,0x0)/PCI(0x0,0x0)/PCI(0x09,0x0)/PCI(0x0,0x0)/PCI(0x01,0x0)/PCI(0x0,0x0)/Ctrl(0x0,0x0)/Scsi(0x3,0x0)/PCI(0x0,0x0)/HD(1,GPT,83B59636 - 996C - 4550 - A27A - EBEAA43820D0,0x800,0x32000)

- **Disk Specification from Fibre Card**

Disk specific method from Fibre connection when Fibre Card is inserted to PCIe of IOU is described as an example.


FIGURE 3.76 Specification of Disk from Fibre Card



- **GigaLAN**

Specific method of GigaLAN built in IOU is described as an example.

FIGURE 3.77 Specification of GigaLAN



Device path of GigaLAN is as follows.

Pciroot(0x0)/PCI(0x02,0x0)/PCI(0x0,0x0)/PCI(0x10,0x0)/PCI(0x0,0x0)/PCI(0x09,0x0)/PCI(0


# CHAPTER 4 UEFI Command Operations

This chapter describes the operations of UEFI commands.

## 4.1 Automatic startup file

The UEFI of the PRIMEQUEST 2000 series supports the UEFI shell function. Users can use the UEFI shell to execute commands from the UEFI console. [FIGURE 4.1 Sample screenshot of the UEFI shell immediately after it starts](#) shows a screenshot of when the UEFI shell starts.

FIGURE 4.1 Sample screenshot of the UEFI shell immediately after it starts



### 4.1.1 Automatic startup file

Immediately after starting, the UEFI shell checks for the startup.nsh file in the defined execution path. If the file exists, the shell executes the commands specified in the file. Then, it waits for command input from the console. This situation does not always require the startup.nsh file.

#### Remarks

The execution path is the directory path specified in the shell environment path variable. You can display and change this directory path by using the set command.

## 4.1.2 UEFI shell command syntax

You can view and display the shell environment variables by using the set command.

To access an environment variable value as an argument for a shell command, enclose the variable name in percent signs "%", as shown below.

%myvariable%

The shell has a special variable called lasterror. This variable retains the value returned by the last executed shell command.

The file name argument in shell commands uses the following characters as wildcards: "\*", "?", "[", and "]".

TABLE 4.1 Wildcard characters in the UEFI shell

Character string	Meaning
*	Matches 0 or more characters in the file name.
?	Matches exactly 1 character in the file name.
[Character string]	Matches any of the characters between the brackets [ ]. An example is [azA-Z].

## 4.1.3 Output redirection

UEFI shell command output can be redirected to a file. The syntax to do so is as follows.

```
Command > unicode_output_file_pathname
Command >a ascii_output_file_pathname
Command 1> unicode_output_file_pathname
Command 1>a ascii_output_file_pathname
Command 2> unicode_output_file_pathname
Command 2>a ascii_output_file_pathname
Command >> unicode_output_file_pathname
Command >>a ascii_output_file_pathname
Command 1>> unicode_output_file_pathname
Command 1>>a ascii_output_file_pathname
```

TABLE 4.2 Output redirection lists the types of output redirection and append.

TABLE 4.2 Output redirection

Character string	Meaning
>	Redirects the standard output to a Unicode file.
>a	Redirects the standard output to an ASCII file.
1>	Redirects the standard output to a Unicode file.
1>a	Redirects the standard output to an ASCII file.
2>	Redirects the standard error output to a Unicode file.
2>a	Redirects the standard error output to an ASCII file.
>>	Appends the standard output to a Unicode file.
>>a	Appends the standard output to an ASCII file.
1>>	Appends the standard output to a Unicode file.



1>>a	Appends the standard output to an ASCII file.
------	---

**Remarks**

You can redirect the standard output or standard error output to the same file. Note that the standard output or standard error output cannot be redirected to multiple files at the same time.

## 4.1.4 UEFI shell command list

TABLE 4.3 UEFI shell commands lists the UEFI shell commands supported by the UEFI of the PRIMEQUEST 2000 series.

TABLE 4.3 UEFI shell commands

No.	Command name	Description
1	cd	Displays and changes the current directory.
2	connect	Binds the UEFI driver to a device and starts the driver.
3	cp	Copies one or more files or directories to another location.
4	date	Displays and sets the current system date.
5	disconnect	Disconnects one or more drivers from a device.
6	drvcfg	Executes the driver configuration protocol. *1
7	echo	Displays messages and enables or disables command echo.
8	edit	Used to edit an ASCII or Unicode file in full screen mode.
9	exit	Exits the UEFI shell.
10	help	Displays the command list or command help.
11	ls	Displays the files and subdirectories in a directory.
12	map	Displays and defines a mapping.
13	mkdir	Creates one or more directories.
14	mount	Mounts a file system on a block device.
15	mv	Moves one or more files.
16	pci	Displays a PCI device or a PCI configuration space.
17	reconnect	Reconnects one or more drivers.
18	reset	Resets the system.
19	rm	Deletes one or more files or directories.
20	set	Displays, creates, changes, or deletes a UEFI environment variable.
21	time	Displays the current time. Also, it sets the system time.
22	type	Displays the contents of a file.
23	ver	Displays the volume information for a file system.
24	vol	Displays the volume information for a file system.

\*1 : Execute "Connect -r" command before executing drvcfg command.

# CHAPTER 5    Dynamic Reconfiguration Operation

This chapter describes the DR command and the Hot plug collaboration function.

## 5.1    DR Command

This chapter describes the CLI (command line interface) provided by the DR command. The root permission is necessary for executing.

### 5.1.1    dr command (common part)

#### 5.1.1.1 Synopsis

```
/opt/FJSVdp-util/sbin/dp [--version] [--help] COMMAND [ARGS]
```

#### 5.1.1.2 Description

This is basic command to DR operation. The subcommand is taken in the argument.

#### 5.1.1.3 Options

Options	Meaning
--version	Print the version number of DR command
--help	Print the synopsis and a list of subcommands.
COMMAND	Specify subcommand
ARGS	Specify arguments of subcommand

#### 5.1.1.4 Exit status

Exit status	Meaning
0	Successful program completion
1	Unsuccessful program completion
128+signal number <s>	Terminated abnormally because the signal of signal number <s> was received

### 5.1.2    Device hot-add/hot-remove operation (add/rm subcommand)

#### 5.1.2.1 Synopsis

```
/opt/FJSVdp-util/sbin/dp [--help] <add | rm> Device
```

#### 5.1.2.2 Description

This is the subcommand for hot-add/hot-remove IOU or PCI Express card.

#### 5.1.2.3 Options

Arguments	Meaning
-----------	---------

Device	Target device. e.g. IOUx, PClex “x” represents the slot number. Only one target can be specified at a time.
--help	Print the synopsis of add/rm subcommand

#### 5.1.2.4 Example

e.g. when you hot-add IOU3  
# /opt/FJSVdp-util/sbin/dp add IOU3  
#

### 5.1.3 Show slot status (slot subcommand)

#### 5.1.3.1 Synopsis

/opt/FJSVdp-util/sbin/dp stat DeviceType

#### 5.1.3.2 Description

This is the subcommand for displaying hot plug slot status of IOU or PCI Express card.  
The number displayed after the output device represents the slot number.

The meaning of the state of IOU type is as follows:

- empty : IOU is not assigned to the partition (OS)
- offline : IOU is assigned to the partition, but the slot power is OFF. (IOU is disabled)
- online : IOU is assigned to the partition and the slot power is ON. (IOU is enabled)

The meaning of the state of pcie type is as follows:

- empty : There's no PCI Express card on the slot
- offline : PCI Express card is on the slot, but the slot power is OFF. (PCIe is disabled)
- online : PCI Express card is on the slot, and the slot power is ON. (PCIe is enabled)

#### 5.1.3.3 Options

Arguments	Meaning
Device Type	Target device type. e.g. IOU, pcie Only one target can be specified at a time.
--help	Print the synopsis of stat subcommand

#### 5.1.3.4 Example

e.g. When you hot-add PCI card to slot number 20 of PCI slot  
# /opt/FJSVdp-util/sbin/dp stat pcie  
pcie20: online  
pcie21: offline  
pcie22: empty

## 5.1.4 Show resources on device (show subcommand)

### 5.1.4.1 Synopsis

/opt/FJSVdp-util/sbin/dp show Device [--possible]

### 5.1.4.2 Description

This is the subcommand for displaying resources on the device.

- When specified device is IOU, All I/O resources (PCI) on IOU are displayed
- When specified device is pcie, the name of PCI Express device is displayed

### 5.1.4.3 Options

Arguments	Meaning
Device	Target device. e.g. IOUx, pciex "x" represents the slot number. Only one target can be specified at a time.
--help	Print the synopsis of show subcommand

### 5.1.4.4 Example

e.g. When you want to display I/O resources on IOU1:

```
# /opt/FJSVdp-util/sbin/dp show IOU1
04:00.0 PCI bridge: PLX Technology, Inc. Device 8748 (rev ba)
05:09.0 PCI bridge: PLX Technology, Inc. Device 8748 (rev ba)
06:00.0 PCI bridge: PLX Technology, Inc. Device 8748 (rev ba)
07:01.0 PCI bridge: PLX Technology, Inc. Device 8748 (rev ba)
07:02.0 PCI bridge: PLX Technology, Inc. Device 8748 (rev ba)
07:08.0 PCI bridge: PLX Technology, Inc. Device 8748 (rev ba)
07:09.0 PCI bridge: PLX Technology, Inc. Device 8748 (rev ba)
07:10.0 PCI bridge: PLX Technology, Inc. Device 8748 (rev ba)
07:11.0 PCI bridge: PLX Technology, Inc. Device 8748 (rev ba)
09:00.0 Ethernet controller: Intel Corporation I350 Gigabit Network Connection (rev 01)
09:00.1 Ethernet controller: Intel Corporation I350 Gigabit Network Connection (rev 01)
0c:00.0 Ethernet controller: Intel Corporation I350 Gigabit Network Connection (rev 01)
0c:00.1 Ethernet controller: Intel Corporation I350 Gigabit Network Connection (rev 01)
0f:00.0 Fibre Channel: Emulex Corporation Saturn-X: LightPulse Fibre Channel Host Adapter (rev 03)
0f:00.1 Fibre Channel: Emulex Corporation Saturn-X: LightPulse Fibre Channel Host Adapter (rev 03)
```

## 5.1.5 Information gathering (dr report subcommand)

### 5.1.5.1 Synopsis

/opt/FJSVdp-util/sbin/dp [--help] report

### 5.1.5.2 Description

This is the subcommand for gathering information for investigation.

### 5.1.5.3 Options

Argument	Meaning
----------	---------

--help

Print the synopsis of report subcommand

#### 5.1.5.4 Example

e.g.

```
# /opt/FJSVdp-util/sbin/dp report
```

```
Create report file at /tmp/dpreport-localhost-20130101-123456.tar.bz2
```

```
#
```

## 5.2 Hot plug collaboration function

### 5.2.1 Description of collaboration function

The resources (CPU and memory and IO resource) of SB or IOU increases or decreased by the DR operation. If external software depends on quantities or location of these resources, they are affected by DR operation. For this case, if the desired programs (called "collaboration program") of external programs are registered in specific directories, the desired programs are automatically executed in hot plug collaboration function at SB/IOU hot plug.

### 5.2.2 Collaboration program execution timing

Hot plug collaboration function executes collaboration programs by the following hot plug events:

- SB hot add
  - Before enabling CPU and memory resources on a hot added SB (simply called "before addition of SB")
  - After enabling CPU and memory resources on a hot added SB (simply called "after addition of SB")
  - At the time that CPU and memory resources on a added SB fails to be enabled (simply called "at the addition of SB failure time")
- SB hot remove
  - Before disabling CPU and memory resources on a hot removed SB (simply called "before deletion of SB")
  - After deleting a SB from a partition (simply called "after deletion of SB")
  - At the time that a SB failed to be deleted from a partition (simply called "at the deletion of SB failure time")
- IOU hot add
  - Before enabling PCI devices on a hot added IOU (simply called "before addition of IOU")
  - After enabling PCI devices on a hot added IOU (simply called "after addition of IOU")
  - At the time that PCI devices on a hot added IOU fails to enable (simply called "at the addition of IOU failure time")
- IOU hot remove
  - Before disabling PCI devices on a hot removed IOU (simply called "before deletion of IOU")
  - After turning off an IOU (simply called "after deletion of IOU")
  - At the time that an IOU failed to be turned off (simply called "at the deletion of IOU failure time")

At each execution time, the hot plug collaboration function sequentially executes the collaboration program stored in the specified directory.

The collaboration programs that are executed before addition of SB, after addition of SB, before deletion of SB, after deletion of SB, before addition of IOU, after addition of IOU, before deletion of IOU and after deletion of IOU are executed in ascending order of program file names.

The collaboration program that are executed at the SB addition failure time, at the SB deletion failure time, at the IOU addition failure time and at the IOU deletion failure time are executed in descending order of program file names.

For the directory that stored collaboration program, see Section 5.2.4 "Directory that stored collaboration programPreface". For naming rule of collaboration program, see Section 5.2.5 "Naming convention of collaboration program".

### 5.2.3 Timeout of collaboration program

Hot plug collaboration function does not know details of collaboration programs. Thus hot plug collaboration function sequentially execute collaboration programs for preventing depletion of resources. A collaboration program may terminate abnormally by some reasons. Thus when collaboration program does not finish in constant waiting time, hot plug collaboration function handles it as follows:

- 1) Send SIGTERM signal to collaboration program
- 2) Send SIGKILL signal to collaboration program when a collaboration program does not finish even if waiting for one minute after SIGTERM is sent

This waiting time can be modified by configuration file. The assignable value is shown below. The default value is five minutes.

Set value	Action
5-1024	Wait for the completion of a collaboration program at specified time. The unit of value is the minute.
0	Wait for the completion of a collaboration program unlimitedly
-1 or less	The value is out of assignable value. Wait for the completion of a collaboration program at 5 minutes as default.
1-4	The value is out of assignable value. Wait for the completion of a collaboration program at 5 minutes as default.
1025 or more	The value is out of assignable value. Wait for the completion of a collaboration program at 5 minutes as default.

Specify 0 to waiting time, when collaboration program must be completed to continue DR. But DR function stops until the collaboration program is completed.

### 5.2.4 Directory that stored collaboration program

The collaboration program must be stored in the following directory.  
/opt/FJSVdp-util/user\_command

The configuration file of the collaboration program must be stored in the following directory.  
/opt/FJSVdp-util/etc

Note that creating new directory under the above directories is not allowed.

### 5.2.5 Naming convention of collaboration program

Naming convention of collaboration program is shown below.  
nn-XXXXX

➤ nn

"nn" must be a two-digital number (one-byte characters) ranging from 10 to 90

Hot plug collaboration function executes the collaboration programs in ascending order of their collaboration program name. To execute a collaboration program earlier than the other collaboration

programs by installed other packages, assign the collaboration programs with lower numbers than those assigned to the collaboration programs installed by the other packages. To execute a collaboration program later than the other collaboration programs by installed other packages, assign the collaboration programs with higher numbers than those assigned to the collaboration programs installed by the other packages.

➤ XXXXX

“XXXXX” represents a collaboration program identifier which constructed by alpha-numeral and hyphen (one-byte characters)

The recommended identifier for a collaboration program is a name from which the contents of the program can easily be inferred. To avoid duplicative collaboration program name, head of identifier should have the package name.

Note: “-” between “nn” and “XXXX” must not be omitted

Naming convention of configuration file of collaboration program is shown below:

XXXXX.conf

➤ XXXXX

“XXXXX” is character string which specified as collaboration program identifier.

“nn-” of collaboration program name must be omitted.

An example of a collaboration program name is shown below.

e.g. Package name is FJSVxxx and collaboration program are get-cpu-info and get-node-info

[collaboratino program name]

10-FJSVxxx-get-cpu-info

20-FJSVxxx-get-node-info

[configuration file of collaboration program]

FJSVxxx-get-cpu-info.conf

FJSVxxx-get-node-info.conf

## 5.2.6 Method of describing configuration file of collaboration program

How to write a configuration file of a collaboration program is as follows:

<Setting itme> = <Setting value>

Setting item	Setting value
--------------	---------------

verbose	set of verbose mode true or false
---------	--------------------------------------

When true is set to verbose item, collaboration program is executed called with “-v” argument which indicates verbose mode

Default value is false

timeout	timeout period of collaboration program
---------	---

For assignable value, please refer to “5.2.3 Timeout of collaboration program”.

If a collaboration program is executed in verbose mode, standard output and standard error output of the collaboration program is output to a special log file. Other outputs of collaboration program which executed in non-verbose mode are output to system log as well as log of DR command. For the log of collaborate program, refer to the following “5.2.10 Output of collaboration program”.

Configuration file of collaboration program is not indispensable. If configuration file does not exist, hot plug collaboration function executes collaboration programs by using the default value.

Note:

- Blank line and the line that starts by # in the configuration file is ignored.
- You can use Japanese after #, but in this case character code of Japanese must use UTF-8 form.
- Write one setting item by one line.
- You can insert the blank before or after the setting item, blank and the setting value.

An example of a configuration file is shown below.

e.g. When collaboration program named nn-FJSVxxxx-get-info executes in verbose mode and timeout period is 10 minutes.

```
# FJSVxxx-get-cpu-info
```

```
verbose = true
```

```
timeout = 10
```

## 5.2.7 Permission required for collaboration program

P command is executed with the root permission. And because hot plug collaboration function is executed as one function of the DR command, the collaboration programs must be assigned the execution attribute of the root permission. Collaboration programs without the execution attribute of the root permission are not executed.

## 5.2.8 Argument passed to collaboration program

When executing a collaboration program, hot plug collaboration function passed hot plug event timing to the collaboration program as option. Result of hot plug and hot added/removed resources are passed to the collaboration program as option, when the collaboration program is executed at the addition/deletion of SB/IOU failure time.

The list of the arguments passed to a collaboration program is shown below.

Options	Arguments	Meaning
p	· hot plugged device	Specifies the hot plugged device.
	SBx	“x” and “y” are set to either -1 or 0-3.
	IOUy	
e	· hot plug eventl timing	Specifies the hot plug event timing.
	ADD_PRE	ADD_PRE : before dynamic addition
	ADD_POST	ADD_POST : after dynamic addition
	RM_PRE	RM_PRE: before dynamic deletion
	RM_POST	RM_POST : after dynamic deletion
	· result of hot plug	Specifies the result of hot plug



r	SUCCESS	When the hot plug event timing is only ADD_POST or RM_POST, this option is specified.
	FAILURE	
v	· none	Specifies the verbose mode.
		Collaboration program can use it for trigger of debug messages.
c	· CPU number	Specifies the hot added/removed CPU number list from now.
		When hot plugged device is SBx and hot plug event timing is ADD_PRE or RM_PRE, this option is specified.  Example of specified CPU number list is shown below. The CPU number list is a list delimited by the comma. When this list is delimited by the hyphen, it means all ranges of the first and last number are included. None means there is no CPU.  1-10 2,3 1-10,12-19 None
m	· amount of memory	Specifies the hot added/removed amount of memory from now.
		When hot plugged device is SBx and hot plug event timing is ADD_PRE or RM_PRE, this option is specified.  Unit of amount of memory is kilo byte.  Example of specified amount of memory is shown below. 8388608
n	· NUMA Node number	Specifies the hot added/removed NUMA node number list from now.
		When hot plugged device is SBx and hot plug event timing is ADD_PRE or RM_PRE, this option is specified.  Example of specified NUMA node number list is shown below. The NUMA node number list is a list delimited by the comma. When this list is delimited by the hyphen, it means all ranges of the first and last number are included. None means there is no NUMA node.  2,3 4 5-7 None
d	· PCI address	Specifies the "bus number: device number: function number (PCI address)" of hot removed PCI device except for PCI bridge from now.
		When hot plugged device is IOUx and hot plug event timing is RM_PRE, this option is specified.  Example of specified PCI address is shown below. 01:23.4 01:23.4,56:78:9,ab:cd.e  Refer to the output of the lspci command for the example of the PCI address..

Example of specified options by the hot plug collaboration function is shown below.

```
/path/to/program1 -p SB1 -e ADD_PRE -c 10-19 -m 12345678 -n 2-3
```

```
/path/to/program2 -e ADD_POST -r SUCCESS -p SB2
```

```
/path/to/program3 -v -p IOU1 -e RM_PRE -d 00:01.2,03:04.5
```

```
/path/to/program4 -e RM_POST -v -p IOU2 -r FAILURE
```

### 5.2.9 Exit status of collaboration program

When collaboration program terminates normally and DR function can be continued, the collaboration program must return 0. When collaboration program terminates abnormally and DR function cannot be continued, the collaboration program must return non 0.

Hot plug collaboration function checks the return value of the collaboration program. If return value is not 0, hot plug collaboration function stops at the time.

### 5.2.10 Output of collaboration program

Standard output (stdout) and standard error output (stderr) from collaboration program output to system log. But, when collaboration program executes in verbose mode, stdout and stderr output to a file in the following directory. In this case file name becomes "collaboration program name.log". And the output does not output to system log.

```
/opt/FJSVdp-util/var/log
```

Form of the outputs is as follows:

```
<time> : dp-util : <collaboration program name> : <INFO | ERR> : <output of collaboration program>
```



Example of output is shown below.



e.g. When standard error output and standard output of 10-FJSVxxx-get-cup-info output to system log


```
Jul 12 22:05:00 dp-util : 10-FJSVxxx-get-cpu-info : ERR : Invalid Option
```


```
Jul 12 22:06:00 dp-util : 15-FJSVxxx-get-mem-info : INFO : Good news, memory will be added 1 YB :)
```

### 5.2.11 Flow of collaboration program execution









## CHAPTER 6    **Setting of sadump environment**

In this chapter, how to configure sadump is explained.

A configuration of sadump is saved to UEFI configuration information. Back up it to restore the configuration. About backing up and restoring UEFI configuration information, refer "8.1.1 Backing up and restoring UEFI configuration information" in "PRIMEQUEST 2000 Series Administration Manual".

### **6.1    Sadump Configuration Menu**

To configure sadump, select main menu to set up sadump from the [Device Manager] menu. Configure sadump by inputting values in the main menu and submenu which is shown below. The structure of menu is as follows.

When the "PCI ROM Priority" setting of the PCI Subsystem Configuration menu is "EFI Compatible ROM", the Sadump setting menu is displayed.

From Device Manager Menu

Main menu



[Set up Manager] Menu



[Dump device Manager] Menu



FIGURE 6.1 Structure of menu for sadump configuration (1)



From [Dump device Manager]

[Create a dump device] Menu



[Select device] Menu



[Select multiple devices] Menu



[Confirmation] Menu



FIGURE 6.2 Structure of menu for sadump configuration (2)

From [Dump device Manager]





FIGURE 6.3 Structure of menu for sadump configuration (3)

### 6.1.1 Screen areas

The sadump configuration screen consists of four screen areas as shown below.



No.	Item	Description
1	Title	Displays title of menu.
2	Menu selection area	Displays menu to operate. They can be operated by [Enter] key, etc. Selected item is highlighted.
3	Help display area for menu selection	Displays the detailed explanation about menu selected in menu selection area.
4	Help display area for operations	Displays help information to operate screen.

FIGURE 6.4 Screen areas of sadump configuration

### 6.2 Main menu

In the [Device Manager] menu, select [Sadump Configuration], and then a main menu is displayed. You can set up sadump or dump device in this menu.



FIGURE 6.5 Main menu

TABLE 6.1 Displayed contents of the menu selection area

Item	Description
Set up Manager	Go to sadump setup menu.
Dump device Manager	Go to dump device maintenance menu.
Exit	Exit this menu

TABLE 6.2 Displayed contents of the help display area for operation

Item	Description
↑↓=Move Highlight	Moves the cursor up or down
<Enter>=Select Entry	Selects an entry.

**Note**

Don't operate [F2] key. [Esc] key is displayed on the screen but don't operate it.

## 6.3 [Set up Manager] Menu

Select the [Set up Manager] menu from the main menu and then sadump setup menu is displayed.

In this menu, items for sadump configuration are listed. The items are displayed as follows in initial state where sadump is not set up.




FIGURE 6.6 sadump setup menu

TABLE 6.3 Displayed contents of the menu selection area

Item	Description
ENABLE	Specifies [Enable] or [Disable] for sadump function. - Enable: Enable sadump - Disable: Disable sadump The default is [Disable].
COMPRESS	Specifies format when sadump writes to dump device. -Uncompress: Data is not compressed
RECYCLE	Specifies [Enable] or [Disable] for dump device reuse. When [Enable] is specified, the oldest dump is overwritten. -Enable: Enable RECYCLE option -Disable: Disable RECYCLE option The default is [Enable].
REBOOT	Specifies behavior of sadump after dumping -0: Halt -1-3600: Reboots after specified time(second) The default is [0].
Restore to factory settings	Sets all items to default.
Commit Changes and Exit	Saves the changes and exits this menu.
Discard Changes and Exit	Cancels the changes and exits this menu.

TABLE 6.4 Displayed contents of the help display area for operation

Item	Description
↑↓=Move Highlight	Moves the cursor up or down
<Enter>=Select Entry	Selects an entry. In the case of ENABLE, COMPRESS, RECYCLE, selection item is shown as pop-up window. In the case of REBOOT, you can input a value. Specify a value, and commit it by [Enter] key.

**Note**

Don't operate [F2] key. [Esc] key is displayed on the screen but don't operate it.

## 6.4 [Dump device Manager] Menu

This is displayed when the [Dump device Manager] menu is selected in the main menu.  
In this menu, you can create, setup, discard dump device.




FIGURE 6.7 Dump device maintenance menu

TABLE 6.5 Displayed contents of menu selection area

Item	Description
Display area	Displays the number of dump devices which are already created, and displays the number of dump devices which are already set up.
Create a dump device	Go to dump device create menu.
Select a dump device	Go to dump device setup menu.
Discard a dump device	Go to dump device discard menu.
Exit	Exits this menu

TABLE 6.6 Displayed contents of the help display area for operation

Item	Description
↑↓=Move Highlight	Moves the cursor up or down
<Enter>=Select Entry	Selects an entry.

**Note**

Don't operate [F2] key. [Esc] key is displayed on the screen but don't operate it.

## 6.5 [Create a dump device] Menu

This is displayed when the [Create a dump device] menu is selected in the main menu. Specify operation, creating dump device or selecting created dump device.




FIGURE 6.8 Dump device create menu

TABLE 6.7 Displayed contents of menu selection area

Item	Description
Create mode	Select create mode of dump device. Single: Create with single disk or single partition. To set up for redundancy, select [Single] and then configure multiple sadump devices. Multiple: Create with multiple disks. Use this when system memory is large and one disk is insufficient. The default is [Single].
Disk selection	Go to dump device select menu
Exit	Exits this menu.

TABLE 6.8 Displayed contents of the help display area for operation


Item	Description
↑↓=Move Highlight	Moves the cursor up or down
<Enter>=Select Entry	Selects an entry.

**Note**

Don't operate [F2] key. [Esc] key is displayed on the screen but don't operate it.

## 6.6 [Select device] Menu

This is displayed when the [Create mode] menu is set to [Single] in the [Create a dump device] menu. Select disk or disk partition and create dump device.

	<p>(Data corruption)</p> <p>Confirm again if correct disk is selected when selecting dump device. If wrong disk is selected, the data the disk has is corrupted.</p>
---	--




FIGURE 6.9 Dump device select menu



TABLE 6.9 Displayed contents of menu selection area

Item	Description
Exit	Exits this menu
ACPI name of disk/disk partition	Select disk or disk partition to create dump device

**Remarks**

-Regarding to ACPI name which is used for disk or disk partition, refer"[5.7 Device Path](#)".

-To use devices of ETERNUS as dump device, setting up UEFI driver is needed beforehand. Refer "PRIMEQUEST 1000/2000 Series SAN Boot Environment Configuration Manual (C122-E155EN)" for details.

TABLE 6.10 Displayed contents of the help display area for operation

Item	Description
↑↓=Move Highlight	Moves the cursor up or down
<Enter>= Select Entry	Create dump device with selected disk or disk partition, and go to dump device create menu. If [Exit] is selected, go to dump device create menu without creating dump device.

**Note**

[Esc] key is displayed on the screen but don't operate it.

- A dump device is initialized when it is created. It takes a time to initialize, depends on the size of selected disk or disk partition. In some cases it takes more than several minutes until going to the next screen.

## 6.7 [Setting dump device] Menu

This is displayed when the [Select a dump device] menu is selected in the [Dump device Manager] menu.  
Select dump device for use from created dump device.




FIGURE 6.10 [Setting dump device] Menu

TABLE 6.11 Displayed contents of the menu selection area

Item	Description
The 1st dump device	Select the 1st dump device. If not selected yet, only [1] is displayed.
The 2nd dump device	Select the 2nd dump device. If not selected yet, only [2] is displayed.
The 3rd dump device	Select the 3rd dump device. If not selected yet, only [3] is displayed.
Clear setting	Clears all the current setting.
Commit Changes and Exit	Saves the changes and exits this menu.
Discard Changes and Exit	Cancels the changes and exits this menu.

TABLE 6.12 Displayed contents of the help display area for operation

Item	Description
↑↓=Move Highlight	Move the cursor up or down.
<Enter>= Select Entry	If [1], [2] or [3] is selected, move to [Select device]. Otherwise, perform processing corresponding to the selected item.

**Note**

- Don't operate [F2] key. [Esc] key is displayed on the screen but don't operate it.
- If [Commit Changes and Exit] is performed, all the selected devices, including the devices that has already been selected previously, is being checked. If there's a selected device that is actually not present, the device selection is automatically cleared.

## 6.8 [Select device] Menu

This is displayed when [1], [2] or [3] is set in the [Setting dump device] menu.  
Dump devices on the current system is listed. Select a dump device from a list.  
In case of multiple disk configurations, select the 1st dump disk.




FIGURE 6.11 [Select device] Menu

TABLE 6.13 Displayed contents of menu selection area

Item	Description
ACPI name of dump device	ACPI name of disk/partition is displayed. Selected dump device is highlighted.

TABLE 6.14 Displayed contents of the help display area for operation

Item	Description
↑↓=Move Highlight	Move the cursor up or down.
<Enter>= Select Entry	Select the dump device on the cursor, and return back to [Setting dump device] menu.

**Note**

[Esc] key is displayed on the screen but don't operate it.

## 6.9 [Select discard dump device] Menu

This is displayed when the [Discard a dump device] is selected in the [Dump device Manager] menu. Discard unnecessary dump device. To discard dump device, select the dump device in the following menu. In case of multiple disk configuration, select the 1st dump device. Then all the remaining dump devices are automatically discarded.




FIGURE 6.12 [Select discard dump device] Menu

TABLE 6.15 Displayed contents of menu selection area

Item	Description
Discard all dump device and Exit	Discards all the dump devices, and then exits this menu.
Exit	Exits this menu without discarding any dump device selected.
ACPI name of dump device	Select a dump device.

TABLE 6.16 Displayed contents of the help display area for operation

Item	Description
↑↓=Move Highlight	Move the cursor up or down.
<Enter>= Select Entry	If some dump device is selected, discard the selected dump device. Otherwise, perform the selected entry.

**Note**

Don't operate [F2] key. [Esc] key is displayed on the screen but don't operate it.

## 6.10 [Select multiple devices] Menu

This is displayed when [Create mode] is set to [Single] in the [Create a dump device] menu.  
Select multiple disks for dump devices.




FIGURE 6.13 [Select discard dump device] Menu [Select multiple devices] Menu

TABLE 6.17 Displayed contents of menu selection area

Item	Description
Go to create dump device	Go to [Confirmation] menu.
Exit	Exits this menu without actually creating any dump device.
ACPI name of dump device	ACPI name of the dump device disk is displayed. Select a dump device by [Space] key, then [] on the right-hand of the entry is changed to [X].

**Remarks**

. Regarding to ACPI name which is used for disk or disk partition, refer "5.7 Device Path".

TABLE 6.18 Displayed contents of the help display area for operation

Item	Description
↑↓=Move Highlight	Move the cursor up or down.
<spacebar>= Toggle checkbox	Select a disk. Selected disk is marked with [X]. Operating [Space] key once more, the selection is canceled.

**Note**

[Esc] key is displayed on screen but don't operate it.

**[Confirmation] Menu**

This is displayed when the [Go to create dump device] is selected in the [Select multiple devices] menu  
Confirm multiple disks selected for dump devices.




FIGURE 6.14 [Confirmation] Menu

TABLE 6.19 Displayed contents of menu selection area

Item	Description
Create dump device and Exit	Saves the dump device configuration and exits this menu.
Exit	Exits this menu without saving any dump device configuration.
Display area	ACPI name of the disks selected in the [Select multiple devices] menu.

TABLE 6.20 Displayed contents of the help display area for operation

Item	Description
↑↓=Move Highlight	Move the cursor up or down.
<Enter>= Select Entry	Select an entry and perform the corresponding processing.

Note

[Esc] key is displayed on screen but don't operate it.

# Appendix A List of Setting Items

The initial values of setting items and values that can be set are listed.

## A.1 Setting Items of MMB Web-UI

Initial value and value that can be set of setting items of MMB Web-UI are listed on each window.

- A.1.1 Setting items of [System Event Log Filtering Condition] Window
- A.1.2 Setting items of [Operation Log Filtering Condition] Window
- A.1.3 Setting items of [System Information] Window
- A.1.4 Setting items of [System Setup] Window
- A.1.5 Setting items of [System Power Control] Window
- A.1.6 Setting items of [Power Control] Window
- A.1.7 Setting items of [Schedule Control] Window
- A.1.8 Setting items of [Add Schedule/ Edit Schedule] Window
- A.1.9 Setting items of [Partition Configuration] Window
- A.1.10 Setting items of [IPv4 Console Redirection Setup] Window
- A.1.11 Setting items of [IPv6 Console Redirection Setup] Window
- A.1.12 Setting items of [Power Management Setup] Window
- A.1.13 Setting items of [ASR Control] Window
- A.1.14 Setting items of [Console Reduction] Window
- A.1.15 Setting items of [Mode] Window
- A.1.16 Setting items of [Add User]/ [Edit User] Window
- A.1.17 Setting items of [Date/Time] Window
- A.1.18 Setting items of [IPv4 Interface] Window
- A.1.19 Setting items of [IPv6 Interface] Window
- A.1.20 Setting items of [Management LAN Port Configuration] Window
- A.1.21 Setting items of [Network Protocols] Window
- A.1.22 Setting items of [Refresh Rate] Window
- A.1.23 Setting items of [SNMP Community] Window
- A.1.24 Setting items of [SNMP Trap] Window
- A.1.25 Setting items of [SNMP v3 Configuration] Window
- A.1.26 Setting items of [Crate CSR] Window
- A.1.27 Setting items of [Create Selfsigned Certificate] Window
- A.1.28 Setting items of [Edit User] Window
- A.1.29 Setting items of [Add Filter]/ [Edit Filter] Window
- A.1.30 Setting items of [Alarm E-Mail] Window
- A.1.31 Setting items of [Alarm E-Mail Filtering Condition] Window

### A.1.1 Setting items of [System Event Log Filtering Condition] Window

The following table lists the initial value and value that can be set for setting items of [Operation Log Filtering Condition] Window.

TABLE A.1 Setting item of [System Event Log Filtering Condition] Window

Setting Items	Initial Value	Value that can be set	Remarks
Severity	All ON	<ul style="list-style-type: none"> <li>• Error</li> <li>• Warning</li> <li>• Info</li> <li>• Monitor</li> </ul> (Multiple selection is	Monitor is displayed only when logged in by CE privilege.



		possible)	
Partition	<ul style="list-style-type: none"> <li>Except Partition Operator : All</li> <li>In case of Partition Operator: Specified. (Select partition targeted for management )</li> </ul>	<ul style="list-style-type: none"> <li>All</li> <li>Specified</li> </ul>	All and Specified can be switched, and the data selected by the check boxes in Specified is maintained.
Unit	All	<ul style="list-style-type: none"> <li>All</li> <li>Specified</li> </ul>	All and Specified can be switched, and the data selected by the check boxes in Specified is maintained.
Source	All	<ul style="list-style-type: none"> <li>All</li> <li>Specified</li> </ul>	All and Specified can be switched, and the data selected by the check boxes in Specified is maintained.
Sort by Date/Time	New event first	<ul style="list-style-type: none"> <li>New event first</li> <li>Old event first</li> </ul>	
Start Date/Time	First event	<ul style="list-style-type: none"> <li>First event</li> <li>Specified Time</li> </ul>	When Specified Time is selected, Start Time can be entered. First event and Specified Time can be switched, and the time data of Specified Time is maintained.
End Date/Time	Last event	<ul style="list-style-type: none"> <li>Last event</li> <li>Specified Time</li> </ul>	When Specified Time is selected, End Time can be entered. Last event and Specified Time can be switched, and the time data of Specified Time is maintained.
Number of events to display	100 events	0 or more, integer less than or equal to the denominator in the fraction displayed (Maximum 3000 events).	The denominator of fraction which is displayed is the total number of registered events.

## A.1.2 Setting Item of [Operation Log Filtering Condition] Window

The following table lists the initial value and the value that can be set for setting items of [Operation Log Filtering Condition] Window.

TABLE A.2 Setting Items of [Operation Log Filtering Condition] Window

Setting Items	Initial Value	Value that can be set	Remarks
Operation	All	<ul style="list-style-type: none"> <li>All</li> <li>Specified</li> </ul>	All and Specified can be switched, and the data selected by the check boxes in Specified is maintained.
Sort by Date/Time	New event first	<ul style="list-style-type: none"> <li>New event first</li> <li>Old event first</li> </ul>	
Start Date/Time	First event	<ul style="list-style-type: none"> <li>First event</li> <li>Specified Time</li> </ul>	When Specified Time is selected, Start Time can be entered. Switch First event and Specified time and maintain

			Time Data of Specified Time.
End Date/Time	Last event	<ul style="list-style-type: none"> <li>Last event</li> <li>Specified Time</li> </ul>	When Specified Time is selected, End Time can be entered. Switch Last event and Specified time and maintain Time Data of Specified Time side.
Number of events to display	100 events	0 or more, integer less than or equal to the denominator in the fraction displayed (Maximum 1000 events).	The denominator of fraction which is displayed is a total number of registered events.

### A.1.3 Setting Items of [System Information] Window

The following table lists the initial value and the value that can be set for setting items of [System Information] Window.

TABLE A.3 Setting Items of [System Information] Window

Setting items	Initial value	Value that can be set	Remarks
System Name	"PRIMEQUEST" + Product Serial Number	Maximum 64 characters can be entered [0-9], [a-z], [A-Z], ! " # \$ % & ' ( ) = - ^ ~ ¥ @ ' [ ] { } ; : * + ? < > . / _	It is also used as System Name of SNMP
Asset Tag	None	Maximum 32 characters can be entered (Only administrator privilege)	

### A.1.4 Setting items of [System Setup] Window

The following table lists the initial value and the value that can be set of setting items of [System Setup] Window.

TABLE A.4 Setting items of [System Setup] Window

Setting Items	Initial Value	Value that can be set	Remarks
Power Feed Mode	Single	<ul style="list-style-type: none"> <li>Single</li> <li>Dual</li> </ul>	
Power Restoration Policy	Restore	<ul style="list-style-type: none"> <li>Always off</li> <li>Always on</li> <li>Restore</li> <li>Schedule Sync</li> </ul>	
Partition Power On Delay	0 Seconds	0 ~ 9999 Seconds	
Altitude	Altitude < 1000 m	<ul style="list-style-type: none"> <li>Altitude &lt; 1000 m</li> <li>1000 m &lt;= Altitude &lt; 1500 m</li> <li>1500 m &lt;= Altitude &lt; 2000 m</li> <li>2000 m &lt;= Altitude</li> </ul>	Setting error for Altitude value can be $\pm 100$ m.
PSU Redundancy	Non-Redundant (When Power Feed Mode is single)	<ul style="list-style-type: none"> <li>Redundant</li> <li>Non-redundant</li> </ul>	When Power Feed Mode is Dual, fix with Redundant

Setting Items	Initial Value	Value that can be set	Remarks
Mode			
Reserved SB Force Power Off Wait	10 Minutes	0~99Minutes	
System Power Save Control	Disable	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>	Can be set only when PSU_P 200V is used
System Power Saving Threshold	8640W	300W ~ 8640W	Grayed out when [System Power Save Control] is [Disable]

### A.1.5 Setting items of [System Power Control] Window

The following table lists the initial value and the value that can be set for setting items of [System Power Control] Window.

TABLE A.5 Setting Items of [System Power Control] Window

Setting Items	Initial Value	Value that can be set	Remarks
System Power Control	None	<ul style="list-style-type: none"> <li>• Power On all partition(s)</li> <li>• Power Off all partition(s) (all partitions(s) will be automatically shutdown)</li> <li>• Force Power Off</li> </ul>	

### A.1.6 Setting items of [Power Control] Window

The following table lists the initial value and the value that can be set for the setting items of [Power Control] Window.

TABLE A.6 Setting Items of [Power Control] Window

Setting items	Initial value	Value that can be set	Remarks
Power Control	None	<ul style="list-style-type: none"> <li>• Power On</li> <li>• Power Off</li> <li>• Power Cycle</li> <li>• Reset</li> <li>• NMI</li> <li>• Force Power Off</li> <li>• sadump</li> <li>• (Not Specified)</li> </ul>	
Force Power Off Delay	Off	Time (1~9Minutes) can be specified in case of ON	
Boot Selector	No Override	<ul style="list-style-type: none"> <li>• No Override</li> <li>• Force boot into EFI Boot Manager</li> <li>• Force PXE/iSCSI</li> <li>• Force boot from DVD</li> </ul>	

### A.1.7 Setting Items of [Schedule Control] Window

The following table lists the initial value and the value that can be set for the setting items of [Schedule Control] Window.

TABLE A.7 Setting Items of [Schedule Control] Window

Setting items	Initial value	Value that can be set	Remarks
Schedule Control	Off	<ul style="list-style-type: none"> <li>• On</li> <li>• Off</li> </ul>	

### A.1.8 Setting Items of [Add Schedule]/ [Edit User] Window

The following table lists the initial value and the value that can be set for the setting items of [Add Schedule]/ [Edit User] Window.

TABLE A.8 Setting Items of [Add Schedule]/ [Edit User] Window

Setting items	Initial value	Value that can be set	Remarks
Partition	The partition defined with smallest number		
Type	Not selected	<ul style="list-style-type: none"> <li>• Daily</li> <li>• Weekly</li> <li>• Monthly</li> <li>• Special</li> </ul>	
Pattern	Weekly: Not selected Monthly: From 1 to 1 Special: Jan/1	<ul style="list-style-type: none"> <li>• Weekly: Sun, Mon, Tue, Wed, Thu, Fri, Sat</li> <li>• Monthly: Jan~ Dec</li> <li>• Special: Jan/1~Dec /31</li> </ul>	
Term	<ul style="list-style-type: none"> <li>• Daily: From: Jan/1 To: Jan/1</li> <li>• Weekly: From: Jan To: Jan</li> <li>• Monthly: From: Jan To: Jan</li> </ul>	<ul style="list-style-type: none"> <li>• Daily: Jan/1~Dec/31</li> <li>• Weekly: Jan~ Dec</li> <li>• Monthly: Jan~ Dec</li> </ul>	
On Time	Hour: 0 Min: 0	Hour: Specified as 24 hours Time : Specified in units of 10 minutes	
Off Time	Hour: 0 Min: 0	Hour: Specified as 24 hours Time : Specified in units of 10 minutes	

### A.1.9 Setting Items of [Partition Configuration] Window

The following table lists the initial value and the value that can be set for the setting items of [Partition Configuration] Window.

TABLE A.9 Setting Items of [Partition Configuration] Window

Setting items	Initial value	Value that can be set	Remarks
Partition	None	Maximum 16 characters	

Setting items	Initial value	Value that can be set	Remarks
Name		can be entered. Alphanumeric characters, single byte space, #, _,-	

### A.1.10 Setting Items of [IPv4 Console Redirection Setup] Window

The following table lists the initial value and the value that can be set for the setting items of [IPv4 Console Redirection Setup] Window.

TABLE A.10 Setting Items of [IPv4 Console Redirection Setup] Window

Setting items	Initial value	Value that can be set	Remarks
IP Address	0.0.0.0	0-255, 0-255, 0-255, 0-255	IP Address must be in the same network segment as the MMB virtual management IP address.
Subnet Mask	255.255.255.255	0-255, 0-255, 0-255, 0-255	
Video Redirection	Disable	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>	
Virtual Media	Disable	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>	

### A.1.11 Setting Items of [IPv6 Console Redirection Setup] Window

The following table lists the initial value and the value that can be set for the setting items of [IPv6 Console Redirection Setup] Window.

TABLE A.11 Setting Items of [IPv6 Console Redirection Setup] Window

Setting items	Initial value	Setting value	Remarks
IP Address	None	0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF	
Prefix Length	None	1~128	
KVM Redirection	Disable	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>	
Virtual Media	Disable	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>	

### A.1.12 Setting Items of [Power Management Setup] Window

The following table lists the initial value and the value that can be set for the setting items of [Power Management Setup] Window.

TABLE A.12 Setting Items of [Power Management Setup] Window

Setting items	Initial value	Setting value	Remarks
Power Save	Disable	<ul style="list-style-type: none"> <li>• Enable</li> </ul>	Grayed out when [System

Setting items	Initial value	Setting value	Remarks
Control		<ul style="list-style-type: none"> <li>• Disable</li> </ul>	Power Save Control] of the [System Setup] Window is [Disable].
Action reaching Power Save	Partition Power Off	<ul style="list-style-type: none"> <li>• Continue</li> <li>• Partition Power Off</li> <li>• Partition Force Power Off</li> </ul>	Grayed out when [Power Save Control] of the Partition is [Disable]
Power Save Grace Period	5 Minutes	0~99 Minutes	Grayed out when [Power Save Control] of the Partition is [Disable]

### A.1.13 Setting Items of [ASR Control] Window

The following table lists the initial value and the value that can be set for the setting items of [ASR Control] Window.

TABLE A.13 Setting Items of [ASR Control] Window

Setting items	Initial value	Value that can be set	Remarks
ASR			
Number of Restart Tries	5 Times	1~10 Times 0: No retry	
Action after exceeding Restart tries	Stop rebooting and Power Off	<ul style="list-style-type: none"> <li>• Stop rebooting and Power Off</li> <li>• Stop rebooting</li> <li>• Diagnostic Interrupt assert</li> </ul>	
Boot Watchdog			
Boot Watchdog	Disable	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>	
Timeout time(seconds)	6000s	1s~6000s	
Action when watchdog expires	Continue	<ul style="list-style-type: none"> <li>• Continue</li> <li>• Reset</li> <li>• Power Cycle</li> <li>• NMI</li> </ul>	
Software Watchdog			
Software Watchdog	Disable	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>	
Timeout time(seconds)	300s	1s~6000s	
Action when watchdog expires	Continue	<ul style="list-style-type: none"> <li>• Continue</li> <li>• Reset</li> <li>• Power Cycle</li> <li>• NMI</li> </ul>	

### A.1.14 Setting Items of [Console Redirection] Window

The following table lists the initial value and the value that can be set for the setting items of [Console Redirection] Window.

TABLE A.14 Setting Items of [Console Redirection] Window

Setting items	Initial value	Value that can be set	Remarks
Operation	None	<ul style="list-style-type: none"> <li>• Video Redirection</li> </ul>	Can be selected only when [Video Redirection] is

Setting items	Initial value	Value that can be set	Remarks
			[Enable] on [Console Redirection Setup] Window.

### A.1.15 Setting Items of [Mode] Window

The following table lists the initial value and the value that can be set for the setting items of [Mode] Window.

TABLE A.15 Setting Items of [Mode] Window

Setting items	Initial value	Value that can be set	Remarks
Memory Operation Mode (setting)	Normal Mode	<ul style="list-style-type: none"> <li>• Performance Mode</li> <li>• Normal Mode</li> <li>• Partial Mirror Mode</li> <li>• Full Mirror Mode</li> <li>• Sapre Mode</li> </ul>	
Memory Mirror RAS Mode (setting)	Mirror Keep Mode	<ul style="list-style-type: none"> <li>• Mirror Keep Mode</li> <li>• Capacity Keep Mode</li> </ul>	
PCI Address Mode (setting)	PCI Segment Mode	<ul style="list-style-type: none"> <li>• PCI Bus Mode</li> <li>• PCI Segment Mode</li> </ul>	
Dynamic Partitioning (setting)	Disable	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>	
On board LAN Mode (setting)	Enabled(WOL disabled)	<ul style="list-style-type: none"> <li>• Enabled(WOL enabled)</li> <li>• Enabled(WOL disabled)</li> <li>• Disabled</li> </ul>	

### A.1.16 Setting Items of [Add User]/ [Edit User] Window

The following table lists the initial value and the value that can be set for the setting items of [Add User]/ [Edit User] Window.

TABLE A.16 Setting Items of [Add User]/ [Edit User] Window

Setting items	Initial value	Value that can be set	Remarks
User Name	None	Minimum 8 and Maximum 32 characters can be entered. [0-9], [a-z], [A-Z], "-", "_".  However, the first character must be [a-z] [A-Z].	
Password	None	More than 8 characters and less than 32 characters. [0-9], [a-z], [A-Z] Special characters: ! # \$ % & ' ( ) = - ^ ~ ¥ @ ` [ ] { } : * ; + ? < . > , / _	
Privilege	In case of Add User: Admin In case of Edit User:	<ul style="list-style-type: none"> <li>• Admin</li> <li>• Operator</li> <li>• User</li> </ul>	

Setting items	Initial value	Value that can be set	Remarks
	current privilege	<ul style="list-style-type: none"> <li>• CE</li> <li>• Partition Operator</li> </ul>	
Status	In case of Add User: Enable In case of Edit User: current status.	<ul style="list-style-type: none"> <li>• Enabled</li> <li>• Disabled</li> </ul>	
Full Name	None	Maximum 32 characters can be entered.	
Operable Partition (for Partition Operator)	None	<ul style="list-style-type: none"> <li>• On: Operational</li> <li>• Off: Non-operational</li> </ul>	Grayed out if privilege is other than partition operator.

### A.1.17 Setting Items of [Date/Time] Window

The following table lists the initial value and the value that can be set for the setting items of [Date/Time] Window.

TABLE A.17 Setting Items of [Date/Time] Window

Setting Item	Initial Value	Value that can be set	Remarks
Date	Shows time on the clock of the server.	YYYY-MM-DD • YYYY: Year • MM: Month • DD: Day	
Time	Shows time on the clock of the server.	<ul style="list-style-type: none"> <li>• Modify the Time is On: Time is set Hour:Minute:Second:24 hours format</li> <li>• Modify the Time is Off: Time is not set.</li> </ul>	
Time Zone	None	Select from pull down menu.	
NTP	Disable	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>	
NTP Time Correction Mode	Step	<ul style="list-style-type: none"> <li>• Step</li> <li>• Slew</li> </ul>	
NTP Server 1	None	In case of IPv4 0-255, 0-255, 0-255, 0-255 In case of IPv6 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF	It can be set only when NTP is Enabled.
NTP Server 2	None	In case of IPv4 0-255, 0-255, 0-255, 0-255 In case of IPv6 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF	It can be set only when NTP is Enabled.
NTP Server 3	None	In case of IPv4 0-255, 0-255, 0-255, 0-255 In case of IPv6 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF	It can be set only when NTP is Enabled.



## A.1.18 Setting Items of [IPv4 Interface] Window

The following table lists the initial value and the value that can be set for the setting items of [IPv4 Interface] Window.

TABLE A.18 Setting Items of [IPv4 Interface] Window

Main Item	Setting Item	Initial Value	Value that can be set	Remarks
Virtual IP Address	Hostname	"PRIMEQUEST"+ Product Serial Number	Sets hostname in FQDN format. [a-z],[A-Z],[0-9],[ (Hyphen),[.] (Dot)	• The first character should be alphabetic character. • [ (Hyphen), [.] (Dot) cannot be used as the first character and the last character.
	IP Address	None	0-255, 0-255, 0-255, 0- 255	
	Subnet mask	None	0-255, 0-255, 0-255, 0- 255	
	Gateway address	None	0-255, 0-255, 0-255, 0- 255	
MMB#0 IP Address	Interface	Disable	• Enable • Disable	
	Hostname (Optional)	None	Sets hostname in FQDN format. [a-z], [A-Z], [0-9], "-" (Hyphen), "."(Dot)	• The First character should be alphabetic character. • "-" (Hyphen), "." (Dot) cannot be used as the first character and the last character.
	IP Address	None	0-255, 0-255, 0-255, 0- 255	
	Subnet Mask	None	0-255, 0-255, 0-255, 0- 255	
	Gateway address	None	0-255, 0-255, 0-255, 0- 255	
MMB#1 IP Address	Interface	Disable	• Enable • Disable	
	Hostname (Optional)	None	Sets hostname in FQDN format. [a-z], [A-Z], [0-9], "-" (Hyphen), "."(Dot)	• The First character should be alphabetic character. • "-" (Hyphen), "." (Dot) cannot be used as the first character and the last character.
	IP Address	None	0-255, 0-255, 0-255, 0- 255	
	Subnet Mask	None	0-255, 0-255, 0-255, 0- 255	
	Gateway address	None	0-255, 0-255, 0-255, 0- 255	
DNS (optional)	DNS	Disable	• Enable • Disable	
	DNS Server 1	None	Sets the IP address of primary DNS Server	
	DNS Server 2	None	Sets the IP address of primary DNS Server	
	DNS Server 3	None	Sets the IP address of primary DNS Server	
Management	Dualization	Disable	• Enable	

Main Item	Setting Item	Initial Value	Value that can be set	Remarks
LAN			• Disable	
Maintenance IP Address	Interface	Disable	• Enable • Disable	
	IP Address	None	0-255, 0-255, 0-255, 0-255	
	Subnet Mask	None	0-255, 0-255, 0-255, 0-255	
	Gateway address	None	0-255, 0-255, 0-255, 0-255	
	SMTP address	None	0-255, 0-255, 0-255, 0-255	
Internal IP Address	Interface	Disable	• Enable • Disable	
	IP Address	None	0-255, 0-255, 0-255, 0-255	
	Subnet Mask	None	0-255, 0-255, 0-255, 0-255	

### A.1.19 Setting Items of [IPv6 Interface] Window

The following table lists the initial value and the value that can be set for the setting items of [IPv6 Interface] Window.

TABLE A.19 Setting Items of [IPv6 Interface] Window

Main Item	Setting Item	Initial Value	Value that can be set	Remarks
Virtual IP Address	Hostname	"PRIMEQUEST"+ Product Serial Number	Sets hostname in FQDN format. [a-z], [A-Z], [0-9], "-" (Hyphen), "." (Dot)	• The first character must be alphabetic character. • "-" (Hyphen), "." (Dot) cannot be used as the first character and the last character.
	IP Address	None	0-FFFF,0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF	
	Prefix Length	None	1~128	
	Gateway address	None	0-FFFF,0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF	
MMB#0 IP Address	Interface	Disable	•Enable •Disable	
	Hostname (optional)	None	Sets hostname in FQDN format. [a-z],[A-Z],[0-9], "-" (Hyphen), "." (Dot)	• First character must be alphabetic character. • "-" (Hyphen), "." (Dot) cannot be used as the first character and the last character.
	IP Address	None	0-FFFF,0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF	
	Prefix Length	None	1~128	
	Gateway address	None	0-FFFF,0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF	

Main Item	Setting Item	Initial Value	Value that can be set	Remarks
			0-FFFF, 0-FFFF	
MMB#1 IP Address	Interface	Disable	• Enable • Disable	
	Hostname (optional)	None	Sets hostname in FQDN format. [a-z],[A-Z],[0-9], "-" (Hyphen), "." (Dot)	• First character must be alphabetic character. • "-" (Hyphen), "." (Dot) cannot be used as the first character and the last character.
	IP Address	None	0-FFFF,0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF	
	Prefix Length	None	1~128	
	Gateway address	None	0-FFFF,0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF	
DNS (optional)	DNS	Disable	• Enable • Disable	
	DNS Server 1	None	Sets the IP address of primary DNS Server	
	DNS Server 2	None	Sets the IP address of primary DNS Server	
	DNS Server 3	None	Sets the IP address of primary DNS Server	
Management LAN	Dualization	Disable	• Enable • Disable	
Maintenance IP Address	Interface	Disable	• Enable • Disable	
	IP Address	None	0-FFFF,0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF	
	Prefix Length	None	1~128	
	Gateway address	None	0-FFFF,0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF	
	SMTP address	None	0-FFFF,0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF	

### A.1.20 Setting Items of [Management LAN Port Configuration] Window

The following table lists the initial value and the value that can be set for the setting items of [Management LAN Port Configuration] Window.

TABLE A.20 Setting Items of [Management LAN Port Configuration] Window

Main Item	Setting Item	Initial Value	Value that can be set	Remarks
Speed/Duplex for MMB#0	User port	Auto	• Auto • 1G/Full	1G/Full can be set only to User port.
	Maintenance			

Main Item	Setting Item	Initial Value	Value that can be set	Remarks
Speed/Duplex for MMB#1	port	Auto	<ul style="list-style-type: none"> <li>• 100M/Full</li> <li>• 100M/Half</li> <li>• 10M/Full</li> <li>• 10M/Half</li> </ul>	1G/Full can be set only to User port.
	REMCS port			
	User port			
	Maintenance port			
	REMCS port		<ul style="list-style-type: none"> <li>• Auto</li> <li>• 1G/Full</li> <li>• 100M/Full</li> <li>• 100M/Half</li> <li>• 10M/Full</li> <li>• 10M/Half</li> </ul>	

### A.1.21 Setting Items of [Network Protocols] Window

The following table lists the initial value and the value that can be set for the setting items of [Network Protocols] Window.

TABLE A.21 Setting Items of [Network Protocols] Window

Main Item	Setting Item	Initial Value	Value that can be set	Remarks
Web (HTTP/HTTPS)	HTTP	Disable	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>	
	HTTP Port#	8081	80,1024~65535	
	HTTPS	Disable	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>	
	HTTPS Port#	432	432,1024~65535	
	HTTP/HTTPS Timeout (sec)	600 seconds	60~9999 seconds 0:No timeout	
Telnet	Telnet	Disable	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>	
	Telnet Port#	23	23,1024~65535	
	Telnet Timeout	600 second	60~9999 seconds 0:No timeout	
SSH	SSH	Disable	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>	
	SSH Port#	22	22,1024~65535	
	SSH Timeout	600 seconds	60~9999 seconds 0:No timeout	
SNMP	SNMP Agent	Disable	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>	
	Agent Port#	161	161,1024~65535	
	SNMP Trap	Disable	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>	
	Trap Port#	162	161,1024~65535	

### A.1.22 Setting Items of [Refresh Rate] Window

The following table lists the initial value and the value that can be set for the setting items of [Refresh Rate] Window.

TABLE A.22 Setting Items of [Refresh Rate] Window

Setting Item	Initial Value	Value that can be set	Remarks
--------------	---------------	-----------------------	---------

Setting Item	Initial Value	Value that can be set	Remarks
Refresh Rate	Disable	<ul style="list-style-type: none"> <li>• Enable</li> <li>-Seconds:5~999 seconds</li> <li>• Disable</li> </ul>	

### A.1.23 Setting Items of [SNMP Community] Window

The following table lists the initial value and the value that can be set for the setting items of [SNMP Community] Window.

TABLE A.23 Setting Items of [SNMP Community] Window

Main Item	Setting Item	Initial Value	Value that can be set	Remarks
System Information	System Location	None	[0-9], [a-z], [A-Z] Special characters: ! # \$ % & ' ( ) = - ^ ~ ¥ @ ` [ ] { } : * ; + ? < . > , / _	<ul style="list-style-type: none"> <li>• # and half width space cannot be used as the first character.</li> <li>• Half width space cannot be used as the last character.</li> </ul>
	System contact	None	[0-9], [a-z], [A-Z] Special characters: ! # \$ % & ' ( ) = - ^ ~ ¥ @ ` [ ] { } : * ; + ? < . > , / _	<ul style="list-style-type: none"> <li>• # and half width space cannot be used as the first character.</li> <li>• Half width space cannot be used as the last character.</li> </ul>
Community	Community/ User	None	[0-9], [a-z], [A-Z] Special characters: ! # \$ % & ' ( ) = - ^ ~ ¥ @ ` [ ] { } : * ; + ? < . > , / _	"#" cannot be used as the first character.
	IP/Address/Mask	None	In case of IPv4 0-255, 0-255, 0-255, 0-255 In case of IPv6 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF	
	SNMP Version	1	<ul style="list-style-type: none"> <li>• 1</li> <li>• 2</li> <li>• 3</li> </ul>	
	Access	Read Only	<ul style="list-style-type: none"> <li>• Read Only</li> <li>• Read Write</li> </ul>	
	Auth	None	<ul style="list-style-type: none"> <li>• noauth</li> <li>• auth</li> <li>• priv</li> </ul>	

### A.1.24 Setting Items of [SNMP Trap] Window

The following table lists the initial value and the value that can be set for the setting items of [SNMP Trap] Window.

TABLE A.24 Setting Items of [SNMP Trap] Window

Setting Item	Initial Value	Value that can be set	Remarks
--------------	---------------	-----------------------	---------

Setting Item	Initial Value	Value that can be set	Remarks
Community/User	None	In case of SNMP v1, v2, sets the SNMP Community string. In case of SNMPv3, specifies the user name.	
IP Address	None	In case of IPv4 0-255, 0-255, 0-255, 0-255 In case of IPv6 0-FFFF, 0-FFFF, 0-FFFF,0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF	
SNMP Version	1	<ul style="list-style-type: none"> <li>• 1</li> <li>• 2</li> <li>• 3</li> </ul>	
Auth	None	<ul style="list-style-type: none"> <li>• noauth</li> <li>• auth</li> <li>• priv</li> </ul>	
Auth Type	None	<ul style="list-style-type: none"> <li>• MD5</li> <li>• SHA</li> </ul>	
Auth passphrase	None	[0-9], [a-z], [A-Z] Special characters: ! " # \$ % & ' ( ) = - ^ ~ ¥ @ ` [ ] { } : * ; + ? < . > , / _	
Priv passphrase	None	[0-9], [a-z], [A-Z] Special characters: ! " # \$ % & ' ( ) = - ^ ~ ¥ @ ` [ ] { } : * ; + ? < . > , / _	

### A.1.25 Setting Items of [SNMP v3 Configuration] Window

The following table lists the initial value and the value that can be set for the setting items of [SNMP v3 Configuration] Window.

TABLE A.25 Setting Items of [SNMP v3 Configuration] Window

Setting Item	Initial Value	Value that can be set	Remarks
Engine ID	None	[0-9], [a-z], [A-Z] Special characters: ! " # \$ % & ' ( ) = - ^ ~ ¥ @ ` [ ] { } : * ; + ? < . > , / _	
User Name	None	[0-9], [a-z], [A-Z] Special characters: ! " # \$ % & ' ( ) = - ^ ~ ¥ @ ` [ ] { } : * ; + ? < . > , / _	
Auth type	MD5	<ul style="list-style-type: none"> <li>• MD5</li> <li>• SHA</li> </ul>	
Auth passphrase	None	[0-9], [a-z], [A-Z] Special characters: ! " # \$ % & ' ( ) = - ^ ~ ¥ @ ` [ ] { } : * ; + ? < . > , / _	
Priv passphrase	None	[0-9], [a-z], [A-Z] Special characters: ! " # \$ % & ' ( ) = - ^ ~ ¥ @ ` [ ] { } : * ; + ? < . > , / _	

### A.1.26 Setting Items of [Create CSR] Window

The following table lists the initial value and the value that can be set for the setting items of [Create CSR] Window.

TABLE A.26 Setting Items of [Create CSR] Window

Setting Item	Initial Value	Value that can be set	Remarks
Key length	1024	• 1024 • 2048	
Country Name	None	ISO Country Code (2 alphabetic characters)	Example :Japan “JP” USA “US”
State or Province Name	None	Maximum 56 characters can be entered.	
Locality Name	None	Maximum 56 characters can be entered.	
Organization Name	None	Maximum 56 characters can be entered.	
Organization Unit Name	None	Maximum 56 characters can be entered.	
Common name	None	Maximum 56 characters can be entered.	
E-Mail Address	None	None E-Mail address. Maximum 40 characters can be entered.	

### A.1.27 Setting Items of [Create Selfsigned Certificate] Window

The following table lists the initial value and the value that can be set for the setting items of [Create Selfsigned Certificate] Window.

TABLE A.27 Setting Items of [Create Selfsigned Certificate] Window

Setting items	Initial value	Values that can be set	Remarks
Key length	1024	•1024 •2048	
Term	None	1~4095 Days	
Country Name	None	Maximum 56 characters can be entered	
State or Province Name	None	Maximum 56 characters can be entered	
Locality Name	None	Maximum 56 characters can be entered	
Organization Name	None	Maximum 56 characters can be entered	
Organization Unit Name	None	Maximum 56 characters can enter	
Common Name	None	Maximum 56 characters can be entered	
E-Mail Address	None	E-Mail Address. Maximum 40 characters can be entered	

### A.1.29 Setting Items of [Add Filter] / [Edit Filter] Window

The following table lists the initial value and the value that can be set for the setting items of [Edit User Add Filter] / [Edit Filter] Window.

TABLE A.29 Setting Items of [Add Filter] / [Edit Filter] Window

<b>Setting item</b>	<b>Initial value</b>	<b>Values that can be set</b>	<b>Remarks</b>
Protocol	SSH	<ul style="list-style-type: none"> <li>• HTTP</li> <li>• HTTPS</li> <li>• Telnet</li> <li>• SSH</li> <li>• SNMP</li> </ul>	
Access Control	Disable	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>	
IP Address	None	<p>In case of IPv4 0-255,0-255,0-255,0-255</p> <p>In case of IPv6 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF</p>	
Subnet Mask/Prefix Length	None	<p>In case of IPv4 0-255,0-255,0-255,0-255</p> <p>In case of IPv6 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF, 0-FFFF</p>	



### A.1.30 Setting Items of [Alarm E-Mail] Window

The following table lists the initial value and the value that can be set for the setting items of [Alarm E-Mail] Window.

TABLE A.30 Setting Items of [Alarm E-Mail] Window

Setting Item	Initial value	Values that can be set	Remarks
Alarm E-Mail	Disable	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>	
From	None	E-Mail Address	When [Use envelope "from" address] check box is checked, the address of [From:] is set as the source E-Mail address and the mail are sent. By default the checkbox is off.
To	None	E-Mail Address	When multiple addresses are specified, they are separated by using "," (Comma).
SMTP Server	None	IP address or FQDN1 of SMTP server	
Subject	None	[0-9],[a-z],[A-Z], Special characters: !, #, ", \$, %, &, ', (, *, +, -, ., /, _ , ~ space	

### A.1.31 Setting Items of [Alarm E-Mail Filtering Condition] Window

The following table lists the initial value and the value that can be set for the setting items of [Alarm E-Mail Filtering Condition] Window.

TABLE A.31 Setting Items of [Alarm E-Mail Filtering Condition] Window

Setting item	Initial value	Values that can be set	Remarks
Severity	All ON	<ul style="list-style-type: none"> <li>• Error</li> <li>• Warning</li> <li>• Info</li> </ul> (Multiple selection is possible)	
Partition	All ON	Select the partition (Multiple selection is possible)	
Unit	All	<ul style="list-style-type: none"> <li>• All</li> <li>• Specified</li> </ul>	When specified is selected, the unit to be displayed is set ON.
Source	All	<ul style="list-style-type: none"> <li>• All</li> <li>• Specified</li> </ul>	When specified is selected, the source to be displayed is set ON.

## A.2 Setting Items on UEFI

This list shows the initial value and the values that can be set for Setting Items on UEFI

Setting Items on A.2.1 [I/O Space Assignment Configuration] window

Setting Items on A.2.2 [LAN Remote Boot Configuration] window

Setting Items on A.2.3 [CPU Configuration] window

Setting Items on A.2.4 [PCI Bus Padding Configuration] window

Setting Items on A.2.5 [PCI Subsystem Configuration] window

Setting Items on A.2.6 [IOU OpROM Scan Configuration] window  
Setting Items on A.2.7 [PCI\_Box OpROM Scan Configuration] window  
Setting Items on A.2.8 [iSCSI Configuration] window  
Setting Items on A.2.9 [Attempt Configuration] window  
Setting Items on A.2.10 [Memory Configuration] window  
Setting Items on A.2.11 [USB Configuration] window  
Setting Items on A.2.12 [Security Configuration] window

## A.2.1 Setting Items on [I/O Space Assignment Configuration] Window

Following table lists the initial value and the values that can be set for Setting Items on [I/O Space Assignment Configuration] window.

TABLE A.32 Setting Items of [I/O Space Assignment Configuration] Window

Setting item	Initial value	Values that can be set	Remarks
Slot#	Auto	<ul style="list-style-type: none"><li>• Auto</li><li>• Disable</li></ul>	

## A.2.2 Setting Items on [LAN Remote Boot Configuration] Window

Following table lists the initial value and the values that can be set for Setting Items on [LAN Remote Boot Configuration] window.

TABLE A.33 Setting Items of [LAN Remote Boot Configuration] Window

Setting item	Initial value	Values that can be set	Remarks
(Network Port information)	Disabled	<ul style="list-style-type: none"><li>• UEFI(PXE/iSCSI)</li><li>• Legacy PXE</li><li>• Legacy iSCSI</li><li>• Disabled</li></ul>	

## A.2.3 Setting Items on [CPU Configuration] Window

Following table lists the initial value and the values that can be set for Setting Items on [CPU Configuration] window.

TABLE A.34 Setting Items of [CPU Configuration] Window

Setting item	Initial value	Values that can be set	Remarks
Hyper threading	Enabled	<ul style="list-style-type: none"><li>• Disable</li><li>• Enable</li></ul>	
Active Processor Cores	All	<ul style="list-style-type: none"><li>• All</li><li>• 1</li><li>• 2</li><li>• 3</li><li>• 4</li><li>• 5</li><li>• 6</li><li>• 7</li><li>• 8</li><li>• 9</li></ul>	

## Appendix A List of Setting Items

Setting item	Initial value	Values that can be set	Remarks
		<ul style="list-style-type: none"> <li>• 10</li> <li>• 11</li> <li>• 12</li> <li>• 13</li> <li>• 14</li> </ul>	
Hardware Prefetcher	Enabled	<ul style="list-style-type: none"> <li>• Disable</li> <li>• Enable</li> </ul>	
Adjacent Cache Line Prefetch	Enabled	<ul style="list-style-type: none"> <li>• Disable</li> <li>• Enable</li> </ul>	
DCU Streamer Prefetcher	Enabled	<ul style="list-style-type: none"> <li>• Disable</li> <li>• Enable</li> </ul>	
DCU Ip Prefetcher	Enabled	<ul style="list-style-type: none"> <li>• Disable</li> <li>• Enable</li> </ul>	
Execute Disable Bit	Enabled	<ul style="list-style-type: none"> <li>• Disable</li> <li>• Enable</li> </ul>	
Intel Virtualization Technology	Enabled	<ul style="list-style-type: none"> <li>• Disable</li> <li>• Enable</li> </ul>	
Intel(R) VT-d	Disabled	<ul style="list-style-type: none"> <li>• Disable</li> <li>• Enable</li> </ul>	
Power Technology	Energy Efficient	<ul style="list-style-type: none"> <li>• Disabled</li> <li>• Energy Efficient</li> <li>• Custom</li> </ul>	
Enhanced SpeedStep	Enabled	<ul style="list-style-type: none"> <li>• Disable</li> <li>• Enable</li> </ul>	Displayed when "Custom" is selected on "Power Technology".
Turbo Mode	Enabled	<ul style="list-style-type: none"> <li>• Disable</li> <li>• Enable</li> </ul>	Displayed when "Custom" is selected on "Power Technology".
Energy Performance	Performance	<ul style="list-style-type: none"> <li>• Performance</li> <li>• Balanced Performance</li> <li>• Balanced Energy</li> <li>• Energy Efficient</li> </ul>	Displayed when "Custom" is selected on "Power Technology".
P-State Coordination	HW ALL	<ul style="list-style-type: none"> <li>• HW_ALL</li> <li>• SW_ALL</li> <li>• SW_ANY</li> </ul>	Displayed when "Custom" is selected on "Power Technology".
CPU C3 Report	Disabled	<ul style="list-style-type: none"> <li>• Disable</li> <li>• Enable</li> </ul>	Displayed when "Custom" is selected on "Power Technology".
CPU C6 report	Enabled	<ul style="list-style-type: none"> <li>• Disable</li> <li>• Enable</li> </ul>	Displayed when "Custom" is selected on "Power Technology".
CPU C7 report	Enabled	<ul style="list-style-type: none"> <li>• Disable</li> <li>• Enable</li> </ul>	Displayed when "Custom" is selected on "Power Technology".
Package C State limit	No Limit	<ul style="list-style-type: none"> <li>• C0</li> <li>• C2</li> <li>• C6</li> <li>• C7</li> <li>• No Limit</li> </ul>	Displayed when "Custom" is selected on "Power Technology".
QPI Link Frequency Select	Auto	<ul style="list-style-type: none"> <li>• Auto</li> <li>• 8.0GT/s</li> <li>• 7.2GT/s</li> <li>• 6.4GT/s</li> </ul>	
Frequency Floor Override	Disabled	<ul style="list-style-type: none"> <li>• Disable</li> <li>• Enable</li> </ul>	
Perfmon and DFX devices	Disabled	<ul style="list-style-type: none"> <li>• Disable</li> <li>• Enable</li> </ul>	

## A.2.4 Setting Items on [PCI Bus Padding Configuration] Window

Following table lists the initial value and the values that can be set for Setting Items on [PCI Bus Padding Configuration] window.

TABLE A.35 Setting Items of [PCI Bus Padding Configuration] Window

Setting item	Initial value	Values that can be set	Remarks
Number of bus# padded to slot	1	<ul style="list-style-type: none"> <li>• 1</li> <li>• 2</li> <li>• 3</li> <li>• 4</li> </ul>	

## A.2.5 Setting Items on [PCI Subsystem Configuration] Window

Following table lists the initial value and the values that can be set for Setting Items on [PCI Subsystem Configuration] window.

TABLE A.36 Setting Items of [PCI Subsystem Configuration] Window

Setting item	Initial value	Setting value	Remarks
PCI ROM Priority	EFI Compatible ROM	<ul style="list-style-type: none"> <li>• Legacy ROM</li> <li>• EFI Compatible ROM</li> </ul>	
ASPM Support	Disabled	<ul style="list-style-type: none"> <li>• Disabled</li> <li>• Auto</li> <li>• Limit to L0s</li> </ul>	
Number of bus# Padded to slot	1	<ul style="list-style-type: none"> <li>• 1</li> <li>• 2</li> <li>• 3</li> </ul>	

## A.2.6 Setting Items on [IOU OpROM Scan Configuration] Window

Following table lists the initial value and the values that can be set for Setting Items on [IOU OpROM Scan Configuration] window.

TABLE A.37 Setting Items of [IOU OpROM Scan Configuration] Window

Setting Item	Initial Value	Setting Value	Remarks
Slot 1 OpROM (DU)	Disabled	<ul style="list-style-type: none"> <li>• Enabled</li> <li>• Disabled</li> </ul>	Settings for DU#0Slot#0
Slot 2 OpROM	Disabled	<ul style="list-style-type: none"> <li>• Enabled</li> <li>• Disabled</li> </ul>	Settings for PCI Express slot#0 of IOU#0
Slot 3OpROM	Disabled	<ul style="list-style-type: none"> <li>• Enabled</li> <li>• Disabled</li> </ul>	Settings for PCI Express slot #1of IOU#0
Slot 4OpROM	Disabled	<ul style="list-style-type: none"> <li>• Enabled</li> <li>• Disabled</li> </ul>	Settings for PCI Express slot #2of IOU#0
Slot 5OpROM	Disabled	<ul style="list-style-type: none"> <li>• Enabled</li> <li>• Disabled</li> </ul>	Settings for PCI Express slot #3of IOU#0
Slot 17 OpROM (DU)	Disabled	<ul style="list-style-type: none"> <li>• Enabled</li> <li>• Disabled</li> </ul>	Settings for DU#0 Slot#1
Slot 18 OpROM	Disabled	<ul style="list-style-type: none"> <li>• Enabled</li> <li>• Disabled</li> </ul>	Settings for PCI Express slot #0of IOU#1
Slot 19 OpROM	Disabled	<ul style="list-style-type: none"> <li>• Enabled</li> <li>• Disabled</li> </ul>	Settings for PCI Express slot #1of IOU#1

Setting Item	Initial Value	Setting Value	Remarks
Slot 20 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #2of IOU#1
Slot 21 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #3of IOU#1
Slot 33 OpROM (DU)	Disabled	• Enabled • Disabled	Settings for DU#1 Slot#0
Slot 34 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #0 of IOU#2
Slot 35 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #1of IOU#2
Slot 36 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #2of IOU#2
Slot 37 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #3of IOU#2
Slot 49 OpROM (DU)	Disabled	• Enabled • Disabled	Settings for DU#1Slot#1
Slot 50 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #0of IOU#3
Slot 51 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #1of IOU#3
Slot 52 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #2of IOU#3
Slot 53 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #3of IOU#3

## A.2.7 Setting Items on [PCI\_Box OpROM Scan Configuration] Window

Following table lists the initial value and the values that can be set for Setting Items on [PCI\_Box OpROM Scan Configuration] window.

TABLE A.38 Setting Items of [PCI\_Box OpROM Scan Configuration] Window

Setting Item	Initial Value	Setting Value	Remarks
Slot 65 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #0 of PCI_Box#0
Slot 66 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #1 of PCI_Box#0
Slot 67 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #2 of PCI_Box#0
Slot 68 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #3 of PCI_Box#0
Slot 69 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #4 of PCI_Box#0
Slot 70 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #5 of PCI_Box#0
Slot 71 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #6 of PCI_Box#0
Slot 72 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #7 of PCI_Box#0
Slot 73 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #8 of PCI_Box#0
Slot 74 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #9 of PCI_Box#0
Slot 75 OpROM	Disabled	• Enabled	Settings for PCI Express

Setting Item	Initial Value	Setting Value	Remarks
		• Disabled	slot #10 of PCI_Box#0
Slot 76 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #11 of PCI_Box#0
Slot 81 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #0 of PCI_Box#1
Slot 82 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #1 of PCI_Box#1
Slot 83 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #2 of PCI_Box#1
Slot 84 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #3 of PCI_Box#1
Slot 85 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #4 of PCI_Box#1
Slot 86 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #5 of PCI_Box#1
Slot 87 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #6 of PCI_Box#1
Slot 88 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #7 of PCI_Box#1
Slot 89 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #8 of PCI_Box#1
Slot 90 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #9 of PCI_Box#1
Slot 91 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #10 of PCI_Box#1
Slot 92 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #11 of PCI_Box#1
Slot 97 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #0 of PCI_Box#2
Slot 98 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #1 of PCI_Box#2
Slot 99 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #2 of PCI_Box#2
Slot 100 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #3 of PCI_Box#2
Slot 101 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #4 of PCI_Box#2
Slot 102 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #5 of PCI_Box#2
Slot 103 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #6 of PCI_Box#2
Slot 104 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #7 of PCI_Box#2
Slot 105 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #8 of PCI_Box#2
Slot 106 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #9 of PCI_Box#2
Slot 107 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #10 of PCI_Box#2
Slot 108 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #11 of PCI_Box#2
Slot 113 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #0 of PCI_Box#3
Slot 114 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #1 of PCI_Box#3
Slot 115 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #2 of PCI_Box#3
Slot 116 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #3 of PCI_Box#3
Slot 117 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #4 of PCI_Box#3
Slot 118 OpROM	Disabled	• Enabled	Settings for PCI Express

Setting Item	Initial Value	Setting Value	Remarks
		• Disabled	slot #5 of PCI_Box#3
Slot 119 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #6 of PCI_Box#3
Slot 120 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #7 of PCI_Box#3
Slot 121 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #8 of PCI_Box#3
Slot 122 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #9 of PCI_Box#3
Slot 123 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #10 of PCI_Box#3
Slot 124 OpROM	Disabled	• Enabled • Disabled	Settings for PCI Express slot #11 of PCI_Box#3

## A.2.8 Setting Items on [iSCS Configuration] Window

Following table lists the initial value and the values that can be set for Setting Items on [iSCS Configuration] window.

TABLE A.39 Setting Items of [iSCS Configuration] Window

Setting Item	Initial Value	Setting Value	Remarks
iSCSI Initiator Name	-	iSCSI Initiator Name	4-223 characters can be entered.

## A.2.9 Setting Items on [Attempt Configuration] Window

Following table lists the initial value and the values that can be set for Setting Items on [Attempt Configuration] window.

TABLE A.40 Setting Items of [Attempt Configuration] Window

Setting Item	Initial Value	Setting Value	Remarks
iSCSI Mode	Disabled	• Enabled for MPIO • Enabled • Disabled	
Internet Protocol	IP4	• IP4 • IP6 • Autoconfigure	
Connection Retry Count	0	• 0~16	
Connection Establishing Timeout	1000		Unit is millisecond.
ISID	Generated from MAC address	Enter last six digits of ISID.	
Enable DHCP	[ ]	• [ ] • [X]	
Initiator IP Address	-	0-255, 0-255, 0-255, 0-255	Displayed only when [DHCP] is [Enable]
Initiator Subnet Mask	-	0-255, 0-255, 0-255, 0-255	Displayed only when [DHCP] is [Enable].
Gateway		0-255, 0-255, 0-255, 0-255	Displayed only when [DHCP] is [Enable].
Get Target info via DHCP	[ ]	• [ ] • [X]	Displayed only when [DHCP] is [Enable].

Setting Item	Initial Value	Setting Value	Remarks
Target Name	-	4~223 characters can be entered. The types of characters that can be entered are as follows 0-9, A-Z, a-z, ! " # \$ % & ' ( ) * + , - . / : ; < = > ? @ [ \ ] ^ _ ` {   } . ~	Displayed when [Get Target info via DHCP] is disabled.
Target IP Address	-	0-255, 0-255, 0-255, 0-255	Displayed when [Get Target info via DHCP] is disabled.
Target Port	0	• 0~65535	
Boot LUN	0	• x-xxxx-xxxx-xxxx- xxxx(in Hexadecimal)	
Authentication Type	CHAP	• None • CHAP	
CHAP Type	One way	• One way • Mutual	
CHAP Name	-	125 characters can be entered. The types of characters that can be entered are as follows. 0-9, A-Z, a-z, ! " # \$ % & ' ( ) * + , - . / : ; < = > ? @ [ \ ] ^ _ ` {   } . ~	
CHAP Secret	-	12~16 characters can be entered. The types of characters that can be entered are as follows. 0-9, A-Z, a-z, ! " # \$ % & ' ( ) * + , - . / : ; < = > ? @ [ \ ] ^ _ ` {   } . ~	
Reverse CHAP Name	-	125 characters can be entered. The types of characters that can be entered are as follows. 0-9, A-Z, a-z, ! " # \$ % & ' ( ) * + , - . / : ; < = > ? @ [ \ ] ^ _ ` {   } . ~	
Reverse CHAP Secret	-	12~16 characters can be entered. The types of characters that can be entered are as follows. 0-9, A-Z, a-z, ! " # \$ % & ' ( ) * + , - . / : ; < = > ? @ [ \ ] ^ _ ` {   } . ~	

## A.2.10 Setting Items on [Memory Configuration] Window

Following table lists the initial value and the values that can be set for Setting Items on [Memory Configuration] window.

TABLE A.41 Setting Items of [Memory Configuration] Window

Setting Item	Initial Value	Setting Value	Remarks
DIMM Speed	Normal Mode	• Performance Mode • Normal Mode	
Patrol scrub	Disabled	• Disabled • Enabled	



Setting Item	Initial Value	Setting Value	Remarks
Refresh Rate	Auto	<ul style="list-style-type: none"> <li>• Auto</li> <li>• 1x</li> </ul>	

### A.2.11 Setting Items on [USB Configuration] Window

Following table lists the initial value and the values that can be set for Setting Items on [USB Configuration] window.

TABLE A.42 Setting Items of [USB Configuration] Window

Setting Item	Initial Value	Setting value	Remarks
Legacy USB Support	Enabled	<ul style="list-style-type: none"> <li>• Disabled</li> <li>• Enabled</li> <li>• Auto</li> </ul>	
Mass Storage Devices:	Auto	<ul style="list-style-type: none"> <li>• Auto</li> <li>• Floppy</li> <li>• Forced FDD</li> <li>• Hard Disk</li> <li>• CD-ROM</li> </ul>	
USB Port disable	Enabled	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>	

### A.2.12 Setting Items on [Security Configuration] Window

Following table lists the initial value and the values that can be set for Setting Items on [Security Configuration] window.

TABLE A.43 Setting Items of [Security Configuration] Window

Setting Item	Initial Value	Setting Value	Remarks
TPM Support	Disabled	<ul style="list-style-type: none"> <li>• Disabled</li> <li>• Enabled</li> </ul>	
TPM State	Disabled	<ul style="list-style-type: none"> <li>• Disabled</li> <li>• Enabled</li> </ul>	
Pending TPM operation	None	<ul style="list-style-type: none"> <li>• None</li> <li>• Enable Take Ownership</li> <li>• Disable Take Ownership</li> <li>• TPM Clear</li> </ul>	

## A.3 Setting Items on Video redirection

Following is the list of initial values and the values that can be set for Setting Items on BMC.

Setting item on A.3.1 [Video]  
 Setting item on A.3.2 [Keyboard]  
 Setting item on A.3.3 [Mouse]  
 Setting item on A.3.4 [Options]

### A.3.1 Setting Items on [Video] Window

Following table lists the initial values and the values that can be set for Setting Items on [Video] window.

TABLE A.44 Setting Items of [Video] Window

Setting Item	Initial Value	Setting Value	Remarks
Low Bandwidth Mode	Normal	<ul style="list-style-type: none"><li>• Normal</li><li>• 8bpp</li><li>• 8bpp B&amp;W</li><li>• 16bpp</li></ul>	

### A.3.2 Setting Items on [Keyboard] Window

Following table lists the initial values and the values that can be set for Setting Items on [Keyboard] window.

TABLE A.45 Setting Items of [Keyboard] Window

Setting Item	Initial Value	Setting Value	Remarks
Host Physical Keyboard	Auto Detect	<ul style="list-style-type: none"><li>• Auto Detect</li><li>• English (United States)</li><li>• French</li><li>• German (Germany)</li><li>• Spanish</li></ul>	
Soft Keyboard		<ul style="list-style-type: none"><li>• English (United States)</li><li>• English (United Kingdom)</li><li>• Spanish</li><li>• French</li><li>• German (Germany)</li><li>• Italian</li><li>• Danish</li><li>• Finnish</li><li>• German (Switzerland)</li><li>• Norwegian</li><li>• Portuguese</li><li>• Swedish</li><li>• Hebrew</li><li>• French (Belgium)</li><li>• Dutch (Belgium)</li><li>• Russian (Russia)</li><li>• Japanese</li><li>• Turkish-F</li><li>• Turkish-Q</li></ul>	

### A.3.3 Setting Items on [Mouse] Window

Following table lists the initial values and the values that can be set for Setting Items on [Mouse] window.

TABLE A.46 Setting Items of [Mouse] Window

Setting Item	Initial Value	Setting Value	Remarks
Mouse Mode	Absolute mouse mode	<ul style="list-style-type: none"><li>• Absolute mouse mode</li><li>• Relative mouse mode</li><li>• Hide mouse mode</li></ul>	

### A.3.4 Setting Items on [Options] Window

Following table lists the initial values and the values that can be set for Setting Items on [Options] window.

TABLE A.47 Setting Items of [Options] Window

Setting Item	Initial Value	Setting Value	Remarks
GUI language	EN-English	<ul style="list-style-type: none"><li>• DE-Deutsch</li><li>• EN-English</li><li>• JA-Japanese</li></ul>	

FUJITSU